

. . .

, ₁

,

·

ł

EOP:	TITLE:	(REV:	5		
AP-TURB.3	TURBINE VI	BRATION	PAGE	2	of	5

- A. PURPOSE This procedure provides the necessary actions to be taken in the event of increasing turbine vibrations.
- B. ENTRY CONDITIONS/SYMPTOMS

ħ,

at,

- 1. SYMPTOMS The symptoms of TURBINE VIBRATION are;
 - a. Annunciator I-27, Rotor Eccentricity or Vibration alarm is lit.
 - b. Increasing or High Turbine Vibration detected.

• . 4 , ; ñ.

i

¥,

. . .

ø ,

×

•

EOP:	TITLE:	REV:	5
AP-TURB.3	TURBINE VIBRATION	DACE	2
		PAGE	د

of 5

.

.

ß

•

0

4

STEP ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
<u>NOTE</u> : o The exciter bearing No. 9 is not bearings Nos.1 through 8.	as limiting as the turbine
o Step l is an IMMEDIATE ACTION st	ep.
(1) Check Turbine Vibration:	Perform the following:
o Bearings No. 1 through No. 8 - LESS THAN 14 MILS	a. Trip the turbine.
o Bearing No. 9 - INDICATION ON SCALE	b. Go to AP-TURB.1, TURBINE TRIP WITHOUT RX TRIP REQUIRED <u>OR</u> E-O, REACTOR TRIP or SAFETY INJECTION, as required.
	ан) Г. Бу
	· · ·
-	
·	
	•
•	
	*
•	



. .

· , ,

• • • · · · ·

EOP:	TITLE:
EOP: AP-TURB.3	

,

_

×

14

ר אַ


ب

TURBINE VIBRATION

REV: 5

.

STEP ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
2 Check No. 9 Bearing Vibration - LESS THAN 14 MILS	Initiate load reduction to decrease vibrations.
-	<u>IF</u> vibrations can <u>NOT</u> be reduced, <u>THEN</u> shutdown the plant, (Refer to O-2.1, NORMAL SHUTDOWN TO HOT SHUTDOWN).
* * * * * * * * * * * * * * * * * * *	
IF AT ANY TIME VIBRATIONS EXCEED 14 MILS,	RETURN TO STEP 1.
* * * * * * * * * * * * * * * * * * * *	* * * * * * * * * * * * * * * * * *
	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1
3 Check Turbine Vibration:	
a. Bearings No. 1 through No. 8 - LESS THAN 7 MILS	a. Attempt to stabilize vibration as follows:
	o <u>IF</u> increasing turbine speed, <u>THEN</u> stop speed increase and evaluate.
	o <u>IF</u> generator on line, <u>THEN</u> begin reducing load to stabilize vibrations.
b. Bearing No. 9 - LESS THAN 7 MILS	b. Attempt to stabilze vibrations as follows:
- 1	 Adjust generator hydrogen temperature,
	-0R-
	o Adjust turbine lube oil temperature,
	-OR-
	o Adjust exciter cooling.
· · ·	



TITLE:

AP-TURB.3

EOP:

TURBINE VIBRATION

ø

REV: 5

PAGE 5 of 5

					1		
	STE	P	ACTION/EXPEC	TED RESPONSE		RESPONSE NOT OBTAINED	
	L						•
	4	Veri STAF	ify Turbine 3LE OR DECRE	Vibrations - ASING		Continue reducing load unt vibrations are stable or decreasing, <u>OR</u>	il
				ч		Take unit off line, if nec (Refer to 0-2.1, NORMAL SH HOT SHUTDOWN) and go to St	UTDOWN TO
	5	Stop	D - LOÀD RED	UCTION			1
	6		ck The Turbi Unusual Noi	ne Generator ses:		<u>IF</u> unusual noises detected notify the Maintenance Man	
			urbine generat DISES	or - NO UNUSUA	L		£
	7		olete - HIGH FICATION	ER SUPERVISI	ON		
`					-END-		
				2	-540-		
				u ,	1		
				· .			· .
			s 19	,			,
				· .			
					٩		
							• · •
				*	-		



ار `گر

\$

.

. • .

н. Н ,

•

.

,

.

1 • • • •

. .