

COOPER NUCLEAR STATION
 TABLE 3.1.1
 REACTOR PROTECTION SYSTEM INSTRUMENTATION REQUIREMENTS

Reactor Protection system Trip Function	Applicability Conditions				Trip Level Setting	Minimum Number of Operable Channels Per Trip Systems (1)	Action Required When Equipment Operability is Not Assured (1)
	Mode Switch Position						
	Shutdown	Startup	Refuel	Run			
Mode Switch in Shutdown	X(7)	X	X	X		1	A
Manual Scram	X(7)	X	X	X		1	A
IRM (17) High Flux	X(7)	X	X	(5)	\leq 120/125 of in- dicated scale	3	A
Inoperative		X	X	(5)		3	A
APRM (17) High Flux (Flow biased)				X	\leq (0.66W+54%) (14) $\left[\frac{FRP}{MFLPD} \right]$	2	A or C
High Flux	X(7)	X(9)	X(9)	(16)	\leq 15% Rated Power		A or C
Inoperative		X(9)	X(9)	X	(13)	2	A or C
Downscale		(11)		X(12)	\geq 2.5% of indi- cated scale	2	A or C
High Reactor Pressure NBI-PS-55 A,B,C, & D		X(9)	X(10)	X	\leq 1045 psig	2	A
High Drywell Pressure PC-PS-12 A,B,C, & D		X(9)(8)	X(8)	X	\leq 2 psig	2	A or D
Reactor Low Water Level NBI-LIS-101 A,B,C, & D		X	X	X	\geq + 12.5 in. indi- cated level	2	A or D
Scram Discharge Volume High Water Level CRD-LS-231 A,B,C, & D		X	X(2)	X	\leq 36 gallons	2	A

NOTES FOR TABLE 3.1.1

1. There shall be two operable or tripped trip systems for each function. If the minimum number of operable instrument channels for a trip system cannot be met, the affected trip system shall be placed in the safe (tripped) condition, or the appropriate actions listed below shall be taken.
 - A. Initiate insertion of operable rods and complete insertion of all operable rods within four hours.
 - B. Reduce power to less than 30% of rated.
 - C. Reduce power level to IRM range and place mode switch in the Startup position within 8 hours and depressurize to less than 1000 psig.
 - D. Reduce turbine load and close main steam line isolation valves within 8 hours.
2. Permissible to bypass, with control rod block, for reactor protection system reset in refuel and shutdown positions of the reactor mode switch.
3. Permissible to bypass when reactor pressure is \leq 1000 psig and the mode switch is not in Run.
4. Permissible to bypass when turbine first stage pressure is less than 30% of full load.
5. IRM's are bypassed when APRM's are onscale and the reactor mode switch is in the run position.
6. The design permits closure of any two lines without a full scram being initiated.
7. When the reactor is subcritical, irradiated fuel is in the vessel, and the reactor water temperature is less than 212^oF, only the following trip functions need to be operable:
 - a. Mode switch in shutdown.
 - b. Manual scram.
 - c. High flux IRM. 120/125 indicated scale.
 - d. APRM (15%) high flux scram.
8. Not required to be operable when primary containment integrity is not required.
9. Not required while performing low power physics tests at atmospheric pressure during or after refueling at power levels not to exceed 5 MW(t).
10. Not required to be operable when the reactor pressure vessel head is not bolted to the vessel.

3.1 BASES (Cont.d)

ence paragraph VII.5.7 FSAR). Thus the IRM System is not required in the "Run" mode. The APRM's cover only the power range. The IRM's and APRM's provide adequate coverage in the startup and intermediate range.

The requirement to have the scram functions indicated in Table 3.1.1 operable in the Refuel mode assures that shifting to the Refuel mode during reactor power operation does not diminish the protection provided by the reactor protection system.

Turbine stop valve closure occurs at 10% of valve closure. Below 233 psig turbine first stage pressure (30% of rated), the scram signal due to turbine stop valve closure is bypassed because the flux and pressure scrams are adequate to protect the reactor.

Turbine control valves fast closure initiates a scram based on pressure switches sensing Electro-Hydraulic Control (EHC) system oil pressure. The switches are located on the Control Valve Emergency Trip oil header, and detects the loss of oil to hold the valves open.

This scram signal is also bypassed when turbine first stage pressure is less than 233 psig.

The requirements that the IRM's be inserted in the core when the APRM's read 2.5 indicated on the scale in the Startup and Refuel modes assures that

4.1 BASES (Cont.d)

zero flow signal will be sent to half of the APRM's resulting in a half scram and rod block condition. Thus, if the calibration were performed during operation, flux shaping would not be possible. Based on experience at other generating stations, drift of instruments, such as those in the Flow Biasing Network, is not significant and therefore, to avoid spurious scrams, a calibration frequency of each refueling outage is established.

Group (C) devices are active only during a given portion of the operational cycle. For example, the IRM is active during startup and inactive during full-power operation. Thus, the only test that is meaningful is the one performed just prior to shutdown or startup; i.e., the tests that are performed just prior to use of the instrument.

Calibration frequency of the instrument channel is divided into two groups. These are as follows:

1. Passive type indicating devices that can be compared with like units on a continuous basis.
2. Vacuum tube or semi-conductor devices and detectors that drift or lose sensitivity.

Experience with passive type instruments in generating stations and substations indicates that the specified calibrations are adequate. For those devices which employ amplifiers, etc., drift specifications call for drift to be less than 0.4%/month; i.e., in the period of a month a maximum drift of 0.4% could occur, thus providing for adequate margin.