FOR INFORMATION ONLY

EOP-2 RPV CONTROL

ENTRY CONDITIONS

RPV pressure above 1080 psig	RPV water level below 177 in.	Reactor power above 2.5% or unknown when a scram is required	Drywell pressure above 2.7 psig

While executing this procedure

IF	THEN
PRIMARY CONTAINMENT FLOODING IS OR HAS BEEN REQUIRED	Exit this EOP and enter the SAGs.

Has a scram been initiated?
- No → Scram the reactor.
- Yes →

Are all control rods inserted to or beyond position 02?
- Yes →
- No/Unknown → Will the reactor remain shutdown under all conditions without boron?
  - Yes →
  - No/Unknown → Exit this procedure and enter EOP-3, "Failure to Scram."

Section RPV/P

Monitor and control RPV PRESSURE

IF	THEN
A high-drywell pressure MSIV isolation signal exists (2 * psig)	Prevent injection from those ECCS and RCIC pumps not required to assure adequate core cooling before depressurizing below the air maximum injection pressures (LPSP).
Emergency RPV depressurization is anticipated	Irrespective of the resulting RPV cooldown rate, rapidly depressurize the RPV with the main turbine bypass valves.
EMERGENCY RPV DEPRESSURIZATION IS OR HAS BEEN REQUIRED	Exit "Section RPV/P" of this procedure and enter "Emergency RPV Depressurization."
STEAM COOLING IS REQUIRED	Exit "Section RPV/P" of this procedure and enter "Steam Cooling."
Torus temperature cannot be maintained below the Heat Capacity Temperature Limit	Irrespective of the resulting RPV cooldown rate, maintain RPV pressure below the Heat Capacity Temperature Limit.
Torus water level cannot be maintained below the SRV Tail Pipe Level Limit	Irrespective of the resulting RPV cooldown rate, maintain RPV pressure below the SRV Tail Pipe Level Limit.
RPV water level cannot be determined	Exit this procedure and enter EOP-7, "RPV Flooding" at "Shutdown Flooding."
The reactor is not shutdown	Exit this procedure and enter EOP-3, "Failure to Scram."

Stabilize RPV pressure below 1080 psig with the main turbine bypass valves.
Irrespective of RPV pressure control system in use (see Section RPV/L), close control system valves.

IF	THEN
RPV pressure cannot be stabilized below 1080 psig using the main turbine bypass valves and Group 1 Pressure Control Systems	Assign or RPV pressure control by using the steam conditioning mode of RHR (OPERG).

Depressurize the RPV. Maintain the RPV cooldown rate less than 100 °F/hr.

IF	THEN
SRVs are being used to depressurize the RPV AND The containment SRV pneumatic supply is or becomes unavailable	Depressurize with sustained SRV opening.

WAIT until the shutdown cooling RPV pressure interlock clears.

Cool down to cold shutdown conditions using shutdown cooling. Use only those RHR pumps not required to maintain RPV water level above 177 in. by operation in the LPCI mode. Maintain the RPV cooldown rate less than 100 °F/hr.

IF	THEN
Shutdown cooling cannot be established	Maintain RPV pressure below the shutdown cooling RPV pressure interlock using one or more of the systems used for depressurization.

Section RPV/L

Monitor and control RPV WATER LEVEL ❶

Verify initiation of each of the following:
- Isolation
- ECCS
- Emergency Diesel Generators

IF	THEN
Primary containment water level and torus pressure cannot be maintained below the Primary Containment Pressure Limit AND Adequate core cooling can be assured	Terminate injection into the RPV from sources external to the primary containment.
RPV water level cannot be determined	Exit this procedure and enter EOP-7, "RPV Flooding" at "Shutdown Flooding."

Restore and maintain RPV water level between 177 in. and 222.5 in. using one or more Group 1 Water Level Control Systems.

IF	THEN
RPV water level cannot be restored and maintained above 177 in.	Maintain RPV water level above -19 in. (TAF). Use one or more Group 2 Water Level Control Systems not to be used to assign or RPV water level control.
The ADS timer initiates	Override ADS.
RPV water level cannot be restored and maintained above -19 in.	Exit "Section RPV/L" of this procedure and enter "Alternate RPV Level Control."

Group 1 Pressure Control Systems

Assigned Pressure Control Band:

- SRVs
  - Unless it is the water level is above 9 A.B.
  - If possible, open SRVs in the following sequence: (LRV-71A, J, K, G, L, D, C, F, H, L, B.
  - If the containment SRV pneumatic supply is or becomes unavailable, place the control switch for each SRV in CLOSE / AUTO.
- HPCI
  - Align suction to the CST, if available.
- RCIC
  - Align suction to the CST, if available.
- RWCU, recirc mode
  - Bypass the filter/demineralizers.
  - Defeat SLC and other RWCU isolation interlocks if necessary (EP-2).
- RWCU, blowdown mode
- Main steam line drains
- Reactor feed pumps
- SJAEs
- Steam Reboiler

Group 1 Water Level Control Systems

Assigned Water Level Band:

- Condensate / Feedwater
- CRD
- HPCI
  - Align suction to the CST, if available.
  - Defeat the high area temperature isolation and high steam water level suction transfer if necessary (EP-2).
- RCIC
  - Align suction to the CST, if available.
  - Defeat the low RPV pressure and high area temperature isolations if necessary (EP-2).
- LPCI
  - Inject through the broken recirc loop as soon as possible.
- CS

Group 2 Water Level Control Systems

Assigned Water Level Band:

- RHR Service Water Booster
- Fire Water Booster
- RHR Keep Fill
- CS Keep Fill
- Condensate Transfer
- SLC (low or boron tank)

(EP-8)

Emergency RPV Depressurization

IF	THEN
It is anticipated that primary containment water level will drop above -19 in.	BEFORE primary containment water level reaches -19 ft, open the following valves and associated MSIV solenoid pilot valves (EP-2): ➢ 1/2MSIV-15 ➢ 2/1MSIV-15 ➢ 2/1MSIV-71
RPV water level cannot be determined	Exit this procedure and enter EOP-7, "RPV Flooding" at "Shutdown Flooding."
The reactor is not shutdown	Exit this procedure and enter EOP-3, "Failure to Scram."

Is drywell pressure above 2.7 psig?
- No →
- Yes → Prevent injection from those RHR and CS pumps not required to assure adequate core cooling (EPA).

IF torus water level is above 9 A.B. THEN open all 7 MSIV valves.

Can all 7 ADS valves be opened?
- Yes →
- No → IF torus water level is above 9 A.B. THEN open additional MSIVs until a total of 7 MSIVs are open.

Are 7 or more MSIVs open?
- Yes →
- No → Is RPV pressure less than 50 psig above torus pressure?
  - Yes →
  - No → Irrespective of the resulting RPV cooldown rate and the effect on torus water temperature, depressurize the RPV using Group 2 Pressure Control Systems, defeating isolation interlocks if necessary (EP-2).

WAIT until RPV pressure is less than 50 psig above torus pressure.

Maintain RPV pressure less than 50 psig above torus pressure using one or more of the systems used for depressurization.

IF	THEN
Less than 9 SRVs are open and RPV pressure is at least 50 psig above torus pressure	Rapidly depressurize the RPV, return to ❶

WAIT until the shutdown cooling RPV pressure interlock clears.

Cool down to cold shutdown conditions using shutdown cooling. Use only those RHR pumps not required to maintain RPV water level above 177 in. by operation in the LPCI mode.

IF	THEN
Shutdown cooling cannot be established AND Further RPV cooldown is required	Continue to cool down using one or more systems used for depressurization, defeating isolation interlocks if necessary (EP-2).

Group 2 Pressure Control Systems

- SRVs from 1/2MSIV-71 (EP-11)
  - Unless it is the water level is above 9 A.B.
- Main Condenser (EP-9)
- Main steam line drains
- Reactor feed pumps
- SJAEs
- Steam Reboiler
- HPCI steam line
- HPCI steam line
- RCIC steam line
- RWCU, recirc mode
  - Bypass the filter/demineralizers.
- RWCU, blowdown mode
- Head vent
- RHR (steam condensing mode) (OPERG)
- RHR (shutdown cooling mode)
  - Use only those RHR pumps not required to maintain RPV water level above 177 in. by operation in the LPCI mode.

Alternate RPV Level Control

IF	THEN
Primary containment water level and torus pressure cannot be maintained below the Primary Containment Pressure Limit AND Adequate core cooling can be assured	Terminate injection into the RPV from sources external to the primary containment.
RPV water level cannot be determined	Exit this procedure and enter EOP-7, "RPV Flooding" at "Shutdown Flooding."
RPV water level is rising	Exit "Alternate RPV Level Control" and enter "Section RPV/L."

Override ADS.

Line up for injection, start pumps, and area/practice of pumps NPSH and system limits, raise injection flow to the maximum with all available RPV injection systems (Group 1 and Group 2 Water Level Control Systems).

IF	THEN
Less than 2 of the following Group 1 water level control subsystems can be lined up: ➢ Condensate ➢ LPCIA ➢ LPCIB ➢ CSA ➢ CSB	Commence pumping as many Group 2 Water Level Control Systems as possible for injection.

WAIT until RPV water level drops to -8 in. (TAF).

IF	THEN
Not enough LPCI or CS pumps are running and lined up for injection into the RPV.	Line up for injection, start pumps and raise Group 2 Water Level Control System injection flows to the maximum rates.
RPV water level cannot be maintained above -19 in. without Emergency RPV Depressurization AND Pumps capable of recovering and maintaining RPV water level above -19 in. following Emergency RPV Depressurization are running and lined up for injection.	BEFORE RPV water level drops to -19 in. EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.

WAIT until RPV water level drops to -19 in.

Is any RPV injection source lined up with at least one pump running?
- No → STEAM COOLING IS REQUIRED.
- Yes →

WAIT until reduction in RPV injection is Requested.

Can RPV water level be restored and maintained above -19 in.?
- No → EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.
- Yes →

Line up for injection, start pumps and area/practice of pumps NPSH and system limits, raise injection flow to the maximum with all available RPV injection systems (Group 1 and Group 2 Water Level Control Systems).

IF	THEN
RPV water level cannot be restored and maintained above -19 in.	PRIMARY CONTAINMENT FLOODING IS REQUIRED.

Steam Cooling

IF	THEN
EMERGENCY RPV DEPRESSURIZATION IS REQUIRED	Exit "Steam Cooling" and enter "Emergency RPV Depressurization."
RPV water level is rising	Exit "Steam Cooling" and enter "Section RPV/P."
Any RPV injection source is lined up with at least one pump running AND RPV water level cannot be restored and maintained above -19 in.	EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.
The reactor is not shutdown	Exit this procedure and enter EOP-3, "Failure to Scram."
Core uncovery due to continued depletion of RPV pressure and the containment SRV pneumatic supply is or becomes unavailable	CORE ASSUMED UNCOVERED EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.
RPV water level cannot be determined	Exit this procedure and enter EOP-7, "RPV Flooding" at "Shutdown Flooding."

Establish a stable or lowering RPV pressure trend using the following systems:
- SRVs
  - Unless it is the water level is above 9 A.B.
  - If possible, open SRVs in the following sequence: (LRV-71A, J, K, G, L, D, C, F, H, L, B.
- HPCI
  - Align suction to the CST, if available. Defeat interlocks if necessary (EP-2).
- RCIC
  - Align suction to the CST, if available. Defeat interlocks if necessary (EP-2).
- RWCU, recirc mode
  - Bypass the filter/demineralizers. If necessary, defeat SLC and other RWCU isolation interlocks (EP-2).

IF	THEN
RPV pressure cannot be stabilized and is rising	EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.

WAIT until RPV water level drops to -8 in.

EMERGENCY RPV DEPRESSURIZATION IS REQUIRED.

❶ An RPV water level assessment must not be used if either of the following conditions exists:
- An unknown or non-hydrostatic water level above the RPV Saturation Temperature.
- The instrument reads above the Maximum Usable Indicating Level.

RPV Saturation Temperature



Minimum Usable Indicating Levels: [in.]



Heat Capacity Temperature Limit



SRV Tail Pipe Level Limit



Primary Containment Pressure Limit



NEW YORK POWER AUTHORITY JAMES A. FITZPATRICK NUCLEAR POWER PLANT EMERGENCY OPERATING PROCEDURE		
RPV CONTROL		
EOP-2	Rev. 5	13 Dec 98

FOR INFORMATION ONLY

D-7