ONE LINE & ELEMENTARY DIAGRAMS

GANG OPERATED HORN GAP SWITCH

HIGH VOLTAGE PRIMARY FUSE CUTOUT

60A — DISCONNECT SWITCH – SIZE AS INDICATED (3 POLE UNLESS OTHERWISE NOTED)

GROUNDING SWITCH

3 L.A. — LIGHTNING ARRESTER (NUMBER INDICATES QUANTITY)

CAPACITOR

DISCONNECT LINK

100A N A O E L — TRANSFER SWITCH – SIZE AS INDICATED
A – AUTOMATIC N – NORMAL
M – MANUAL E – EMERGENCY
L – LOAD

GROUNDING TRANSFORMER SIZE & RATING AS INDICATED

1 — GROUND DETECTION CURRENT TRANSFORMER – NUMBER INDICATES QUANTITY – RATIO AS NOTED

3 — CURRENT TRANSFORMER – NUMBER INDICATES QUANTITY RATIO AS NOTED

3 — BUSHING TYPE CURRENT TRANSFORMER NUMBER INDICATES QUANTITY RATIO AS NOTED

2 — BUSHING TYPE POTENTIAL DEVICE NUMBER INDICATES QUANTITY RATING AS NOTED

2 — POTENTIAL TRANSFORMER NUMBER INDICATES QUANTITY RATING AS NOTED

POWER TRANSFORMER SIZE & RATING AS NOTED (NUMBER OF WINDINGS AS SHOWN)

MEDIUM OR HIGH VOLTAGE DRAWOUT TYPE ELECTRICALLY OPERATED AIR CIRCUIT BREAKER, INTERRUPTING CAPACITY, SIZE & VOLTAGE AS NOTED

AF AT U — AIR CIRCUIT BREAKER DRAWOUT TYPE ELECTRICALLY OPERATED, MAGNETIC OVERCURRENT TRIP – CURRENT RATING & INTERRUPTING CAPACITY AS NOTED
AIC = AMP INTERRUPTING CAPACITY
AF = AMP FRAME
AT = AMP TRIP
U = UNDERVOLTAGE ATTACHMENTS
M = MANUALLY OPERATED

AIR CIRCUIT BREAKER 3 POLE UNLESS OTHERWISE NOTED

GROUND CONNECTION

DRAWOUT DISCONNECT DEVICE

1 — MAGNETIC STARTER WITH THERMAL OVERLOADS, SINGLE SPEED, NON-REVERSING FULL VOLTAGE – NUMBER INDICATES NEMA SIZE (SYMBOL WITH "RV" INDICATES REDUCED VOLTAGE)

1 — MAGNETIC STARTER WITH THERMAL OVERLOADS, SINGLE SPEED, REVERSING FULL VOLTAGE – NUMBER INDICATES NEMA SIZE (SYMBOL WITH "RV" INDICATES REDUCED VOLTAGE)

2 25 — MAGNETIC STARTER WITH THERMAL OVERLOADS, 2S=MULTI SPEED NON-REVERSING, FULL VOLTAGE NUMBER INDICATES NEMA SIZE

F 2 — THIS SYMBOL ABOVE STARTER OR CONTACTOR INDICATES COMBINATION STARTER OR CONTACTOR
F – INDICATES FUSED DISC SWITCH & FUSE
B – INDICATES CIRCUIT BREAKER
S – INDICATES UNFUSED DISC SWITCH

1 — MAGNETIC CONTACTOR NUMBER INDICATES NEMA SIZE

NANUAL MOTOR STARTER, 1 POLE WITH THERMAL OVERLOAD

GENERATOR SIZE & RATING AS NOTED

15 — MOTOR – NUMBER INDICATES HORSEPOWER

10 HP MOT / 7½ KW GEN — MOTOR – GENERATOR SET

1750 — SYNCHRONOUS MOTOR – NUMBER INDICATES HORSEPOWER

EXC — EXCITER

BATTERY

HEATER

FUSE

SHUNT

RESISTOR

RTD — RESISTANCE TEMPERATURE DETECTOR

INTERLOCKS:
E – ELECTRICAL
K – KEY
M – MECHANICAL

NO NORMALLY OPEN
NC NORMALLY CLOSED

CONTROL SWITCH WITH INDICATING LIGHTS

START – STOP MAINTAINED CONTACT PUSH BUTTON

START – STOP MAINTAINED CONTACT PUSH BUTTON WITH INDICATING LIGHTS

START – STOP MOMENTARY CONTACT PUSH BUTTON

T — START – STOP MOMENTARY CONTACT PUSH BUTTON WITH INDICATING LIGHTS
T = TEST

INDICATING LIGHTS

SLECTOR SWITCH WITH INDICATING LIGHTS

STOP LOCK-OUT PUSH BUTTON

PERMISSIVE SWITCH WITH INDICATING LIGHTS

CONTROL DEVICE: TYPE AS NOTED

TS — TEMP SW CONTACT
LVS – LEVEL SW CONTACT
PS – PRESS SW CONTACT
FS – FLOAT SW CONTACT
LS – LIMIT SW CONTACT
FR – FIRE RELAY CONTACT
T – THERMOSTAT
PE – PNEU–ELEC RELAY
EP – ELEC–PNEU SW
H – HUMIDISTAT

A — METERS & INSTRUMENTS
PREFIX "R" DENOTES RECORDING TYPE, NUMBER NEXT TO SYMBOL DENOTES QUANTITY IF MORE THAN ONE IS REQD

A AMMETER
V VOLTMETER
W WATTMETER
VAR VARMETER
WH WATTHOUR METER
F FREQUENCY METER
WHD DEMAND WATTHOUR METER
SY SYNCHROSCOPE
PF POWER FACTOR METER
THC THERMAL CONVERTER
TR TEMP RECORDER
TI TEMP INDICATOR
TACH TACHOMETER
TM TRANSMITTER

AS — SWITCHES
AS–AMMETER SW
VS–VOLTMETER SW
SYN SW–SYNCHRO SW
HS–HAND SW
SS–SEL SW
CS–CONTROL SW
TS–TEST SWITCH

TRD — TRANSDUCER

VA — VOLTAGE ADJUSTING RHEOSTAT

—TRANSFORMER CONNECTIONS—

△ 3ø, 3W DELTA
∠ 3ø, OPEN DELTA
/ SINGLE PHASE
⟊ 3ø, WYE OR STAR

86 — RELAYS & DEVICES
NUMBER NEXT TO SYMBOL DENOTES QUANTITY IF MORE THAN ONE IS REQUIRED

21 DISTANCE
27 UNDERVOLTAGE
30 ANNUN ALARM
40 LOSS OF FIELD
46 NEGATIVE SEQUENCE
50 INSTANT OVERCURRENT
50–1 INSTANT ELEMENT SHORT CIRC TRIP
50–2 INSTANT ELEMENT LOCKED ROTOR TRIP
50/51 OVERCURR–INSTANT & TIME DELAY
51 AC OVERCURRENT–TIME DELAY
55 POWER FACTOR
59 OVERVOLTAGE
60 VOLTAGE BALANCE
63 PRESSURE
64 GROUND PROTECTIVE
67 AC DIRECTIONAL OVERCURRENT
74 ALARM AUX RELAY
76 DC OVEREXCITATION
81 FREQUENCY
86 LOCKOUT
87 DIFFERENTIAL
25 SYNCHRONIZING CHECK

CR CONTROL RELAY
AR AUXILIARY RELAY
LR LATCHING RELAY
(LATCH OR UNLATCH COIL AS SHOWN)

TDR TIME DELAY RELAY
COIL: TDPU – TIME DELAY PICK UP
TDDO – TIME DELAY DROP OUT
CONTACT TDCAE – TIME DELAY CLOSE AFTER ENERGIZATION
TDOAE – TIME DELAY OPEN AFTER ENERGIZATION
TDCAD – TIME DELAY CLOSE AFTER DE–ENERGIZATION
TDOAD – TIME DELAY OPEN AFTER DE–ENERGIZATION

DEVICES

2 TIME DELAY CLOSING RELAY
20 ELEC OPER VALVE
33 POSITION OR LIMIT SW
41 FIELD CIRCUIT BREAKER
42 MOTOR STARTER
52 AC CIRCUIT BREAKER
62 TIME DELAY OPENING RELAY
71 LEVEL SWITCH
72 DC CIRCUIT BREAKER
80 FLOW SWITCH

RELAY OR DEVICE "SUFFIX LETTERS"

F FIELD
G GROUND
N NEUTRAL
TELM TELEMETRERING
V VOLTAGE
X AUXILIARY
GN GENERATOR DIFFERENTIAL
GD GENERATOR DISTANCE
GF GENERATOR FIELD
GG GENERATOR GROUND
GNS GENERATOR NEG SEQUENCE
GT GENERATOR TRANSFORMER
GOE GENERATOR OVER EXCITATION
345KV LINE
TGP MAIN TRANSFORMER GAS
TN MAIN TRANSFORMER NEUTRAL
LGT LINE GEN TRANSF OVERALL
NGP NORM STA SERV TRANSF GAS
NT NORM STA SERV TRANSF
SGP START UP STA SERV TRANSF GAS
ST START UP STA SERV TRANSF
STL 161KV LINE
EGP EMERG TRANSF GAS
T TURBINE
IAS 4160V SWGR START–UP BKR 1A
IAN 4160V SWGR NORMAL BKR 1A
IBS 4160V SWGR START–UP BKR 1B
IBN 4160V SWGR NORMAL BKR 1B
ICS 4160V SWGR START–UP BKR 1C
ICN 4160V SWGR NORMAL BKR 1C
IDS 4160V SWGR START–UP BKR 1D
IDN 4160V SWGR NORMAL BKR 1D
IFS 4160V SWGR EMERG BKR 1F
IGS 4160V SWGR EMERG BKR 1G
DG1 DIESEL GEN NO 1
DG2 DIESEL GEN NO 2
IFE DIESEL GEN NO 1 BKR 1FE
IGE DIESEL GEN NO 2 BKR 1GE
NB 4160V SWGR NORMAL SUPPLY
SB 4160V SWGR START–UP SUPPLY

SOLENOID

WIRE TERMINAL POINT

WIRE CONNECTION POINT

R — INDICATING LIGHT WITH DROPPING RESISTOR
R–RED B–BLUE
G–GREEN C–CLEAR
W–WHITE A–AMBER

R — INDICATING LIGHT

TEST JACK CONNECTION POINT

PUSH BUTTON–MOMENTARY CONTACT NORMALLY CLOSED

PUSH BUTTON–MOMENTARY CONTACT NORMALLY OPEN

PUSH BUTTON–MAINTAINED CONTACT

O L — MANUAL MOTOR STARTER – SINGLE POLE WITH THERMAL OVERLOAD

OL — OVERLOADS (THREE LINE DIAGRAM)

BLOCKING DIODE

OL — OVERLOADS

CONTACT – NORMALLY OPEN (NO)

CONTACT – NORMALLY CLOSED (NC)

BA — BELL ALARM CONTACT (OPEN OR CLOSED AS INDICATED)

52A — BREAKER CONTACT (OPEN WHEN BREAKER IS OPEN)

52B — BREAKER CONTACT (CLOSED WHEN BREAKER IS OPEN)

52H IN — BREAKER POSITION SWITCH (CLOSED WHEN BREAKER IS IN OPERATING POSITION)

52H OUT — BREAKER POSITION SWITCH (OPEN WHEN BREAKER IS IN OPERATING POSITION)

CS 2 — CONTROL SWITCH, CONTACTS AS INDICATED IN CONTROL SWITCH DEVELOPMENT

CS T C — CONTROL SWITCH TEST, LOCATED AT 4160V SWGR
C – INDICATES CLOSED POSITION
T – INDICATES TEST POSITION

MULTIPLE CONDUCTOR – SHIELDED CABLE (TWO CONDUCTOR SHOWN)

MULTIPLE CONDUCTOR – SHIELDED CABLE – SHIELD GROUNDED (TWO CONDUCTOR SHOWN)

SIGNAL CONNECTOR (MULTI CONDUCTOR)

POWER, GROUNDING, & LIGHTING PLANS

LIGHTING PANEL (SEE LIGHTING PANEL SCHEDULES)

PANEL – MISCELLANEOUS AS NOTED ON PLAN DWGS

POWER PANEL

MOTOR HORIZONTALLY MOUNTED

MOTOR – VERTICALLY MOUNTED

CONTACTOR

MOTOR STARTER OR CONTROLLER

TRANSFER SWITCH–SIZE & TYPE AS NOTED

DISCONNECT OR SAFETY SWITCH SIZE AS NOTED

TRANSFORMER – DRAW TO SCALE SIZE & RATING AS NOTED

MOTOR OPERATED VALVE

AV — AIR OPERATED VALVE

LOCAL PUSHBUTTON STATION OR LOCAL CONTROL STATION, TYPE AS NOTED

OL SEL — SINGLE POLE MANUAL MOTOR STARTER WITH THERMAL OVERLOAD
SEL = SELECTOR SWITCH

J — JUNCTION BOX
TB – TERMINAL BOX
PB – PULL BOX

RIGID CONDUIT – RUN EXPOSED

RIGID CONDUIT – RUN CONCEALED

CONDUIT OR CABLE TURNING UP OR TOWARDS OBSERVER

CONDUIT OR CABLE TURNING DOWN OR AWAY FROM OBSERVER

DIRECT BURIAL CABLE

FLEXIBLE CONDUIT

CONDUIT "SEALING" FITTING

HORZ VERT — UNIT HEATER

TS — CONTROL DEVICES: TYPE AS NOTED

TS – TEMP SW
SV – SOLENOID VALVE
LVS – LEVEL SWITCH
PS – PRESSURE SWITCH
FS – FLOAT SWITCH
LS – LIMIT SWITCH
SS – SELECTOR SWITCH
CS – CONTROL SWITCH
PMS – PERMISSIVE SW
RTD – RESIST TEMP DETEC
T – THERMOSTAT
TE – TEMP ELEMENT
PE – PNEU–ELECT RELAY
SP – ELECT–PNEU SWITCH
T/C – THERMOCOUPLE
H – HUMIDISTAT
FT – FLOW TRANSFMITTER
PT – PRESSURE TRANS
LT – LEVEL TRANS
FI – FLOW INDICATOR
FLS – FLOW SWITCH
A – ALTERNATOR
SD – SMOKE DETECT
V – VALVE

CABLE TRAY OR CABLE LADDER (SIZE & ELEVATION AS NOTED ON PLAN DWGS)

IG — INSTRUMENT GROUND CABLE

G — GROUND CABLE – RUN EXPOSED

G — GROUND CABLE – RUN CONCEALED OR BELOW GRADE

GROUND ROD 5/8" DIA x 20'–0" LONG COPPER WELD

GROUND CONNECTION "THERMO PROCESS" WELD "CADWELD" OR APPROVED EQUAL

GROUND CONNECTION – PRESSURE TYPE SOLDERLESS CONNECTOR

ARC — INDICATES AUXLIARY RELAY CABINET

INDICATES LOCAL DEVICE

INDICATES LOCAL DEVICE ON LOCAL PANEL

B — INDICATES EQUIPMENT LOCATED AT BENCHBOARD LETTER OR NUMBER DESIGNATION AS SHOWN

40–27 — INDICATES EQUIPMENT LOCATED AT CABINET NUMBER DESIGNATION AS SHOWN

F — INDICATES EQUIPMENT LOCATED AT VERTICAL BOARD, LETTER OR NUMBER DESIGNATION AS SHOWN

40–11 — INDICATES EQUIPMENT LOCATED AT COMPUTER EQUIPMENT DESK, LETTER OR NUMBER DESIGNATION AS SHOWN

C — INDICATES ANNUNCIATION – LETTER DENOTES BOARD OR PANEL LOCATION

3 A 2–40 10'–0" — "A" INDICATES FIXTURE TYPE "2–40" INDICATES NO. & WATTAGE OF LAMPS "3" INDICATES NO. OF FIXTURES 10'–0" INDICATES MOUNTING HEIGHT

CEILING MTD A C–2 / WALL MTD A — INCANDESCENT OR MERCURTY LTG FIXTURE "A" INDICATES FIXTURE TYPE "C–2" INDICATES LTG PNL "C", CIRCUIT 2 (SMALL CIRCLE FOR INDIVIDUAL IDENTIFICATION)

EXIT LIGHTING FIXTURE

FLUORESCENT LIGHTING FIXTURE

BARE LAMP FLUORESCENT STRIP

STREET LIGHTING FIXTURE

FLOODLIGHT FIXTURE

EMERGENCY LIGHTING UNIT AC/DC

EMERGENCY LIGHTING REMOTE LAMP

GOOSENECK LIGHING STANCHION AND FIXTURE

REMOTE LAMP MOUTNED ABOVE EMERGENCY LIGHTING UNIT

G P 3 — SWITCH – SINGLE POLE
120V 20A TOGGLE
G – INDICATES ASSOCIATED CONTROLLED FIXTURES
3 – INDICATES 3 WAY SWITCH
P – INDICATES SWITCH WITH PILOT LIGHT

CKTS LP9,11,15 4#12 — HOME RUN TO PANELBOARD – ALL UNMARKED CONDUITS ARE 3/4" IN SIZE AND CONTAIN 2#12 UNLESS OTHERWISE NOTED

SWITCH & SINGLE CONVENIENCE RECEPTACLE COMBINATION

SWITCH & DUPLEX CONVENIENCE RECEPTACLE COMBINATION 20A, 125VAC, GE 5951–1 OR EQUAL

SINGLE RECEPTACLE, CONVENIENCE, 2P 3W 15A 125V HUBBELL TYPE 5261 OR APPVD EQUAL

DUPLEX RECEPTACLE, CONVENIENCE, 2P 3W 15A 125V HUBBELL TYPE 5262 OR APPVD EQUAL

CR — DUPLEX RECEPTACLE, CONVENIENCE, 2P 3W 15A 125V – "CR" INDICATES CORROSION RESISTANCE. HUBBELL TYPE 52CM62 WITH 52CM08 CAP OR APPVD EQUAL

R — DUPLEX RECEPTACLE, CONVENIENCE, 2P 3W 15A 125V HUBBELL TYPE 5262I OR APPVD EQUAL – "R" INDICATES REGULATED VOLTAGE

SINGLE RECEPTACLE 2P 3W GROUNDING 20A 250V NEMA 6–20R, HUBBELL TYPE 5461 WITH SUPER STAINLESS PLATE HUBBELL 93091 OR APPVD EQUAL

POWER RECEPTACLE 3W 4P 60A 600VAC CROUSE–HINDS TYPE "AREA" CAT NO. AREA6425 OR APPVD EQUAL

POWER RECEPTACLE 3W 4P 30A 600VAC CROUSE–HINDS TYPE "ARE" CAT NO. ARE3423 OR APPVD EQUAL

PLUG–IN STRIP – TYPE AS NOTED ON DWGS

CEILING MTD / WALL MTD

FN — FAN OUTLET

CK — CLOCK OUTLET

RL — REELITE

DC — DROP CORD

P — PORCELAIN LAMP HOLDER (PC INDICATES PULL CHAIN)

OUTLET BOX

FIRE ALARM & COMMUNCATION PLANS

TS — TELEPHONE SWITCHBOARD

PUBLIC TELEPHONE CO. TELEPHONE WITH ACCESS TO PUBLIC EXCHANGE, DESK TYPE

PUBLIC TELEPHONE IN FULL BOOTH

D — INDUSTRIAL TYPE TELEPHONE
D = DESK SET
W = WALL SET
WP = WEATHERPROOF WALL SET

SOUND POWERED TELEPHONE SET

S.P. — JACK FOR SOUND POWERED TELEPHONE

T — OUTLET FOR PLUG–IN PORTABLE INDUSTRIAL TELEPHONE

LOUDSPEAKER, HORN TYPE, SINGLE UNIT

LOUDSPEAKER, SPECIAL TYPE

LOUDSPEAKER, OFFICE TYPE WITH VOLUME CONTROL

I — TWO–WAY INTERCOM SET

MICROPHONE (RADWASTE AREA)

TV R — CLOSED CIRCUIT TELEVISION RECEIVER

TV C — CLOSED CIRCUIT TELEVISION TRANSMITTER & CAMERA

ABBREVIATIONS

TRANSF TRANSFORMER
SWGR SWITCHGEAR
MCC MOTOR CONTROL CENTER
PDP POWER DISTRIBUTION PANEL
LDP LIGHT DISTRIBUTION PANEL
PP POWER PANEL
LP LIGHTING PANEL
GND GROUND
CND CONDUIT
PT POTENTIAL TRANSFORMER
CT CURRENT TRANSFORMER
POS(+) POSITIVE
NEG(–) NEGATIVE
RP RELAY PANEL
EP EXPLOSION PROOF
WP WEATHER PROOF
VT VAPOR TIGHT
DT DUST TIGHT
WT WATER TIGHT (SUBMERSIBLE)
EC EMPY CONDUIT
DP DRIP PROOF

POLE LINE & UNDERGROUND DISTRIBUTION PLANS

35–5 O — EXISTING POLE LENGTH & CLASS AS NOTED

35–5 ● — NEW POLE LENGTH & CLASS AS NOTED

35–5–6M — POLE WITH DOWN GUY & ANCHOR–LENGTH & CLASS & STRENGTH OF GUY IN POUNDS AS NOTED

35–5–6M — POLE WITH STREET LIGHTING FIXTURE LENGTH & CLASS AS NOTED

1 — SINGLE PHASE TRANSFORMER SIZE & RATING AS NOTED

3 — THREE PHASE TRANSFORMER SIZE & RATING AS NOTED

STREET LIGHTING REGULATOR RATING AS NOTED

SECTIONALIZING SWITCH–MOUNTED ON CROSSARM – NORMALLY OPEN

SECTIONALIZING SWITCH–MOUNTED ON CROSSARM – NORMALLY CLOSED

POLE TOP SWITCH

L.A. — LIGHTING ARRESTER IN EACH PHASE WIRE

3#2 — PRIMARY LINE – NO. & SIZE OF WIRE AS NOTED

#8 — SERIES STREET LTG CKT 1/C OF SIZE NOTED

3#2 — 3ø SECONDARY LINE – NO. & SIZE OF WIRE AS NOTED

1ø SECONDARY LINE – NO. & SIZE OF WIRE AS NOTED

CONDUCTOR DEAD END

MH# — MANHOLE

HH# — HANDHOLE

TOP OF DUCTBANK (ELEV AS NOTED)

INDICATES NUMBER & ARRGT OF DUCTS IN DUCTBANK

INDICATES 6 OF DUCTBANK (LOCATE WITH DIMENSIONS OR CO–ORDINATE NUMBERS)

ARROW INDICATES DIRECTION OF DUCTBANK TOWARDS LOW POINT

NOTES

1. FOR ADDITIONAL SYMBOLS RELATED TO BENCHBOARD & CABINET DESIGNATIONS SEE DWG 3032.

NON CONTROLLED PRINT
MAR 20 2007
N.P.P.D.. RIMS

D-57

454003947

AS BUILT

CADD DRAWING
DO NOT REVISE MANUALLY

FOR PREVIOUS REVISIONS, SEE SUPERSEDED CARDS

REVISIONS BY N.P.P.D.

NO.	REVISIONS	DFT	CKD	APP	DATE
N05	CED 6007522 (DCN 02–0638)	RGA	KG	DLR	3/18/03
N06	DCN 05–1970	RGA	RGA	KG	12/30/05

REVISIONS NO.

SIGNIFICANT NUMBER / GROUP | 1 | 2 | 3 | 4 | 5 | 6

DRAWN RGA DATE 8/18/05
CHECKED DATE
APPROVED DATE
SEE SUPERSEDED CARDS
FILMED

ELECTRICAL
SYMBOL LIST
COOPER NUCLEAR STATION

BURNS & ROE

3070

REVISION N06

CARD FILE C0053207