ANNUNCIATOR SB2F-1-8

ANNUNCIATOR SB2F-4-8

ANNUNCIATOR SB2F-4-7

ANNUNCIATOR SB2F-1-7

ANNUNCIATOR SB2F-2-1

ANNUNCIATOR SB2F-3-1

ANNUNCIATOR SB2F-4-9

ANNUNCIATOR SB2F-1-10

ANNUNCIATOR SB2F-3-10

ANNUNCIATOR SB2F-4-10

DRG 5338971, SH.110
VALVE 731
403BA
ECN-70395, REV.1

ANNUNCIATOR SAF-1-1

ANNUNCIATOR SAF-2-1

RCP NUMBER SEAL/STANDPIPE LEVEL OFF NORMAL LIGHTS PANEL SAF

RCP31 TOP POT HI (AT PUMP)
RCP31 BOT. POT HI
RCP31 TOP POT LO (AT PUMP)
RCP31 BOT. POT LO
RCP32 TOP POT HI (AT PUMP)
RCP32 BOT. POT HI
RCP32 TOP POT LO (AT PUMP)
RCP32 BOT. POT LO
RCP33 TOP POT HI (AT PUMP)
RCP33 BOT. POT HI
RCP33 TOP POT LO (AT PUMP)
RCP33 BOT. POT LO
RCP34 TOP POT HI (AT PUMP)
RCP34 BOT. POT HI
RCP34 TOP POT LO (AT PUMP)
RCP34 BOT. POT LO

ANNUN. SAF-3-1

ANNUN. SAF-4-1

120VAC
CONTINUED BELOW

CONTINUED ABOVE

RCP MOTOR NUMBER OIL LEVEL OFF NORMAL LIGHTS

EXTERNAL ACTUATION FROM SWITCH GEAR REACTOR TRIP BREAKERS REF. DWG. 1138501 SH.11

ANNUNCIATOR SDF-2-8

ANNUNCIATOR SB1F-3-11

DRG 5338971, SH.110 VALVE 731 403AR BF SWP ECN-70095

ANNUNCIATOR SB2F-1-4

ANNUNCIATOR SB2F-2-4

ANNUNCIATOR SB2F-3-4

ANNUNCIATOR SB2F-4-9

INPUT T.B. LEFT SIDE

T.B. POINTS (INPUT)

120 VAC TERMINAL BLOCK OUTPUT T.B. RIGHT SIDE

T.B. POINTS (OUTPUT)

CONTINUED AT TOP NEXT COLUMN

CONTINUED AT TOP NEXT COLUMN

NOTE
ALL INTERFACE TERMINALS ARE WIRED FROM FOXBORO UNLESS STATED OTHERWISE.
ALL RELAYS ARE BF2F TYPE UNLESS NOTED OTHERWISE.
"S" USED TO IDENTIFY SPARE RELAY.
ANN. REF W. DWG. 5008578 SHEETS, 164 165, 168, 170, 172, 187.

ALL INPUT TERMINALS
ALL OUTPUT TERMINALS

TERMINAL BOARD 26
20 AMP FUSE BLOCK
120 VAC 60~2

* "3" INDICATES RACK 2, FRONT.
TB- INDICATES TERMINAL BOARD
"1"-INDICATES TERMINAL NO 1.
* THESE DESIGNATIONS HAVE BEEN ELIMINATED FROM TERMINALS SHOWN ON THIS DWG. FOR CLARITY.

RECEIVED
JUL 10 1974
U.S. ATOMIC ENERGY COMMISSION
Regulatory Mail Section

6246
8111030028

8111030028

WESTINGHOUSE ELECTRIC CORPORATION
ATOMIC POWER D.C. PITTSBURGH, PA. U.S.A.