
INDICATION DC CONTROL W/
RESET
AUTO TRANSFER TO START-UP TRANSFORMER
TRIP AUX. TRANSF. BKR
CLOSE START UP TRANSF BKR
ENERGIZE AUTO TRANSFER TIMERS
SWITCH TO DIESEL GENERATOR
RESET
LOCKOUT PROCESS CONTROL
TRIP START UP TRANSF BKR
CLOSE DIESEL BKR
ENERGIZE AUTO TRANSF TRIP MOTOR LOAD BKRS
SWITCH TO DIESEL GEN
4 KV BUS U.V. (4.0 TO 3 SEC)
4 KV BUS U.V. (3.0 TO 2.3 SEC)
START DIESEL
4 KV ST-UP BUS U.V. (1.0 TO 0.4 SEC)
TEMPORARY JUMPER TILL UNIT 2 CWSR IN OPERATION
DISC IN FIELD
RHF
SHF
CHE
CHF
CHFT
SHEF13
SHEF14
SHEF15
SHEF16
SHEF17
SHEF18
SHEF19
SHEF20
SHEF21
SHEF22
SHEF23
SHEF24
SHEF25
SHEF26
SHEF27
SHEF28
SHEF29
SHEF30
SHEF31
SHEF32
SHEF33
SHEF34
SHEF35
SHEF36
SHEF37
SHEF38
SHEF39
SHEF40
SHEF41
SHEF42
SHEF43
SHEF44
SHEF45
SHEF46
SHEF47
SHEF48
SHEF49
SHEF50
SHEF51
SHEF52