SYSTEM OPERATING DATA NOTE 10

#	AIR FLOW CFM	AIR TEMP. • F	
3	900	19-120	
4	19000	95-200	
5	3000	19/120	
6	14000	19/95	

FAN OPERATION NOTES:

A. VENTILATION FANS XFN0200 AND XFN0202 OPERATE AT ALL TIMES. IF A LOSS OF FLOW IS DETECTED AN ALARM IS GENERATED AND ADDITIONAL FANS ARE STARTED AUTOMATICALLY.

B. XFN0204 STARTS AUTOMATICALLY WHEN XEG0103 IS STARTED. XFN0203 AND XFN0205 WILL START AUTOMATICALLY IF DG ROOM TEMPERATURE INCREASES ABOVE 80 DEG F AND DG IS RUNNING. XFN0203 AND XFN0205 WILL SECURE IF ROOM TEMPERATURE DROPS BELOW 60 DEG F.

C. HVAC ALARMS ARE INDICATED ON XPN5387. GENERAL "EB HVAC TROUBLE ALARM" IS INDICATED ON TEMP MONITORING SYSTEM AND ANNUNCIATED IN MAIN CONTROL ROOM.

D. COMMON LOW DG COOLING FLOW ALARM LIGHT ON XPN5387.

EB DIESEL GENERATOR ROOM
EL. 436'-6"

FIRE SERVICE FAN AND DAMPER DISABLE NOTE 4

FS — SS P5387 AH421D

DIESEL GENERATOR XEG0103 RUNNING SIGNAL

TS 78002

FS — CS P5387 AH421E — FIRE SERVICE FAN AND DAMPER DISABLE NOTE4

CS P5387 AH421C — FS FIRE SERVICE FAN DISABLE NOTE4

OUTSIDE AIR INTAKE

2 HP RPM 1160 460V — E FC — XDP5201-AH — SSW — XFN0204-SSW-1-AH — ECR50793C XFN0204-AH NOTE B — 6 → 14000 CFM (100% RADIATOR COOLING SUPPLY)

FAN RUNNING L

LOW FLOW NOTES 8,11 LOW FLOW ALARM LIGHT NOTE D — A L — L

DIESEL GENERATOR XEG0103 — DIESEL DRIVEN RADIATOR EXHAUST FAN NOTE B — E FC — XDP5200-AH — SSW — XEX0103-SSW-1-AH — 4 → 19000 CFM (100% RADIATOR COOLING EXHAUST)

LOW FLOW NOTE 11 LOW FLOW ALARM LIGHT NOTE D — A L — L — NOTE 8

FAN RUNNING L

OUTSIDE AIR INTAKE

3/4 HP RPM 860 460V — E FC — XDP5202-AH — SSW — XFN0205-SSW-1-AH — ECR50793C XFN0205-AH NOTE B — 5 → 7000 CFM (100% ROOM COOLING SUPPLY)

FAN RUNNING L

LOW FLOW NOTES 8,11 LOW FLOW ALARM LIGHT NOTE D — A L — L

1.5 HP RPM 1725 460V — E FC — XDP5203-AH — SSW — XFN0203-SSW-1-AH — ECR50793C XFN0203-AH NOTE B — 5 → 3000 CFM (100% ROOM COOLING EXHAUST)

FAN RUNNING L NOTE 8

LOW FLOW NOTES 8,11 LOW FLOW ALARM LIGHT NOTE D — A L — L

OUTSIDE AIR INTAKE

G FC — XDP5207-AH — 3 → 900 CFM (100% VENT AIR)

1/6 HP RPM 1697 120V (VARIABLE SPEED FANMOTOR) — FAN IN OPER. L

G FC — XDP5206-AH — SSW — XFN0202-SSW-1-AH — ECR50793C XFN0202-AH NOTE A — 3 → 900 CFM (100% VENT AIR)

3

LOW FLOW NOTE 11 LOW FLOW ALARM LIGHT NOTE D — A L — L — NOTE 8

FAN RUNNING L

GENERAL NOTES (1-11): SEE SHEET 1

ESSENTIAL

ALL SYSTEM COMPONENTS ARE NON-NUCLEAR SAFETY RELATED

DRAWING CLASS LEGIBILITY 1

SYSTEM DESIGN DATA NOTE 10

#	AREA AIR FLO W CFM	AREA AIR TE MP.• F	AREA EMERGENCY• AIR TEMP. •F
3	900/21,900	19/120	19/120

•EMERGENCY CONDITION EXISTS WHEN NORMAL POWER IS LOST AND DG IS PROVIDING POWER

1/4"=1'-0" 0 5' 10' 15' 20'

NO.	DATE	BY	REVISION	CKD. BY	LE APPROVAL
1	4/28/15	JTS	REVISED PER ECR-50793C	MGR	RS
0	2/3/15	JMR	ISSUED PER ECR-50793	MGR	RS

FSAR Figure 9.4-35 SH. 2

SOUTH CAROLINA ELECTRIC & GAS COMPANY

VIRGIL C. SUMMER NUCLEAR STATION

BUILDING SERVICE SYSTEM FLOW DIAGRAM

EB HVAC DG1 ROOM

DESIGN ENGINEERING — V. C. SUMMER NUCLEAR STATION JENKINSVILLE S. C.

MADE	CHECKED	LE APPROVAL
1. JMR	2. MGR	3. RS

SCALE NO SCALE — DRAWING NUMBER D-912-192 — SHT. NUMBER 2 — REV 1