

REPORT: P187R40

DOCUMENTATION MANAGEMENT
DOCUMENT ON-LINE CONTROL SYSTEM
TRANSMITTAL / RECEIPT ACKNOWLEDGMENT

50-346

pk

TRANSMITTAL NUMBER: 0107-01143
TRANSMITTAL DATE : 07/23/2001
TRANSMITTAL PAGE : 001

COPY NUMBER : 1665

TO: DOC. CONTROL DESK,

USNRC
DIVISION OF EMERGENCY
PREPARDNESS
WASHINGTON, D.C. 20555

AS THE HOLDER OF THESE DOCUMENT COPIES, YOU ARE RESPONSIBLE FOR THEIR CONTROL AND MAINTENANCE IN ACCORDANCE WITH THE ACTIONS SPECIFIED BY THIS TRANSMITTAL. DOCUMENTS WHICH ARE NO LONGER CURRENT SHALL EITHER BE REMOVED AND DESTROYED OR MARKED TO REFLECT THAT THEY ARE SUPERSEDED OR VOIDED AND ARE NO LONGER CONSIDERED CONTROLLED.

***** ENSURE THAT DOCUMENTS ARE FILED IN TAB ORDER AS IDENTIFIED ON THE TABLE OF CONTENTS, AS APPLICABLE *****

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT DOCUMENT CONTROL, DAVIS-BESSE NUCLEAR POWER STATION, TELEPHONE (419) 321-7483.

THE ATTACHED DOCUMENT COPIES ARE DISTRIBUTION ONLY. NO RECEIPT ACKNOWLEDGMENT IS REQUIRED.

A045-

REPORT: P187R40

DOCUMENTATION MANAGEMENT
DOCUMENT ON-LINE CONTROL SYSTEM
TRANSMITTAL / RECEIPT ACKNOWLEDGMENT

TRANSMITTAL NUMBER: 0107-01143
TRANSMITTAL DATE : 07/23/2001
TRANSMITTAL PAGE : 002

COPY NUMBER : 1665

	TYPE	DOCUMENT			STATUS

TOC	EPON		SHT/SEC:		
REMOVE:	TOC	EPON	SHT/SEC:	REV/SUB: 0052	REVISED
INSERT:	TOC	EPON	SHT/SEC:	REV/SUB: 0053	APPROVED
MANUAL: EPON			SHT/SEC:		
PROC RA-EP-02861			SHT/SEC:		
REMOVE:	PROC	RA-EP-02861	SHT/SEC:	REV/SUB: 0001	REVISED
	PC	C99-2368	SHT/SEC:	REV/SUB: 0002	INCORPORATED
INSERT:	PROC	RA-EP-02861	SHT/SEC:		APPROVED

END OF TRANSMITTAL

MANUAL TABLE OF CONTENTS
 DB EMERGENCY PLAN OFF NORMAL OCCURRENCE PROCEDURES
 MANUAL: EPON REVISION: 53

PAGE NO. 1
 DATE 07/23/01

TAB	PROCEDURE NUMBER	REV	ST	EFFECT DATE	ALTERATIONS	ALTERATION EFF DATE	TITLE
001	RA-EP-02000	00	CE	1/29/1997			MEDICAL EMERGENCIES
002	RA-EP-02800	00	CE	5/1/1995			PREPARATION AND TRANSPORT OF CONTAMINATED INJURED PERSONNEL
003	RA-EP-02805	02	CE	1/29/1997			DAVIS-BESSE EMERGENCY TELEPHONE SYSTEM
004	RA-EP-02807	00	CE	10/26/1995			EMERGENCY HELICOPTER LANDING ZONE
005	RA-EP-02810	01	CE	11/8/1999	C 000387	4/28/2000	TORNADO
006	RA-EP-02820	02	CE	11/6/1997			EARTHQUAKE
007	HS-EP-02830	01	CE	12/30/1992			FLOODING
008	HS-EP-02840	01	CE	12/8/1992			EXPLOSION
009	RA-EP-02850	03	CE	12/27/2000			HAZARDOUS CHEMICAL AND OIL SPILLS
010	RA-EP-02861	02	CE	7/23/2001			RADIOLOGICAL INCIDENTS
011	RA-EP-02864	00	CE	1/10/1995			CONTAINMENT EVACUATION
012	RA-EP-02870	00	CE	5/13/1996	C 962164	12/12/1996	STATION ISOLATION
					C 970372	6/18/1997	
013	RA-EP-02880	01	CE	10/14/1998			INTERNAL FLOODING

DOCUMENTATION MANAGEMENT
CONTROL COPY
 NO. 1665

Davis-Besse Nuclear Power Station
EMERGENCY PLAN OFF NORMAL PROCEDURE

RA-EP-02861

(Supersedes RA-EP-02861 R1)

RADIOLOGICAL INCIDENTS

REVISION 02

Prepared by: PF Termini *PT* 6-20-01
Date

Sponsor: *D. H. ...* 6-22-01
Manager - Regulatory Affairs Date

Approved by: *B. Wiley* 7/9/01
Director - Support Services Date

Approved by: *J. W. ...* 7/10/01
Plant Manager Date

Effective Date: 7-23-01

Procedure Classification:

- Safety Related
- Quality Related
- Non-Quality Related

**LEVEL OF USE:
IN-FIELD REFERENCE**

DOCUMENTATION MANAGEMENT
CONTROL COPY
NO. 11665

TABLE OF CONTENTS

	<u>Page</u>
1.0 PURPOSE	4
2.0 REFERENCES	4
3.0 DEFINITIONS	4
4.0 RESPONSIBILITIES	5
5.0 INITIATING CONDITIONS	5
6.0 PROCEDURE	6
6.1 General.....	6
6.2 Abnormal or Unknown Radiation Levels	6
6.3 Abnormal or Unknown Airborne Radioactivity.....	9
6.4 Radioactive Material Spill.....	12
7.0 FINAL CONDITIONS	14
8.0 RECORDS	15
COMMITMENTS	16

1.0 PURPOSE

- 1.1 This procedure describes actions and tasks to be performed when one or more of the following radiological incidents occur at the Davis-Besse Nuclear Power Station:
- 1.1.1 Confirmation of abnormal radiation levels
 - 1.1.2 Confirmation of abnormal radioactivity
 - 1.1.3 Confirmation of a spill of radioactive material inside of a Radiologically Restricted Area (RRA)
 - 1.1.4 Confirmation of a spill of potentially or known radioactive material outside a posted RRA

2.0 REFERENCES

2.1 Developmental

- 2.1.1 Davis-Besse Nuclear Power Station (DBNPS) Emergency Plan
- 2.1.2 Surface Contamination Decision Levels; Healey, J.W.; LA-4558-MS, Los Alamos National Laboratory; 1981
- 2.1.3 Model Spill Procedures, Appendix J to Regulatory Guide-10.8R2, USNRC; White Flint, MD; 1987

2.2 Implementation

- 2.2.1 RA-EP-01500, Emergency Classification
- 2.2.2 HS-EP-02240, Offsite Dose Assessment
- 2.2.3 RA-EP-02864, Containment Evacuation
- 2.2.4 DB-OP-00002, Operations Section Event/Incident Notifications and Actions
- 2.2.5 DB-OP-02530, Fuel Handling Accident
- 2.2.6 DB-OP-02550, Dry Fuel Storage Abnormal Event
- 2.2.7 DB-OP-06412, Process and Area Radiation Monitors
- 2.2.8 DB-OP-06504, Emergency Ventilation System
- 2.2.9 Offsite Dose Calculation Manual (ODCM)

3.0 DEFINITIONS

- 3.1 CONFIRMATION – As it is used in this procedure, means an initial alarm is determined to be valid by one or more of the following:
- Radiation Protection survey or investigative results
 - An independent radiation monitor alarm
 - System or equipment conditions would make a release of radioactive material likely

4.0 RESPONSIBILITIES

- 4.1 The Shift Manager shall implement this procedure.
- 4.2 Radiation Protection personnel shall investigate, verify and keep the Shift Manager informed of the radiological conditions.

5.0 INITIATING CONDITIONS

- 5.1 When one or more of the following conditions exist:
 - 5.1.1 Confirmed area radiation monitor alarm from one or more of the following:
 - a. FIRE OR RADIATION TRBL (9-1-G).
 - 5.1.2 Confirmed process radiation monitor alarm form one or more of the following:
 - a. CREVS TRAIN 1 RAD HI (9-1-A)
 - b. CREVS TRAIN 2 RAD HI (9-2-A)
 - c. UNIT VENT RAD HI (9-3-A).
 - 5.1.3 Abnormal radiation levels or airborne radioactivity detected during a survey
 - 5.1.4 A spill of radioactive or potentially radioactive material, that causes any of the following:
 - a. Within the RRA – unposted, unconfined liquid or solid radioactive material in sufficient quantity to cause a dose rate equal to or greater than 100 mrem/hour at 30 cm above the surface of the radioactive material.
 - b. Outside the RRA, but within the Protected Area – unposted, unconfined liquid or solid radioactive material in sufficient quantity to cause a dose rate equal to or greater than 5 mrem/hour at 30 cm above the surface of the radioactive material.
 - c. Outside the Protected Area – unposted, unconfined liquid or solid radioactive material in sufficient quantity to be detected by readily available survey methods and equipment.
 - d. Unposted, unconfined liquid or solid radioactive material in such quantity, location, or form that there exists a potential such that, in the judgement of the Shift Manager, the resources available on shift would be insufficient to control, confine, survey, and post the area.
 - 5.1.5 Confirmed computer radiation alarm
 - 5.1.6 Confirmed alert and/or high radiation alarm on the Radiation Monitoring System (RMS) panel.

6.0 PROCEDURE6.1 General

6.1.1 Contact Radiation Protection personnel to investigate the radiation event and to take appropriate actions.

6.1.2 Evaluate making an announcement describing the radiation event, and areas to evacuate or avoid.

REFER TO Step 6.2.1.d for announcement.

6.1.3 WHEN confirmation of a radiation event as described in Section 5.0 is completed,

THEN GO TO the appropriate section:

Section 6.2, Abnormal or Unknown Radiation Levels,

OR

Section 6.3, Abnormal or Unknown Airborne Radioactivity,

OR

Section 6.4, Radioactive Material Spill.

6.2 Abnormal or Unknown Radiation Levels

6.2.1 The Shift Manager should perform the following as necessary:

Note 6.2.1.a

Operations personnel who are instrument qualified may perform radiation surveys of the affected areas using portable radiation monitoring equipment.

- a. Direct Radiation Protection personnel to investigate the incident and conduct radiological surveys.
- b. REFER TO DB-OP-06412, Process and Area Radiation Monitors, and verify automatic or manual actions associated with alarming area radiation monitors or process radiation monitors are correct.
- c. Consider the following actions.
 1. Evacuation of affected areas
 2. Control or prevent access to the affected areas.

- d. IF the decision has been made to evacuate the affected area,
THEN sound the Containment Evacuation Alarm
AND make an announcement such as:
- “Attention all personnel.”
- “Attention all personnel.”
- “Evacuate the _____ Area and report to the
Radiological Restricted Area Access Control Point. Notify your
supervisor. Avoid the _____ Area.”
- “Evacuate the _____ Area and report to the
Radiological Restricted Area Access Control Point. Notify your
supervisor. Avoid the _____ Area.”
- e. IF containment evacuation is necessary,
THEN REFER TO RA-EP-02864, Containment Evacuation.
- f. IF Dry Fuel Storage is the source of the abnormal radiation levels,
THEN REFER TO DB-OP-02550, Dry Fuel Storage Abnormal Events.
- g. REFER TO RA-EP-01500, Emergency Classification, and evaluate
radiation levels for emergency classification.
- h. Review current plant status and determine operating conditions which
may affect or have caused the situation.
- i. Initiate actions to recover from the radiological incident.
1. Contact Radiation Protection to determine the course of action to
take to minimize radiation dose to the plant staff and the public.
- j. IF normal access has been restricted,
THEN make an announcement when normal access is restored to the
affected area.

6.2.2 Radiation Protection personnel:

Investigate the abnormally high or unknown radiation areas and perform the
following as necessary:

- a. Radiation surveys
- b. Verify area radiation monitor alarms
- c. Establish and post radiological boundaries
- d. Determine the source of radiation
- e. Inform the Shift Manager of survey results

- f. Inform plant personnel of radiological conditions.
- g. Contact the On Call Manager – Radiation Protection, explain the radiological incident and request their presence at the plant to help determine the course of action. Request additional Radiation Protection personnel, if needed.
- h. Coordinate with the Shift Manager to determine the course of action to take to minimize radiation dose when recovering from the radiological incident. The following items should be considered:
 - What are the offsite dose consequences?
 - What are the dose consequences if the radiological incident continues, both to the plant staff and the public?
 - What are the dose consequences to the personnel attempting to fix the problem?
 - Can the normal work control process be used to fix the problem?
- i. Provide coverage for personnel entering a radiation area greater than or equal to 100 mrem/hr.
- j. Consider suspending Radiation Work Permits (RWPs) which would allow access to the area involved.
- k. Supervise the decontamination of personnel.
- l. Supervise the decontamination of areas or equipment.
- m. Inform the Shift Manager of changes in the radiological conditions in the affected areas.

6.3 Abnormal or Unknown Airborne Radioactivity

6.3.1 Shift Manager shall perform the following as necessary:

- a. IF a fuel handling accident has occurred,
THEN REFER TO DB-OP-02530, Fuel Handling Accident.
- b. Direct Radiation Protection personnel to investigate the incident and conduct radiological surveys.
- c. REFER TO DB-OP-06412, Process and Area Radiation Monitors, and verify automatic or manual actions associated with alarming area radiation monitors or process radiation monitors are correct.
- d. Consider the following actions:
 1. Evacuation of affected areas.
 2. Control or prevent access to the affected areas.
- e. IF the decision has been made to evacuate the affected area,
THEN sound the Containment Evacuation Alarm
AND make an announcement such as:

"Attention all personnel."

"Attention all personnel."

"Evacuate the _____ Area and report to the Radiological Restricted Area Access Control Point. Notify your supervisor. Avoid the _____ Area."

"Evacuate the _____ Area and report to the Radiological Restricted Area Access Control Point. Notify your supervisor. Avoid the _____ Area."
- f. IF containment evacuation is necessary,
THEN REFER TO RA-EP-02864, Containment Evacuation.

CAUTION 6.3.1.g

If CTMT isolation is needed, SFAS will not initiate a trip signal due to radiation. It is the responsibility of the Control Room Operator to establish CTMT integrity by verifying SFAS Level 1 equipment.

- g. IF any of the following ventilation systems have shutdown due to off-normal airborne radioactivity levels:
- Fuel Handling Ventilation System
 - OR
 - Radwaste Area Ventilation System
 - OR
 - Containment Purge Area Ventilation System,
- THEN REFER TO DB-OP-06504, Emergency Ventilation System.
- h. IF the Station Vent Monitor alarms,
THEN perform the following:
1. Stop all releases in progress
 2. REFER TO DB-OP-06412, Process and Area Radiation Monitors, (Station Vent Radiation Monitor Operation during a Radioactive Release Event).
- i. IF the Station Vent Monitor alarm does not clear after the releases have been terminated,
THEN contact Radiation Protection personnel,
AND request an initial assessment to determine if the release has exceeded any limits or requirements as stated in the following documents:
1. Offsite Dose Calculation Manual (ODCM)
 2. DB-OP-00002, Operations Section Event/Incident Notifications and Actions.
- j. IF Dry Fuel Storage is the source of the abnormal airborne radioactivity levels,
THEN REFER TO DB-OP-02550, Dry Fuel Storage Abnormal Events.

- k. REFER TO RA-EP-01500, Emergency Classification,
AND evaluate airborne activity levels for emergency classifications.
- l. IF the station has entered an emergency classification
AND an abnormal release is in progress,
THEN REFER TO HS-EP-02240, Offsite Dose Assessment
AND perform dose assessment calculation to determine protective action
recommendations (PARs).
- m. Review current plant status and determine operating conditions which
may affect or have caused the situation.
- n. Initiate actions to recover from the radiological incident.
 - 1. Contact Radiation Protection to determine the course of action to
take to minimize radiation dose to the plant staff and the public.
- o. IF normal access has been restricted,
THEN make an announcement when normal access is restored to the
affected area.

6.3.2 Radiation Protection personnel:

Investigate the high airborne activity areas and perform the following as
necessary:

- a. Radiological surveys of the affected and adjacent areas
- b. Verify area radiation monitor alarms
- c. Establish radiological boundaries
- d. Determine the source of airborne activity
- e. Inform the Shift Manager of survey results and discuss actions to reduce
airborne radioactivity
- f. Inform plant personnel of radiological conditions
- g. Contact the On Call Manager - Radiation Protection, explain the
radiological incident and request their presence at the plant to help
determine the course of action. Request additional Radiation Protection
personnel, if needed.

- h. Coordinate with the Shift Manager to determine course of action to take to minimize radiation dose when recovering from the radiological incident. The following items should be considered:
- What are the offsite dose consequences?
 - What are the dose consequences if the radiological incident continues, both to the plant staff and the public?
 - What are the dose consequences to the personnel attempting to fix the problem?
 - Can the normal work control process be used to fix the problem?
- i. Provide coverage for personnel entering airborne radioactivity areas.
- j. Consider suspending those RWPs which allow access to the areas involved.
- k. Supervise the decontamination of personnel.
- l. Supervise the decontamination of areas or equipment.
- m. Inform the Shift Manager of changes in the radiological conditions of the affected areas.
- n. Perform an assessment on the radiological release and provide this information to the Shift Manager.

6.4 Radioactive Material Spill

6.4.1 Shift Manager shall perform the following as necessary:

Note 6.4.1.a

Operations personnel who are instrument qualified may perform radiation surveys of the affected areas using portable radiation monitoring equipment.

- a. Direct Radiation Protection personnel to investigate the incident and conduct radiological surveys.
- b. REFER TO DB-OP-06412, Process and Area Radiation Monitors, and verify automatic or manual actions associated with alarming area radiation monitors or process radiation monitors are correct.
- c. Consider evacuation of affected areas, and take actions to prevent access.

- d. IF the decision has been made to evacuate the affected area, THEN sound the Containment Evacuation Alarm, AND make an announcement such as:
- “Attention all personnel.”
- “Attention all personnel.”
- “Evacuate the _____ Area and report to the Radiological Restricted Area Access Control Point. Notify your supervisor. Avoid the _____ Area.”
- “Evacuate the _____ Area and report to the Radiological Restricted Area Access Control Point. Notify your supervisor. Avoid the _____ Area.”
- e. IF containment evacuation is necessary, THEN REFER TO RA-EP-02864, Containment Evacuation.
- f. IF the spill results in abnormal airborne radioactivity levels, THEN REFER TO Subsection 6.3, Abnormal or Unknown Airborne Radioactivity.
- g. REFER TO RA-EP-01500, Emergency Classification, and evaluate radiation levels for emergency classification.
- h. Review current plant status and determine operating conditions which may affect or have caused the situation.
- i. Initiate actions necessary to contain, and stop the spill.
1. Contact Radiation Protection to determine the course of action to take to minimize radiation dose to the plant staff and the public.
- j. Make an announcement when normal access is restored to the affected area.

6.4.2 Radiation Protection personnel:

Investigate the area of the radioactive spill and perform the following as necessary:

- a. Radiological surveys
- b. Verify area radiation monitor alarms
- c. Establish radiological boundaries
- d. Determine the source of the spilled radioactive material
- e. Take steps in order to contain or reduce the spill
- f. Inform plant personnel of radiological conditions
- g. Contact the On Call Manager - Radiation Protection, explain the radiological incident and request their presence at the plant to help determine the course of action. Request additional Radiation Protection personnel, if needed.
- h. Coordinate with the Shift Manager to determine course of action to take to minimize radiation dose when recovering from the radiological incident. The following items should be considered:
 - What are the offsite dose consequences?
 - What are the dose consequences if the radiological incident continues, both to the plant staff and the public?
 - What are the dose consequences to the personnel attempting to fix the problem?
 - Can the normal work control process be used to fix the problem?
- i. Provide coverage for personnel entering the affected area.
- j. Consider suspending those RWPs which would allow access to the areas involved.
- k. Inform the Shift Manager of survey results and discuss actions to contain or reduce the spill.
- l. Supervise the decontamination of personnel.
- m. Supervise the decontamination of equipment.
- n. Inform the Shift Manager of changes in the radiological conditions of the affected areas.

7.0 FINAL CONDITIONS

- 7.1 The radiological incident is under control as determined by the Shift Manager.

8.0 RECORDS

8.1 The following quality assurance records are completed by this procedure and shall be listed on the Nuclear Records List, captured, and submitted to Nuclear Records Management in accordance with NG-NA-00106:

8.1.1 None

8.2 The following non-quality assurance records are completed by this procedure and may be captured and submitted to Nuclear Records Management, in accordance with NG-NA-00106:

8.2.1 None

COMMITMENTS

<u>Step Number</u>	<u>Reference</u>	<u>Comments</u>
6.3	Q 00072	Off-Normal releases of radioactivity

END