

Radiation Work Procedure

RWP No. 14, Rev. 5
Water Samples

Description of Work

Operate and inspect equipment including the taking of samples, radiation surveys, and personnel entering building for observation only.

Special Hazards

1. "B" locked or alarmed doors are "High Rad" areas during operation or shut down.
2. Variable rad levels due to power level changes and reactor water conditions.
3. Temporary "High Rad" or contamination areas.

Monitoring Requirements

Maximum Radiation Conditions for Work

(No entries appeared here. JJW)

Special Instructions

Check CAM for abnormal rise when entering and periodically check CAM while in the building. Do not enter "B" lock or alarmed door without notice to console operator. Notify S. F. and monitor any spills. Do not walk in spills.

8305180601 710915
PDR ADOCK 05000133
Q PDR

EXHIBIT F-2