

SURVEILLANCE REQUIREMENTS (continued)

SURVEILLANCE	FREQUENCY
<p>SR 3.6.1.3.2</p> <p>-----NOTES-----</p> <ol style="list-style-type: none"> <li>1. Only required to be met in MODES 1, 2, and 3.</li> <li>2. Valves and blind flanges in high radiation areas may be verified by use of administrative means.</li> <li>3. Not required to be met for PCIVs that are open under administrative controls.</li> </ol> <p>-----</p> <p>Verify each primary containment isolation manual valve and blind flange that is located outside primary containment, drywell, and steam tunnel and is required to be closed during accident conditions is closed.</p>	<p>31 days</p>

(continued)

SURVEILLANCE REQUIREMENTS (continued)

SURVEILLANCE	FREQUENCY
<p>SR 3.6.1.3.3 -----NOTES-----</p> <ol style="list-style-type: none"> <li>1. Only required to be met in MODES 1, 2, and 3.</li> <li>2. Valves and blind flanges in high radiation areas may be verified by use of administrative means.</li> <li>3. Not required to be met for PCIVs that are open under administrative controls.</li> <li>4. Not required to be met for the Inclined Fuel Transfer System (IFTS) penetration when the associated primary containment blind flange is removed, provided that the fuel building spent fuel storage pool water level is maintained greater than 23 feet above the top of the fuel, and the IFTS transfer tube drain valve and bottom gate valve remain closed. The IFTS transfer tube drain valve may be opened under administrative controls. Removal of the IFTS Blind Flange shall not exceed 60 days per operating cycle while in Modes 1, 2, or 3.</li> </ol> <p>-----</p> <p>Verify each primary containment isolation manual valve and blind flange that is located inside primary containment, drywell, or steam tunnel and is required to be closed during accident conditions is closed.</p>	<p>Prior to entering MODE 2 or 3 from MODE 4, if not performed within the previous 92 days</p>

(continued)