



NOTE:  
 1. SEISMIC BOUNDARY FLAGS ARE NOT SHOWN ON VENT AND DRAIN CONNECTIONS. ON VENT AND DRAIN CONNECTIONS FROM SEISMIC CATEGORY I PIPING AND COMPONENTS, THE SEISMIC BOUNDARY EXTENDS TO THE FIRST PIPING CLASS BREAK SHOWN ON THESE CONNECTIONS.  
 2. BLIND SPOOL PIECE REQUIRED FOR SEISMIC QUALIFICATION AND ISOLATION OF RELIEF PIPING. REF. ER 973977N201.

REFERENCE DRAWING:  
 C. E. DRAWING E-5370-210-121

LEGEND	
—	SYSTEM/AMP REPORT
—	CHEMICAL AND VOLUME CONTROL/82-6-2005-18
—	LICENSE RENEWAL BOUNDARY

**ARKANSAS NUCLEAR ONE**  
 UNIT 2  
 RUSSELLVILLE, ARKANSAS

**PIPING & INSTRUMENT DIAGRAM**  
 CHEMICAL & VOLUME CONTROL SYSTEM

DRAWING NO	SHEET	REVISION
LRA-M-2231	2	0

D-39