



- GENERAL NOTES**
- (DGA-12) OPERATING NUMBER
 - FOR P&ID SYMBOLS SEE Dwg. C-10000-C (S11)
 - LOCATED ON "A" PANEL
 - ENGINE DRIVEN
 - FOR ROOT VALVE SCHEDULE SEE Dwg. F-4513-C (S28)

LR NOTE: PLEASE REFER TO DRAWING LR-000 SHEETS 2A THROUGH 2F FOR LR BOUNDARY DRAWING NOTES, SYMBOLS, AND ACRONYMS.

NOTE: THIS DRAWING WAS CREATED USING COMPUTER AIDED DRAFTING. DO NOT MAKE MANUAL CHANGES.

CONSTITUTION ENERGY GROUP		NINE MILE POINT NUCLEAR STATION UNIT NO. 1	
APP	APP	EMERGENCY DIESEL GENERATOR #102	
APP	DATE	STARTING AIR, COOLING WATER	
DES	DR	LUBE OIL & FUEL	
NO	SCALE	P & I DIAGRAM	
NO	SCALE	DWG NO	INDEX
		LR-18026-C	3-N2-S15
			SM 1
			REV 0

DOSZ