



CONSTELLATION ENERGY GROUP		NINE MILE POINT NUCLEAR STATION UNIT NO. 1	
EMERGENCY DIESEL GENERATOR #103			
STARTING AIR, COOLING WATER, LUBE OIL & FUEL			
P & I DIAGRAM			
APP	DATE	DWG NO.	REV
DES	DR	INDEX	
SCALE	NONE	LR-18026-C	3-N2-S15
REV			2
			0

LR NOTE:  
PLEASE REFER TO DRAWING LR-18000-C SHEETS 1 AND 2 FOR LR BOUNDARY DRAWING NOTES, SYMBOLS, AND ACRONYMS.

- GENERAL NOTES
- (DGA-12) OPERATING NUMBER
  - FOR P&ID SYMBOLS SEE DNG. C-18000-C (S11)
  - LOCATED ON "W" PANEL
  - ENGINE DRIVEN
  - FOR ROOT VALVE SCHEDULE SEE DNG. F-45026-C (S28)
  - FOR INSTRUMENT DIAGRAM SEE DRAWING A-50026-C SH1 - SH5
  - FLOW TRANSDUCERS 79-18 AND 79-18A MAY BE REMOVED FOR CALIBRATION AND/OR TESTING PURPOSES.

NOTE: THIS DRAWING WAS CREATED USING COMPUTER AIDED DRAFTING DO NOT MAKE MANUAL CHANGES

1053