

SURVEILLANCE REQUIREMENTS

SURVEILLANCE		FREQUENCY
SR 3.6.6.1	Verify each containment spray manual, power operated, and automatic valve in the flow path that is not locked, sealed, or otherwise secured in position is in the correct position.	31 days
SR 3.6.6.2	Not used.	
SR 3.6.6.3	Not used.	
SR 3.6.6.4	Verify each containment spray pump's developed head at the flow test point is greater than or equal to the required developed head.	In accordance with the Inservice Testing Program
SR 3.6.6.5	Verify each automatic containment spray valve in the flow path that is not locked, sealed, or otherwise secured in position, actuates to the correct position on an actual or simulated actuation signal.	18 months
SR 3.6.6.6	Verify each containment spray pump starts automatically on an actual or simulated actuation signal.	18 months
SR 3.6.6.7	Not used.	
SR 3.6.6.8	Verify each spray nozzle is unobstructed.	Following maintenance which could result in nozzle blockage