

This map was exported using ESRI's ArcMap Version 9.3.1 software. In order to access the attributes of the "Sources" polygons, click the "View" menu, then select "Toolbars" and then "Object Data". Using the Object Data tool, click on the border of a polygon three times. The first click will identify the "Layers" and highlight all of the polygons, the second click will identify the "Sources" sub-layer and the third click will identify the specific polygon selected. After the third click, the attributes of the polygon will be displayed on the bottom, left hand side of the page. The attributes include an ID number, the upstream ("FrmNode") and downstream ("ToNode") node numbers of the link loaded in the analysis network and the Year 2000 ("Pop2000") permanent resident population assigned to the link.




Figure 1. Population Loading within the Levy Nuclear Plant EPZ.