



Legend	
—	WS Max WS
—■—	Ground
—□—	Levee
—▲—	Ineff
●	Bank Sta

Note:
 RS = River Station
 WS = Water Surface Elevation
 Max = Maximum
 Ineff = Ineffective flow area
 RM = River mile

PSEG Power, LLC
 PSEG Site ESPA
 Part 2, Site Safety Analysis Report

Cross Section of Delaware River at RM 52
 (PSEG Site)

FIGURE 2.4.7.-1 Rev. 0