



**Legend**  
 WS – water surface  
 RS – river station  
 Max- maximum  
 UP EST– upper estuary  
 ENT BS – entire basin  
 Sta – station  
 Ineff – ineffective flow area  
 Black cross-sectional area - Blocked flow obstruction  
 Green cross-sectional area – Ineffective flow area  
 RM – river mile

PSEG Power, LLC  
 PSEG Site ESPA  
 Part 2, Site Safety Analysis Report  
 Cross-Section of Delaware River at RM  
 52 (PSEG Site)  
 FIGURE 2.4.3-7 Rev. 0