



70
64
52
46
Ø3

For installation, operation and servicing of the device, reference the operating and service manuals.
Leak Testing Frequency: 6month (not required for Kr-85). On-Off Mechanism and Indicator Test Frequency: 6 months. The receipt, possession, use and transfer of this device Model BC-MK 1.0, Serial Number _____ are subject to a general license or the equivalent and the regulations of the U. S. NRC or of an Agreement State. This label shall be maintained on the device in a legible condition. Removal of this label is prohibited.
Caution - Radioactive Material

betacontrol

				Allgemein- toleranzen DIN ISO 2768-f	Oberfläche	Maßstab 1:1	Position - Menge -
						Bl. 1 x 52 x 69	-
						-	AlMg3
				Datum	Name	Schild USA	
				Bearb. 19.08.04	Saß.		
				Gepr.			
				Norm			
				betacontrol		700-103-737/4	Blatt -
							Bl
Zust.	Änderungen	Datum	Name	Dateiname -			