



Legend
 WS – water surface
 RS – river station
 Max- maximum
 UP EST– upper estuary
 ENT BS – entire basin
 Sta – station
 Ineff – ineffective flow area
 Black cross-sectional area - Blocked flow obstruction
 Green cross-sectional area – Ineffective flow area
 RM – river mile

PSEG Power, LLC
 PSEG Site ESPA
 Part 2, Site Safety Analysis Report
 Cross-Section of Delaware River at RM
 52 (PSEG Site)
 FIGURE 2.4.3-7 Rev. 0