



#### Legend

WS – water surface

RS – river station

Max- maximum

UP EST– upper estuary

ENT BS – entire basin

Sta – station

Ineff – ineffective flow area

Black cross-sectional area - Blocked flow obstruction

Green cross-sectional area – Ineffective flow area

RM – river mile

PSEG Power, LLC  
PSEG Site ESPA  
Part 2, Site Safety Analysis Report

Cross-Section of Delaware River at RM  
52 (PSEG Site)

FIGURE 2.4.3-7

Rev. 0