



Note:
 RS = River Station
 WS = Water Surface Elevation
 Max = Maximum
 Ineff = Ineffective flow area
 RM = River mile

Legend	
WS Max WS	— (Blue line)
Ground	— (Black line with square markers)
Levee	— (Green line with triangle markers)
Ineff	— (Horizontal Green line)
Bank Sta	• (Red dot)

PSEG Power, LLC
 PSEG Site ESPA
 Part 2, Site Safety Analysis Report

Cross Section of Delaware River at RM 52
 (PSEG Site)

FIGURE 2.4.7.-1 Rev. 0