




○ — Node
 —□— Hydrodynamic Mass Element
 Not to Scale

Figure 14.3.3-6

Hydrodynamic Masses in Vessel/Barrel
 Downcomer Annulus