NIAGARA MOHAWK POWER CORPORATION

LICENSED OPERATOR JOB PERFORMANCE TRAINER

			Revision: 1
Title: Def	eat Feedwater System Lev	el 8 Interlocks	
Task Number:	2599010501		
Operator:		(RO/SRO) Instru	ictor:
Directions to	operators:		
Interloc to the t question	tell you to begin you are tks. I will describe gen tools to complete this ta ns. When all questions h on to start.	eral conditions and sk. Before you sta	l provide you access urt, I will answer any
Training Metho	od: Perform	Simulate	'
Training Locat	tion: Plant	Simulator	Control Room
Average Comple	etion Time: minutes	Actual Comp	oletion Time:
Instructors Si	ignature:		Date:
Approvals: // // // // // As	aining Supersy age super to	Suptroficor	perations - Unit 2
EXAMREQ2/147			30 91

9304290240 911031 PDR ADDCK 05000410 PDR

4/29/240

V • K/A Rating: 4.50

Initial (Task) Conditions:

- 1. RPV Flooding is in progress.
- 2. Feedwater pumps are available and needed for injection.
- 3. Main Turbine is not operating.

General Tools and Equipment:

None

General References:

EOP-6, Rev. O, Att. 20, "Defeating L8 FWS Interlocks".

Task Standards:

Jumpers installed in the following locations: (P612A) Alarm Card GEJ (C33-K624A) terminals 10 to fuse C33A-F4 point 2, (P612A) Alarm Card GJA (C33 - K624B) terminals 10 to fuse C33A-F5B point 2, (P612A) Terminal Board CC points 23 to 24.

Critical Steps are Denoted by (*):

NOTE: All steps are non-sequence critical unless noted.

Initiating cues:

As Shift Supervisor, I direct you to: "Defeat Feedwater System Level 8 Interlocks".

Performance Steps		Standard	· Sat/Unsat	
Star	t Time:		1	
1.	Obtain current copy of procedure.	Procedure obtained.	Sat/Unsat	
		•	1	
2.	Review precautions and	Procedure reviewed.	Sat/Unsat	

prerequisites.

• . • • ,

Sat/Unsat Jumper installed. Alarm Card GEJ (C33-K624A) a. terminal 10 to C33A-F4 point 2. (Cue: P612A, terminals, inform operator jumper installed.) Sat/Unsat Alarm Card GJA (C33-624B) b. Jumper installed. terminal 10 to C33A-F5B point 2. (Cue: P612A, and terminals, inform operator jumper installed.) Terminal Board CC Sat/Unsat Jumper installed. С. terminals 23 to 24. (Cue: P612A, Locate

Sat/Unsat

Termination Cu	ie: Jumpers	installed	in	P612A.
----------------	-------------	-----------	----	--------

Time Stop:

installed.)

jumpers:

Locate Relay and

Locate Relay

Relay and terminals, inform operator jumper

a.

b.

-٠ -, • ** ,