

VOL. 14

FNP-0-EIP-5
October 6, 1980
Revision 2

FARLEY NUCLEAR PLANT
EMERGENCY PLAN IMPLEMENTING PROCEDURE
FNP-0-EIP-5

S
A
F
E
T
Y

R
E
L
A
T
E
D

MAINTENANCE SUPPORT TO THE EMERGENCY PLAN

PERSONAL PRIVACY INFORMATION
DELETED IN ACCORDANCE WITH THE
FREEDOM OF INFORMATION ACT

Approved:

W. J. Hunt
Plant Manager

Date Issued: 11-3-80

Date of Implementation: 11-17-80

Disk EIP-1

Page	Rev. #
1-2	Rev. 2

DOCUMENT CONTROL
CONTROLLED COPY
DO NOT REPRODUCE
COPY NO. 039

8011240495

MAINTENANCE SUPPORT TO THE EMERGENCY PLAN

1.0 Purpose

This procedure delineates the responsibilities of the Maintenance and Instrumentation and Control (I&C) groups during emergencies at the Farley Nuclear Plant.

2.0 References

- 2.1 Joseph M. Farley Nuclear Plant Emergency Plan
- 2.2 FNP Operating Manual, Vol. 14, FNP-0-EIP-10, Evacuation and Personnel Accountability.
- 2.3 FNP Operating Manual, Vol. 14, FNP-0-EIP-14, Re-entry Procedures

3.0 General

- 3.1 Maintenance and I&C support during emergencies shall consist of but is not limited to the following actions:
 - 3.1.1 Perform temporary and/or permanent repairs to plant systems/components in order to mitigate the effects of the emergency.
 - 3.1.2 Perform maintenance activities associated with the recovery from an emergency.
- 3.2 All personnel assigned to the Maintenance and I&C groups shall report to the Service Building Maintenance Shop in accordance with FNP-0-EIP-10, Evacuation and Personnel Accountability, in the event of an Emergency.
- 3.3 The Maintenance and I&C groups shall provide at least one individual from the following personnel groups as required for assignment to an Emergency Repair Party for initial re-entry and repair:

- Mechanical Maintenance Personnel
- Electrical Maintenance Personnel
- Instrument Maintenance Personnel

4.0 Procedure

- 4.1 The Maintenance Manager shall:
 - 4.1.1 Assist the Emergency Director by selecting personnel for assignment to an Emergency Repair Party.

- 4.1.2 Assist the Emergency Director by planning the activities of and giving instructions to members of the Emergency Repair Party.
- 4.1.3 With the aid of the Health Physics Manager, maintain exposures to maintenance personnel as low as reasonably achievable during re-entry, repair or decontamination activities which result from an emergency.
- 4.2 Maintenance and I&C personnel who are members of the Emergency Repair Party shall:
 - 4.2.1 Comply with the instructions of FNP-0-EIP-14, Re-entry procedures.
 - 4.2.2 Comply with the instructions of the Emergency Director and the Maintenance Manager.