TABLE 3.2.B (CONTINUED)

INSTRUMENTATION THAT INITIATES OR CONTROLS THE CORE AND CONTAINMENT COOLING SYSTEMS

Of Operable Instrument Channels Per Trip System(1)	Trip Function	Trip Level Setting	Number of Instru- ment Channels Pro- vided by Design	Remarks
2 per 4 KV Bus	Emergency Trans- former Degraded voltage (Inverse time - voltage). (CV-6)	87% (+/- 5%) of Rated Voltage. Tests at 2940 volts in 30 seconds (+/- 10%).		1. Trips emergency transformer feed to 4KV emergency bus. 2. Fast transfer permissive.

Minimum No.