



TABLE NO. 1
 THERMOCOUPLE IDENTIFICATION & LOCATION

INPUT NUMBER	THERMOCOUPLE IDENTIFICATION	LOCATION	WIRE NOS. PREFIXED BY "IADSNO"		TERMINAL NOS.		LINE CODE NUMBER	SHLD	PRODUCTION INFORMATION BAY 3						
			POSITIVE WIRE	NEGATIVE WIRE	(+)	(-)			JACK NO	LINE CODE	LINE NO.	PIN NO.	LINE CODE	PIN NO.	
1.	B21-N004B	B21-F041B	04BP	04BN	A	B	9	C	TB0003	A	-01	B	-02	C	-03
2.	B21-N004C	B21-F041C	04CP	04CN	D	E	9	F	TB0003	D	-04	E	-05	F	-06
3.	B21-N004D	B21-F041D	04DP	04DN	G	H	9	I	TB0003	G	-07	H	-08	I	-09
4.	B21-N004E	B21-F041E	04EP	04EN	J	K	9	L	TB0003	J	-10	K	-11	L	-12
5.	B21-N004F	B21-F041F	04FP	04FN	M	N	9	O	TB0003	M	-13	N	-14	O	-15
6.	B21-N004G	B21-F041G	04GP	04GN	P	Q	9	R	TB0003	P	-16	Q	-17	R	-18
7.	B21-N004H	B21-F041H	04HP	04HN	A	B	10	C	TB0003	A	-01	B	-02	C	-03
8.	B21-N004I	B21-F041I	04IP	04IN	D	E	10	F	TB0003	D	-04	E	-05	F	-06
9.	B21-N004J	B21-F041J	04JP	04JN	G	H	10	I	TB0003	G	-07	H	-08	I	-09
10.	B21-N004K	B21-F041K	04KP	04KN	J	K	10	L	TB0003	J	-10	K	-11	L	-12
11.	B21-N004L	B21-F041L	04LP	04LN	M	N	10	O	TB0003	M	-13	N	-14	O	-15
12.	B21-N004M	B21-F041M	04MP	04MN	P	Q	10	R	TB0003	P	-16	Q	-17	R	-18
13.	B21-N004N	B21-F041N	04NP	04NN	A	B	11	C	TB0007	A	-01	B	-02	C	-03
14.	B21-N004O	B21-F041O	04OP	04ON	D	E	11	F	TB0007	D	-04	E	-05	F	-06
15.	B21-N004P	B21-F041P	04PP	04PN	G	H	11	I	TB0007	G	-07	H	-08	I	-09
16.	B21-N004Q	B21-F041Q	04QP	04QN	J	K	11	L	TB0007	J	-10	K	-11	L	-12
17.	B21-N004R	B21-F041R	04RP	04RN	A	B	24	C	TB0007	A	-13	B	-14	C	-15
18.	SPARE A														
19.	SPARE B														
20.	SPARE C														
21.	SPARE D														
22.	SPARE E														
23.	SPARE F														
24.	SPARE G														

CABLE NO. LINE CODE
 1321C0053 133, 134
 1321C0036 135, 136
 1321C0111
 1321C0015 9
 1321C0016 10
 1321C0014 11, 24

LINE CODES: 10-11, 24, 101, 102, 133-140, 154

TH APERTURE CARD

3	NJ1842	
4	NJ1847	
4	NJ26943	

8412200X104

PDR RIDS

