

CONTACT	POSITION	
	NORMAL	FBIS INITIATION
1-IT		X
3-ST		X

FBIS INITIATION
 CUTLER HAMMER
 TYPE E30-A4
 WITH ONE KLA4
 CONTACT BLOCK &
 PROTECTIVE
 COVER SLIDE KR32

HAND SWITCH
 HS - SEE TABLE
 MOMENTARY CONTACT

REF. DWGS
 1. J-02GG08
 2. M-02GG01

IT
 APERTURE
 CARD

1. RESET CAPABILITY IS PROVIDED IN THE MAIN
 CONTROL ROOM AS PART OF THE ESFAS
 SYSTEM.

NOTES:

REV.	DATE	REVISIONS	BY	CHK'D	DESIGN	ENGR	PROJ	ENGR
1								
2								
3								
4								
5								
6								
7								
8								
9								
10								

BECHTEL
 GAITHERSBURG, MARYLAND
SNUPPS
 SCHEMATIC DIAGRAM
 MANUAL INITIATION-
 FUEL BLDG. ISOLATION SIGNAL

UTILITY DRAWING NO.	REV.
10486	E-03GGi8 (Q) 2

REVIEW LEVEL 3

CP LOCATION - CP	SA036A	SA036B
HS LOCATION - INSTR	GQH550	GQH551
HS NUMBER	GQH550	GQH551
SCHEME NO.	1GGK18A	4GGK18B

BLOCK DIAGRAM
 SCHEME NO. SEE TABLE

16X

REVIEW LEVEL 3

APERTURE
CARD

1. RESET CAPABILITY IS PROVIDED IN THE MAIN CONTROL ROOM AS PART OF THE ESFAS SYSTEM.

NOTES:

	7/14/82 ADDED REF. DING NOS.		7/28/82	7/28/82	7/28/82	7/28/82	7/28/82	7/28/82	7/28/82	7/28/82	7/28/82
	7/20/82 ADDED JAND SW. INFORM.		8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82
	7/26/82 ISSUED FOR CONSTRUCTION		8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82	8/1/82
No. _____	DATE _____	REVISIONS _____	DRWN _____	CHK'D _____	DESIGN SUPP. _____	ENGR _____	IN CHARGE _____	7/28/82	8/1/82	8/1/82	8/1/82
SCALE 1" = 1'		DESIGNED EXD		DRAWN RUF		ENGR ENR		7/28/82		8/1/82	
BECHTEL											
GAITHERSBURG, MARYLAND											
SNUPPS											
SCHEMATIC DIAGRAM											
MANUAL INITIATION-											
FUEL BLDG. ISOLATION SIGNAL											
						JOB NO. 1046G		BECHTEL DRAWING NO. E-03GG18 (Q)		REV 2	
DRAWING APPLICABLE TO UNITS						1		2		3	
1						2		3		4	

17.22 "C" 517

PDR RIDS

7506260068

