



- (IAB-152FP21) TO 480V MCC BUS I-52F
- (ICF-152FC21) TO TERM. BOX TB-1034
- (ICF-152FC22) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC23) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC24) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC25) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC26) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC27) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC28) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC29) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC30) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC31) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC32) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC33) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC34) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC35) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC36) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC37) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC38) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC39) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC40) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC41) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC42) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC43) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC44) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC45) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC46) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC47) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC48) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC49) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC50) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC51) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC52) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC53) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC54) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC55) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC56) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC57) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC58) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC59) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC60) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC61) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC62) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC63) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC64) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC65) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC66) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC67) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC68) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC69) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC70) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC71) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC72) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC73) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC74) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC75) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC76) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC77) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC78) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC79) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC80) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC81) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC82) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC83) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC84) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC85) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC86) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC87) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC88) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC89) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC90) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC91) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC92) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC93) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC94) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC95) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC96) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC97) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC98) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC99) TO MECH. CONT. CONSOLE 'C'
- (ICF-152FC00) TO MECH. CONT. CONSOLE 'C'

NOTES:  
 1. GROUND CONDUCTOR PROVIDED WITH ALL POWER CABLES SHALL BE CONNECTED TO MOTOR FRAME BY FIELD.

- REFERENCES:  
 FRONT VIEW MCC I-52F EXTENSION / MCC I-3352 ----- 237127A-E210  
 CKT DIAG. 480V MCC I-52F EXTENSION ----- 237127A-E210  
 CKT DIAG. 480V MCC I-3352 ----- 237127A-E262

PRO APERTURE CARD

WIRING DIAGRAM-MOTOR CONTROL CENTER I-52F EXT. B I-3352

FLUOR ENGINEERS, INC.

237127A-E319-02-1

830912-0523



RIDS

8309120523

