

Table with columns for terminal details, including terminal number, location, and system type. Includes a legend for terminal types and symbols.

Table with columns for device identification, functional description, and electrical ratings. Includes a legend for device symbols and types.

Table with columns for terminal type, description, and location. Includes a legend for terminal types and symbols.

Table with columns for terminal type, description, and location. Includes a legend for terminal types and symbols.

Table with columns for terminal location and sheet reference. Includes a legend for terminal locations.

NOTES: ALL WIRING SHALL BE... (Nuclear safety related notes)

NOTES: ALL WIRING SHALL BE... (Wiring and connection notes)

PRC APERTURE CARD

- 1. POWER FOR OPERATION OF EQUIPMENT...
2. UNLESS OTHERWISE INDICATED...
3. PROVIDE PHYSICAL ISOLATION...
4. THE INBOARD AND OUTBOARD...
5. THE A.E. SHALL REMOVE...
6. POTENTIAL WIRE MARKS...
7. DEVICES AND WIRING...
8. THE LOADS SHOWN...
9. SEE REF. 24 FOR...
10. DIVISION WIRING...
11. INDIVIDUAL CONTACTS...
12. CONTACT CLOSURES...
13. DO NOT TERMINATE...
14. DIVISIONAL SEPARATION...
15. FOR DEVICES WHICH...

ADDED NOTES 12-6-77
ADDED REF DOCUMENT 216

LINE CODES THIS SET:
LAST LINE CODE USED: 100

Rids

8212130387

