



CONTACTS HANDLE END	POSITION (FRAME VIEW)				CONTACT LOCATION
	PULL TO LOCK	STOP	AUTO	START	
1				X	SP
2			X		SP
3		X			SP
4	X				SP
5				X	SP
6			X		SP
7		X			SP
8	X				SP

GE. CO. SBM PISTOL GRIP HANDLE  
SPRING RETURN TO AUTO

1. WIRE THESE AND PRINTING BY SYSTEM, BUSHY AND 1/16" 25. 250. 250. 250.

2. ALL CONTACTS ARE PROVIDED BY UNIT AND SYSTEM (EX. 8720-350)

LEGEND:

(TRA-DNA A)  
 IH13-P502 - TERMINATION CABLE BOARD  
 IH13-P501 - DIESEL GEN. BENCH BOARD  
 INTERNAL WIRE MARK (SEE NOTE)  
 CLASS 16 DIM 9 THIS SHEET

(E) EXTERNAL WIRE MARK (SEE NOTE)  
 DR - DIESEL BOARD  
 AC - AIR CONTROL BOARD  
 8-20-663 ONE ONLY WIRE MARK




CONTACTS HANDLE END	POSITION (F.V.)		CONTACT LOCATION
	LOWER	RAISE	
1	X	X	SP
2	X	X	SP
3	X	X	SP
4	X	X	SP
5	X		SP
6		X	SP
7	X		SP
8		X	SP

GE. CO. SBM 10AAG06 LEVER HANDLE  
SPRING RETURN TO MID POSITION

CONTACTS HANDLE END	POSITION (F.V.)		CONTACT LOCATION
	LOWER	RAISE	
1	X	X	SP
2	X	X	SP
3	X	X	SP
4	X	X	SP
5	X		SP
6		X	SP
7	X		SP
8		X	SP

GE. CO. SBM  
PARTIAL SHEET



CONTACTS HANDLE END	POSITION (F.V.)		CONTACT LOCATION
	LOWER	RAISE	
1	X	X	SP
2	X	X	SP
3	X	X	SP
4	X	X	SP
5	X		SP
6		X	SP
7	X		SP
8		X	SP

GE. CO. SBM 10AAG06 PISTOL GRIP HANDLE  
SPRING RETURN TO MID POSITION

(1) THIS SHEET WAS BEEN DELIVERED BY THE INDENTOR ON 4/1/50

PRO APERTURE CARD

17  
11  
11  
11  
11

17  
11  
11  
11  
11  
11  
11  
11  
11  
11

RIDS

8212160575

