



C-H TYPE M-600

RELAYS		74-22326-G		74-22326-7	
	CONTACTS	FUNCTION	DWG NO.	FUNCTION	DWG NO.
NOTE 3	1-1-1-2	ANNUNCIATOR	E-20	ANNUNCIATOR	E-628
	3-1-1-4	SPARE	—	SPARE	—
	5-1-1-6	OPERATING COIL	THIS DWG	OPERATING COIL	THIS DWG

[illegible]

C-M TYPE M-600

RELAYS		74-22425-7	74-22426-8
CONTACTS	FUNCTION	DWG NO.	FUNCTION DWG NO.
1 — 11 — 2	ANNUNCIATOR	E-626	ANNUNCIATOR E-626
3 — 5 — 4	ALARM LIGHT	E-640	SPARE —
5 — 6 — 6	OPERATING COIL	THIS DWG	OPERATING COIL THIS DWG

```

graph TD
    A["(NOTE 5)  
HW55-F077"] --> B((21, x1))
    B --> C[JX103D]
    C --> D((21, x1))
    D --> E[JDC208]
    E --> F((1, 11, x1))
    F --> G[622424]
    G --> H((31, x1))
    H --> I[HW55-F075]
  
```

[illegible]

Rids

8301110155

