



CONTACT	POSITION FRONT VIEW			CWD
	CLOSERS O-RIDE	AUTO	OPEN	
1	X			*
2			X	*
3	X			*
4			X	*

SPRING RETURN TO AUTO WITH KEY LOCK, KEY REMOVABLE IN AUTO ONLY.
* THIS SHEET

- NOTES
1. FIELD TO WIRE CONTACTS.
 2. FIELD TO JUMPER INTERNALLY.
 3. FIELD TO VERIFY IF JUMPERS ARE INSTALLED. IF NOT FIELD TO ADD JUMPERS.

LIMIT SW DEVELOPMENT			
EBASCO SYMBOL	CONT.	VALVE OPNG. %	CWD SH.
		0	100
bo	1-2		*
ac	3-4		*
bo	5-6		*
aa	7-8		*
ac	9-10		*
bc	11-12		*
ao	13-14		*
bc	15-16		*
a %	17-18		*
b %	19-20		*
a %	21-22		*
b %	23-24		*
b %	25-26		*
a %	27-28		*
b %	29-30		*
a %	31-32		*
tc	35-36	OPENS ON OVERLOAD ON CLOSE STROKE	*
to	45-46	OPENS ON OVERLOAD ON OPEN STROKE	*
--- CONT. CLOSED * THIS SHEET			

PRC APERTURE CARD

NUCLEAR SAFETY RELATED WPPSS QUALITY CLASS I

EBASCO SERVICES INCORPORATED DIV. CONTROL DR. LVT GM. E. RVALLE DATE MAY 5 1977		WASHINGTON PUBLIC POWER SUPPLY SYSTEM NUCLEAR PROJECTS NO. 3 & 5 CONTROL WIRING DIAGRAM CS PUMP B MIN FLOW ISO VA 2CS-VQ006 SBR (51-665)		WPPS-3240 D-6001 SHEET 2286
--	--	--	--	-----------------------------------

44
11
58
83
10
177

44
11
58
8.5
11
17

RIDS

8303090651

