



86DG (HAND RESET)

CONTACTS	POSITION		FUNCTION	CWD
	TRIP	RESET		
A11-B11		X	PERMISSIVE DSL ENG (START A)	0586
A12-B12	X		NOT AVAILABLE	
A1-B1		X	PERMISSIVE DSL ENG (START B)	0586
A5-B5		X	COIL LOCKOUT	*
A6-B6	X		TRIP DSL ENG	0585
C11-D11		X	ANN LOCAL	*
C12-D12	X		DSL GEN	0574
C1-D1		X	NOT AVAILABLE	
C5-D5		X	DSL GEN PERMISSIVE	0574
C6-D6	X		NOT AVAILABLE	
C7-D7		X	(SPARE)	

86DE (HAND RESET)

CONTACTS	POSITION		FUNCTION	CWD
	TRIP	RESET		
A11-B11		X	PERMISSIVE DSL ENG (START A)	0586
A12-B12	X		NOT AVAILABLE	
A1-B1		X	PERMISSIVE DSL ENG (START B)	0586
A5-B5		X	COIL LOCKOUT	*
A6-B6	X		TRIP DSL ENG	0585
C11-D11		X	ANN LOCAL	*
C12-D12	X		DSL GEN BKR TRIP	0574
C1-D1		X		
C5-D5		X	PERMISSIVE DSL GEN BKR	0574
C6-D6	X		NOT AVAILABLE	
C7-D7		X	(SPARE)	

LEGEND
* THIS SHEET

PRC
APERTURE
CARD

5 4 3 12-15-81 PW SKG 9-7-79 AR REV. DATE BY APPROVED		EBASCO SERVICES INCORPORATED DIV. CONTROL DR. RK CH. YALKSNINIS DATE MAR. 21, 1978	APPROVED 	WASHINGTON PUBLIC POWER SUPPLY SYSTEM NUCLEAR PROJECTS NO. 3 & 5 CONTROL WIRING DIAGRAM EMER DIESEL GENERATOR A-SA LOCKOUT RELAY	WPPS-3240 D-6001 SHEET 0580
----------------------------------------------------------------------	--	---------------------------------------------------------------------------------------------	--------------	-------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------

SCALE 1/8" = 1'-0" (11-24-00033)

RIDS

8303160799

