



CS-2

CONTACTS	POSITIONS	CWD		
HANDLE NO.	CLOSE	AUTO	OPEN	
1 IC 23 8	X			*
2 IC 40 4			X	*
3 IC 40 4		X		*
4 IC 40 4	X	X	X	*
5 IC 40 4	X	X	X	*
6 IC 40 4	X	X	X	*
7 IC 40 4	X	X	X	*
8 IC 40 4	X	X	X	*

SPRING RETURN TO AUTO

SS

CONTACT	POSITION FRONT VIEW	CWD
	OFF	ON
1		X 0579
2		X 0579
3		X *
4		X 0583

MAINTAINED CONTACT WITH KEYLOCK, KEY REMOVABLE IN "OFF" POSITION ONLY.

CS-1

CONTACT	POSITION FRONT VIEW	CWD	
	OPEN	AUTO	CLOSE
1	X		
2		X	
3			X
4	X		

SPRING RETURN TO AUTO

TS

CONTACT	POSITION FRONT VIEW	CWD
	REM	LOC
1	X	*
2		X
3	X	*
4		X
5	X	*
6		X
7	X	*
8		X
9	X	*
10		X
11	X	*
12		X
13	X	*
14		X
15	X	*
16		X
17	X	*
18		X
19	X	*
20		X

MAINTAINED CONTACT * THIS SHEET

NOTE:
1. THIS ELEMENTARY IS SIMILAR FOR DIESEL GENERATOR B-5B BREAKER

LEGEND:
 Δ - LOCATED ON CONTROL BOARD
 ⊖ - SWGR
 □ - DIESEL GEN CNTL PNL
 ○ - CP

PRO APERTURE CARD

NUCLEAR SAFETY RELATED WPPSS QUALITY CLASS I

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	EDASCO SERVICES INCORPORATED DIV. CONTROL DR. KK CH. V. ALKONINIS DATE MARCH 21, 1978	APPROVED <i>W. Wallech</i> DATE MARCH 21, 1978	WASHINGTON PUBLIC POWER SUPPLY SYSTEM NUCLEAR PROJECTS NO. 3 & 5 CONTROL WIRING DIAGRAM EMER DIESEL GENERATOR A-SA BREAKER ELEMENTARY	WPPSS-3240 D-6001 SHEET 0574E
--	--	--	---	-------------------------------------

RIDS

8303160316

