



CS-3

CONTACT	POSITION FRONT VIEW			CWD
	OFF/O'RIDE	AUTO	ON	
1	X			*
2			X	*
3	X			*
4		X		*

SPRING RETURN FROM ON TO AUTO, MAINTAINED IN OFF/O'RIDE.
THIS SHEET

33-CELL SW

CONTACT	CWD
331	332
333	334
335	336
337	338
339	340
341	342
343	344
345	346
A1	B1
A11	B11
A12	B12
C1	D1

(CELL SW SHOWN IN BKR CONNECTED POSITION)

52-BKR AUX SW

CONTACT	CWD
17	18 a
19	20 b
21	22 a
23	24 b *
25	26 a *
27	28 b *
29	30 a
31	32 b

- NOTES:
1. RELAY 63X/LC-110H DEENERGIZES ON HIGH PZR LVL ERROR
 2. RELAY 63X/LC-110 DEENERGIZES ON LO-LO (ABS) PZR LVL
 3. RELAY 63XL/PC-100 DEENERGIZES ON LO-LO PZR PRESSURE
 4. RELAY 63XH/PC-100 DEENERGIZES ON HIGH PZR PRESSURE

PRC APERTURE CARD

NUCLEAR SAFETY RELATED WPPSS QUALITY CLASS I & II

9-4-81 5-8-81 9-14-79 6-27-79 REV. DATE BY APPROVED	EBASCO SERVICES INCORPORATED DIV. CONTROL DR. LVT CH. A. SEN DATE AUG 30, 1978	WASHINGTON PUBLIC POWER SUPPLY SYSTEM NUCLEAR PROJECTS NO. 3 & 5 CONTROL WIRING DIAGRAM PRESSURIZER BACK UP HEATER BANK B-2	WPPS-3240 D-6001 SHEET 153
---	---	--	----------------------------------

RIDS

8303170073

