



- NOTES:
1. FOR LEADING AND SYMBOLS REFER TO DRAWINGS 3-8-101-011 AND 3-8-101-02.
2. O - DENOTES LOCATION NUMBER, FOR COMPLETE LOCATION NUMBER REFER TO CABLE BLOCK DIAGRAMS SHOWING LOCATION NUMBER. EXAMPLE: 011-115-0115 IS MAIN CONTROL BOARD OR 011-004-0104 FOR MAIN CONTROL BOARD & TERMINATION CABINET. CABLE LOCATION NUMBER REFER TO DRAWING 3-8-101-02.
3. CABLE NUMBERS FOR POWER CABLES ARE ASSIGNED FROM REFERENCED ONE LINE DRAWINGS.
4. THIS DRAWING 0-PERSEDES BAR DRAWING NO. ARI7-1E-4557 & ARI7-1E-4553.
5. INFORMATION DIAGRAM SHOWS IS FOR 011-01100, MIN-0115B IS SIMILAR EXCEPT AS NOTED ON BLOCK DIAGRAM IN BRACKETS ().
6. FOR SUP. NEUTRALION CABLES, LOCATIONS, MINE NO. 011-0115B & CABLE BLOCK DIAGRAMS 3-8-101-02 & 3-8-101-02.

NUCLEAR SAFETY RELATED			0
ELEMENTARY DIAGRAM			
CVCS RMST TO CHARGING PUMP MOV-0112C & MOV-0113B			
SCALE	JOB NO	DRAWING NO.	REV
NONE	14928	9-E-CV31-01	3
FK			

1 1 1 1 1 1
12 14.5 16 18 20 22

8704210336

PDR RIDS

8701210336

