



NOTES

1. ALL HEADER VALVES ARE LOCATED ON PIPING AND MECHANICAL AREA DRAWINGS 500852-500962.
2. ALL QUICK DISCONNECT VALVES ARE LOCATED ON PIPING AND MECHANICAL AREA DRAWINGS 500852-500962.
3. NUMBER NEXT TO HEADER, INDICATES NO. OF QUICK DISCONNECT VALVES PER HEADER.
4. ALL QUICK DISCONNECTS ARE ACCOMPANIED BY VELOCITY FUSE & SHUTOFF VALVE, SEE DWG. 049080.
5. ALL SERVICE AIR PIPING WITH EXCEPTION OF TEST AND VENT PIPING SHALL BE 1" MINIMUM.
6. USE 3" CONTRAMATICS 3-WAY, CARBON STEEL, TWO POSITION, 90° CYCLE, MODEL S, UNDER SPEC. 8711.

SERVICE AIR UNIT 2

ISOMETRIC OF SHEET 4
HEADER LINES ONLY

| | |
|-------------------|--------------------|
| UNIT - 2 | |
| P. G. & E. CO. | DRAWING NO. CHANGE |
| SHEET 6 OF SHEETS | 108025 25 |

SCAN 25 IC

THIS DRAWING HAS BEEN REPRODUCED WITHOUT CHANGE FROM ORIGINAL DRAWING. RM INDEXED REV. CHANGE NO. DATE APPROVED. APPD. IBC 25 35 N/M NEG