DWG NO 3-EDG-01

TO/FROM D.G. J8 AIR STARTING SYSTEM

3-70-279A

RV-3-3461A

3-70-573A

3-70-272A

3-70-280A

3C2A AIR COMPRESSOR (A)

1 1/2"-G

PS -J- 6696A2

PS -J- 6700A2

PI -J- 3693A

3-70-590A

3-70-420A

3-70-419A

3-70-418A

250 PSIG RV-3-213A

250 PSIG RV-3-212A

250 PSIG RV-3-211A

250 PSIG RV-3-210A

AIR RECEIVER TANK D 3T272A

AIR RECEIVER TANK C 3T271A

AIR RECEIVER TANK B 3T270A

AIR RECEIVER TANK A 3T269A

PS -J- 6700A1

PI -J- 3690A

PS -J- 6696A1

3-70-303A

3-70-317A

3-70-589A

3-70-421A

3-70-271A

3-70-270A

3-70-268A

3-70-267A

3-70-273A

3-70-274A

3-70-275A

3-70-276A

1 1/2"-61-G

1 1/2" L.O. 3-70-263A

1 1/2" L.O. 3-70-414A

1 1/2" L.O. 3-70-265A

1 1/2" L.O. 3-70-416A

3-70-572A

3-70-300A

YS-3-3413A

190 PSIG

PCV-3-2066A

1 1/2" L.O. 3-70-305A

CV-3-2067A

3P239A OIL INJECTOR

3-70-302A

3-70-304A

PI -J- 3692A

3-70-319A

3-70-316A

PI -J- 3691A

SV-3-2068A

PINION ENGAGING AIR

3-70-306A

EXHAUST TO ATMOS

1 1/4" HOSE

3K9A

3K8A

CLUTCH

CRANKING AIR MOTORS

3/8" SS TUBING

3-70-318A

3-70-314A

PS -J- 3691A

3-70-261A

YS-3-3409A

PCV-3-194A

3-70-257A

CV-3-124A

3P240A OIL INJECTOR

3-70-258A

T.C. 3-70-259A

PI -J- 3669A

SV-3-2023A

3-70-441A

PI -J- 205A

3-70-254A

3K7A

3K6A

PS -J- 6670A

3-70-431A

PI -J- 6459A

TI -J- 3606A

BYPASS

3-70-321A

3-70-320A

PI -J- 6456A

3-70-433A

3-70-410A

3F236A AFTER FILTER

3-70-402A

3-70-327A

PURGE LINE

MI -J- 6416A

SV-3-5343A

3-70-408A

3-70-407A

3-70-330A

PURGE BYPASS

3F237A

FILTER BLEED

3-70-409A

3-70-331A

FI -J- 6401A

SV-3-5342A

SV-3-5344A

3-70-326A

PI -J- 6457A

PI -J- 6458A

3-70-328A

3-70-329A

3T261A

3T262A

SV-3-5341A

SV-3-5338A

PURGE EXHAUST

3-70-403A

3-70-405A

SV-3-5340A

SV-3-5339A

3-70-404A

3-70-406A

3-70-423A

TI -J- 3607A

PI -J- 6460A

TS -J- 6141A

3-70-432A

3F234A PREFILTER

3-70-322A

3-70-323A

3-70-533A

SV-3-6287A

3-70-324A

3-70-325A

3F235A PREFILTER

3-70-401A

SV-3-6288A

3F233A OIL SEPARATOR

3V70A AFTERCOOLER

3-70-332A

SV-3-6286A

AIR QUALITY IMPROVEMENT SKID A

AIR DRYER

3K4A FILTER SILENCER

INTAKE

3K4A DIESEL GENERATOR

EXHAUST TO ATMOS

3K4A EXHAUST SILENCER

EXHAUST

3K4A DIESEL ENGINE

D-044

NOTES:

1. FOR GENERAL NOTES & LEGEND SEE DWG NO. 0-NOTES-01.

FPL

EMERGENCY DIESEL GENERATOR-AIR START

FLORIDA POWER & LIGHT
TURKEY POINT NUCLEAR UNIT 3
LICENSE RENEWAL BOUNDARY DRAWING

DRAWING NUMBER 3-EDG-01

REVISION 0

3EDG01.DWG