FROM QUENCH TANK
FROM MISC DRAINS
FROM SI TANK 1B1
FROM SI TANK 1B2
FROM RLY VLV V3466
FROM LOOP 1B1
FROM MISC DRAINS
FROM REGEN HT EXCH
FROM REGEN HT EXCH
FROM REGEN HT EXCH
FROM VALVE V3661
FROM RC LOOP 1B2
FROM RC LOOP 1B1
FROM RC LOOP 1B
FROM RC LOOP 1A
FROM RC LOOP 1A2
FROM RC LOOP 1A1
FROM SI TANK 1A2
FROM SI TANK 1A1

CONTAINMENT DRAIN HEADER #1
CONTAINMENT DRAIN HEADER #2

V6100
V6125
FROM N2 SUPPLY V6741
V6101
V6300
FROM INST. AIR
TO CNTMT VENT HEADER
FR PRIMARY WTR PUMPS
PT 6601
V6102
V6103
LT 6601
V6105
V6106
REACTOR DRAIN TANK 1A
V6104
TO CONTAINMENT SUMP
V6128
V6127
FROM MISC VLV LEAKOFFS
FROM MISC VLV LEAKOFFS
FROM MISC VLV LEAKOFFS
V6107
V6125
DR
V6123
TO GAS SURGE HDR
V6122
TO GAS ANALYZER
FLASH TANK GAS VENT TRAP
V6309
PT 6603
V6218
FS 6604
V6895
FROM INST. AIR
FO TO HUT
V6307
V6120
LS
FLASH TANK 1A
V6128
LIC 6603
LT 6604
V6127
V6274
TO PRE-CONC ION EXCH
V6131
TO HOLDUP TANKS
V6179
V6315
V6121
FROM INST. AIR
V6132
V6286
PI 6606
V6135
V6124
FIC 6603
V6308
FC
N2
V6129
SS-6-1A
FLASH TANK PUMP 1A
V6130
V6267
FC
LCV-8804
LS
V6135
TO HOLDUP TANKS
V6134
V6131
SS-6-1B
FLASH TANK PUMP 1B
V6132
V6133
TO DRN COLLECTION HDR
V6126
FROM SAMPLE VESSEL
V6116
FROM SAMPLE VESSEL
V6118
3/4" V
V6644
TO EQUIPMENT DRN TNK
TO PRE-CONC FILTERS
V6331
V6332
PI 6605
V6115
V6111
V6114
V6117
V6350
V6002
FROM INST. AIR
FROM INST. AIR
FROM INST. AIR
FC
HCV-06-9
V6109
SS-6-2A
REACTOR DRAIN PUMP 1A
PI 6604
V6265
FR REFUELING CAV DRN
V6106
DR
V6301
1-3-WM-450
V6302
V6163
LO
V6110
SS-6-2B
REACTOR DRAIN PUMP 1B
V6112
V6113
V6116
TO REFUELING WTR TK
FR HOLDUP RECIRC PUMP
V6450
FROM V2500
INSIDE CONTAINMENT
OUTSIDE CONTAINMENT
REACTOR BUILDING
REACTOR AUXILIARY BUILDING
FROM INST. AIR
FR REACTOR CAVITY SUMP
V06164
FO
HCV-06-8
FROM SAMPLE CABINET
V06165
V06166
V06167
DR
DR

D-110

NOTES:

1. FOR GENERAL NOTES & LEGEND SEE DRAWING NO. 1-NOTES-01.

FLORIDA POWER & LIGHT
ST. LUCIE NUCLEAR UNIT 1

WASTE MANAGEMENT

LICENSE RENEWAL BOUNDARY DRAWING

DRAWING NUMBER	REVISION
1-WM-01	0

P&ID BORDER.DWG