

INSTRUMENT SCHEMATIC NOTE 4)



NOTES:

1. ALL WORK TO BE CLASS I UNLESS OTHERWISE NOTED THUS III I
2. FOR GENERAL NOTES & LEGEND SEE BECHTEL DWG M-200 UNLESS SHOWN OTHERWISE.
3. ALL VALVE NUMBERS ARE PRECEDED BY DG-.
4. EXHAUST TE's ARE SUPPLIED WITH THE ENGINE AND INTERNALLY WIRED.

LEGEND:

EXPANSION JOINT

—P———P— INDICATES LIMITS OF ENGINE SKID

NOTE A:
EMERGENCY DIESEL ENGINE PERFORMS SAFETY RELATED FUNCTION. HOWEVER. NOT ALL COMPONENTS ON ENGINE ARE OA-SCOPED.

D067

LEGEND

MAGENTA - IN SCOPE LR

BLACK - NOT IN SCOPE LR

LR-M-226 SH-1
UNIT 1 & 2
AIR INTAKE & EXHAUST
DIESEL GENERATOR BUILDING
REV. 1 DATE:10-17-03