Table 3.3.1-1 (page 2 of 7)
Reactor Trip System Instrumentation

FUNCTION	APPLICABLE MODES OR OTHER SPECIFIED CONDITIONS	REQUIRED CHANNELS	CONDITIONS	SURVEILLANCE REQUIREMENTS	ALLOWABLE VALUE	NOMINAL TRIP SETPOINT
6. Overtemperature ΔT	1,2	4	E	SR 3.3.1.1 SR 3.3.1.3 SR 3.3.1.6 SR 3.3.1.7 SR 3.3.1.12 SR 3.3.1.16 SR 3.3.1.17	Refer to Note 1 (Page 3.3.1-18)	Refer to Note 1 (Page 3.3.1-18)
7. Overpower ΔT	1,2	4	E	SR 3.3.1.1 SR 3.3.1.3 SR 3.3.1.6 SR 3.3.1.7 SR 3.3.1.12 SR 3.3.1.16 SR 3.3.1.17	Refer to Note 2 (Page 3.3.1-19)	Refer to Note 2 (Page 3.3.1-19)
8. Pressurizer Pressure						
a. Low	1(f)	4	M	SR 3.3.1.1 SR 3.3.1.7 SR 3.3.1.10 SR 3.3.1.16	≥ 1935 psig	1945 psig
b. High	1,2	4	E	SR 3.3.1.1 SR 3.3.1.7 SR 3.3.1.10 SR 3.3.1.16	≤ 2395 psig	2385 psig
9. Pressurizer Water Level - High	1(f)	3	M	SR 3.3.1.1 SR 3.3.1.7 SR 3.3.1.10	≤ 93%	92%
10. Reactor Coolant Flow - Low						
a. Single Loop	1(g)	3 per loop	N	SR 3.3.1.1 SR 3.3.1.7 SR 3.3.1.10 SR 3.3.1.16	≥ 87%	88%
b. Two Loops	1(h)	3 per loop	M	SR 3.3.1.1 SR 3.3.1.7 SR 3.3.1.10 SR 3.3.1.16	≥ 87%	88%
11. Undervoltage RCPs	1(f)	1 per bus	M	SR 3.3.1.9 SR 3.3.1.10 SR 3.3.1.16	≥ 5016 V	5082 V

(continued)

(f) Above the P-7 (Low Power Reactor Trips Block) interlock.

(g) Above the P-8 (Power Range Neutron Flux) interlock.

(h) Above the P-7 (Low Power Reactor Trips Block) interlock and below the P-8 (Power Range Neutron Flux) interlock.