

From: [Hyslop, JS](#)
To: [ANDERSON, Victoria](#)
Cc: [Robinson, Jay](#); [Metzger, Brian](#); [Frumkin, Daniel](#); [Melly, Nicholas](#); [Taylor, Gabriel](#); [Stroup, David](#)
Subject: FW: FPRA FAQ 14-0007 - additions/mods by NRC
Date: Thursday, December 07, 2017 9:13:00 AM
Attachments: [FPRAFAQ 14-07RevF Fin-Update\(From VA\) JSH 12_06_17 Backto NEI-Fixed nos.doc](#)

Victoria,

Attached are NRC's comments to your update of fire PRA FAQ 14-0007. Our changes are of the following types:

- 1) We believe all the calculations in the FAQ are wrong and we have corrected them. The origin of the error is that your latest author extracted the transient frequencies incorrectly from NUREG-2169.
- 2) At the end of the FAQ, we added an example to try to highlight the impact of floor area for your choices of influence factors and floor area. Text was added to support this additional example. This new example supports the FAQ, and does not adjust any conclusions. This example was added in response to an earlier comment we provided in the last version of the FAQ we exchanged with you.
- 3) In section 3.1, we read your adjustment to our revision to the concept behind the TISR technology, and we have revised it to more reflect our understanding of the basis. We tried to be sensitive to your modification.
- 4) We added a discussion at the beginning of the FAQ to provide context for when to establish a TISR.
- 5) Lastly, we have added a paragraph to limit the TISR transient frequencies to 1% of the PAU transient frequencies because in running different cases of this technology we found that a very small relative floor area can eliminate the impact of influence factor differences.

We are providing you this ahead of our Dec 13 meeting to enhance our meeting discussion.

Thanks.

J.S.

FAQ Number: 14-0007 **FAQ Revision:** G

FAQ Title: Transient Fire Frequency Likelihood

Plant: Exelon: Various **Date:** 11/02/2017

Contact: Gregory Zucal, Exelon Risk Management **Phone:** 610-431-8260

Email: gzucal@jensenhughes.com

Distribution: (NEI Internal Use)

FPRA TF BWROG PWROG

Purpose of FAQ:

To propose an enhancement to the existing methodology to distribute transient ignition frequencies (Bins 3, 6, 7, 24, 25, 36, 37) that contains a structured approach to account for variations within a PAU (Fire Compartment per NUREG/CR-6850).

Relevant NRC document(s):

NUREG/CR-6850, NUREG-2169

Details:

NRC document needing interpretation (include document number and title, section, paragraph, and line numbers as applicable):

NUREG/CR-6850 Volume 2 Section 6.5.7.

Circumstances requiring interpretation or new guidance:

The current methodology involves the application of transient influence factor rankings to PAUs. Variations of the influence factors within PAUs are not addressed until calculating ignition frequencies for scenarios. Waiting to account for PAU variability until the scenario development task increases the complexity of that task and introduces more opportunities to misrepresent the transient ignition frequency for fire scenarios. An alternative approach is to evaluate transient influence factors for spaces smaller than PAUs or fire compartments prior to the development of fire scenarios. The result is a more intuitive process for modeling variations of transient ignition frequency that will be easier to maintain and adjust in future fire PRA model updates.

Detail contentious points if licensee and NRC have not reached consensus on the facts and circumstances:

None

Potentially relevant existing FAQ numbers:

NFPA 805 FAQ 12-0064

Response Section

Proposed resolution of FAQ and the basis for the proposal

The proposed resolution to the FAQ creates a new term, Transient Ignition Source Regions (TISRs), to describe regions smaller than a PAU. TISRs may be postulated for spaces that represent obviously different transient frequencies from the remainder of the PAU. The clearest example are functionally different spaces within a PAU that display a different likelihood of transient fires. For example, areas within a PAU such as a Transient Free Zone or a space dedicated to storage of materials would justifiably be assigned a TISR providing the remainder of the PAU demonstrates significantly different characteristics for transient fire frequency. On the other hand, a TISR should not be specified simply because foot traffic from nuclear plant personnel is expected to be less in one area of the PAU than another area of the same PAU, say for example in a corner of a PAU. It should be noted that certain differences which affect transient frequency within a PAU must be evaluated on a case by case basis to determine if the PAU can be divided into TISRs. For example, a remote area in a PAU isolated by an obstruction such as a floor-to-ceiling stack of cable trays may warrant a TISR. In general, a TISR should be supported by plant combustible control procedures¹ or physical barriers/obstructions, and the proposed TISR area within the PAU assessed to determine if the maintenance, hot work, occupancy, and storage is different enough from the overall PAU itself to warrant a TISR.

This FAQ describes how to vary the fire ignition frequency for a TISR for the following ignition sources: 1) general transient fires and 2) transient fires caused by welding and cutting. As a part of this task, W_{GT} , N_{GT} , W_{WC} , and N_{WC} formulas provided in FAQ 12-0064 are revised for evaluating these fire ignition sources; enabling the assignment of Transient Influence Factors to areas of the plant that are smaller than PAUs, i.e., TISRs.

The basis of the alternative method is included below along with the specific modification to the necessary formulas.

1.0 CURRENT METHODOLOGY

For illustrative purposes the examples in this FAQ use transient fire ignition frequency bins 6 and 7 included in NUREG -2169 (listed in Table 1).

TABLE 1. RELEVANT TRANSIENT FIRE IGNITION FREQUENCY BINS

Bin	Generic Location	Description	NUREG-2169 FIF
-----	------------------	-------------	----------------

¹ A combustible control program may or may not affect fire ignition frequency. For a Transient Free Zone, the combustible control program generally excludes transient combustibles; however some combustible control programs only limit the amount of combustibles and the effect of the combustible control program is on HRR rather than reducing frequency.

FAQ Number: 14-0007

FAQ Revision: G

FAQ Title: Transient Fire Frequency Likelihood

The concept behind the TISR methodology for general transient fires and for transient fires from welding and cutting, which allows the influence factors to be weighted by floor area, is that floor area is proportional to the number of likelihood of a transient fires which can be located in for a TISR. Thus, a TISR with a larger floor area will not contain a larger number reasonably have a higher likelihood of a transient fire scenarios than a TISR with a smaller floor area. To apply this FAQ, the number of transient fires across different TISRs should be proportional to the floor area of the different TISRs, assuming their other weighting factors (occupancy, maintenance, and storage) are equal. The application of this FAQ ensures that the transient frequency is not diluted for larger areas, and is not overemphasized for smaller areas. Practically speaking, Thus to apply this FAQ, grids representing the number and location of transient fires the floor area of the TISRs must be applied to evaluate the importance of transients for the fire frequency ignition bins of general transients and to evaluate transients from welding and cutting.

The approach to calculating the ignition frequencies for TISRs first involves assigning transient influence factor rankings to the TISRs in a similar manner to that performed for PAUs. The next step is to identify the size of each TISR. The size should be based on the available floor area and the amount of exposed cables for floor based transient fires and cable tray fires respectively. The next step is to determine the Transient Ignition Source Region Factors (TISRf) using Equations 7 and 8 where $n_{A,k,j}$ is the available floor area in TISR “k”, within PAU “J”.

$$TISRf_{GT,k,j} = \frac{(n_{M,k,j} + n_{O,k,j} + n_{S,k,j}) * n_{A,k,j}}{\sum_k [(n_{M,k,j} + n_{O,k,j} + n_{S,k,j}) * n_{A,k,j}]} \quad (7)$$

$$TISRf_{WC,k,j} = \frac{n_{H,k,j} * n_{A,k,j}}{\sum_k n_{H,k,j} * n_{A,k,j}} \quad (8)$$

The final step to calculate ignition frequencies for TISRs is to multiply transient bin PAU frequency by the applicable TISRf. This is depicted in Equation 9 where p represents the applicable transient fire type (i.e. GT, WC).

$$\lambda_{p,k} = \lambda_{p,j} * TISRf_{p,k,j} \quad (9)$$

As a result of this definition of the TISRf, the ignition frequency of a PAU is conserved upon the division of a PAU into TISRs.

The scenario frequencies are calculated in the same manner as they were without TISRs except that the floor area ratio calculated is based on the TISR rather than the PAU. If a scenario includes multiple TISRs, the applicable frequencies for each TISR are calculated and then summed to arrive at a total scenario frequency.

FAQ Number: 14-0007

FAQ Revision: G

FAQ Title: Transient Fire Frequency Likelihood

	GT (Bin 7)	WC (Bin 6)	Total
A	1.21E-03 5.99E-04	5.8455E-04	1.1579E-03
B	1.21E-03 5.99E-04	5.8455E-04	1.1579E-03
C	1.21E-03 5.99E-04	1.7567E-03	2.926E-03
D	3.09E-03 1.53E-03	1.7567E-03	4.843.20E-03

The TISRFs are presented in Table 6 along with the corresponding ignition frequencies for each TISR. ~~The table also calculates the distribution of the PAU frequency to each TISR with and without the proposed enhancement, whereby the frequency of the base case (compared to the enhancement) is the frequency assigned to each TISR of PAU D based on the fraction of floor area of each TISR. This comparison provides some insights with respect to the n_m , n_o , n_s , and n_H contribution to the TISRF (Illustration #1). Without accounting for the influence factor variations, the distribution of transient frequency would have simply been based on the floor area ratios. In particular, the frequencies for the transient free zone and storage area TISRs are reduced based on the lower influence factor rankings compared to the 3rd TISR. As the methodology is setup to preserve the PAU frequencies the frequency for the 3rd TISR increases~~

TABLE 6. TISR FREQUENCIES - ILLUSTRATION #1

TISR	Fraction Floor Area of PAU	TISR Frequency Without Based On Floor Area Alone TISR Method	TISRF		TISR Frequencies				Percent Change
			GT	WC	GT	WC	Total	% of PAU	
D_TFZ	10%	4.843.20E-04	0.03	0.04	1.065.28E-045	7.306.94E-05	1.2279E-04	3.87%	-632%
D_Storage	20%	9.686.39E-04	0.19	0.08	52.96E-04	1.4639E-04	7.424.35E-04	15.33.6%	-2332%
D_Other	70%	3.392.24E-03	0.77	0.88	1.12.38E-03	1.5346E-03	3.922.64E-03	81.02.6%	+186%

Table 7 shows the TISR frequencies for the same choice of floor areas and n_m , n_o , n_s , and n_H , whereby the comparison with and without the proposed enhancement is done with respect to the floor areas (Illustration #2). As expected, the reduction in frequencies due to floor area is largest for the TISR with the smallest floor area, and the reduction gradually decreases as the floor area increases. The TISR Frequencies from Table 6 are repeated in Table 7 for comparison purposes; the TISRF values for GT and WC which establish the "TISR Frequencies" are not repeated in Table 7.

