Br. 2

Licensing Assistance Team
Division of Nuclear Materials Safety
U.S. Nuclear Regulatory Commission, Region I
2100 Renaissance Boulevard, Suite 100
King of Prussia, PA 19406-2713

RE: Request to Amend License 47-35296-01

03038909

To Whom It May Concern:

The purpose of this letter is to request an amendment to NRC radioactive materials license number 47-35296-01 issued to STS International (STS). STS is pursuing an amendment that would allow STS Authorized Users (AUs) to perform certain non-routine maintenance operations on licensed gauges. Specifically, the intended non-routine maintenance operations would allow STS to work on source holders, shutters, various motors, and install/de-install sources from gauges.

Eleven procedures have been prepared describing the specific operations. They involve replacing the source holder, shutters, and various motors on two types of gauges. The procedures are included in Attachment A.

Non-routine maintenance will be limited to STS radioactive materials supervisors. They are Alfonso Silva and Harold Carter. These individuals have received appropriate training regarding implementation of the non-routine maintenance procedures; their training record and copies of their training certificates are provided in Attachment B. Non-routine maintenance procedures will only be implemented by persons in possession of appropriate radiation detection instrumentation that meets the criteria in NUREG-1556 Volume 18. External radiation dose will be monitored with both whole body and extremity (ring) dosimeter badges obtained from a NVLAP accredited vendor. Proper implementation of these procedures will not result in doses which exceed any annual dose limit established by NRC.

The following steps will be implemented during non-routine maintenance activities:

- Radioactive source(s) will be under constant surveillance if not secured against unauthorized removal or access:
- Work areas will be posted with CAUTION RADIOACTIVE MATERIALS or CAUTION RADIATION AREA, as appropriate;
- All procedures will be implanted as written, in accordance with manufacturer's or distributor's instructions;
- All parts, components, materials (i.e., lubricants) used will be as recommended by the
 manufacturer or distributor. Should that not be possible, the item(s) in question will be
 evaluated to ensure that they do not degrade the engineering safety analysis performed
 and accepted as part of the original device registration; and
- Before being returned to routine use, the sealed source/device will be tested to verify that it functions as designed and the source integrity is not compromised.



We also commit to ensuring that no persons occupying adjacent areas to the restricted areas where non-routine maintenance operations take place will receive a dose exceeding the dose limits established by NRC for members of the public. This will be confirmed by surveying exposure rates with an appropriate instrument and limiting access to these areas. Area surveys performed during non-routine maintenance operations will be maintained in our radiation safety files for a minimum of three years and will include the survey date, name of person performing the survey, instrument used (serial number and calibration information), and measured radiation levels.

Thank you for your attention to this amendment request.

Sincerely yours,

David Morgan

Vice President Operations

Encls: Attachment A – Non-Routine Maintenance Procedures

Attachment B - AU training certificates

ATTACHMENT A NON-ROUTINE MAINTENANCE PROCEDURES

- 1. Replace MMVACIS Source Motor
- 2. Replace MMVACIS Source
- 3. Replace MVACIS Shutter Gearmotor
- 4. Replace MVACIS Co60 Source Holder Assembly 2
- 5. Replace MVACIS Gearmotor Assembly
- 6. Replace R-VACIS (Primary) Source Actuator
- 7. Replace R-VACIS Co60 Source Holder Assembly
- 8. Replace R-VACIS Secondary Shutter Gearmotor
- 9. Replace R-VACIS Secondary Shutter
- 10. Replace VACISGT Source Motor
- 11. Replace VACISGT Source

Asset Nu	umber		
Asset Na	ame	MMV	
Job Plan	Number	MMVSMTRR01	
Descripti	ion	Source Motor replacement	
Duratio	(Hours)	4	
		Duration (hours)	
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.
Task	20	Make sure lock is in the source shutter to prevent source from opening while shutter linkage is off.	0.
Task	30	remove outer metal covers of the source holder.	0.
Task	40	Remove the shutter linkage from the top of the source motor.	0.
Task	50	Remove the shutter linkage bracket off the source motor that holds the shutter linkage to motor.	0.
Task	60	unplug the motor wires from the Out vehicle wiring harness.	0.
Task	70	lossen all the allen bolts holding servo coupling to the motor shaft	0.:
Task	80	remove the four allen bolts holding the source motor to the source motor bracket.	
Task	90	remove source motor from the bracket being careful not to damage the servo coupling.	0.:
rusk	50	Tellione source motor from the ordered being earers not to duringe the servo coupling.	
Task	100	install new source motor thru the source motor bracket while at the same time sliding the servo couping back onto the motor shaft.	0.:
Task	110	reinstall the four source motor allen bolts securing the motor back to the source motor bracket.	0
Idak	110	remistan the four source motor after boits securing the motor back to the source motor bracket.	—— ·
Tack	120	Aighten down the eller helps on the constraint	0.:
Task		tighten down the allen bolts on the servo coupling.	0.
Task	130	reinstall the shutter linkage bracket back onto the source motor shaft.	0.
Task	140	reinstall the shutter linkage to the source motor.	0.
Task	150 160	plug source motor wires back into the Out Vehicles wiring harness.	0.
Task		remove the source shutter lock.	
Task	170	reinstall the metal covers of the source holder	0.
Task	180	Perform job Plan "Function Test" and lock the source	0.
Task	190		
Task	200		
Task	210		
Task	220		
Task	230		
Task Task	240 260		
<u>Labor Da</u>	<u>dld</u>		
Craft Cod	de	Quantity Hours	
MMV		1 4	

Parts/Materials Required		
Part Number	Description	Quantity
0205-03-0012-001 Tools/Support Equipment Required	source motor assembly	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

Asset N	umber		
Asset Name		MMV	
Job Plar	n Number	MMVSRCEC01	
Descript	tion	Source change out	
Duratio	(Hours)	5.3	
		Duration (hours)	
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.2
Task	20	Make sure lock is in the source and perform source wipe test on old Source if not performed in the last 6 months.	0.2
Task	30	remove outer metal covers.	0.5
Task	40	Remove the shutter linkage from the top of the source holder (blue Pig)	0.2
Task	50	Remove the shutter motor from the source holder.	0.2
Task	60	Remove the battery box that houses the back up batteries to close the shutter in an emergency from the source holder (blue Pig)	0.2
Task	70	remove limit switches from the top of the source holder (blue Pig) making sure to mark the wires.	0.2
Task	80	remove the four bolts on both sides of the source holder connecting the source to the out vehicle source brackets.	0.5
Task	90	connect a lifting chain to the two lifting brackets on the source holder.	
T1.	100		
Task	100	using a forklift place the chains on the forks of the forklift and raise forks till the chain is tight but not lifting the source holder.	0.2
Task	110	from the bottom of the out vehicle remove the two 3/4 in bolts mounting the source to the out vehicle source box.	0.1
Task	120	slowly raise the source holder (blue Pig)out of the out vehicle and lowering the source to the ground.	0.5
Task	130	remove the chains and the lifting brackets off the old source and install on the new source.	0.2
Task	140	perform a wipe test on the new source	0.1
Task	150	raise the new source and slowly lower into the out vehicle making sure the holes for the mounting bolts line and install bolts finger tight.	0.5
Task	160	lower source holder and remove the chains and leaving the lifting brackets on the source.	0.2
Task	170	install the 4 bolts on both sides of the source holder the side mounting brackets on the out vehicle.	0.2
Task	180	intall the source motor	0.5
Task	190	intstall battery box that hoses the bak up batteries to close the shutter in an emergency.	0.5
Task	200	install the limit switch back on top the source making sure the wire are plugged back in correctly.	
Task	210	install the shutter linkage back to the source motor	0.2
Task	220	reinstall the metal covers to the source box.	0.5
Task	230	Perform Job Plan "Function Test" and lock the source	
Task	240		
Task	260		
Lahor D	ata		

Craft Code Quantity Hours

GT (vtm) 5.3

Parts/Materials Required		
Part Number	Description	Quantity
0014-03-0001-001 Tools/Support Equipment Required	source cobalt 60	1
Part Number	Description	Quantity
6600-02-0100-001 3514-03-0011-001 3514-02-0005-001	General FSR Tool Kit Rad Meter wipe test kit fork lift lifting chain	1 1 2 1 1

Asset Nu	ımber				
Asset Na	ime	MVACIS			
Job Plan	Number	MVCGRMTR01			
Descripti	ion	Replace "Shutter" Gearmotor			
Duratio	(Hours)	1.87			
		Duration (hours)			
Task	10	Position source enclosure to an open area where you can easily access all sides.	0.1		
Task	20	Ensure the source is tilted all the way down and the locking pin is installed indicating the source shutter is closed.	0.0		
Task	30	Perform Job Plan "Initial Safety Preparation Power Off"	0.0		
Task	40	Remove the front source cover, (16 ea. ½-20 screws and washers). Usethe #3 Phillips screwdriver.	0.0		
Task	50	Open the source shutter actuator box (4 ea. captured fasteners) using a ¾" standard screwdriver and disconnect the wires going to the shutter actuator "motor"	0.1		
Task	60	Loosen allen screws on servo coupling attached to the Gearmotor shaft.	0.0		
Task	70	Remove the 4 screws attaching the gearmotor to the gearmotor "housing" assembly.	0.1		
Task	80	Slide the old gearmotor out and slide new gearmotor into the gearmotor "housing" assembly and servo coupling.	0.1		
Task	90	Reinstall the 4 screws attaching the gearmotor to the gearmotor "housing" assembly.	0.0		
TUSK	30	Remistan the 4-screws statedning the gestinotes to the gestinotes measing assembly.	-		
Task	100	Tighten the allen screws on the servo coupling.	0.0		
Task	110	Using a ¼" standard screwdriver reconnect the wires going to the shutter actuator "motor" assembly and close the source shutter actuator box.			
Task	120	Replace the front source cover, (16 ea. %-20 screws and washers). Usethe #3 Phillips screwdriver.	0.0		
Task	130	Remove the source locking pin.	0.0		
Task	140	Perform Job Plan function Test.	0.		
Task	150				
Task	160				
Task	170				
Task	180				
Task	190				
Task	200				
Task	160				
Task	170				
Task	180				
Task	190				
Task	200				
			1.8		
Labor Da	<u>ata</u>				

Craft Code Quantity Hours

MVACIS 1 1.87

Parts/Materials Required		
Part Number	Description	Quantity
0205-03-0015-001 Tools/Support Equipment Required	Gearmotor	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

Asset Nu	umber				
Asset Na	ame	MVACIS			
Job Plan	Number	MVCC60AR01			
Descript	ion	Replace Co60 Source Holder Assembly			
Duratio	(Hours)	7.08			
		Duration (hours)			
		Due to the DANGER of a crush hazzard or being struck by MHE equipment it is recommended that you have two technicians perform the source removal and new			
Task	10	Position source enclosure to an open area where you can easily access all sides.	0.1		
Task	20	Ensure the source is tilted all the way down and the locking pin is installed with the source in the closed position.	0.0		
Task	30	Remove the front and back source covers, (16 ea. ¼-20 screws and washers for each cover). Usethe #3 Phillips screwdriver.	0.1		
Task	40	Lower the source enclosure to the ground or to a strong platform that can hold the weight of the source enclosure.	0.0		
Task	50	Perform Job Plan "Safety Power Off"	0.0		
Task	60	Then remove the locking pin and insert combination lock, locking combo lock for transport. Have a calibrated RAD Meter on hand to ensure enternal source shutter is	0.0		
IUSK	00	The first the locking pin the first combination lock, dealing combo lock to transport. The a combination lock, dealing combo lock to transport. The a combination lock, dealing combo lock to transport.			
Task	70	Perform Job Plan "Leak Test" if the Leak Test has not been done in the past 6 months.	0.3		
Task	80	Open the source shutter actuator box (4 ea. captured fasteners) using a ¼" standard screwdriver and disconnect the wires going to the shutter actuator "motor"	0.1		
, 22.1	-	Remove the source shutter actuator box (4 ea. captured lasteners) using a 7 standard screworker and disconnect the wires going to the shutter actuator motor. Remove the source shutter actuator box from its mounting bracket (4 ea. 10-32 x 1" socket head cap screws). Use the 5/32" Allen key. Let the box dangle from the			
Task	90	wires that are attached to it.	0.1		
Task	100	Remove the source shutter actuator box bracket.	0.0		
IUSK	100	Remove the source shatter actuator box bracket.			
Task	110	Remove the pin blocker from the face of the source (2 ea. ¼-20 x .75" socket head cap screws). Use a 3/16" Allen key.	0.0		
Task	120	Remove the laser bracket from the face of the source (2 ea. ¼-20 x .5" hex head screws). Use the 7/16" socket or wrench. (If it has one.)	0.0		
	130	Loosen Motor shaft pivot arm assy and remove from the motor shaft. 0.			
Task					
Task	140				
Task	150	Unbolt and remove source Gearmotor Assembly. (2 bolts)	0.0		
Task	160	Remove Mechanical Indicator Installation and Indicator Cable Assy from top of the source holder.	0.1		
Task	170	Remove the source locking pin BLOCK.	0.0		
Task	180	Remove source shaft limit switch bracket and its two limit switches.	0.1		
Task	190	Loosen Shutter shaft pivot arm assy and remove along with attached pivot rod linkage assy and Motor shaft pivot arm assy.	0.1		
Task	200	Remove the Source "PLC" Junction Box and and let it hang by the cables so you can have access behind the sourceholder. You will have to disconnect some cables so	0.2		
Task	210	Unbolt and remove the old source holder assembly sliding it onto the ground or a strong platform that you have the source enclosure resting on.	0.3		
Task	220	Use MHE support to place the old source holder assembly onto a wood pallet for easy transport.	0.1		
Task	230	Now use MHE support to help move the New Source Holder Assembly into position so you and another technician can slide it into the Source Frame Assembly's tilt	0.3		
Task	240	Once the Source Holder Assembly is in the Source Frame Assembly correctly rebolt it in place.	0.3		
Task	250	Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed.	0.		
Task	260	Reinstall the Source "PLC" Junction Box and any cables that were removed.	0.2		
Task	270	Reinstall the pin blocker on the face of the source (2 ea. %-20 x .75" socket head cap screws). Use a 3/16" Allen key.	0.0		
Task	280	Reinstall the laser bracket on the face of the source (2 ea. ¼-20 x .5" hex head screws). Use the 7/16" socket or wrench. (If it has one.)	0.0		
Task	290	Reinstall the source shutter actuator box bracket.	0.0		
Task	300	Reinstall the source Shutter Actuator Box Assembly.			

Task	310	Rebolt the source Gearmotor Assembly. (2 bolts)	0.08		
Task	320	Using a ¼" standard screwdriver reconnect the wires going to the shutter actuator "motor" assembly into the source shutter actuator box.	0.08		
Task	330	Reinstall the Shutter shaft pivot arm assy with the attached pivot rod linkage assy and Motor shaft pivot arm assy onto the source shutter shaft.	0.17		
Task	340	Reinstall the Motor shaft pivot arm assy onto the actuator motor shaft.	0.17		
Task	350	Reinstall source locking pin BLOCK.	0.08		
Task	360	Reinstall the Mechanical Indicator Installation and Indicator Cable Assembly back onto the top of the source shutter shaft.	0.17		
Task	370	Reconnect source actuator "motor" limit switches (2).	0.17		
Task	380	Reconnect the source shaft limit switch bracket and its two limit switches.	0.17		
Task	390	Replace and close the source shutter actuator box (4 ea. captured fasteners)	0.08		
Task	400	Raise the source enclosure so you can have access to all sides.	0.08		
Task	410	Remove the source combination lock and insert the source locking pin.			
Task	420	Reinstall the front and back source covers, (16 ea. ¼-20 screws and washers for each cover). Usethe #3 Phillips screwdriver.			
Task	430	Remove the source locking pin. 0.0			
Task	440	Perform Job Plan "Function Test" .	0.5		
			7.08		
Labor D	<u>ata</u>				
Craft Co MV	de ACIS	Quanity Hours 1 7.08			
Parts/Ma	aterials Requi	red			
Part Nur	Part Number Description Quantity				

Quantity

1

2

Co60 Source Holder Assembly

General FSR Tool Kit

Rad Meter

Wipe Test Kit

MHE / Forklift Support lifting chain / strap

Description

0014-03-0001-001

Tools/Support Equipment Required

6600-02-0100-001

3514-03-0011-001

3514-02-0005-001

Part Number

Asset N	umber		
Asset N	ame	MVACIS	
Job Plar	n Number	MVCGMASR01	
Descript	tion	Replace Gearmotor Assy.	
Duratio	(Hours)	1.83	
		Duration (hours)	
Task	10	Position source enclosure to an open area where you can easily access all sides.	0.1
Task	20	Ensure the source is tilted all the way down and the locking pin is installed indicating the source shutter is closed.	0.0
Task	30	Perform Job Plan "Initial Safety Preparation Power Off"	0.0
Task	40	Remove the front source cover, (16 ea. ¼-20 screws and washers). Usethe #3 Phillips screwdriver.	0.0
Task	50	Open the source shutter actuator box (4 ea. captured fasteners) using a ¾" standard screwdriver and disconnect the wires going to the shutter actuator "motor"	0.1
Task	60	Disconnect the source actuator "motor" limit switches (2) from the gearmotor assembly and let hang by their wires.	0.0
Task	70	Loosen the allen screws in the motor shaft pivot arm assy and pull up and off the gearmotor shaft.	0.0
Task	80	Unbolt and remove source Gearmotor Assembly. (2 bolts)	0.0
Task	90	Rebolt the new Gearmotor Assembly back onto the source holder. (2 bolts)	0.0
	20		
Task	100	Reconnect the source actuator "motor" limit switches (2) to the gearmotor assembly.	0.0
Task	110	Place the motor shaft pivot arm assy back onto the gearmotor shaft and tighten the allen screws.	0.0
Task	120	Using a %" standard screwdriver reconnect the wires from the new gearmotor assembly to the source shutter actuator box and close the source shutter actuator box.	0.1
Task	130	Replace the front source cover, (16 ea. 1/2-20 screws and washers). Usethe #3 Phillips screwdriver.	0.0
Task	140	Remove the source locking pin.	0.0
Task	150	Perform Job Plan Function Test.	0.
Task	160		
Task	170		
Task	180		
Task	190		
Task	200		
Task	160		
Task	170		
Task	180		
Task	190		
Task	200		
Labor D			1.8

Craft Code Quantity Hours

MVACIS 1 1.83

Parts/Materials Required		
Part Number	Description	Quantity
0205-03-0012-001 Tools/Support Equipment Required	Gearmotor Assy	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

Asset N	umber		
Asset N	ame	R-VACIS	
Job Plar	n Number	RVCSACTR01	
Descript	tion	Replace (Primary) Source Actuator	
Duratio	(Hours)	2.13	
		Duration (hours)	
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.1
Task	20	Unlock and open the back source access door.	0.0
Task	30	Remove the environmental cabinet for easy access to the source actuator.	0.0
Task	40	Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position.	0.0
Task	50	Disconnect the 7-pin cable attached to the top of the source junction box.	0.0
Task	60	Using a ½ in. wrench, remove the four bolts underneath the Source Actuator Mount that attach the Source "Primary" Actuator to the Source Housing.	0.3
Task	70	With your hands lift the Source Actuator straight up and out from the source enclosure.	0.0
Task	80	Place the new source actuator into the source enclosure making sure the shaft lines up with the new source actuator.	0.0
Task	90	Using a ½ in. wrench, tighten the four bolts underneath the Source Actuator Mount that attach the Source "Primary" Actuator to the Source Housing.	0.3
Task	100	Reconnect the 7-pin cable to the top of the junction box.	0.0
Task	110	Remove the source locking pin.	0.0
Task	120	Reinstall enviromental cabinet.	0.0
Task	130	Lock the back source access door.	0.0
Task	140	Perform Job Plan "Function Test"	→ 0.0 0.0 0.0
Task	150	Periotifi Job Piani Punction Test	· · · · · · · ·
Task	160		\dashv
Task	170		-
Task	180		-
Task	190		+
Task	200		
Task	160		-
Task	170		
Task	180		
Task	190		
Task	200		1
Labor D			2.1

Craft Code Quantity Hours

R-VACIS 1 2.13

Parts/Materials Required		
Part Number	Description	Quantity
391975-001 Tools/Support Equipment Required	Source "Primary" Actuator	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

Task

Task

240

250

Asset Name R-VACIS Job Plan Number Replace Cobalt 60 Source Holder Assembly	Asset N	umber		
Description Replace Cobalt 60 Source Holder Assembly	Asset N	ame	R-VACIS	
Duration (hours) Duration Duration (hours)	Job Plar	n Number	RVCC60AR01	
Due to the DANGER of a crush hazzard or being struck by MHE equipment it is recommended that you have two technicians perform the source removal and new Perform Job Plan "initial Safety Preparation Power Off" O.17 Task 20 Unlock and open the back source access door. Remove the environmental cabinet for easy access to the Co 60 source and components. 1 ask 40 Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter in the closed position with the locking pin inserted and secondary shutter. 0.03 1	Descript	tion	Replace Cobalt 60 Source Holder Assembly	
Due to the DANGER of a crush hazzard or being struck by MHE equipment it is recommended that you have two technicians perform the source removal and new Perform. Job Plan "initial Safety Preparation Power Off" 1 Ask	Duratio	(Hours)		
Task 10 Perform Job Plan 'Initial Safety Preparation Power Off' Junick and open the back source access dor. Remove the environmental cabinet for easy access to the Co 60 source and components. Cassar 40 Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position.*** Deform Job Plan 'Leak Est' if the Leak Est has not been done in the past 6 months. Task 50 Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box. Task 70 Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure. Task 80 Using a X in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 90 With another Technician, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. Task 100 Using a X in. wrench, remove the Secondary Shutter from the Source enclosure. Task 110 With your hands lift the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source bracket. Task 140 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. Task 140 Ufit up and remove the source out of the source and route it to the lifting forks on the MHIE equipment so you can lift the source up for placement in the source and lack the source and place it onto the Source Bracket. Task 160 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Sou				7
Task 20 Unlock and open the back source access door. Remove the environmental cabinet for easy access to the Co 60 source and components. Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position.*** Task 50 Perform Job Plan "Leak Test" if the Leak Test has not been done in the past 6 months. Task 70 Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box. Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure. Task 80 Using a X in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 100 Using a X in. wrench, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. Task 110 With your hands lift the Source "Primary" Actuator Straight up and out from the source enclosure. Task 120 Using an Allen wrench, loosen and remove all four bolts underneath the blue Internal Source Holder to the Source Bracket. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Task 160 Using an Allen wrench, lossen and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and lift up the NEW source and place it onto the Source Bracket and list two retaining screws. 10 Once in place lower the lifting forks and remove the strap or chains. 10 Once in place lower the lifting forks and remove the source Bracket and list two retaining screws. 10 Once in place lower the lifting forks and remove the source Bracket. 10 Once in place lower the lifting forks and remove the Source B	Task	10		0.17
Remove the environmental cabinet for easy access to the Co 60 source and components. Co.00				
Task 50 Perform Job Plan "Leak Test" if the Leak Test sha not been done in the past 6 months. Task 50 Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box. Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure. Task 80 Using a X in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 90 With another Technician, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. Task 110 Using a X in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. Task 130 Attach a chain or tow strap to the source and place it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Task 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart platform and to a safe place preferably a pallet that can be easily moved. Task 160 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Task 170 Once in place lower the lifting forks and remove the strap or chains. Task 180 Using an Allen wrench, instell and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 190 With another Technician, align the Secondary Shutter with the four holes in the Muntting Plate. Task 170 Once in place lower the lifting forks and remove the strap or chains. Using a X lin. wrench, insert and tighten the four mounting bolts on the base of the new Secondary Shutter. Task 170 Place the source "Primary" actuator into the source washing sure the shaft lines up with the New source actuator. Task 170 Using a X lin. wrench, insert and tighten the four mounting				4
Perform Job Plan "Leak Test" if the Leak Test has not been done in the past 6 months. Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box. Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure. Using a % in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 80 Using a % in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 100 Using a % in. wrench, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. 100 Using a % in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. 100 Using a M in. wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. 101 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. 102 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. 103 Attach a chain or tow strap to the NEW source and place it onto the Source and place preferably a pallet that can be easily moved. 103 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart. 103 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart. 103 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart. 104 Using an Allen wrench, install and lighten all four boths to attach the blue Internal Source Holder to the Source Bracket. 105 Using an Allen wrench, install and lighten all four boths that attach the blue Internal Source Hol				
Task 70 Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box. Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure. Task 80 Using a ½ in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 100 Using a ½ in. wrench, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. Task 110 With another Technician, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. Task 110 With your hands lift the Source "Primary" Actuator straight up and out from the source enclosure. Task 120 Using an Allen wrench, losen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Lift up and remove the source cart platform and to a safe place preferably a pallet that can be easily moved. Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Lift up the NEW source and light the four both that attach the blue Internal Sou				→
Task 80 Using a X in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 80 Using a X in. wrench, remove the four mounting bolts on the back of the Secondary Shutter. Task 90 With another Technician, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. Task 100 Using a X in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. Task 110 With your hands lift the Source "Primary" Actuator straight up and out from the source enclosure. Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. Attach a chain or tow strap to the NEW source card route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source ard 10.25 Lift up the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart 10.25 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.55 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.56 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.57 Light up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.58 Light up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.58 Light up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.58 Light up the NEW source and place it onto the Source Bracket and its two retaining screws. 10.59 Light up the NEW source and place it onto the S				-
Task 100 Using a X in. wrench, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. 100 Using a X in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. 100 With your hands lift the Source "Primary" Actuator straight up and out from the source enclosure. 100 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. 101 Lift up and remove the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. 102 Lift up and remove the source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart lask 150 Attach a chain or tow strap to the Source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart lask 160 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source up for placement in the source cart lask 170 Once in place lower the lifting forks and remove the strap or chains. 103 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 104 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 105 Using a X in. wrench, install and tighten the four mounting bolts on the back of the new Secondary Shutter. 106 Using a X in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. 107 Using a X in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 108 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. 108 Place the source "Primary" actuator into the source enclosure making sure the s			· · · · · · · · · · · · · · · · · · ·	
Task 100 Using a X in. wrench, remove the Secondary Shutter from the Source Enclosure and set it in a safe place. 100 Using a X in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. 100 With your hands lift the Source "Primary" Actuator straight up and out from the source enclosure. 100 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. 101 Lift up and remove the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. 102 Lift up and remove the source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart lask 150 Attach a chain or tow strap to the Source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart lask 160 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source up for placement in the source cart lask 170 Once in place lower the lifting forks and remove the strap or chains. 103 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 104 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 105 Using a X in. wrench, install and tighten the four mounting bolts on the back of the new Secondary Shutter. 106 Using a X in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. 107 Using a X in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 108 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. 108 Place the source "Primary" actuator into the source enclosure making sure the s				
Task 100 Using a ½ in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder. Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source cart platform and to a safe place preferably a pallet that can be easily moved. Task 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 1 0.25 Task 160 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 2 0.33 Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 3 0.35 Task 200 Using a ½ in. wrench, install and tighten the four holes in the Mounting Plate. 3 0.36 Could be source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. 3 0.36 Could be source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. 3 0.36 Could be source "Primary" actuator into the source actuator making sure the shaft lines up with the New source actuator. 3 0.37 Could be source "Primary" actuator into the source actuator making sure the shaft lines up with the New source actuator. 4 0.38 Could be source "Primary" actuator into the source access door. 5 0.50 Could be source "Primary" actuator into the source access door. Could be source "Primary" actuator in				
Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. Task 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 1 0.25 Task 160 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 1 0.5 Task 170 Once in place lower the lifting forks and remove the strap or chains. 1 0.5 Task 190 With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate. 1 0.17 Task 200 Using a X in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. 1 0.33 Task 100 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. 1 0.36 Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Mount that attach the Source Actuator to the Source Holder. 2 0.38 Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. 3 0.03 Task 200 Remove the source combination lock. 3 0.03 Task 200 Remove the source combination lock. 3 0.03 Task 200 Referent Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. 3 0.03 Task 200 Remove the source combination lock. 3 0.03 Task 200 Remove the source combination lock.	Task	90	With another Technician, remove the Secondary Shutter from the Source Enclosure and set it in a safe place.	0.17
Task 120 Using an Allen wrench, loosen and remove all four bolts that attach the blue Internal Source Holder to the Source up for removal safely. Task 130 Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. Task 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart platform and to a safe place preferably a pallet that can be easily moved. Task 150 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 1 0.25 Task 160 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 1 0.5 Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 2 0.33 Task 190 With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate. Task 200 Using a X in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. Task 170 Using a X in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Reinstall environmental cabinet and lock the back source access door. Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surv	Task	100	Using a ½ in. wrench, remove the four bolts underneath the Source "Primary" Actuator Mount that attach the Source Actuator to the Source Holder.	0.33
Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. List up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. List up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the source into the Source Bracket and its two retaining screws. Once in place lower the source into the Source Bracket and its two retaining screws. Once in place lower the Source and lock the back of the help of the Source Holder to the Source Bracket. Once in place lower the source into the Source enclosure making sure the shaft lines up with the New source actuator. Once in place lower the Source Into the Source Into the Source Actuator to the Source Holder. Once In place Into the Source Into the Source Actuator Mount that attach the Source Actuator to the Source Holder. Once In place Into the Source	Task	110	With your hands lift the Source "Primary" Actuator straight up and out from the source enclosure.	0.08
Attach a chain or tow strap to the source and route it to the lifting forks on the MHE equipment so you can lift the source up for removal safely. Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. List up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. List up the NEW source and place it onto the Source Bracket and its two retaining screws. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the lifting forks and remove the strap or chains. Once in place lower the source into the Source Bracket and its two retaining screws. Once in place lower the source into the Source Bracket and its two retaining screws. Once in place lower the Source and lock the back of the help of the Source Holder to the Source Bracket. Once in place lower the source into the Source enclosure making sure the shaft lines up with the New source actuator. Once in place lower the Source Into the Source Into the Source Actuator to the Source Holder. Once In place Into the Source Into the Source Actuator Mount that attach the Source Actuator to the Source Holder. Once In place Into the Source	Tack	120	Using an Allon wranch logger and remove all four helts that attach the blue Internal Source Holder to the Source Bracket	0.22
Lift up and remove the source out of the source cart platform and to a safe place preferably a pallet that can be easily moved. 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart 150 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 150 Once in place lower the lifting forks and remove the strap or chains. 150 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 150 Using a ¼ in. wrench, insert and tighten the four holes in the Mounting Plate. 150 Using a ¾ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. 150 Using a ¾ in. wrench, insert and tighten the four mounting sure the shaft lines up with the New source actuator. 150 Using a ¾ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 150 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. 150 Reinstall enviromental cabinet and lock the back source access door. 151 Perform Job Plan "Function Test" 152 On Perform Job Plan "Function Test" 153 On Safe Perform Job Plan "Function Test" 154 On Safe Perform Job Plan "Function Test" 155 On Safe Perform Job Plan "Function Test"				4 1
Task 150 Attach a chain or tow strap to the NEW source and route it to the lifting forks on the MHE equipment so you can lift the source up for placement in the source cart 10 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. 10 Once in place lower the lifting forks and remove the strap or chains. 10 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. 10 Using a ¼ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. 10 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that atta				
Task 160 Lift up the NEW source and place it onto the Source Bracket and its two retaining screws. Task 170 Once in place lower the lifting forks and remove the strap or chains. Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 190 With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate. Task 200 Using a ¼ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. Task 160 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. Task 170 Using a ¼ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Remove the source combination lock. Reinstall enviromental cabinet and lock the back source access door. Perform Job Plan "Function Test" 10.05 10.06 10.07 10.08 10.08 10.09 10				→
Task 170 Once in place lower the lifting forks and remove the strap or chains. Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 190 With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate. Task 200 Using a ¼ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. Task 160 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. Task 170 Using a ½ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Task 210 Reinstall enviromental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" Once In Place Install environmental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" Once In Place Hosource Bracket. Once In Holder to the Source Bracket. Once In Holder to the Source Bracket. Once In Holder to the Source Actuator to the Source Actuator. Once In Holder to the Source Actuator to the Source Holder. Once In Holder to the Source Actuator to the Source Actuator to the Source Holder. Once In Holder to the Source Holder to the Source Actuator to the Source Actuator to the Source Holder. Once In Holder to the Source Holder to the Source Holder. Once In Holder to the Source Bracket. Once In Holder to t				-
Task 180 Using an Allen wrench, install and tighten all four bolts that attach the blue Internal Source Holder to the Source Bracket. Task 190 With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate. Task 200 Using a ¾ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter. Task 160 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. Task 170 Using a ¾ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Task 210 Reinstall enviromental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" O.33 O.34 O.35 O.35 O.36 O.37 O.38 O.38 O.39				-
Task190With another Technician, align the Secondary Shutter with the four holes in the Mounting Plate.0.17Task200Using a ⅓ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter.0.33Task160Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator.0.08Task170Using a ⅓ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder.0.33Task180Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box.0.08Task190Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed.0.5Task200Remove the source combination lock.0.03Task210Reinstall enviromental cabinet and lock the back source access door.0.17Task220Perform Job Plan "Function Test"0.5				₹ ———
Task200Using a ⅓ in. wrench, insert and tighten the four mounting bolts on the back of the new Secondary Shutter.0.33Task160Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator.0.08Task170Using a ⅓ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder.0.33Task180Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box.0.08Task190Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed.0.5Task200Remove the source combination lock.0.03Task210Reinstall enviromental cabinet and lock the back source access door.0.17Task220Perform Job Plan "Function Test"0.5				
Task 160 Place the source "Primary" actuator into the source enclosure making sure the shaft lines up with the New source actuator. Task 170 Using a ½ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Task 210 Reinstall environmental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" 0.08 0.08 0.09 0.0				4
Task 170 Using a ½ in. wrench, insert and tighten the four bolts underneath the Source Actuator Mount that attach the Source Actuator to the Source Holder. Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Task 210 Reinstall enviromental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" O.53 O.08 O.09 O.50 O.51 O.51 O.52 O.53 O.55				- — — — — — — — — — — — — — — — — — — —
Task 180 Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box. Task 190 Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed. Task 200 Remove the source combination lock. Task 210 Reinstall enviromental cabinet and lock the back source access door. Task 220 Perform Job Plan "Function Test" 0.08 0.08 0.09				4
Task190Perform Job Plan "Leak Test" and have a calibrated RAD Meter on hand for any radiation surveys needed.0.5Task200Remove the source combination lock.0.03Task210Reinstall enviromental cabinet and lock the back source access door.0.17Task220Perform Job Plan "Function Test"0.5				4 ———
Task200Remove the source combination lock.0.03Task210Reinstall enviromental cabinet and lock the back source access door.0.17Task220Perform Job Plan "Function Test"0.5				4
Task210Reinstall enviromental cabinet and lock the back source access door.0.17Task220Perform Job Plan "Function Test"0.5				-
Task 220 Perform Job Plan "Function Test" 0.5				
				-
			r Chlorini Joo Flair Turiction rest	

Labor Data Craft Code Quanity Hours R-VACIS 5.94 Parts/Materials Required Part Number Description Quantity 0014-03-0001-001 Cobalt 60 Source Holder Assembly 1 Tools/Support Equipment Required Part Number Description Quantity 6600-02-0100-001 General FSR Tool Kit 3514-03-0011-001 RAD Meter 3514-02-0005-001 Wipe Test Kit 2 MHE / Forklift Support 1 lifting chain / strap

Asset Number	er			
,				
Asset Name		R-VACIS		
Job Plan Nur	mber	RVC2SGMR01		
Description		Replace Secondary Shutter Gearmotor		
Duratio (He	ours)	2.27		
		Duration (hours)		
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.1	
Task	20	Unlock and open the back source access door.	0.0	
	30	Remove the environmental cabinet for easy access to the secondary shutter motor.	0.0	
	40	Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position.	0.0	
	50	Open the Source Junction Box and disconncet the wires going to the secondary shutter gearmotor.	0.0	
	60	Remove the gearmotor wires from their fastners where they are just hanging from the gear motor.	0.1	
	70	Loosen the allen screws from the pulley attached to the gearmotor shaft.	0.0	
rusit	, ,	Remove the 4 allen bolts that attach the gearmotor to the secondary shutter assembly pulling down away from the secondary shutter while letting the shaft slide out	-	
Task	80	of the pulley.	0.2	
	90	Take the new gearmotor and put it back into the scondary shutter at an angle and slide the pulley with the belt on it back onto the gearmotor shaft.	0.0	
I ask	90	hake the new gearmotor and put it back into the scondary shatter at an angle and shad the puney with the best on it back onto the gearmotor shart.	0.0	
To al. 4				
	100	Bolt the new gearmotor back to the secondary shutter assembly with the 4 allen bolts.	0.2	
Task 1	110	Reconnect the gearmotor wires back to the Source junction Box routing them through their fastners. 0.2		
Task 1	120	Reinstall the cover to the source junction box.	0.0	
	130	Reinstall the environmental cabinet.	0.0	
	140	Remove the source locking pin.	0.0	
	150	Close and lock the back source access door.	0.0	
	160	Perform Job Plan "Function Test".	0.0	
	170	Terium Job Plan Turiction rest	2.2	
	180			
	190			
	200			
	160			
	170			
	180			
	190			
Task 2	200			
<u>Labor Data</u>				
Craft Code		Quantity Hours		
R-VACIS		1 2.27		

Parts/Materials Required		
Part Number	Description	Quantity
393833-001 Tools/Support Equipment Required	Gearmotor	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

Asset N	umber		
Asset Na	ame	R-VACIS	
Job Plan	Number	RVC2STRR01	
Descript	ion	Replace Secondary Shutter.	
Duratio	(Hours)	2.31	
		Duration (hours)	
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.1
Task	20	Unlock and open the back source access door.	0.0
Task	30	Remove the environmental cabinet for easy access to the secondary shutter motor.	0.0
Task	40	Ensure both shutters are closed by putting source internal shutter in the closed position with the locking pin inserted and secondary shutter in the closed position.	0.0
Task	50	Disconnect the 22 connector pin and 7-pin cables attached to the top of the Source Junction Box.	0.0
		Due to the weight of the Secondary Shutter, it is recommended that you have two Technicians perform this procedure.	
Task	60	Using a ¾ in. wrench, remove the four mounting bolts on the back of the Secondary Shutter.	0.3
Task	70	With another Technician, remove the Secondary Shutter from the Source Enclosure and set it in a safe place.	0.1
Task	80	With another Technician, align the new Secondary Shutter with the four holes in the Mounting Plate.	0.1
Task	90	Using a % in. wrench, tighten the four mounting bolts on the back of the new Secondary Shutter.	
Task	100	Reconnect the 22 connector pin and 7-pin cables to the top of the Source Junction Box.	0.0
Task	110	Remove the source locking pin.	
Task	120	Reinstall enviromental cabinet.	0.0
Task	130	Lock the back source access door.	0.0
Task	140	Perform Job Plan "Function Test"	0.
Task	150		
Task	160		
Task	170		
Task	180		
Task	190		
Task	200		
Task	160		
Task	170		
Task	180		
Task	190		f
Task	200		
Labor Da			2.3
			

Craft Code Quantity Hours

R-VACIS 1 2.31

Parts/Materials Required		
Part Number	Description	Quantity
320421-001	Secondary shutter	1
Tools/Support Equipment Required Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	
	l L	

Asset Nu	ımber			
Asset Name		GT (VTM)		
Job Plan Number		VGTSMTRR01		
Descripti	ion	Source Motor replacement		
Duratio	(Hours)	4		
		Duration (hours)		
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.	
Task	20	Make sure lock is in the source shutter to prevent source from opening while shutter linkage is off.	0.	
Task	30	remove outer metal covers of the source holder.	0.	
Task	40	Remove the shutter linkage from the top of the source motor.	0.	
Task	50	Remove the shutter linkage bracket off the source motor that holds the shutter linkage to motor.	0.	
Task	60	unplug the motor wires from the Out vehicle wiring harness.	0.	
Task	70	lossen all the allen bolts holding servo coupling to the motor shaft	0.	
Task	80	remove the four allen bolts holding the source motor to the source motor bracket.	o.	
Task	90	remove source motor from the bracket being careful not to damage the servo coupling.	0.	
Task	100	install new source motor thru the source motor bracket while at the same time sliding the servo couping back onto the motor shaft.		
Task	110	reinstall the four source motor allen bolts securing the motor back to the source motor bracket.		
Task	120	tighten down the allen bolts on the servo coupling.		
Task	130	reinstall the shutter linkage bracket back onto the source motor shaft.		
Task	140	reinstall the shutter linkage to the source motor.		
Task	150	plug source motor wires back into the Out Vehicles wiring harness.		
Task	160	remove the source shutter lock.		
Task	170	reinstall the metal covers of the source holder		
Task	180	Perform job Plan "Function Test" and lock the source		
Task	190			
Task	200			
Task	210			
Task	220			
Task	230			
Task	240			
Task	260			
<u>Labor Da</u>	<u>eta</u>			
Craft Coo	de	Quantity Hours		
GT (vtm))			

Parts/Materials Required		
Part Number	Description	Quantity
0205-03-0012-001 Tools/Support Equipment Required	source motor assembly	1
Part Number	Description	Quantity
6600-02-0100-001	General FSR Tool Kit	1

5.3

GT (vtm)

Asset N	umber				
ASSECTATION OF					
Asset Name		GT (VTM)			
Job Plan	Number	VGTSRCEC01			
Descript	cion	Source change out			
Duratio	(Hours)	5			
		Duration (hours)			
Task	10	Perform Job Plan "Initial Safety Preparation Power Off"	0.		
Task	20	Make sure lock is in the source and perform source wipe test on old Source if not performed in the last 6 months.	0.		
Task	30	remove outer metal covers.	0.		
Task	40	Remove the shutter linkage from the top of the source holder (blue Pig)	0.		
Task	50	Remove the shutter motor from the source holder.	0.		
Task	60	Remove the Secondary source shutter from the source holder (blue Pig)	0.		
Task	70	remove limit switches from the top of the source holder (blue Pig) making sure to mark the wires.	0.		
Task	80	remove the four bolts on both sides of the source holder connecting the source to the out vehicle source brackets.	0.		
Task	90	connect a lifting chain to the two lifting brackets on the source holder.	0.		
rusk	30	commercial management of the trial management of the commercial management			
Task	100	using a forklift place the chains on the forks of the forklift and raise forks till the chain is tight but not lifting the source holder.	O.		
Task	110	from the bottom of the out vehicle remove the two 3/4 in bolts mounting the source to the out vehicle source box.			
T l-	120	aloud and the course helder (blue Dia) and of the cout unbide and leaves in the course to the ground	0.		
Task	120	Stowny laste the source floract (blace 1 lb) out of the out termine and lottering the source that gives			
Task	130	Terriore the chains and the many brackets of the old source and instant of the rest			
Task	140	perform a wipe test on the new source			
Task	150	raise the new source and slowly lower into the out vehicle making sure the holes for the mounting bolts line and install bolts finger tight.	0.		
Task	160	lower source holder and remove the chains and leaving the lifting brackets on the source.	0.		
Task	170	mistall the 4 botts of both seeds of the bottles field in the seed			
Task	180	intall the source motor			
Task	190	intstall secondary source sutter	0.		
Task	200	install the limit switch back on top the source making sure the wire are plugged back in correctly.			
Task	210	install the shutter linkage back to the source motor			
Task	220	reinstall the out covers to the source box.			
Task	230	Perform Job Plan "Function Test" and lock the source			
Task	240				
Task	260				
<u>Labor D</u>	eata				
Craft Co	ode	Quantity Hours			

Parts/Materials Required Part Number Description Quantity
Part Number Description Quantity
0014-03-0001-001 source cobalt 60 1
Tools/Support Equipment Required
Part Number Description Quantity
6600-02-0100-001 General FSR Tool Kit 1
3514-03-0011-001 Rad Meter 1
3514-02-0005-001 wipe test kit 2

fork lift lifting chain

ATTACHMENT B AUTHORIZED USER TRAINING RECORD AND CERTIFICATES

Alfonso Silva Harold Carter



INTEGRATED SOLUTIONS FOR A SECURE FUTURE

TO: Licensing Assistance Team; Division of Nuclear Materials Safety; U.S. Nuclear Regulatory Commission, Region I

FROM: Program Manager, Non-Intrusive Inspection Systems, STS International, Inc.

DATE: 28 April 2018

SUBJECT: Verification of VACIS Non-Routine Maintenance Procedure Training for Alfonso Silva and Harold Carter

The following STS International, Inc. employees have received VACIS Non-Routine Maintenance Procedure training for the eleven (11) procedures listed in Attachment A of this license amendment request for NRC radioactive materials license number 47-35296-01.

- 1. Alfonso Silva
 - a. OEM (SAIC) training course

i. Dates: 4-31 Aug 2007

ii. Location: SAIC training facility

b. On the Job Training

i. Dates: Apr-Sep 2014

ii. Instructor: Lloyd Thomas

iii. Location: Afghanistan, various locations

c. Radiation Safety Officer

i. Dates: 11-15 Jan 2016

ii. Instructor: Dade Moeller Training Academy

iii. Location: Gaithersburg, MD


- 2. Harold Carter
 - a. On the Job Training

i. Dates: Sep 2009-Dec 2011

- ii. Instructor: Gustavo Mariano (SAIC certified Field Support Representative)
- iii. Location: Iraq, various locations
- b. Radiation Safety Officer
 - i. Dates: 23-27 Jul 2012
 - ii. Instructor: Nevada Technical Associates, Inc.
 - iii. Location: Arlington, TX
- 3. Point of contact for this memorandum is David N. Vandivort, Program Manager, david.vandivort@stsint.com, 703-575-5185.

David N. Vandivort Program Manager STS International, Inc.

Dand NVandus





Has successfully completed the 40 hour technical short course entitled

Radiation Safety Officer

July 23, 2012 – July 27, 2012

This certificate presented in Arlington, Texas, July 27, 2012

By Nevada Technical Associates, Inc.

Approval codes for C.E. units are: ASRT 30.5 units: NVZ0146001, AAHP 32 units: 2008-00-005, ABIH 4.5 units: 08-1362

Hermon Rao

Instructor

Certificate Number: 1343026833



ACKNOWLEDGEMENT - RECEIPT OF CORRESPONDENCE

Name and Address of Applicant and/or Licensee	Date			
	May 14, 2018			
David Manage	License Number(s)			
David Morgan Vice President, Operations	47-35296-01			
STS International, Inc.	Mail Control Number(s)			
1225 South Clark Street	608763			
Suite 1300 Arlington, Virginia 22202	Licensing and/or Technical Reviewer or Branch			
	Commercial, Industrial, R&D, and Academic Branch Rec'd in RI on 05/08/18			
This is to acknowledge receipt of your: ✓ Letter and	d/or Application Dated:			
The initial processing, which included an administrative				
✓ Amendment Termination	New License Renewal			
✓ There were no administrative omissions identified	during our initial review.			
This is to acknowledge receipt of your application for renewal of the material(s) license identified above. Your application is deemed timely filed, and accordingly, the license will not expire until final action has been taken by this office.				
Your application for a new NRC license did not include your taxpayer identification number. Please complete and submit NRC Form 531, Request for Taxpayer Identification Number, located at the following link: http://www.nrc.gov/reading-rm/doc-collections/forms/nrc531.pdf Follow the instructions on the form for submission.				
The following administrative omissions have been	identified:			
Your application has been assigned the above listed MAIL CONTROL NUMBER. When calling to inquire about this action, please refer to this control number. Your application has been forwarded to a technical reviewer. Please note that the technical review, which is normally completed within 180 days for a renewal application (90 days for all other requests), may identify additional omissions or require additional information. If you have any questions concerning the processing of your application, our contact information is listed below:				
Region I U. S. Nuclear Regulatory Commission of Nuclear Materials Safety 2100 Renaissance Boulevard, Suite King of Prussia, PA 19406-2713 (610) 337-5260, (610) 337-5239	,			