S/RVs 3.4.3

SURVEILLANCE REQUIREMENTS

SURVEILLANCE			FREQUENCY
SR 3.4.3.1	4.3.1 Verify the safety function lift setpoints of the required S/RVs are as follows:		In accordance with the Inservice Testing Program
	replaced with s	erable required S/RVs may be pare OPERABLE S/RVs having until the next refueling outage.	
	Number of S/RVs	Setpoint (psig)	
	2 6 8	1175 (≥ 1140 and ≤ 1210) 1195 (≥ 1160 and ≤ 1230) 1205 (≥ 1169 and ≤ 1241)	
	Following testin	g, lift settings shall be within $\pm$ 1%.	

## SURVEILLANCE REQUIREMENTS

SURVEILLANCE			FREQUENCY
SR 3.4.3.1	Verify the safety function lift setpoints of the required S/RVs are as follows:		In accordance with the Inservice Testing Program
	NOTENOTE Up to two inoperable required S/RVs may be replaced with spare OPERABLE S/RVs having lower setpoints until the next refueling outage.		
	Number of S/RVs	Setpoint (psig)	
	2 6 8	1175 (≥ 1140 and ≤ 1210) 1195 (≥ 1160 and ≤ 1230) 1205 (≥ 1169 and ≤ 1241)	
	Following testi	ng, lift settings shall be within $\pm 1\%$ .	