



- NOTES
1. INSTALL LAYER OF 1/2" FELT BETWEEN INSIDE WEBS AND EXISTING INTAKE STRUCTURE WALL.
  2. CAULK AROUND SPAN DECK AFTER IT HAS BEEN INSTALLED.
  3. FUEL LEVEL SIGHT GLASS SHALL BE AN AUTOMATIC OIL LEVEL 1 1/2" WITH BROWN WAVE FRONT, OIL RESISTANT HOPEWELL BRAND, AND COMPLETE WITH GAUGE GLASS & GROUND RODS. SEE DETAIL.
  4. REMOVE EXISTING SIGHT LEVEL INDICATOR AND INSURE 2" PLUS.
  5. THE OPENING AROUND PIPES PENETRATING SLEEVES SHALL BE PACKED WITH A MOISTURE RESISTANT MATERIAL AND COMPLETELY SEALED.

REV. NO.	DATE	BY	CHKD.	APP. BY