

SURVEILLANCE REQUIREMENTS

SURVEILLANCE		FREQUENCY										
SR 3.4.3.1	<p>Verify the safety function lift setpoints of the safety valves are as follows:</p> <table border="0"> <thead> <tr> <th style="text-align: center;"><u>Number of Safety Valves</u></th> <th style="text-align: center;"><u>Setpoint (psig)</u></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1135 ± 34.1</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">1240 ± 37.2</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">1250 ± 37.5</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">1260 ± 37.8</td> </tr> </tbody> </table> <p>Following testing, lift settings shall be within ± 1%.</p>	<u>Number of Safety Valves</u>	<u>Setpoint (psig)</u>	1	1135 ± 34.1	2	1240 ± 37.2	2	1250 ± 37.5	4	1260 ± 37.8	In accordance with the Inservice Testing Program
<u>Number of Safety Valves</u>	<u>Setpoint (psig)</u>											
1	1135 ± 34.1											
2	1240 ± 37.2											
2	1250 ± 37.5											
4	1260 ± 37.8											
SR 3.4.3.2	Verify each relief valve actuator strokes when manually actuated.	24 months										
SR 3.4.3.3	<p>-----NOTE----- Valve actuation may be excluded. -----</p> <p>Verify each relief valve actuates on an actual or simulated automatic initiation signal.</p>	24 months										