# Simulator JPM S1

SIMULATOR JPM – 1 AG

Facility:         Davis-Besse         Task No:         001-021-01-0100				
Task Title: Transfer Control Rod Group 7 from the Auxiliary Power Supply				
K/A Reference: (001) A2.11 4.4/4.7 Job Performance Measure No: S1 (NEW)				
Examinee:				
NRC Examiner: Date:				
Method of testing:				
Simulated Performance Actual Performance _X_				
Classroom Simulator _X Plant				
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Task Standard: Transfer Group 7 Rods to the Normal Power Supply, return ICS to Auto and manually trip the Reactor prior to automatic trip				
Required Materials: DB-OP-06402, R25, Limits & Precautions and Section 4.2, Transferring Control Rod(s) from the Auxiliary Power Supply				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate Path: Yes				
Validation Time: 15 minutes				

#### **SIMULATOR INSTRUCTIONS**

## **TASK DESCRIPTION:**

Transfer Group 7 Control Rods from the Auxiliary Power Supply to the Normal Power Supply, identify undesired rod motion and trip the reactor

#### **INITIAL CONDITION:**

Plant stable at 50% power
Group 7 Control Rods on the Auxiliary Power Supply per DB-OP-06405 Section 4.1
Rod Control Panel in MANUAL
ICS REACTOR DEMAND Station in HAND

#### **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

Misalign SUPPLY PHASES between the NORMAL and AUX Power Supplies

Fail Rod Stop Button: A06A1A25S501-1 to OFF

### **MALFUNCTIONS/FAILURE TO INSERT:**

Continuous rod insertion when Reactor Demand is placed in Auto: L502U

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

Plant is stable at 50% Power Group 7 Rods are on the Auxiliary Power Supply for I&C troubleshooting Rod Control Panel in MANUAL ICS REACTOR DEMAND Station in HAND

#### **INITIATING CUES:**

I&C troubleshooting is complete

The Unit Supervisor directs you to transfer Group 7 Rods to the Normal Power Supply per DB-OP-06402, Section 4.2, Transferring Control Rod(s) from the Auxiliary Power Supply, and return the Rod Control Panel, ICS REACTOR DEMAND Station and the Unit Load Demand (ULD) station to Auto

(Provide examinee a copy of DB-OP-06402, Section 4.2)

## **CANDIDATE COPY**

## **INITIAL CONDITIONS:**

Plant is stable at 50% Power
Group 7 Rods are on the Auxiliary Power Supply for I&C troubleshooting
Rod Control Panel in MANUAL
ICS REACTOR DEMAND Station in HAND

#### **INITIATING CUES:**

I&C troubleshooting is complete

The Unit Supervisor directs you to transfer Group 7 Rods to the Normal Power Supply per DB-OP-06402, Section 4.2, Transferring Control Rod(s) from the Auxiliary Power Supply, and return the Rod Control Panel, ICS REACTOR DEMAND Station and the Unit Load Demand (ULD) station to Auto

SIMULATOR JPM – 1 AG

# **PERFORMANCE INFORMATION**

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

	STAF	RT TIME:
1.	PERFORMANCE STEP: Verify Rod Control Panel in MANUAL	
	STANDARD: Observe Rod Control Panel MANUAL light ON, AUTO light	OFF
	CUE: None	
		SAT UNSAT
2.	PERFORMANCE STEP: Verify ICS REACTOR DEMAND Station in HAN	D
	STANDARD: Observe ICS REACTOR DEMAND Station HAND light ON,	AUTO light OFF
	CUE: None	
		SAT UNSAT
3.	PERFORMANCE STEP: Verify Rod Control Panel in SEQ BYPASSC	
	STANDARD: Rod Control Panel SEQ BYPASS light ON	
	CUE: None	
		SAT UNSAT
4.	PERFORMANCE STEP: Select Group 7 using GROUP SELECT switchC	
	STANDARD: Turn GROUP SELECT switch to group 7	
	Comment: Evaluator will provide Independent Verification	
	CUE: None	
		SAT UNSAT

SIMULATOR JPM – 1 AG

5.	PERFORMANCE STEP: Select ALL using the SINGLE SELECT switchC	
	STANDARD: Turn SINGLE SELECT switch to ALL	
	Comment: Evaluator will provide Independent Verification	
	CUE: None	
		SAT UNSAT
ŝ.	PERFORMANCE STEP: Press and release AUXC	
	STANDARD: Press and release AUX pushbutton. Observe AUX light ON	
	CUE: None	
		SAT UNSAT
7.	PERFORMANCE STEP: Press and release JOG SPEEDC	
	STANDARD: Press and release JOG SPEED pushbutton. Observe JOG	SPEED light ON
	CUE: None	
		SAT UNSAT
3.	PERFORMANCE STEP: Check SUPPLY PHASES lights are ON	
	STANDARD: Observe SUPPLY PHASES lights are ON	
	CUE: None	
		SAT UNSAT
9.	PERFORMANCE STEP: Line up SUPPLY PHASESC	
	STANDARD: Position Rod Control T-Handle to the Insert position until SU lights are lined up across from each other	JPPLY PHASE
	CUE: None	
		SAT UNSAT

10.	PERFORMANCE STEP: Verify SYNC CONFIRM	
	STANDARD: Observe SYNC CONFIRM light is ON	
	CUE: None	
		SAT UNSAT
11.	PERFORMANCE STEP: Press and release CLAMPC	
	STANDARD: Press and release CLAMP pushbutton. Observe CLAMP light	nt ON
	CUE: None	
		SAT UNSAT
12.	PERFORMANCE STEP: Transfer Group to Normal Power SupplyC	
	STANDARD: Press and release MANUAL XFR button. Observe MANUAL	XFR light
	CUE: None	
		SAT UNSAT
13.	PERFORMANCE STEP: Verify Group transferred to Normal Power Supp	ly
	STANDARD: Observe PI Panel CONTROL-ON lights for Group 7 rods OF	F
	CUE: None	
		SAT UNSAT
14.	PERFORMANCE STEP: Release ClampC.	
	STANDARD: Press and release CLAMP REL button. Observe CLAMP lig	ht OFF
	CUE: None	
		SAT UNSAT
15.	PERFORMANCE STEP: Select RUN SPEEDC	
	STANDARD: Press and release RUN SPEED. Observe RUN light ON, JO	G light OFF
	CUE: None	
		SAT UNSAT

16.	PERFORMANCE STEP: Select GROUPC	
	STANDARD: Press and release GROUP. Observe GROUP light ON	
	CUE: None	
		SAT UNSAT
17.	PERFORMANCE STEP: Select XFR RESETC	
	STANDARD: Press and release XFR RESET. Observe XFR RESET light	ON.
	CUE: None	
		SAT UNSAT
18.	PERFORMANCE STEP: Verify Group 7 controlling	
	STANDARD: Observe PI panel CONTROL-ON lights for the group 7 ON	
	CUE: None	
		SAT UNSAT
19.	PERFORMANCE STEP: Select OFF using SINGLE SELECT switch	
	STANDARD: Turn SINGLE SELECT switch to OFF	
	CUE: None	
		SAT UNSAT
20.	PERFORMANCE STEP: Select OFF using GROUP SELECT switch	
	STANDARD: Turn GROUP SELECT switch to OFF	
	CUE: None	
		SAT UNSAT
21.	PERFORMANCE STEP: Select SEQ control for Regulating RodsC	
	STANDARD: Press and release SEQ. Observe SEQ light ON	
	CUE: Sequence operation of the Rod Control Panel is directed by the	Shift Manager
		SAT UNSAT

END TIME

22.	PERFORMANCE STEP: Transfer rod control to AUTO			
	STANDARD: Press and release AUTO on the Rod Control Panel. Observe AUTO light ON and MANUAL light OFF			
	CUE: None			
	SAT UNSAT			
<i>H</i> ii	NOTE: Alternate Path Starts here. When the ICS REACTOR DEMAND Station is placed in AUTO, control rods will receive a continuous IN command. The Candidate will implement the immediate actions of DB-OP-02516, CRD Malfunctions for Undesired Control Rod Motion. The ROD STOP button will be depressed and the rods will continue inserting requiring the Reactor to be tripped.			
23.	PERFORMANCE STEP: Transfer ICS Reactor Demand Station to AutoC			
	STANDARD: Press and release AUTO on the ICS REACTOR DEMAND Station. Observe AUTO red light ON and HAND white light OFF			
	CUE: None			
	SAT UNSAT			
24.	PERFORMANCE STEP: Identify Undesired rod motion depress ROD STOP			
	STANDARD: Press and hold ROD STOP button and recognize rods continue inserting			
	COMMENT: May first attempt to stop rod motion by returning Reactor Demand Station to manual which will not stop rod motion			
	CUE: None			
	SAT UNSAT			
25.	PERFORMANCE STEP: Identify Undesired rod motion and trip ReactorC			
	STANDARD: Press Reactor trip button and observe rods insert			
	CUE: None			
	SAT UNSAT			
TEF	RMINATING CUES: This JPM is complete (Terminated by the examiner)			

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S2

SIMULATOR JPM – 2 AG

Facility: Davis-Besse	Task No: 004-044-04-0100			
Task Title: Recover from Letdown Iso	olation on High Temperature			
K/A Reference: (004) A4.06 3.6/3.1	Job Performance Measure No: S2 (JPM 017			
Examinee:				
NRC Examiner:	Date:			
Method of testing:				
Simulated Performance	Actual Performance X			
Classroom Simulator _X_	Plant			
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Task Standard: Restore Letdown through Purification Demineralizer 1				
Required Materials: DB-OP-02523, Component Cooling Water System Malfunctions, Attachment 7				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate Path: No				
Validation Time: 10 Minutes				

#### SIMULATOR INSTRUCTIONS

## **TASK DESCRIPTION:**

Recover from Letdown Isolation on High Temperature

#### **INITIAL CONDITION:**

**FPSS** 

## **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

Purification Demineralizer 1 in service

MU 10A open MU 10B closed MU 1903 closed

#### **MALFUNCTIONS/FAILURE TO INSERT:**

Close CC 97, CCW Isolation Valve to Letdown Cooler 2 IRF KAD3 0.0

After Letdown isolates on high temperature then reopen CC 97 IRF KAD3 0.8

#### **ACTION/CUES**:

2. ACTION: Open MU 104, Purification Demin Bypass

**IRF BM00 1.0** 

CUE: MU 104 is open

6. ACTION: Close MU 104, Purification Demin Bypass

IRF BM00 0.0

CUE: MU 104 is closed

# **EXAMINER COPY**

## **INITIAL CONDITIONS:**

The Plant is in Mode 1

Letdown has isolated on high temperature due to a loss of CCW to Containment

## **INITIATING CUES:**

The cause of Letdown isolation has been determined and corrected

The Unit Supervisor directs you to restore Letdown through Purification Demineralizer 1 using Attachment 7 of DB-OP-02523, CCW Malfunctions

(Provide the examinee a copy of Attachment 7 of DB-OP-02523)

# **CANDIDATE COPY**

## **INITIAL CONDITIONS:**

The Plant is in Mode 1

Letdown has isolated on high temperature due to a loss of CCW to Containment

## **INITIATING CUES:**

The cause of Letdown isolation has been determined and corrected

The Unit Supervisor directs you to restore Letdown through Purification Demineralizer 1 using Attachment 7 of DB-OP-02523, CCW Malfunctions

# SIMULATOR JPM – 2 AG

# PERFORMANCE INFORMATION

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".			
	START TIME:		
	PERFORMANCE INFORMATION		
NOTE: Critical steps denoted with a "C". Failure to meet any one of standards for this item constitutes failure. Sequence is NOT required unless denoted in the "Comments".			
	START TIME:		
1.	PERFORMANCE STEP: Direct plant operator to open MU 104, PURIFICATION DEMINERALIZER BYPASS		
	STANDARD: Communicate with an Equipment Operator		
	COMMENT: Step 1 shall be completed prior to step 3		
	CUE: MU 104 is open (given by examiner – no action required)		
	SAT UNSAT		
2.	PERFORMANCE STEP: Isolate Purification Demineralizer 1C		
	STANDARD: Push close pushbutton on HIS MU10A, MIXED BED 1 LETDOWN INLET, using HISMU10A. Observe GREEN light ON. RED light off		
	CUE: None		
	SAT UNSAT		

SIMULATOR JPM – 2 AG

3.	PERFORMANCE STEP: Manually override the high temperature trip sigrC	nals	
	STANDARD: Simultaneously depress and hold in the OPEN position:		
	<ul> <li>MU2B, LETDOWN COOLERS INLET ISOLATIC HISMU2B – Observe RED light ON, GREEN OF AND</li> </ul>		
	MU1A, RC LETDOWN COOLER 1 INLET ISOLA     HISMU1A – Observe RED light ON, GREEN OF AND		
	<ul> <li>MU1B, RC LETDOWN COOLER 2 INLET ISOLA ISMU1B – Observe RED light ON, GREEN OFF</li> </ul>		
	until Annunciator 2-3-A LETDOWN TEMP HI clears less than 125°F and then release	AND TIMU8 is	
	COMMENT: The critical part of this step is that all three valves can remain open af releasing their respective control switches		
	CUE: None		
		SAT UNSAT	
4.	PERFORMANCE STEP: Restore MU System to normal valve lineupC		
	STANDARD: Push OPEN pushbutton on HIS MU10A, MIXED BED 1 LET using HISMU10A. Observe RED light ON. GREEN light off CUE: <b>None</b>	TDOWN INLET,	
		SAT UNSAT	
5.	PERFORMANCE STEP: Restore MU System to normal valve lineup		
	STANDARD: Contact EO to close MU 104, Purification Demin Bypass Va	alve	
	CUE: MU 104 is closed (given by examiner – no action required)		
		SAT UNSAT	
TE	ERMINATING CUES: This JPM is complete. (Terminated by the Examiner)		
		END TIME	

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	<u> </u>
	<u> </u>
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S3

SIMULATOR JPM – 3 AG

Facility: Davis-Besse	Task No:	005-012-04-0100		
Task Title: Start Decay Heat Removal P	Pump 1 following a loss of	DHR		
K/A Reference: (005) A2.04 2.9/2.9	Job Performance Me	asure No: S3 (NEW)		
Examinee:				
NRC Examiner:		Date:		
Method of testing:				
Simulated Performance	Actual Performance _	<u>x</u>		
Classroom Simulator _>	X_ Plant _			
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.  Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.  Task Standard: Place Decay Heat Pump 1 in service. Recognize DH14B, DH Cooler 1 Outlet valve failure and throttle downstream motor operated valve DH1B.				
Required Materials: DB-OP-02527, Rev. 18 Attachment 1				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate Path: Yes				
Validation Time: 20 minutes				

#### **SIMULATOR INSTRUCTIONS**

#### **TASK DESCRIPTION:**

Start Decay Heat Pump 1, following a loss of running Decay Heat Pump 2

#### **INITIAL CONDITION:**

Mode 5

DH Loop 1 in STBY DH Mode per DB-OP-06012, DH and LPI Operating Procedure, Section 3.5

DH Pump 2 was in service per DB-OP-06012, DH and LPI Operating Procedure, Section 3.8 (DH Loop 2 STBY DH Mode Section 3.6 completed prior to placing in service)

DH11 and DH12 open with control power removed

CC1467 closed

CCW non-essential header is being supplied from CCW Loop 1

Decay Heat Pump 2 tripped

#### ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:

Isolate CCW loads or throttle CC172, DH Cooler Outlet as required to maintain Loop 1 CCW flow less than 7800 gpm when CC1467 is opened per ATT 1 Step 6.3

Ensure Annunciator 3-2-H LP INJ 1 FLOW HI will come in when DH14B fails open, it has a variable setpoint (3750 gpm per DB-OP-06904)

Hang information tags indicating open on DH1517 and DH1518

#### **MALFUNCTIONS/FAILURE TO INSERT:**

When DH Pump 1 is started, DH Cooler 1 outlet valve, DH14B, will fail open

# **EXAMINER COPY**

## **INITIAL CONDITIONS:**

Mode 5

Decay Heat Pump 2 breaker AD112 tripped due to a 50/51 Instantaneous Overcurrent

# **INITIATING CUES:**

The Command SRO directs you to perform Attachment 1, Starting Decay Heat Pump 1 of DB-OP-02527, Loss of Decay Heat Removal

There were NO signs of cavitation on either DH Pump

(Provide examinee a copy of DB-OP-02527 Attachment 1)

# **CANDIDATE COPY**

# **INITIAL CONDITIONS:**

Mode 5, RCS Filled

Decay Heat Pump 2 breaker AD112 tripped due to a 50/51 Instantaneous Overcurrent

## **INITIATING CUES:**

The Command SRO directs you to perform Attachment 1, Starting Decay Heat Pump 1 of DB-OP-02527, Loss of Decay Heat Removal

There were NO signs of cavitation on either DH Pump

#### PERFORMANCE INFORMATION

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

START TIME: \_\_\_\_\_

1. PERFORMANCE STEP: Verify closed DH14B, DH CLR 1 OUTLET

STANDARD: Press AUTO for DH14B using HIS DH14B. Rotate knob to Close DH14B using HIC DH14B. Observe GREEN light ON, RED light OFF

COMMENT: DH14B will already be closed per standby lineup

CUE: If asked, Instrument Air is in a normal lineup

SAT UNSAT

2. PERFORMANCE STEP: Verify closed DH13B DH CLR 1 BYPASS

STANDARD: Press AUTO for DH13B using HIS DH13B. Rotate knob to Close DH13B using HIC DH13B. Observe GREEN light ON, RED light OFF

COMMENT: DH13B will already be closed per standby lineup

CUE: None

SAT UNSAT

NOTE: Decision step here to vent pump based on cavitation. The initial cue states no evidence of cavitation on either pump so venting should be marked N/A

3. PERFORMANCE STEP: Verify DH1517 is open

STANDARD: Verify DH1517 DH PUMP 1 SUCTION, is open using HIS 1517 per Operations Information Tag providing valve position

CUE: None

SAT UNSAT

4. PERFORMANCE STEP: Verify DH Drop Line valves are open using HIS DH11
And HIS DH12

STANDARD: Verify DH Drop Line valves are open using HIS DH11

And HIS DH12

CUE: None

**SAT UNSAT** 

SIMULATOR JPM - 3 AG

5. PERFORMANCE STEP: Verify Decay Heat Train 1 CCW/SW cooling is available .......C.......

STANDARD: Observes CCW Pump 1 in service. Amps indicated. RED light ON Open CC1467 using HIS1467. RED light ON, GREEN light OFF Observes SWP 1 in service. Amps indicated. RED light ON

COMMENT: Opening CC1467 is the only Critical portion of this step

CUE: If asked, CC172 has been throttled to maintain CCW flow <7800 gpm If asked, DH Pump 1 will NOT be placed on DH/LPI Injection line 2

SAT UNSAT

6. PERFORMANCE STEP: Verify DH1B is open

STANDARD: Observes HIS DH1B RED light ON, GREEN light OFF

CUE: None

SAT UNSAT

#### NOTE:

Alternate Path Starts here. When Decay Heat Pump 1 is started, DH14B will fail open. Annunciator 3-2-H LP INJ 1 FLOW HI will alarm. Alarm procedure DB-OP-02003 will be referred to and will direct throttling of DH1B to 3000 gpm.

7. PERFORMANCE STEP: Start Decay Heat Pump 1 .......C.......

STANDARD: Rotate HIS DH6B to start. Observe Decay Heat Pump 1 amps increase.

Observe RED light ON, GREEN light OFF. Release HIS DH6B.

CUE: None

SAT UNSAT

SIMULATOR JPM – 3 AG

8. PERFORMANCE STEP: Respond to Annunciator 3-2-H, LP INJ 1 FLOW HI

STANDARD: Refer to DB-OP-02003, Annunciator 3-2-H LP INJ 1 FLOW HI Recognize DH14B has failed open

COMMENT: Annunciator 3-1-H LP INJ 1 FLOW LO should have been expected.

CUE: If asked, EO reports DH14B can NOT be operated manually, indicates full open locally, no other issues noted

9. PERFORMANCE STEP: Throttle flow with DH1B .......C........

STANDARD: Press HISDH1B-2 ON to turn on DH1B control power.

Press close to throttle DH1B using HIS DH1B to stabilize RCS Temperature and monitor pump parameters

COMMENT: May initially throttle to 3000 GPM IAW Alarm procedure (DB-PF-06703 curves CC6.2 and CC6.4 not applicable)

CUE: If asked for desired flow rate, ask for recommendation

SAT UNSAT

TERMINATING CUES: This JPM is complete (Terminated by the examiner)

Appendix C

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S4

SIMULATOR JPM – 4 AG

Facility:	Davis-Bess	<u>e</u>	Task No:	039-011-04-0	0100
Task Title:	Actions for a	Steam Leak on the	Gland Steam He	eader	
K/A Referer	ո <b>ce</b> : <u>(055) 051 <i>Բ</i></u>	AA2.02 3.9/4.1 <b>Jo</b> l	o Performance l	Measure No: _	S4 (JPM 020)
Examinee:					
NRC Exami	ner:			Date:	
Method of t	esting:				
Simulated P	erformance	Act	ual Performance	e_X_	
Classroom _		Simulator X	Plan	t	
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.					
Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues					
Task Standard: Isolate steam leak in the Gland Steam Header and Initiate and Isolate SFRCS					
Required Materials: DB-OP-02525, Steam Leaks, Attachment 4 Step 9.0					
General Ref	ferences:				
Initiating Cu The plant co		ecified in the Initial C	Conditions and In	itiating Cues.	
Time Critica No	al Task:				
Alternate Pa	ath:				
Validation 1 5 Minutes	Γime:				

# **SIMULATOR INSTRUCTIONS**

#### **TASK DESCRIPTION:**

Perform actions for a steam leak on the Gland Steam Header

#### **INITIAL CONDITION:**

Place the simulator in a Mode 3 configuration with RCS pressure at 2155 psig and RCS temperature at 532 °F with Control Rod Safety groups 1-4 withdrawn

#### ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:

None

## **MALFUNCTIONS/FAILURE TO INSERT:**

- 1. On Simulator page HP & LP TURBINE DRAINS & SEAL SYSTEM TD1 fail open GS 1932 and GS 1931 to simulate a steam leak on GS.
- 2. Place simulator in run for 5 seconds then **freeze the simulation** until Examinee and Examiner are ready to start JPM
- 3. Take simulator to run after Examiner has read the initiating cue.

# **EXAMINER COPY**

## **INITIAL CONDITIONS:**

Plant is in Mode 3 with a plant startup in progress

The Reactor Coolant System is at normal operating pressure and temperature.

All systems are in a normal lineup.

#### **INITIATING CUES:**

An Equipment Operator reports a steam leak on the Gland Steam Header.

The Unit Supervisor directs you to perform step 9.0 of Attachment 4 of DB-OP-02525, Steam Leaks.

(Provide the examinee a copy of Step 9.0 of DB-OP-02525, Attachment 4)

# **CANDIDATE COPY**

## **INITIAL CONDITIONS:**

Plant is in Mode 3 with a plant startup in progress

The Reactor Coolant System is at normal operating pressure and temperature.

All systems are in a normal lineup.

# **INITIATING CUES**:

An Equipment Operator reports a steam leak on the Gland Steam Header.

The Unit Supervisor directs you to perform step 9.0 of Attachment 4 of DB-OP-02525, Steam Leaks.

# **PERFORMANCE INFORMATION**

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".			
	STA	RT TIME:	
1.	PERFORMANCE STEP: Verify GS 2384, Main Steam System Isolation	is closed	
	STANDARD: Check GREEN light ON, RED light OFF on HIS 2384		
	CUE: None.		
		SAT UNSAT	
2.	PERFORMANCE STEP: Close GS 2380, Aux Steam IsolationC		
	STANDARD: Depress CLOSE on HIS 2380. GREEN light ON, RED ligh	t OFF.	
	CUE: None.		
		SAT UNSAT	
3.	s closed		
	STANDARD: Check GREEN light ON, RED light OFF on HIS 2385		
	CUE: None.		
		SAT UNSAT	
4.	PERFORMANCE STEP: Check for steam leak isolation		
	STANDARD: Contact Equipment Operator		
	CUE: Leak has been isolated		
		SAT UNSAT	
5.	PERFORMANCE STEP: Identify that Turbine Sealing Steam is lost		
	STANDARD: Check 0 psig on PI 2340, Gland Steam Header Pressure a condenser pressure PR530 and PR541	and rising	
	CUE: None.		
		SAT UNSAT	

SIMULATOR JPM – 4 AG

6. PERFORMANCE STEP: Trip the reactor

STANDARD: Press either Reactor Trip pushbutton; Rods insert and power decreasing

CUE: None.

SAT UNSAT

7. PERFORMANCE STEP: Initiate & Isolate SFRCS

С

STANDARD: Press both SFRCS Initiate & Isolate pushbuttons.

CUE: None.

SAT UNSAT

TERMINATING CUES: This JPM is complete (Terminated by the examiner)

END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	 
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S5

SIMULATOR JPM – 5 AG

Facility:         Davis-Besse         Task No:         026-002-05-0100				
Task Title: Initiate Containment Spray				
K/A Reference: (026) A2.03 4.1/4.4 Job Performance Measure No: S5 (NEW)				
Examinee:				
NRC Examiner: Date:				
Method of testing:				
Simulated Performance Actual Performance				
Classroom Simulator _X_ Plant				
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.  Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Task Standard: Start both Containment Spray Pumps and open their respective discharge valves Stop CTMT Spray pump and close its discharge valve when leak develops				
Required Materials: DB-OP-06013 Section 5.2 and 5.3				
General References: Db-OP-02000				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate Path: Yes				
Validation Time: 15 Minutes				

# **SIMULATOR INSTRUCTIONS**

#### **TASK DESCRIPTION:**

Start both Containment Spray Pumps and open their respective discharge valves

#### **INITIAL CONDITION:**

A LOCA has occurred. Containment pressure has exceeded the SFAS Level 4 setpoint and containment spray pumps have not started.

#### **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

Insert malfunction that inhibits start of <u>both</u> containment spray pumps and opening of CS discharge valves. Both containment spray pump discharge valves, (CS1530 and CS1531) are closed.

#### **MALFUNCTIONS/FAILURE TO INSERT:**

Insert pipe rupture in Train 2 Containment Spray Header when Containment Spray Pump 2 is started

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

A LOCA has occurred. Containment pressure has exceeded the SFAS Level 4 setpoint and containment spray pumps have not started

#### **INITIATING CUES**:

The Unit Supervisor has directed you to manually start Containment Spray pumps 1 and 2 and spray containment in accordance with DB-OP-06013, Section 5.2 and 5.3

(Provide examinee a copy of DB-OP-06013, Section 5.2 and 5.3)

# **CANDIDATE COPY**

#### **INITIAL CONDITIONS:**

A LOCA has occurred. Containment pressure has exceeded the SFAS Level 4 setpoint and containment spray pumps have not started

#### **INITIATING CUES:**

The Unit Supervisor has directed you to manually start Containment Spray pumps 1 and 2 and spray containment in accordance with DB-OP-06013, Section 5.2 and 5.3

# SIMULATOR JPM - 5 AG

#### PERFORMANCE INFORMATION

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

	START TIME:				
Not	lote: Spray pumps can be started in either sequence. If CTMT Spray Pump 2 is selected to be started first, go to step 5 and return following step 13.				
1.	PERFORMANCE STEP: Verify DH7B, BWST ISOLATION VALVE, is OPEN				
	STANDARD: Observes DH7B RED light ON, GREEN light OFF				
	CUE: None				
	SAT UNSAT				
2.	PERFORMANCE STEP: OPEN CS1530, CTMT SPRAY DISCHC				
	STANDARD: Presses OPEN on HIS 1530. Observes RED light ON, GREEN light OFF				
	CUE: None				
	SAT UNSAT				
3.	PERFORMANCE STEP: Start CTMT SPRAY PUMP 1C				
	STANDARD: Rotates HIS 1533 to Start and releases. Observes amp increase, RED light ON and GREEN light OFF.				
	CUE: None				
	SAT UNSAT				
4.	PERFORMANCE STEP: Verify flow indicated on FI1547, CS PUMP 1 DISCH FLOW				
	STANDARD: Observe flow indication between 1100 GPM and 1900 GPM. Acknowledge Alarms 3-1-J, CS PMP 1 DISCH FLOW LO, and 3-3-J CS PMP 1 DISCH FLOW HI. Observe alarm annunciators extinguish.				
	CUE: None				
	SAT UNSAT				

Note: If CTMT Spray Pump 2 was started first. JPM is complete.

5.	PERFORMANCE STEP: Verify DH7A, BWST ISOLATION VALVE, is OPEN
	STANDARD: At SFAS panel verifies that DH7A GREEN light OFF and RED light ON
	CUE: None
	SAT UNSAT
6.	PERFORMANCE STEP: OPEN CS1531, CTMT SPRAY DISCH
	STANDARD: Presses OPEN on HIS 1531. Observes RED light ON, GREEN light OFF
	CUE: None
	SAT UNSAT
7.	PERFORMANCE STEP: Start CTMT SPRAY PUMP 2C
	STANDARD: Rotates HIS 1532 to Start and releases. Observes amp increase, RED light ON and GREEN light OFF
	CUE: None
	SAT UNSAT
8.	PERFORMANCE STEP: Verify flow indicated on FI1535, CS PUMP 2 DISCH FLOW
	STANDARD: Observe flow above 1900 GPM. Acknowledge Alarms 3-2-J, CS PMP 2 DISCH FLOW LO, and 3-4-J CS PMP 2 DISCH FLOW HI. Observe alarm 3-2-J extinguishes and 3-4-J CS PMP 2 DISCH FLOW HI remains in alarm (light ON).
	CUE: None
	SAT UNSAT
	NOTE: Alternate Path Starts here. When the CTMT Spray Pump 2 is started a leak will develop in Train 2 CTMT Spray Header. Alarm 3-4-J will sound and Alarm Panel 3 Procedure DB-OP-02003 will direct stopping CTMT Spray Pump 2 and closing CS1531.
9.	PERFORMANCE STEP: Respond to Alarm 3-4-J, CS PMP 2 DISCH FLOW HI
	STANDARD: Locate Alarm Panel 3 Procedure DB-OP-02003 for alarm 3-4-J
	CUE: None
	TAPINITAP

10.	PERFORMANCE STEP: Check for flow rate high at FI 1535 located on Panel C5716
	STANDARD: Observe flow above 1900 GPM alarm setpoint
	CUE: None
	SAT UNSAT
11.	PERFORMANCE STEP: Check the Containment Spray Header 2 outside Containment for a piping break or leak
	STANDARD: Contact Equipment Operator to look for leaks
	CUE: Equipment Operator reports "water is spraying from the CTMT Spray line just upstream of CS 1531, CTMT Spray Discharge Valve."
	SAT UNSAT
12.	PERFORMANCE STEP: Stop CTMT Spray Pump 2C
	STANDARD: Turn HIS 1532 to Stop and release. Observe amps decrease with GREEN light ON and RED light OFF
	COMMENT: May press block push button but SFAS is failed for this pump
	CUE: None
	SAT UNSAT
13.	PERFORMANCE STEP: Close CS 1530, CTMT Spray Discharge ValveC
	STANDARD: Press Close on HIS 1530. Observe GREEN light ON and RED light OFF
	COMMENT: May press block push button but SFAS is failed for this pump
	CUE: None
	SAT UNSAT
	ΓΕ: If CTMT Spray Pump 2 was started first, return to step 1 for placing CTMT Spray np 1 in service.
TEF	RMINATING CUES: This JPM is complete (Terminated by the examiner)
	END TIME

# **Verification of Completion**

Job Performance Measure No		
Examinee's Name:		
Examiner's Name:		
Date Performed:		
Facility Evaluator:		
Number of Attempts:	-	
Time to Complete:		
Question Documentation:		
Question:		
Response:		
Result: Satisfactory/Unsatisfactory		
Examiner's signature and date:		

# Simulator JPM S6

SIMULATOR JPM – 6 AG

Facility:	avis-Besse	Task N	lo:	062-005-01-	-0100
Task Title:	Transfer Essential 4160	0 Kv Bus C1 only	to Alte	rnate	
K/A Reference: (	062) A4.01 3.3/3.1	Job Performa	nce M	easure No: _	S6 (JPM 084)
Examinee:			_		
NRC Examiner: _			<u>-</u>	Date:	
Method of testing	<u>1:</u>				
Simulated Perform	nance	Actual Perform	nance _	X	
Classroom	Simulator _ <u>)</u>	<u>X</u>	Plant _		
I will explain the in	Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions The plant condition	: ns are specified in the Ir	nitial Conditions a	nd Initi	iating Cues.	
Task Standard: Transfer C1 bus o	nly to Alternate				
Required Materia DB-OP-06315 Sec	ls: ctions 3.27 with prerequ	isites completed			
General Reference None	ces:				
Initiating Cue: The plant condition	ns are specified in the Ir	nitial Conditions a	nd Initi	iating Cues.	
Time Critical Tas No	k:				
Alternate Path: No					
Validation Time: 9 Minutes					

#### **SIMULATOR INSTRUCTIONS**

# **TASK DESCRIPTION:**

Transfer C1 only to Alternate (BD Transformer)

# **INITIAL CONDITION:**

Mode 1

Normal system lineup

# **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

None

# **MALFUNCTIONS/FAILURE TO INSERT:**

None

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

The Plant is in Mode 1

All systems are in a normal lineup

# **INITIATING CUES**:

The Unit Supervisor directs you to perform a live transfer of Bus C1 ONLY from the normal to the alternate power supply, using Section 3.27 of DB-OP-06315, 4160 V Switching Procedure.

(Provide examinee Section 3.27 of DB-OP-06315, 4160 V Switching Procedure with prerequisites completed)

# **CANDIDATE COPY**

# **INITIAL CONDITIONS:**

The Plant is in Mode 1

All systems are in a normal lineup

#### **INITIATING CUES:**

The Unit Supervisor directs you to perform a live transfer of Bus C1 ONLY from the normal to the alternate power supply, using Section 3.27 of DB-OP-06315, 4160 V Switching Procedure.

#### **PERFORMANCE INFORMATION**

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

	STAF	RT TIME:
1.	PERFORMANCE STEP: Notifies Shift Manager to refer to Tech Specs	
	STANDARD: Notifies Shift Manager to refer to Tech Specs	
	CUE: The Shift Manager is referring to Tech Specs	
		SAT UNSAT
2.	PERFORMANCE STEP: Close ABDC1, BUS TIE XFMR BD and holdC	
	STANDARD: Positions HIS 6220, ABDC1 to CLOSE and holds in the clo Observes breaker ABDC1 RED light ON, GREEN light OFF	
	CUE: None	
		SAT UNSAT
3.	PERFORMANCE STEP: Open AC110, BUS TIE FROM C2 BUSC	
	STANDARD: Positions HIS 6223, AC 110 to OFF and releases. Observe ON, RED light OFF	s GREEN light
	CUE: None	
		SAT UNSAT
4.	PERFORMANCE STEP: Release HIS 6220, ABDC1	
	STANDARD: Release HIS 6220	
	CUE: None	
		SAT UNSAT
TE	RMINATING CUES: This JPM is complete (Terminated by the examiner)	
		END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S7

SIMULATOR JPM – 7 AG

Facility:         Davis-Besse         Task No:         016-001-01-0100				
Task Title: Exchange RC flow Inputs to RPS Channel 2				
K/A Reference: (016) A4.01 2.9/2.8 Job Performance Measure No: S7 (JPM 048)				
Examinee:				
NRC Examiner: Date:				
Method of testing:				
Simulated Performance Actual Performance				
Classroom Simulator _X Plant				
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Task Standard: Transfer RC Flow Inputs for the Computer and NNI from RPS Channel 1 to RPS Channel 2				
Required Materials:  DB-OP-06403, Reactor Protection System (RPS) and Nuclear Instrumentation System (NI) Operating Procedure, Section 4.3 DB-OP-06407, Non-Nuclear Instrumentation System Operating Procedure, Section 4.2				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate Path: No				
Validation Time: 20 Minutes				

#### SIMULATOR INSTRUCTIONS

# **TASK DESCRIPTION:**

Exchange RC Flow Inputs to the Computer and NNI from RPS channel 1 to RPS Channel 2

# **INITIAL CONDITION:**

4 RCPs in operation

# **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

NNI Flow Inputs selected to RPS Channel 1

#### **MALFUNCTIONS/FAILURE TO INSERT:**

None

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

Maintenance is planned for RPS Channel 1 RCS flow instrumentation

The RC Flow inputs are selected from RPS Channel 1

# **INITIATING CUES:**

The Unit Supervisor directs you to exchange RC flow inputs (Computer and NNI) to RPS Channel 2 in accordance with section 4.3 of DB-OP-06403, RPS and NI Operating Procedure

(Provide the examinee a copy of section 4.3 of DB-OP-06403)

# **CANDIDATE COPY**

#### **INITIAL CONDITIONS:**

Maintenance is planned for RPS Channel 1 RCS flow instrumentation

The RC Flow inputs are selected from RPS Channel 1

# **INITIATING CUES**:

The Unit Supervisor directs you to exchange RC flow inputs (Computer and NNI) to RPS Channel 2 in accordance with section 4.3 of DB-OP-06403, RPS and NI Operating Procedure

#### PERFORMANCE INFORMATION

	NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".			
	STAF	RT TIME:		
1.	PERFORMANCE STEP: Locate correct procedure step			
	STANDARD: Mark step 4.3.1 N/A. Begin with step 4.3.2 in DB-OP-06403	3		
	CUE: None			
		SAT UNSAT		
2.	PERFORMANCE STEP: Remove cap on Selection Panel for the alternaC	te RC flow ∆p		
	STANDARD: Locate the selection panel in RPS Channel 2 and rotate the counterclockwise to remove the cap	e cap		
	CUE: None			
		SAT UNSAT		
3.	PERFORMANCE STEP: Disconnect the amphenol connector from RC flC Sub-assembly and reconnect to alternate RC fl			
	STANDARD: Unscrew the amphenol connector from RPS Channel 1 inp RPS Channel 2 RC flow $\Delta p$ input	ut and screw in to		
	CUE: None			
		SAT UNSAT		
4.	PERFORMANCE STEP: Cap the open receptacle			
	STANDARD: Replace cap on the open receptacle			
	CUE: None			
		SAT UNSAT		

5. PERFORMANCE STEP: Administratively document the amphenol exchange in Unit Log

STANDARD: Document RPS Channel 2 supplying NNI in the procedure and inform Control Room to enter in Unit Log

CUE: Another Operator will make the entry in the Unit Log

	SIMULATOR JPM – 7 AG
	SAT UNSAT
6.	PERFORMANCE STEP: Remove the Tave SASS Instrument string from automatic
	STANDARD: Refer to section 4.2 of DB-OP-06407, Non-Nuclear Instrumentation System Operating Procedure
	CUE: Provide the examinee a copy of section 4.2 of DB-OP-06407
	SAT UNSAT
7.	PERFORMANCE STEP: Select the instrument string to be testedC
	STANDARD: Take the test selector switch for Loop 2 Tave and Loop 1 Tave to the "A" or "B" position AND hold
	CUE: There is no suspected problem with the instrument string
	SAT UNSAT
8.	PERFORMANCE STEP: Release the test selector switchC
	STANDARD: Test selector switch released after the Yellow MISMCH light is LIT
	CUE: None
	SAT UNSAT
9.	PERFORMANCE STEP: Verify green AUTO light is OFF for instrument pair in test
	STANDARD: Check that the Green AUTO light is OFF
	CUE: None
	SAT UNSAT
10.	PERFORMANCE STEP: Remove the cap on the Selection Panel for the alternate RCC
	STANDARD: Rotate the cap counterclockwise to remove the cap
	CUE: None
	SAT UNSAT

SIMULATOR JPM – 7 AG

11.	PERFORMA	NCE STEP: Disconnect amphenol receptacle for RC flow a to alternate RC flow NNI ∆p receptacle	nd reconnect
	STANDARD	: Unscrew amphenol connector from RPS Channel 1 input a RPS Channel 2 RC flow $\Delta p$ NNI	and screw in to
	CUE:	None	
			SAT UNSAT
12.	PERFORMA	NCE STEP: Cap the open receptacle	
	STANDARD	: Replace cap on the open receptacle	
	CUE: None		
			SAT UNSAT
13.	PERFORMA	NCE STEP: Administratively document the amphenol excha	ange in Unit Log
	STANDARD	: Document RPS Channel 2 supplying NNI in the procedure Room to enter in Unit Log	and inform Control
	CUE: Anot	her Operator will make the entry in the Unit Log	
			SAT UNSAT
TEF	rminating C	CUES: This JPM is complete (Terminated by the examiner)	
			END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# Simulator JPM S8

SIMULATOR JPM – 8 AG

Facility: Davis-Besse	Task No: 029-003-01-0100				
Task Title: Purge Containment in Mode 5					
K/A Reference: (016) A2.03 2.7/3.1 Job Pe	erformance Measure No: S8 (JPM 162)				
Examinee:					
NRC Examiner:					
Method of testing:					
	Performance X				
Simulated Ferformance Actual	r enormance <u>X</u>				
Classroom Simulator X_	Plant				
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.  Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.  Task Standard: Place Containment Purge in service on Containment					
Required Materials: DB-OP-06503, Containment Purge System (entire procedure), with Section 3.1 prerequisites completed					
General References: None					
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.					
Time Critical Task: No					
Alternate Path: No					
Validation Time: 12 Minutes					

#### **SIMULATOR INSTRUCTIONS**

#### **TASK DESCRIPTION:**

Place Containment Purge in service on Containment

#### **INITIAL CONDITION:**

Mode 5

#### **ADDITIONAL SETUP/DEVIATION FROM INITIAL CONDITION:**

Turn off CTMT Purge Supply and Exhaust Fans Close dampers CV 5004, 5016, 5009 and 5021 Install fuses in SFAS cabinets Verify dampers CV 5005, 5006, 5007, and 5008 are closed

#### **MALFUNCTIONS/FAILURE TO INSERT:**

None

#### **ACTION/CUES**:

None

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

The plant is in Mode 5.

#### **INITIATING CUES**:

The Unit Supervisor directs you to start a purge of the Containment Vessel in accordance with section 3.1 of DB-OP-06503, Containment Purge System Procedure.

The Incore Instrument Tank will NOT be purged.

(Provide the examinee a copy of DB-OP-06503, prerequisites completed)

# **CANDIDATE COPY**

# **INITIAL CONDITIONS:**

The plant is in Mode 5.

#### **INITIATING CUES:**

The Unit Supervisor directs you to start a purge of the Containment Vessel in accordance with section 3.1 of DB-OP-06503, Containment Purge System Procedure.

The Incore Instrument Tank will NOT be purged.

# SIMULATOR JPM - 8 AG

# **PERFORMANCE INFORMATION**

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

	START TIME:
1.	PERFORMANCE STEP: Make a plant announcement.
	STANDARD: Use the GAITRONICS to announce "Attention all station personnel, starting the containment vessel purge".
	CUE: None
	SAT UNSAT
2.	PERFORMANCE STEP: Open the purge CTMT isolation valve CV5008C
	STANDARD: Press the OPEN pushbutton on HIS 5008. RED light ON, GREEN light OFF
	COMMENT: Sequence NOT required.
	CUE: None
	SAT UNSAT
3.	PERFORMANCE STEP: Open the purge CTMT isolation valve, CV5006C
	STANDARD: Press the OPEN pushbutton on HIS 5006. RED light ON, GREEN light OFF
	COMMENT: Sequence NOT required.
	CUE: None
	SAT UNSAT
4.	PERFORMANCE STEP: Open the purge CTMT isolation valve, CV5005C
	STANDARD: Press the OPEN pushbutton on HIS 5005. RED light ON, GREEN light OFF
	COMMENT: Sequence NOT required.
	CUE: None
	SAT UNSAT

5.	PERFORMANCE STEP: Open the purge CTMT isolation valve, CV5007C		
	STANDARD: Press the OPEN pushbutton on HIS 5007. RED light ON,	GREEN light OFF	
	COMMENT: Sequence NOT required.		
	CUE: None		
		SAT UNSAT	
6.	PERFORMANCE STEP: Start CTMT purge exhaust fanC		
	STANDARD: Turn handswitch HIS 5013, to START.		
	CUE: None		
		SAT UNSAT	
7.	PERFORMANCE STEP: Verify CTMT Purge Exhaust fan starts.		
	STANDARD: Verifies HIS 5013 RED light ON, GREEN light OFF.		
	COMMENT: The fan will start in approximately 120 seconds.		
	CUE: None.		
		SAT UNSAT	
8.	PERFORMANCE STEP: Start the CTMT purge supply fanC		
	STANDARD: Within 20 seconds after the exhaust fan is running, turn ha HIS 5003 to START.	and switch	
	CUE: None		
		SAT UNSAT	
9.	PERFORMANCE STEP: Verify CTMT Purge Supply fan starts.		
	STANDARD: HIS 5003 RED light ON, GREEN light OFF.		
	CUE: None		
		SAT UNSAT	
TEF	RMINATING CUES: This JPM is complete (Terminated by the examiner)		

# SIMULATOR JPM – 8 AG

END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# In Plant JPM P1

PLANT JPM – 1 AG

Facility:	Davis-Besse	_ Task No:	001-011-05-0100	
Task Title:	Perform Attachment 5 of Cor	ntrol Room Evacuation	n per DB-OP-02508	
K/A Refere	nce: (004) AA1.06 4.1/4.2	Job Performance M	easure No: P1 (JPM 006)	
Examinee:				
NRC Exami	ner:		Date:	
Method of t	esting:			
Simulated P	erformance X	Actual Performance		
Classroom _	Simulator	Plant _	<u>X</u> _	
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Task Standard: Isolate Letdown, start the Standby Makeup Pump and transfer both Makeup Pump suctions to the BWST from outside the Control Room				
Required Materials: DB-OP-02508, Control Room Evacuation, Attachment 5				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial Conditions and Initiating Cues.				
Time Critical Task: No				
Alternate P	ath:			
Validation 1 15 Minutes	Гіте:			

# **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

A hazardous condition has forced the evacuation of the Control Room

There is NO fire in the Control Room area

ONLY the Immediate Actions of Trip the Reactor and Initiate and Isolate SFRCS were performed prior to evacuation

Makeup Pump 1 is running

#### **INITIATING CUES:**

The Unit Supervisor directs you to perform Attachment 5 of DB-OP-02508, Control Room Evacuation

You have an emergency key ring

The Zone 3 Operator has been provided Attachment 6 and Attachment 7 for controlling the Atmospheric Vent Valves

(Provide the examinee a copy of Attachment 5 of DB-OP-02508)

#### **CANDIDATE COPY**

### **INITIAL CONDITIONS:**

A hazardous condition has forced the evacuation of the Control Room

There is NO fire in the Control Room area

ONLY the Immediate Actions of Trip the Reactor and Initiate and Isolate SFRCS were performed prior to evacuation

Makeup Pump 1 is running

#### **INITIATING CUES:**

The Unit Supervisor directs you to perform Attachment 5 of DB-OP-02508, Control Room Evacuation

You have an emergency key ring

The Zone 3 Operator has been provided Attachment 6 and Attachment 7 for controlling the Atmospheric Vent Valves

PLANT JPM – 1 AG

## PERFORMANCE INFORMATION

	TE: Critical steps denoted with a "C". Failure to meet any one of these standards for this nonstitutes failure. Sequence is NOT critical unless denoted in the "Comments".
	START TIME:
1.	PERFORMANCE STEP: Dispatch the Zone 3 operator to establish local manual control of the AVVs
	STANDARD: Sign off step per initial conditions
	CUE: None
	SAT UNSAT
2.	PERFORMANCE STEP: Isolate LetdownC
	STANDARD: Close MU 2B, REACTOR COOLANT LETDOWN COOLER INLET ISOLATION, using the local switch on Breaker BE 1172 on MCC E11B. Observe Green light ON Red light OFF
	CUE: Local switch (on BE 1172) has been placed in CLOSE. Green light goes ON Red light goes OFF
	SAT UNSAT
3.	PERFORMANCE STEP: Start the standby Makeup PumpC
	STANDARD: Press local START Button on NP0372B for Makeup Pump 2 Main Oil Pump (AC). Observe Green light OFF Red light ON
	CUE: Local START button (on NP0372B) for Makeup Pump 2 Main Oil Pump has been pressed. Green light goes OFF, Red light goes ON
	SAT UNSAT

4.	PERFORMANCE STEP: Start the standby Makeup Pump
	STANDARD: Check Main Oil Pump discharge pressure >15 psig on PI MU106A
	CUE: PI MU106A reads 23 psig
	SAT UNSAT
5.	PERFORMANCE STEP: Start the standby Makeup Pump
	STANDARD: Check MU Pump 2 Aux. Gear LO pump started at NP0372D. Observe Red light is LIT on NP0372D
	CUE: Red light is LIT on NP0372D
	SAT UNSAT
6.	PERFORMANCE STEP: Start the standby Makeup PumpC
	STANDARD: CLOSE/START pressed on NP0372A to START Makeup Pump 2. Observe Green light goes OFF, Red light goes ON
	CUE: CLOSE/START has been pressed on NP0372A.  Green light goes OFF, Red light goes ON
	SAT UNSAT
7.	PERFORMANCE STEP: Align makeup pumps suction to the BWSTC
	STANDARD: NV 3971 switch placed in BWST position. Observe Bottom Red light goes OFF, Top Red light goes ON
	CUE: Switch NV 3971 has been placed in BWST position Bottom Red light goes OFF, Top Red light goes ON
	SAT UNSAT
8.	PERFORMANCE STEP: Align makeup pumps suction to the BWSTC
	STANDARD: NV 6405 switch placed in the BWST position. Observe Bottom Red light goes OFF, Top Red light goes ON
	CUE: Switch NV 6405 has been placed in the BWST position Bottom Red light goes OFF, Top Red light goes ON
	SAT UNSAT

PLANT JPM – 1 AG

9. PERFORMANCE STEP: Proceed to the Radwaste Panel and establish communications with the Unit Supervisor

STANDARD: Communications established with the Unit Supervisor from the Radwaste Panel

CUE: Communications have been established

SAT UNSAT

TERMINATING CUES: This JPM is complete (Terminated by the examiner)

END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	

# In Plant JPM P2

PLANT JPM – 2 AG

Facility: Davis-Besse	Task No: 062-094-01-0401			
Task Title: Restore EDG to supply 416	) Essential Bus per DB-OP-02538			
K/A Reference: (064) AA1.03 3.1/3.3 Jo	b Performance Measure No: P2 (JPM 079)			
Examinee:				
NRC Examiner:	Date:			
Method of testing:				
Simulated Performance X Ac	tual Performance			
Classroom Simulator	Plant X			
Read to the examinee:  I will explain the initial conditions, which steps to simulate or discuss, and provide initiating cues. When you complete the task successfully, the objective for this job performance measure will be satisfied.				
Initial Conditions: The plant conditions are specified in the Initial	Conditions and Initiating Cues.			
Task Standard: Restore power to D1 from EDG 2				
Required Materials: DB-OP-02538, Loss of D2P and DBP, Attachm Picture of top and bottom inside cubicle 13 D1				
General References: None				
Initiating Cue: The plant conditions are specified in the Initial	Conditions and Initiating Cues.			
Time Critical Task: No				
Alternate Path: No				
Validation Time: 22 Minutes				

## **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

The plant has experienced a loss of all AC Power and a loss of essential DC Panel D2P

Bus D1 is de-energized

Emergency Diesel Generator 2 is not running

#### **INITIATING CUES:**

The Unit Supervisor directs you to restore Emergency Diesel Generator 2 to supply Bus D1 in accordance with Attachment 6: RESTORE POWER TO D1 BUS FROM EDG 2 of DB-OP-02538, Loss of D2P and DBP

(Provide a copy of DB-OP-02538 Attachment 6)

## **CANDIDATE COPY**

#### **INITIAL CONDITIONS:**

The plant has experienced a loss of all AC Power and a loss of essential DC Panel D2P

Bus D1 is de-energized

Emergency Diesel Generator 2 is not running

#### **INITIATING CUES:**

The Unit Supervisor directs you to restore Emergency Diesel Generator 2 to supply Bus D1 in accordance with Attachment 6: RESTORE POWER TO D1 BUS FROM EDG 2 of DB-OP-02538, Loss of D2P and DBP

PLANT JPM – 2 AG

## PERFORMANCE INFORMATION

NOTE: Critical steps denoted with a "C". Failure to meet any one of these standards for this item constitutes failure. Sequence is NOT critical unless denoted in the "Comments".

	START TIME:
1.	PERFORMANCE STEP: Open D2P07
	STANDARD: Place breaker D2P07 in the OFF position. Turn the key to extend the plunger and remove the key
	CUE: D2P07 is in OFF.  Key has been turned and removed, the plunger is extended
	SAT UNSAT
2.	PERFORMANCE STEP: Open D2P05
	STANDARD: Place breaker D2P05 in the OFF position. Turn the key to extend the plunger and remove the key
	CUE: <b>D2P05</b> is in <b>OFF</b> .  Key has been turned and removed, the plunger is extended
	SAT UNSAT
3.	PERFORMANCE STEP: Open D2P09
	STANDARD: Place breaker D2P09 in the OFF position. Turn the key to extend the plunger and remove the key
	CUE: <b>D2P09</b> is in <b>OFF</b> .  Key has been turned and removed, the plunger is extended
	SAT UNSAT

4.	PERFOC	RMANCE STEP: Close D2N07	
	STAND	ARD: Insert the key and turn to retract the plunger. Place breaker D2N07 in the ON position.	
		is inserted and turned, plunger is retracted N07 has been placed in ON	
			SAT UNSAT
5.	PERFO	RMANCE STEP: Close D2N05	
	STAND	ARD: Insert the key and turn to retract the plunger. Place breaker D2N05 in the ON position.	
	-	is inserted and turned, plunger is retracted	
			SAT UNSAT
6.	PERFO <b>C</b>	RMANCE STEP: Close D2N09	
	STAND	ARD: Insert the key and turn to retract the plunger. Place breaker D2N09 in the ON position.	
		is inserted and turned, plunger is retracted	
			SAT UNSAT
7.	PERFO	RMANCE STEP: Verify the DC control power source disconnect busses DBP and DBN are closed	t switches on
	STAND	ARD: Verify the DC breakers are in the ON position	
	COMME	NT: * DBP07 is in the ON position is the ONLY critical step	
	CUE:	DBN02 is in the ON position DBN04 is in the ON position DBP02 is in the ON position DBP04 is in the ON position *DBP07 is in the ON position DBP11 is in the ON position	
			SAT UNSAT

8. PERFORMANCE STEP: Transfer D1 control power to alternate .......C.......

STANDARD: Place knife switch in Cubicle 13 of D1 bus to ALTERNATE position

CUE: Provide picture of top and bottom of inside of cubicle (door cannot be opened when bus is energized unless breaker is in the racked out position due to Arc Flash concerns). If wrong cubicle is selected "you see fuse blocks and terminal strips in the top of the cubicle".

Knife switch is placed in ALTERNATE

SAT UNSAT

9. PERFORMANCE STEP: Verify D1 load breakers are tripped

STANDARD: Check the following breakers OPEN using indicating lights, mechanical indicators or communicate with the control room (GREEN light is LIT/position indicator at OPEN):

AD 112, LPI/DH Pump 2 (HIS DH 6A)

AD 111, HPI Pump 2 (HIS 1523)

AD 110, Bus D1 Normal Feed (HIS 6233)

AD 107, SW Pump 2 (HIS 1371) **OR** AD 109, SW Pump 3 as 2 (HIS 1372B)

AD 105, Makeup Pump 2 (HIS MU24B)

AACD1, XFRMR XBD to BUS D1 (HIS 6230)

#### CUE:

AD112, GREEN light is LIT/position indicator at OPEN OR HIS DH6A GREEN light is LIT.

AD111, GREEN light is LIT/position indicator at OPEN OR HIS 1523 GREEN light is LIT.

AD110, GREEN light is LIT/position indicator at OPEN OR HIS 6233 GREEN light is LIT

AD107 (AD109) GREEN light is LIT/position indicator at OPEN

OR HIS 1371(1372B) GREEN light is LIT.

AD109, NO lights lit/breaker racked OUT

OR HIS NO lights lit

AD105, GREEN light is LIT/position indicator at OPEN OR HIS MU24B GREEN light is LIT.

AACD1, GREEN light is LIT/position indicator at OPEN

, GREEN light is LIT/position indicator at OPEN OR HIS 6230 GREEN light is LIT.

SAT UNSAT

PLANT JPM – 2 AG

10.	PERFORMANCE STEP: Open CB1C	
	STANDARD: Breaker CB1 is placed in OFF in Panel C3616	
	CUE: Breaker CB1 is in OFF	
		SAT UNSAT
11.	PERFORMANCE STEP: Close CB2C	
	STANDARD: Breaker CB2 is placed in ON in Panel C3616. Expects EDG	2 start.
	CUE: CB2 is in ON. Emergency Diesel Generator 2 has started	
		SAT UNSAT
12.	PERFORMANCE STEP: Verify Emergency Diesel Generator 2 starts and	loads D1 Bus
	STANDARD: Check indications of Emergency Diesel Generator 2 start.  Breaker AD101 Red light ON  Speed at SI 6232A is 900 RPM  Voltage at DG 2 VOLTS (P1-1076) is 4160 VAC  KW load indicated on KW meter	
	CUE: EDG 2 has started and loading is in progress	
		SAT UNSAT
ΓEF	RMINATING CUES: This JPM is complete (Terminated by the examiner)	
		END TIME

# **Verification of Completion**

Job Performance Measure No		
Examinee's Name:	-	
Examiner's Name:	-	
Date Performed:	-	
Facility Evaluator:	-	
Number of Attempts:	-	
Time to Complete:		
Question Documentation:		
Question:		
Response:		
Result: Satisfactory/Unsatisfactory		
Examiner's signature and date:		

# In Plant JPM P3

PLANT JPM – 3 AG

Facility:	Davis-Besse	е	_ Task No:_	078-010-04-0400
Task Title:	Bypass and Iso	olate the In Ser	vice Air Dryers per [	DB-OP-02528, IA Malfunctions
K/A Refere	nce: (078) AA2	.03 2.6/2.9	Job Performance	Measure No: <u>P3 (078)</u>
Examinee:				
NRC Exami	iner:			Date:
Method of 1	testing:			
Simulated P	erformance X		Actual Performance	e
Classroom <sub>-</sub>		Simulator	. Plar	ıt X
I will explain	omplete the task	•	•	cuss, and provide initiating cues. job performance measure
Initial Cond The plant co		cified in the Init	ial Conditions and Ir	nitiating Cues.
Task Stand Bypass and	ard: I Isolate the In Se	ervice Instrume	ent Air Dryers	
Required M DB-OP-025		ir System Malfu	unctions, Step 4.2.2	and Attachment 20
<b>General Re</b> None	ferences:			
Initiating C The plant co		cified in the Init	ial Conditions and Ir	nitiating Cues.
Time Critic	al Task:			
<b>Alternate P</b> No	ath:			
Validation 10 Minutes	Time:			

## **EXAMINER COPY**

#### **INITIAL CONDITIONS:**

The plant is operating at 100% power

Both sets of Instrument Air Dryers are in service due to high air usage

#### **INITIATING CUES:**

The Control Room announces Instrument Air pressure is lowering

The Unit Supervisor directs you to perform Attachment 20 of DB-OP-02528 to bypass and isolate the in service air dryers

(Provide examinee a copy of Attachment 20 from DB-OP-02528, Instrument Air System Malfunctions)

## **CANDIDATE COPY**

## **INITIAL CONDITIONS:**

The plant is operating at 100% power

Both sets of Instrument Air Dryers are in service due to high air usage

### **INITIATING CUES**:

The Control Room announces Instrument Air pressure is lowering

The Unit Supervisor directs you to perform Attachment 20 per step 4.2.2 of DB-OP-02528 to bypass and isolate the in service air dryers

## PERFORMANCE INFORMATION

NOTE: Critical steps de	noted with a "C".	Failure to meet	any one of	these standards	for this
item constitutes failure.	Sequence is NO	Γ critical unless	denoted in	the "Comments	".

	START TIME:
1.	PERFORMANCE STEP: Bypass Instrument Air Dryers 3 & 4C
	STANDARD: Open IA 411, IA Dryers 3 & 4 Bypass to Receiver, by rotating handle parallel to pipe
	CUE: Handle for IA 411 has been placed parallel to pipe
	SAT UNSAT
2.	PERFORMANCE STEP: Isolate Instrument Air Dryers 3 & 4C
	STANDARD: Close IA 419, IA Dryers 3 & 4 Inlet Isolation by rotating handle perpendicular to pipe
	CUE: Handle for IA 419 has been placed perpendicular to pipe
	SAT UNSAT
3.	PERFORMANCE STEP: Isolate Instrument Air Dryers 3 & 4C
	STANDARD: Close IA 413, IA Dryers 3 & 4 Outlet Isolation by rotating handle perpendicular to pipe
	CUE: Handle for IA 413 has been placed perpendicular to pipe
	SAT UNSAT
4.	PERFORMANCE STEP: De-energize Instrument Air Dryers 3 & 4
	STANDARD: Place HIS 5941, Dryers 3 & 4 On/Off Switch in OFF. Observe GREEN light ON and RED light OFF
	CUE: HIS 5941 is in OFF. GREEN light is ON and RED light is OFF
	SAT UNSAT

PLANT JPM – 3 AG

5.	PERFORMANCE STEP: Bypass Instrument Air Dryers 1 & 2C	
	STANDARD: Open IA 289, IA Dryers 1 & 2 Bypass to Receiver, by rotation to pipe	ng handle parallel
	CUE: Handle for IA 289 has been placed parallel to pipe	
		SAT UNSAT
6.	PERFORMANCE STEP: Isolate Instrument Air Dryers 1 & 2C	
	STANDARD: Close IA 24, IA Dryers 1 & 2 Inlet Isolation, by rotating hand to pipe	dle perpendicular
	CUE: Handle for IA 24 has been placed perpendicular to pipe	
		SAT UNSAT
7.	PERFORMANCE STEP: Isolate Instrument Air Dryers 1 & 2C	
	STANDARD: Close IA 31, IA Dryers 1 & 2 Outlet Isolation, by rotating ha to pipe	ndle perpendicular
	CUE: Handle for IA 31 has been placed perpendicular to pipe	
		SAT UNSAT
8.	PERFORMANCE STEP: De-energize Instrument Air Dryers 1 & 2	
	STANDARD: Place HIS 5940, Dryers 1 & 2 On/Off Switch in OFF. Obser ON and RED light OFF	ve GREEN light
	CUE: HIS 5940 is in OFF. GREEN light is ON and RED light is OFF	
		SAT UNSAT
TEF	RMINATING CUES: This JPM is complete (Terminated by the examiner)	
		END TIME

# **Verification of Completion**

Job Performance Measure No	
Examinee's Name:	
Examiner's Name:	
Date Performed:	
Facility Evaluator:	
Number of Attempts:	
Time to Complete:	
Question Documentation:	
Question:	
Response:	
Result: Satisfactory/Unsatisfactory	
Examiner's signature and date:	