



NOTES:

1. TWO MOMENTARY CONTROLS. OPERATING EITHER CONTROL WILL ACTUATE ALL APPLICABLE DIVISIONS.
2. COMPONENTS ARE ALL INDIVIDUALLY SEALED IN (LATCHED), SO THAT LOSS OF THE ACTUATION SIGNAL WILL NOT CAUSE THESE COMPONENTS TO RETURN TO THE CONDITION HELD PRIOR TO THE ADVENT OF THE ACTUATION SIGNAL.
3. SEPARATE MOMENTARY CONTROLS, ONE FOR EACH APPLICABLE DIVISION.
4. DIVISIONS A AND B ONLY.
5. TWO MOMENTARY CONTROLS. OPERATING EITHER CONTROL WILL CAUSE THE REACTOR TRIP FUNCTION TO BE ACTUATED IN EACH OF THE FOUR DIVISIONS.

WILLIAM STATES LEE III  
 NUCLEAR STATION UNITS 1 & 2  
 FUNCTIONAL DIAGRAM CONTAINMENT  
 AND OTHER PROTECTION