NIAGARA MOHAWK POWER CORPORATION 07-189-91 NINE MILE POINT NUCLEAR STATION UNIT II OPERATIONS 02-REQ-001-215-2-08 (Ops) Revision 5 TITLE: REDUNDANT REACTIVITY CONTROL SYSTEM (RRS) SIGNATURE DATE 24/91 PREPARER TRAINING AREA 7/24/91 SUPERVISOR TRAINING SUPPORT SUPERVISOR .25.91 25/91 PLANT SUPERVISOR/ JBHELKAL USER GROUP SUPERVISOR Summary of Pages (Effective Date: 7/25/91 ) Number of Pages: 34 <u>Pages</u> Date ງກູນອອ 34 P THIS LESSON WRITE 1 NG DEPARTMENT RECORDS ADMINE TRÂTIÔN 152 15 1 2015 3 ERIFICATION: 10 A ENTRY 35pp 2/4/58

9305040058 911031 PDR ADDCK 05000410 PDR

**PDR** 

÷.

• •

### I. TRAINING DESCRIPTION

- A. Title of Lesson: Redundant Reactivity Control System (RRS)
- B. Lesson Description: This lesson contains information pertaining to the Redundant Reactivity Control System. The scope of the training is defined by the learning objectives and in general covers the knowledge requirement of a Licensed Control Room Operator.
- C. Estimate of the Duration of the Lesson: 2 hours
- D. Method of Evaluation, Grade Format, and Standard of Evaluation: Written exam, passing grade of 80% or greater
- E. Method and Setting of Instruction: This lecture should be conducted in the classroom.
- F. Prerequisites:
  - 1. Instructor:
    - a. Certified in accordance with NTP-16.
  - 2. Trainee:
    - a. Licensed Operator Requal In accordance with the requirements of NTP-11.
- G. References:
  - 1. Technical Specifications
    - a. 3.3.4.1 ATWS Recirc. Pump Trip Instrumentation
    - b. 3.1.5 Standby Liquid Control System
  - 2. Procedures
    - a. N2-OP-36b, Redundant Reactivity Control
    - b. N2-EOP-6, EOP Support Procedure
    - c. N2-OSP-LOG-S001, Shift Checks, Mode 1
    - d. N2-ISP-RRS-@101, Alt. ATM St.Pt and Gross Failure Cal.
    - e. N2-EOP-RPV, Reactor Control EOP
  - 3. NMP2-USAR Vol. 16, Section 7.6
  - 4. Drawings
    - a. GE Print ELEM944E309TY RRS

#### II. <u>REQUIREMENTS</u>

- A. AP-9, Administration of Training
- B. NTP-11, Licensed Operator Requalification Training

02-REQ-001-215-2-08 -1 June 1991

UNIT 2 OPS/2403

,

**`** 

.

.

## III. TRAINING MATERIALS

- A. Instructor Materials:
  - 1. Classroom/whiteboard and markers
  - 2. Lesson plan 02-LOT-001-294-2-08, RRS
  - 3. TR
  - 4. Transparencies
  - 5. Overhead projector
  - 6. References 1,2a & 2b
  - 7. Op. Tech Chapter RRS
- B. Trainee Materials:
  - 1. Op Tech. Chapter RRS
  - 2. Pens, pencils, paper `
  - 3. Course evaluation sheet as appropriate

# IV. EXAM AND MASTER ANSWER KEYS

- A. Exams will be generated and administered as necessary.
- B. Exams and master answer keys will be on permanent file in the Records Room.

UNIT 2 OPS/2403

T. T.

· .

r

.

•

#### V. LEARNING OBJECTIVES

A. Terminal Objectives:

Upon satisfactory completion of this lesson, the trainees will demonstrate the knowledge to: Start Up from inoperable the RRCS System. (2949010101) TO-1.0 Reset an ARI initiation signal at Panel TO-2.0 P-603. (2949020101) (2949040101) TO-3.0 Manually initiate ARI from the Relay Room. Manually initiate RRCS from the Control Room TO-4.0 (2949050401) Panel P-603. Verify operation of the RRCS auto-initiation TO-5.0 (2949060401) for high reactor pressure. Verify operation of the RRCS auto-initiation TO-6.0 (2949070401) for reactor low water level. (2949110101) Disable a feedwater runback caused by RRCS. TO-7.0 (2949120101) Respond to a RRCS Test Fault. TO-8.0 TO-9.0 (SRO ONLY)Direct the actions for Alternate (3449880403) Rod Insertion.

O2-REQ-001-215-2-08 -3 June 1991

UNIT 2 OPS/2403



· · · · . .

• •

.

. ,

x

.

2

B. Enabling Objectives:

EO-1.0 Explain the purpose and function of the Redundant Reactivity Control System (RRCS).

EO-2.0 Describe the purpose and function of each of the major components of the RRCS system listed below:

a. Control Panel on P-603

- b. Relay Room Panels C22-P001, and C22-P002
- c. RRCS Logic
- d. ARI Valves
- e. APRMs
- EO-3.0 Describe the locations of the RRCS System controls and indicating lights.

EO-4.0 State the setpoint and describe the purpose of the following interlocks:

- a. ARI initiation
- b. RCS pump down shift and trip
- c. FW runback
- d. SLS initiation

EO-5.0

- .0 Describe the RRCS indications that would be observed following:
  - a. RPV pressure greater than RRCS setpoint
  - b. RPV water level less than RRCS setpoint
  - c. Rx. power not downscale after 25 seconds and RRCS initiated
  - d. Rx. power not downscale after 98 séconds and RRCS initiated
  - e. Manual initiation
  - f. RRCS test fault occurs
- EO-6.0 Given a specific set of plant conditions, determine how the RRCS system responds.
- EO-7.0 Describe how the RRCS system is utilized during the performance of the EOP's.

02-REQ-001-215-2-08 -4 June 1991

UNIT 2 OPS/2403

· · 

.

EO-8.0 Describe the interrelationship of the following systems with the RRCS system:

- a. Electrical distribution
- b. Standby Liquid Control (SLS)
- c. Control Rod Drive (RDH)
- d. Reactor Recirculation (RCS)
- e. Feedwater Control (FWS)
- f. Reactor Vessel Instrumentation (RVI)
- g. Neutron Monitoring (NMS)
- EO-9.0 Explain the basis for each precaution and limitation listed in N2-OP-36B RRCS.
- EO-10.0 Regarding the RRCS system, determine and use the correct procedure to identify the actions and/or locate information related to the following:
  - a. Startup
  - b. Shutdown
  - c. Normal Operations
  - d. Off-Normal operations
  - e. Annunciator responses
- EO-11.0 Given NMP2 Technical Specifications and a set of plant conditions, determine the appropriate bases, limiting conditions for operation, limiting safety system setting, and/or action statement as applicable.
- EO-12.0 Regarding the RRCS system, 1) locate the correct drawing and 2) use drawings to perform the following:
  - a. Identify electrical and mechanical components
  - b. Trace the flowpath of fluids or electricity
  - c. Identify interlocks and setpoints
  - d. Describe system operation
  - e. Locate information about specific components
  - f. Identify system interrelations

02-REQ-001-215-2-08 -5 June 1991

UNIT 2 OPS/2403

· • .

• •

.





EO-1

### I. INTRODUCTION

Student Learning Objectives

A. <u>Purpose</u>

The Redundant Reactivity Control System (RRCS) is a system designed in conjunction with other systems to prevent and/or to mitigate the potential consequences of an Anticipated Transient Without Scram (ATWS) event.

- B. <u>Design Basis</u>
  - An ATWS event is an extremely low probability event requiring a multi-system malfunction.
  - Ultimate goal of RRCS is Rx. Shutdown to ensure long term core cooling capability and meeting clad oxidation limits.
  - 3. RRCS functions to prevent an ATWS by initiating an ARI and/or mitigates the consequences of by reducing reactivity levels in the core by FW Runback, RCS pump down shifts/trips, and boron injection (SLS).

Show TP of objectives Passout TR and Evaluation Forms Inform trainees of method of evaluation

Examples of ATWS Events

1. Closure of MSIVs

- 2. Failure of Control Rods to insert
- 3. Loss of feed leading to low RPV level.
- 4. Turbine Trip

These are ECCS design criteria as outlined by 10CFR50.46

. × . . 1 **x** 

ы.

·

• •



79



C. <u>General Description</u>

• •

- RRCS was designed to ease the severity of an Anticipated Transient Without Scram (ATWS).
  - a. Serves as a backup to the CRD System.
  - b. Provides alternate methods of Rx. Scram.
- 2. Actuation Signals
  - a. RRCS actuated by:
    - Rx. vessel high dome pressure (1050 psig), or
    - 2) Rx. vessel low-low water level (108.8") or
    - 3) Manually
- Reactivity control is effected by one or more functions.
  - a. The Alternate Rod Insertion (ARI) is intended to prevent an ATWS condition by depressurizing the scram discharge air header through valves separate from the RPS scram valves.
  - b. If ARI does not lower reactor power sufficiently, Reactor Recirculation pump motors will be tripped.
  - c. If power level remains high, a Feedwater System runback occurs.
  - d. If power level is still too high, SLS will inject borated water (poison) into the Rx. vessel.

02-REQ-001-215-2-08 -7 June 1991

Ask students the definition of reactivity.

x ĸ . п , n , , .

UNIT 2 OPS/2403

- II. DETAILED DESCRIPTION
  - A. <u>Redundant Reactivity Control System</u> (RRCS)
    - 1. Consists of:

n ,

- a. Two RRCS control panels: C22-P001 and C22-P002, their associated ATWS detection and actuation logic and the necessary interface logic to perform specific functions in response to an ATWS event.
- A control panel for manual initiation of the RRCS located in the Control Room on P-603.
- RRCS has two Divisions of the logic: Division 1, 2.
  - a. Each division has two channels A, B.
  - b. Each channel acts identically.
  - c. Each channel has a manual High RPV pressure, and Low RPV water level logics
- B. Alternate Rod Insertion (ARI)
  - ARI is the preventive aspect of RRCS. It Provides a parallel means of rapid control rod insertion.
- Indicate to students that each of the preventive/ mitigating functions will be covered individually, to be tied altogether later.

Show Transparency of Figure 4

Only one division of RRCS required to activate to cause RRCS initiation.
Both channels in a division must activate for that division to activate.
Show Transparency of Figure 2
This is a <u>energize</u> to function logic system.



DELIVERY NOTES

LESSON CONTENT

ECTIVES/

E0-3

ð -N , . . 

•

, а

LESSON CONTEN	NT		BELIVERY NOTES	NOTES
2.	. ARI	[ initiation signals	• •	EO-4
	a.	High dome pressure, Low-low water level, or Manual	•Dome pressure of 1050 psig •RPV water level 108.8"	EO-6
	b.	When received, 8 RRCS-ARI valve solenoids are <u>energized</u> .	8 valves assumes both divisions of RRCS has activated.	EO-2
	c.	This seals in for a minimum of 30 seconds to ensure that all control rods have time to insert fully.	<ul> <li>•30 seconds allows time for the Scram Air Header to depressurize and the slowest control rod to fully insert (00 position)</li> <li>•Valves remain energized until the reset pushbuttons on P-603 are depressed.</li> </ul>	
	d.	<ul> <li>With the RRCS - ARI valves energized the following occurs.</li> <li>i) VLVs 162 and 163 energize as long as one energizes it will reposition to block and vent the scram air header, if one of these vlv's do not reposition the header will still be depressurized through the check vlv installed around the vlv's.</li> <li>2) Vlv's 156 through 159 energize open to vent off the branches of the scram air header.</li> </ul>	Show Transparency of Figure 3. Discuss operation of ARI values	

•

£

02-REQ-001-215-2-08 -9 June 1991

-

· · . .

.

. • ·

4

ESSON CONTENT		DELIVERY NOTES	NOTES
	<ol> <li>3) Vlv's 160 and 161 energize open to vent the air off the SDV drain and vent vlv's causing them to close.</li> <li>4) All vlv's are sized such that the Control Rods will begin inserting approx. 15 sec. after the vlv's are energized.</li> </ol>	<ul> <li>Ask students, why it is important to have the SDV vent and drain valves go closed?</li> </ul>	
3.	<ul> <li>Local initiation of ARI from Relay Room panels C22-P001 and/or C22-P002.</li> <li>a. Keylock switches 2SA and 2SC (Div. I) 2SB and 2SD (Div. II) are both taken to the "ON" position this will insert two test signals into the ARI logics resulting in an ARI with no other RRCS functions from that division.</li> <li>b. Verify at P-603 "RRCS ARI INITIATE" light is on.</li> </ul>	Keylock switches are located in the center cabinet of each division (P001-2 and P002-2) (3 cabinets total)	EO-3
4.	<ul> <li>Indications expected during an ARI only.</li> <li>a. Manual from Relay Room <ol> <li>P-603 Indications</li> <li>ARI INT light at RRCS control panel on the Division that was manually activated.</li> </ol> </li> <li>2) Relay Room Panel(s) indications <ol> <li>ARI INIT'D light at C22-P002-2</li> </ol> </li> </ul>	Show Transparency of Figure 4 to indicate which lights will come on. These indicators will be on the center cabinet C22-P002-2.	EO-5
	02-REQ-001-215-2-08 -10 June 1991		

.

•

UNIT 2 OPS/2403

•

4

-

۰. ¢ ,

. 1

.

1

×

•

-

. · · · ·

.

.

•

·

x

pressure condition

CTIVES NOTES

VLV's F160B, F162B, F162D, b) F163B, RED lighted at C22-P002-2.

#### с. Recirculation Pump Transfer/Trip

- 1. This transfer/trip will result in a rapid flow reduction. The reduction in flow will result in the void fraction increasing, inserting negative reactivity, reducing Rx. power.
- 2. High-to-low speed transfer of RCS pumps.
  - Creates voids inserting negative · a. reactivity.
  - Reduces power generation. b.
    - Initiation signal 1)
      - A high vessel dome pressure a) signal. (1050 psig)
      - Either RRCS division will trip •This function only occurs on a high RPV b) the RRS pumps from their normal power supplies to their low speed LFMG sets.
      - Div. I RRCS trips the 3A and c) **3B** circuit breakers Div. II RRCS trips the 4A and 4B circuit breakers

#### 3. **RRCS** indications

- a. MCR P-603 panel
  - 1) LFMG TRANSFER lights

Assumption on the indications is that both divisions have activated. The ARI INT lights on P-603 will also be lighted

Show Transparency of Figure 2 trace logic.

EO-4

EO-2

E0-6

E0-5

02-REQ-001-215-2-08 -11 June 1991 ۹ . . . 

n

. Ŧ ۰.

ESSON CONTENT			DELIVERY NOTES	NOTES
		Relay Room Panels ) LFMG XFER lights	C22-P001-2, C22-P002-2	EO-5
	3	<ol> <li>POTENT ATWS lights</li> <li>CONFIRM ATWS lights</li> <li>RRCS TROUBLE lights</li> <li>RPV DOME PRESSURE HIGH CHANNEL A,</li> </ol>	The ARI INIT'D lights at the POO panels will also be lighted	
	ť	CHANNEL B lights 5) VLVs F160A(B), F162A(B, C, D), F163A(B)		z.,
4.	a. N	culation Pump Trip (RPT) Mitigates the consequences of an ATWS event by tripping the RCS pumps early	Transparency of Figure 2 Trace Logic	EO4
v	b	in the event to reduce core flow. Initiation signals 1) A vessel low-low water level signal (108.8").	-	EO-6
	:	OR 2) After a high pressure RRCS initiation if APRM power is <u>not</u> downscale or INOP 25 seconds after the initiation.	-	
	:	3) Either RRCS Division will trip the RCS pumps from their normal power supplies by opening the RCS pump motor breakers.	Either division will trip the 1A, 1B, 2A and 2B circuit breakers.	

.

.

02-REQ-001-215-2-08 -12 June 1991

•

х • • ۰ **۰** ·

4\* \*

,

SSON CONTENT		DELIVERY NOTES	ECTIVES NOTES
5.	RRCS Indications a. MCR P-603 Panel 1) LFMG Transfer lights	<ul> <li>Assumption on the indications is that both divisions have activated.</li> <li>The ARI INT lights at P-603 will also be lighted.</li> </ul>	EO-5
	<ul> <li>b. Relay Room Panels</li> <li>1) LFMG XFER lights</li> <li>2) POTENT ATWS lights</li> <li>3) CONFIRM ATWS lights</li> <li>4) RRCS TROUBLE lights</li> <li>*5) RECIRC PUMP TRIP lights</li> <li>*6) RPV WATER LEVEL LOW CHANNEL A, CHANNEL B lights</li> <li>7) VLVs F160A(B), F162A(B,C,D), F163A(B) red lights.</li> </ul>	<ul> <li>C22-P001-2, C22-P002-2</li> <li>The ARI INIT'D lights at the P00 panels will also be lighted.</li> </ul>	
D. <u>RCS</u> 1.	<u>LFMG Trip</u> Is part of the RCS pump trip aspect of RRCS. a. Serves the same mitigating function.	Transparency of Figure 2 trace through logic	EO-4
2.	<ul> <li>Initiating signals that trip the LFMG 15 Hz power:</li> <li>a. Rx vessel low-low water level</li> <li>b. 25 seconds after a high vessel dome pressure signal occurs and a sufficient power reduction (APRM not downscale or INOP) has not occurred.</li> </ul>		EO-6

.

, . • . . • ۵ ۱ • • · •

.


ESSON CONTENT	DELIVERY NOTES	ECTIVES NOTES
3.	Either RRCS division will trip the RCS pumps from their low-speed power supply by opening breakers 1A/B and 2A/B.	÷
4.	RRCS indications a. Same as described in B.5.	EO-5
E. <u>Fee</u> 1.	water Runback This function mitigates the consequences of Show Transparency of Figure 2 an ATWS event by stopping feedwater flow trace through the logic into the Rx vessel which reduces the core subcooling.	E0-4
2.	<ul> <li>Initiation signal</li> <li>a. A high vessel dome pressure signal</li> <li>b. Starts a 25-second Time Delay (TD) timer.</li> <li>c. After 25 seconds, if the APRM power level has not been reduced below the</li> </ul>	EO-6
	<ul> <li>APRM downscale level or INOP:</li> <li>1) Then the Feedwater Control Valve(s) will be runback to 0% flow (fully shut) by the Feedwater control logic AND the Rx Feedpumps minimum flow valves will be opened.</li> <li>A solenoid vlv other than the standard min. flow vlv control solenoid is energized to open the min. flow vlvs.</li> <li>All FW control vlvs (LV137, 55A/B, LV10A/B/C)</li> <li>This feature bypass LV10A/B/C lockout device function to close valves.</li> </ul>	
	02-REQ-001-215-2-08 -14 June 1991	

UNIT 2 OPS/2403

. ı

. ,







- Feedwater Control will be shifted from Auto to Manual and remain in Manual.
- 3) This occurs for both the Manual and Automatic mode of feedwater control.
- The runback will be completed within 15 seconds of receipt of the RRCS signal.
- 5) Control of the Feedwater System is returned to the operators 25 seconds after the FW Runback signal is initiated: <u>FW control</u> will be in manual.
- 6) This function may be inhibited manually to prevent severe plant transients during surveillance testing.
  - a) Inhibit switch is located on Panel 603.
  - b) Switch operation is controlled administratively.

- •Point out that if power is still being generated Rx Water level will continue to decrease.
- Point out switch contacts on Figure 2 Transparency
- Ann 603430 alarms when this switch is taken to EO-5 off.

. x

· • . · · 

*.* 

4

.

. .

\*

•







- 3. RRCS Indications
  - a. MCR P-603
    - 1) FW RUNBACK INT lights
  - b. Relay Room Panels
    - 1) LFMG XFER lights
    - 2) POTENT ATWS lights
    - 3) CONFIRM ATWS lights
    - 4) RRCS TROUBLE lights
    - 5) RPV DOME PRESSURE HIGH CHANNEL A, CHANNEL B, lights
    - 6) VLVs F160A(B), F162A (B, C, D), F163A(B) red lights
    - 7) FW R BACK INT'D lighted
    - 8) RECIRC pump trip

# F. <u>Standby Liquid Control System (SLS)</u>

- If control rod insertion does <u>not</u> shutdown the Rx, SLS will automatically inject borated water into the Rx vessel (after a time delay) to:
  - a. Stop the fission process
  - b. Achieve a hot S/D condition
  - Eventually allow a cold S/D condition to be reached.

•ARI INT lights will be lighted •C22-P001-2 & C22-P002-2

۰.

ARI INIT'D lights will be lighted at the POO panels.

E0-5

.

1. .

-

.

\$



DELIVERY NOTES



EO-6

- 2. Initiation Signals
  - a. High vessel dome pressure or,
  - b. Low-low vessel water level (<u>not sealed</u> <u>in</u>) (108.8") or,
  - c. Manual (P603). AND Rx. power not downscale or APRMs Inop.
- 3. Actions
  - a. A 98 second timer starts when an RRCS initiation signal is first received.
  - b. After 98 seconds, if the initiation signal is still present and a sufficient power reduction (APRM not downscale) has not occurred or APRM
    INOP then RRCS will initiate SLS.
  - c. Either RRCS division can initiate SLS.
- 4. SLS Operation
  - a. Injection point is CSH line.

02-REQ-001-215-2-08

- b. Manual SLS pump initiation or an RRCS automatic signal will isolate WCS.
  - Prevents WCS system from diluting or cleaning up the borated solution.
  - WCS isolation signal is sealed-in as long as an SLS initiation signal is present.

-17

June 1991

Transparency of Figure 2 trace logic.

. . . . • • . 4 ` . •

r.





- 5. RRCS Indications
  - a. MCR P-603
    - 1) None
  - b. Relay Room Panels
    - 1) RWCU ISOLATE
    - 2) POTENT ATWS
    - 3) CONFIRM ATWS
- G. <u>Average Power Range Monitors (APRM's)</u>
  - APRM's provide a reactor power signal to the RRCS permissive logic.
  - 2. APRM Downscale Trip Signal
    - a. If present, this signal informs RRCS that APRM indicated power has dropped low enough to represent a sufficient power reduction for ATWS purposes.

## 3. RRCS Permissive Signal

- a. Generated if APRM power is above the downscale trip level if the affected APRM is not bypassed.
- b. Permits:
  - 1) Feedwater runback,
  - 2) LFMG trip,
  - 3) Boron injection

ARI INT lights plus others as plant conditions EO-5 vary will be on.
C22-P001-2, C22-P002-2

ARI INIT'D lights plus others as plant conditions vary will be on.

E0-2

•Signal generated by APRM downscale trip unit, set pt. 4% or less.

. • , . . \* \* \* \* , . · • ۵ . • • • •

<ul> <li>c. Also generated by an APRM inoperative condition, if the affected APRM is not bypassed.</li> <li>4. APRM assignments <ul> <li>a. RRCS Div. I</li> <li>b. Channel A</li> <li>APRMS A and E</li> <li>c) Channel B</li> <li>APRMS B and F</li> </ul> </li> <li>b. RRCS Div. II <ul> <li>channel A</li> <li>APRMS C and E</li> <li>channel B</li> <li>APRMS C and E</li> <li>channel B</li> <li>APRMS D and F</li> </ul> </li> <li>1. INSTRUMENTATION, CONTROLS AND INTERLOCKS <ul> <li>A. OUT OF SERVICE</li> <li>SLS storage tank level, &lt; 0</li> <li>gallons (Div. I/TI)</li> <li>Loss of 125 VDC power supply to Channel A are 8 loris of</li> </ul> </li> </ul>	SON CONTENT	·		DELIVERY NOTES	NOTES
<ul> <li>4. APRM assignments drawer mode switch not in "Operate",</li> <li>a. RRCS Div. I drawer module unplugged.</li> <li>1) Channel A APRMS A and E</li> <li>2) Channel B APRMS B and F</li> <li>b. RRCS Div. II</li> <li>1) Channel A APRMS C and E</li> <li>2) Channel B APRMS C and E</li> <li>2) Channel B APRMS D and F</li> </ul> 1. INSTRUMENTATION, CONTROLS AND INTERLOCKS A. <u>Instrumentation</u> Show Transparency of Table 2 E0-5 1. Indicating Lights located on P603 one matrix per Div. <ul> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 one light per division gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>		c.			
<ul> <li>a. RRCS Div. I drawer module unplugged.</li> <li>a. PRMS A and E</li> <li>b. Channel B</li> <li>APRMS B and F</li> <li>b. RRCS Div. II</li> <li>b. RRCS Div. II</li> <li>channel A</li> <li>APRMS C and E</li> <li>channel B</li> <li>APRMS D and F</li> </ul> INSTRUMENTATION, CONTROLS AND INTERLOCKS A. <u>Instrumentation</u> Show Transparency of Table 2 E0-5 1. Indicating Lights located on P603 one matrix per Div. <ul> <li>a. OUT OF SERVICE</li> <li>j) SLS storage tank level, &lt; 0</li> <li>gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>			bypassed.	unit, set pts: less than 14 LPRM inputs,	
<ul> <li>1) Channel A APRMS A and E</li> <li>2) Channel B APRMS B and F</li> <li>b. RRCS Div. II</li> <li>1) Channel A APRMS C and E</li> <li>2) Channel B APRMS D and F</li> <li>. INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A. Instrumentation Natrix often referred to as the "rubics cube" per Div.</li> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>	4.	APRM			
APRMS A and E 2) Channel B APRMS B and F b. RRCS Div. II 1) Channel A APRMS C and E 2) Channel B APRMS C and E 2) Channel B APRMS D and F  . INSTRUMENTATION, CONTROLS AND INTERLOCKS A. Instrumentation 1. Indicating Lights located on P603 one matrix per Div. a. OUT OF SERVICE 1) SLS storage tank level, < 0 gallons (Div. I/II) 2) Loss of 125 VDC power supply to		a.	RRCS Div. I	drawer module unplugged.	
<ul> <li>2) Channel B APRMS B and F</li> <li>b. RRCS Div. II</li> <li>1) Channel A APRMS C and E</li> <li>2) Channel B APRMS D and F</li> <li>INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A Instrumentation Show Transparency of Table 2 EO-5</li> <li>1. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 One light per division gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>					
APRMS B and F b. RRCS Div. II 1) Channel A APRMS C and E 2) Channel B APRMS D and F . INSTRUMENTATION, CONTROLS AND INTERLOCKS A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div. a. OUT OF SERVICE 1) SLS storage tank level, < 0 gallons (Div. I/II) 2) Loss of 125 VDC power supply to			APRMS A and E		,
<ul> <li>b. RRCS Div. II</li> <li>1) Channel A APRMS C and E</li> <li>2) Channel B APRMS D and F</li> <li>INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>			2) Channel B		
<ul> <li>1) Channel A APRMS C and E</li> <li>2) Channel B APRMS D and F</li> <li>. INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>			APRMS B and F		
APRMS C and E 2) Channel B APRMS D and F . INSTRUMENTATION, CONTROLS AND INTERLOCKS A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div. a. OUT OF SERVICE 1) SLS storage tank level, < 0 gallons (Div. I/II) 2) Loss of 125 VDC power supply to		b.	RRCS Div. II		
<ul> <li>2) Channel B APRMS D and F</li> <li>INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE</li> <li>1) SLS storage tank level, &lt; 0 gallons (Div. I/II)</li> <li>2) Loss of 125 VDC power supply to</li> </ul>			1) Channel A	-	
APRMS D and F INSTRUMENTATION, CONTROLS AND INTERLOCKS A. <u>Instrumentation</u> 1. Indicating Lights located on P603 one matrix per Div. a. OUT OF SERVICE 1) SLS storage tank level, < 0 gallons (Div. I/II) 2) Loss of 125 VDC power supply to			APRMS C and E		
<ul> <li>INSTRUMENTATION, CONTROLS AND INTERLOCKS</li> <li>A. <u>Instrumentation</u></li> <li>Show Transparency of Table 2</li> <li>EO-5</li> <li>1. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE         <ol> <li>SLS storage tank level, &lt; 0</li> <li>Gallons (Div. I/II)</li> <li>Loss of 125 VDC power supply to</li> </ol> </li> </ul>			2) Channel B		
<ul> <li>A. <u>Instrumentation</u></li> <li>A. Indicating Lights located on P603 one matrix per Div.</li> <li>a. OUT OF SERVICE</li> <li>b) SLS storage tank level, &lt; 0 One light per division gallons (Div. I/II)</li> <li>c) Loss of 125 VDC power supply to</li> </ul>			, APRMS D and F	2	
<ol> <li>Indicating Lights located on P603 one matrix Matrix often referred to as the "rubics cube" per Div.</li> <li>a. OUT OF SERVICE         <ol> <li>SLS storage tank level, &lt; 0</li> <li>One light per division</li> <li>gallons (Div. I/II)</li> <li>Loss of 125 VDC power supply to</li> </ol> </li> </ol>	. INSTRUMEN		N, CONTROLS AND INTERLOCKS		
per Div. a. OUT OF SERVICE 1) SLS storage tank level, < 0 One light per division gallons (Div. I/II) 2) Loss of 125 VDC power supply to	A. Inst	trumen	tation	Show Transparency of Table 2	EO-5
a. OUT OF SERVICE 1) SLS storage tank level, < 0 One light per division gallons (Div. I/II) 2) Loss of 125 VDC power supply to	1.	Indi	cating Lights located on P603 one matrix	Matrix often referred to as the "rubics cube"	
<ol> <li>SLS storage tank level, &lt; 0 One light per division gallons (Div. I/II)</li> <li>Loss of 125 VDC power supply to</li> </ol>		per l	Div.		
gallons (Div. I/II) 2) Loss of 125 VDC power supply to		a.	OUT OF SERVICE		
2) Loss of 125 VDC power supply to			<ol> <li>SLS storage tank level, &lt; 0</li> </ol>	One light per division	
			gallons (Div. I/II)		
Channal A or P logic			2) Loss of 125 VDC power supply to		
Chamiler A of B royac			Channel A or B logic		

02-REQ-001-215-2-08 -19 June 1991

.

-

۰ ۰ ۰

4

-.

H,





EO-5

b. MANUAL INT

Manual Init. Switches armed and depressed.

- c. ARI INT ARI signal present.
- ARI READY TO RESET
   30 seconds have elapsed since ARI initiation.
- e. FW RUNBACK INT RRCS Runback signal to FWS logic.
- f. READY TO RESET

10 minute timer has timed out, for total elapsed time of 10 minutes and 98 seconds.

- g. LFMG TRANSFER
- h. TEST FAULT
- 2. Relay Room Panels
  - a. RPV DOME PRESSURE HIGH
    Channel A, Channel B
    1) RPV dome press. ≥ 1050 psig
  - B. RPV WATER LEVEL LOW
     Channel A, Channel B
    - 1) RPV water level <u><</u> 108.8" (L2)
  - c. POTENT ATWS
    - 1) RPV level < 108.8" (L2)
    - 2) RPV pressure > 1050 psig

02-REQ-001-215-2-08 -20 June 1991

UNIT 2 OPS/2403

Emphasize 10 minutes <u>plus</u> the 98 second timer.

Since both divisions are identical with exception of vlvs operated only one division will be listed here in the lesson plan a complete listing is in Table 4.

• • • • • . .

, . .

•



.

EO-5


- One or both Divisional Manual Initiation switches armed and depressed.
- d. ARI INT'D
  - RRCS ARI logic satisfied and energized.
- e. RWCU ISOLATE
  - RRCS signal to the RWCU system to isolate present.
- f. CONFIRM ATWS
  - RPV pressure ≥ 1050 psig
  - 2) RPV level <u><</u> 108.8" (L2)
  - One or both Divisional Manual Initiation switches armed and depressed.
- g. RRCS READY FOR RESET
  - 1) Ten minute timer has timed out.
- h. MANUAL INIT SWITCH ARMED
  - Manual initiation switch arming collar rotated to the armed position.
- i. MANUAL INITIATION
  - Divisional initiation switches armed and depressed.

02-REQ-001-215-2-08 -21 June 1991

, .

k





- j. ARI READY FOR RESET
  - 30 seconds timer has timed out after initiation.
- k. TEST FAULT
  - Failure sensed in sensors, logics, or protective devices.
- 1. ATM CALI GROSS FAILURE
  - 1) Analog trip module failure.
- m. RRCS TROUBLE
  - One or more of the items listed under the ANN. Response. See Table 4.
- n. LFMG XFER
  - 1) RRCS logic for LFMG transfer to slow speed energized.
- o. RECIRC PUMP TRIP
  - RRCS logic for RR pump trip to zero speed energized.
- p. FW R BACK INT'D
  - 1) RRCS FW runback logic energized
- q. SLCS STG TK LVL LO CH A(B)
  - 1) SLS storage tank level < 0"
  - Loss of 125v DC to Channel A(B) logic

Sensor output to high or downscale

Too numerous to list here, refer to Table 4 of Op. Tech. or page 22 of the procedure.



CTIVES/

NOTES

02-REQ-001-215-2-08 -22 June 1991

• · · · • . р с с с К · · · x v I

•

Annunciators on P603 Div. I/II RRCS MANUAL INITIATION Armed 603421 Div. I/II RRCS Potential ATWS 603422 RPV Level less than 108.8 inches 1) (Level 2). **RPV Pressure greater than 1050** 2) psig. One on both Div. I(II) RRCS Manual 3) Initiation Switches armed and depressed. Div. I/II RRCS CONFIRMED ATWS 603439 с. One or more of the following conditions exist concurrent with APRM's not be injected. downscale or INOP. (98 sec. T.D.) RPV water level less than 1) 108.8 inches. RPV pressure greater than 2) 1050 psig. One or both Div. I(II) RRCS 3) Manual Initiation Switches armed and depressed. Div. I/II RRCS RECIRC. PUMPS TRIP 603423 d.

1) RPV Level less than 108.8" (trip to zero speed).

•Point out that this is a red Annunciator and is indicative that SLS will be soon or should

Show Transparency of Table 3

3.

LESSON CONTENT

a.

b.

02-REQ-001-215-2-08 -23 June 1991

UNIT 2 OPS/2403

**DELIVERY NOTES** 

NOTES

TIVES

EO-5



.

.

**.** . ٥



. . . .

DELIVERY NOTES

- RPV press. greater than
   1050 psig (Trip to LFMG, at T + 25 seconds may trip to zero speed).
- e. Div. I/II RRCS FW RUNBACK INITIATED 603431

RPV pressure greater than 1050 psig with APRM's not downscale (25 sec. T.D.).

f. Div. I/Div. II RRCS MANUAL INITIATION
 603432

Div. I(II) Manual Initiation Switches armed and depressed.

- g. Div. I/II RRCS OUT OF SERVICE 603440
  - SLS Storage Tank less than O inches level.
  - 2) Loss of 125 VDC power supply
  - 1) RPV water level
- h. Div. I/II RRCS TROUBLE 603445
  - SLS Storage Tank less than 0 inches level.
  - 2) Loss of 125 VDC power supply.
- i. Div. I/II RRCS FW RUNBACK DISABLE 603430
  - FW runback disable switch in the "ON" position.

02-REQ-001-215-2-08 -24 June 1991

E0-5

NOTES

٩

•

, s , s . .

• a

•

. 

.•

x

٨

· ·

	TENT		DELIVERY NOTES	NOTE
Β.		rols		EO-3
	1.	RRCS Manual Initiation Switches	Show Transparency of Figure 4	
		a. Controls located on the Reactor C	ontrol	
		Panel (P603).		
		b. Must Arm and Depress both channel		
		pushbuttons in one division for R	RCS	
	_	activation.		
	2.	ARI reset pushbutton switches (S3A thr	ougn	
		S3D).		
		a. Located on P603.		
		b. Reset is prohibited for 30 second	'S	
		following RRCS-ARI initiation.		-4
		1) Allows all control rods enou	gn	۵
	2	time to insert fully.		
	3.	RRCS reset pushbutton switches (S4A th	rougn	
		S4D)		
		a. Located on P603.		
		b. The high dome pressure, low-low R level, and manual RRCS initiation		
		-		
		signals to the SLS logic <u>seal-in</u> minutes after the SLS permissive		
		(98 second TD) is satisfied.		
		(30 second 15) 13 satisfied.		
			-	

л · 

· .

• a <u>.</u>

. ۰ ۲ ۲ ۲ ۲ , 

. .



- 4. ARI Manual Initiation (Test) switches:
  - a. Used to test the RRCS-ARI function, only. Two (2) position keylock switches (test or normal). In test, switch simulates a high dome pressure or low-low level signal in its sub channel, and initiates ARI.
  - b. Located on the RRCS control panels in the Relay Room.

## C. Interlocks

• - -

- RRCS-ARI seals-in for 30 seconds to ensure full rod insertion. Requires operator action to reset.
- 2. Feedwater runback logic can be manually overridden after 25 seconds.
- SLS pump initiation is sealed in for 10 minutes. Requires operator action to reset.
- Operator can manually override an RRCS initiation signal to either SLS pump by stopping the SLS pump.
- 5. The isolation signal to WCS is sealed-in during SLS pump operation.

Test switches used either during surveillance EO-3 testing by the I&C department OR as directed by EOPs only.

Switches in the back side of C22-P001-2 and C22-P002-2.

EO-4

02-REQ-001-215-2-08 -26 June 1991

r,

. 1

,

.

,

•

4

-

LESSON CONTENT



## IV. SYSTEM OPERATION

- A. <u>Normal Operation</u>
  - 1. RRCS must be operable and in standby status during normal operation.
- B. Off Normal Operation
  - Upon receipt of the RRCS Rx vessel high dome pressure signal (1050 psig) from the RVI, RRCS will:
    - a. Send a signal to trip the RCS pumps to the LFMG's (a high-to-low transfer),
    - b. Send a signal to initiate the ARI function.
    - c. Activate logic that provides a 25 second time delay, after which, if sufficient power reduction is not indicated (APRM not downscale or INOP), further signals will be sent to initiate a Feedwater runback and a trip of the LFMG's, and
    - d. Activate logic that provides a 98 second time delay, after which, if sufficient power reduction is not indicated (APRM not downscale or INOP), it sends a signal to initiate SLS, and isolate WCS.

It may prove helpful here to start a time line where time Ø is the instant the high pressure signal is received. Instructor's option. E0-6

02-REQ-001-215-2-08 -27 June 1991

. . .

•

.

•



- 2. Upon receipt of the Rx vessel low-low water level signal (108.8") from the RVI, RRCS will:
  - a. Send a signal to trip the RCS pumps' main power (60 Hz) supply and the LFMG power (15 Hz) supply.
  - b. Send a signal to initiate the ARI function, and
  - c. Activate logic that provides a 98 second time delay, after which, if sufficient power reduction is not indicated (APRM not downscale or INOP), a signal will be sent to initiate SLS and isolate WCS.
- 3. Upon initiation of a manual RRCS signal, RRCS:
  - a. Sends a signal to initiate the ARI function, and
  - Activate logic that provides a 98 second time delay, after which, if sufficient power reduction is not indicated, (APRM not downscale or INOP), it sends a signal to initiate SLS and isolate WCS.

-28

June 1991

02-REO-001-215-2-08

It may prove helpful here to construct a time line where time Ø is the instant the low-low level signal is received - Instructor Option -

•Remind trainees that manual RRCS activation <u>does not</u> cause any RRCS function other than ARI and potentially SLS.

DELIVERY NOTES



EO-6

UNIT 2 OPS/2403

•


. . •

, .

× \*

۰ ۰





EO-7

- C. EOP Operation
  - 1. EOP-RQ
    - a. Asks if ARI has initiated, if the response is NO
      - 1) RRCS is directed-initiated
      - 2) This action independently depressurizes the scram air header and realigns the SDV vent and drain valves.
    - b. Directs ARI reset
      - Allows defeating the ARI logic trips if necessary.
      - ARI may interfere with other methods of inserting rods, it is therefore appropriate to reset and if necessary to defeat interlocks to reset ARI.
- V. SYSTEM INTERRELATIONS
  - A. Electrical Distribution
    - 120 VAC supplied from Div I (2VBA\*UPS2A) and Div II (2VBA\*UPS2B) through 2VBS\*PNL101A and 2VBS\*PNL301B respectively. Status lights and logic circuitry are the major loads in each division.

•Show a TP of the RQ leg of EOP-RPV here for clarification.

EOP-6, Attachment 14 directs how to defeat these interlocks.

EO-8

02-REQ-001-215-2-08 -29 June 1991

• . . . , · · · 1 ,

1

.







- 125 VDC supplied from Div I (2BYS\*202A) and Div II (2BYS\*PNL202B) for ARI solenoid valves and logic power supplies.
- B. <u>Standby Liquid Control System</u> (SLS) Will automatically inject a neutron absorbing borated solution into the reactor to stop the fission process, achieve a hot shutdown condition, and eventually enable the operator to reach a cold shutdown condition.
- C. <u>Control Rod Drive System</u> (CRD) Provides the valves needed for the ARI function of the RRCS.
- D. <u>Reactor Recirculation System</u> (RCS) Pump trips provide a mitigating function for ATWS events.
- E. <u>Feedwater Control System</u> (FWS) Feedwater runback provides a mitigating function for ATWS events. Also provides indication that the ATWS feedwater runback has initiated and whether manual control is available.
- F. <u>Reactor Vessel Instrumentation</u> (RVI) Provides high dome pressure and low-low level signal to the RRCS.


E0-8

·. · · · · r. R ۰. ۲ • **4 b** 

•

,

LESSON CONTENT





.

- G. <u>Neutron Monitoring System</u> (NMS) APRM's provide a signal representative of reactor power to the RRCS logic. APRM status (inop, bypass) is also provided.
- H. <u>Reactor Water Cleanup System</u> (WCS) System receives isolation signals upon the initiation of the SLS System.
- VI. DETAILED SYSTEM REFERENCE REVIEW

Review each of the following referenced documents with the class.

- A. <u>Procedures</u>
  - 1. N2-OP-36B Redundant Reactivity Control
    - a. Precautions and Limitations (Section D of the procedure)
      - If Standby Liquid Control is inadvertently initiated,
         initiation can be terminated by taking both SLS pump keylock control switches to stop.

EO-9 EO-10

· · · · · ·

• . -G

· • •

• .

.

.



 This precaution/limitation is a reminder to the operators of how to stop SLS injection rapidly in the event of inadvertant initiation. Clean up of SLS injection would be necessary prior to resuming reactor operation. Clean up could be a very time consuming process.

 Division I consists of Channel A and Channel B, and Division II consists of Channel A and Channel

B. Both channels must be reset/energized to reset/initiate that Division.

 This precaution/limitation is a reminder to the operators that <u>both</u> channels in a division must be tripped (energized) for RRCS initiation and to completely reset a division of RRCS <u>both</u> channels in that division must be reset.

02-REQ-001-215-2-08 -32 June 1991

UNIT 2 OPS/2403

• 

•

.



• .



- 3) The "RRCS FW Runback Disable" switch (C33A-S6) should be used to inhibit the RRCS auto FW runback signal during surveillance testing of the RRCS System, when spurious ATWS trip signals may occur.
  - This precaution/limitation is • in the procedure because of the severe nature of this FW Runback. An inadvertant FW Runback with the plant at power will result in a rapid loss of RPV level jeopardizing core cooling, causing ECCS actuators and a potential loss of plant control. Placing this switch in "off" during surveillances that may cause inadvertant initiation of this feature is good operating practice.
- b. RRCS Test Fault

н

 Cover the annunciator response for this condition ANN. 603445.

02-REQ-001-215-2-08 -33 June 1991

. 1 

LESSON CC	DNTENT 4	DELIVERY NOTES	ECTIVES/
в.	Technical Specifications		E0-11
3	3/4.3.4.1 ATWS Recirculation Pump Trip	•	-
2	Interpretation #73 Minimum Operable Channels for		
	Various Instrumentation Systems		•
с.	Drawing	-	EO-12
	GE Elem. 944E309TY RSS		
II. REL	ATED PLANT EVENTS		· ·
Α.	Refer to Addendum "A" and review related events	-	
	with class (if applicable)		
III. SYS	STEM HISTORY		
Α.	Refer to Addendum "B" and review related		
	modifications with class (if applicable).		
X. WRA	\P_UP		
Α.	Review the student learning objectives.	=	
. SIM	IULATOR EXERCISE		

٠

.

## • • • •

, . .

· .

۰ ۲