ES-301

Administrative Topics Outline

Form ES-301-1

Facility: <u>Wolf Creek</u> Examination Level: RO SRO		Date of Examination: Dec 2019 Operating Test Number:					
Administrative Topic (see Note)	Type Code*	Describe activity to be performed					
Conduct of Operations	R,N	A1 - 2.1.25 [3.9] Determine dilution volume to stabilize power 1 hour after power reduction.					
Conduct of Operations	R,D	A2 - 2.1.20 [4.6] Determine Final Accumulator Pressure per OFN EJ-015.					
Equipment Control	R,N	A3 - 2.2.13 [4.1] Develop a Clearance Order for 'B' Containment Cooler.					
Radiation Control	R,D	A4 – 2.3.13 [3.2] Determine maximum allowed dose per EPP 06-013 and calculate stay time.					
NOTE: All items (five total) are required for SROs. RO applicants require only four items unless they are retaking only the administrative topics (which would require all five items).							
 * Type Codes and Criteria: 4 (C)ontrol room, (S)imulator, or Class(R)oom 2 (D)irect from bank (≤ 3 for ROs; ≤ 4 for SROs and RO retakes) 2 (N)ew or (M)odified from bank (≥ 1) 0 (P)revious 2 exams (≤ 1, randomly selected) 							

ES-301

Administrative Topics Outline

Form ES-301-1

Facility: Wolf Creek		Date of Examination: Dec 2019					
Examination Level: RO 🗌 SRO 🛛	\triangleleft	Operating Test Number:					
Administrative Topic (see Note)	Type Code*	Describe activity to be performed					
Conduct of Operations	R, N	A5 - 2.1.37 [4.6] Given Data and completed 1/M plot during a reactor startup, review and determine any required follow-up actions.					
Conduct of Operations	R, M	A6 - 2.1.25 [4.2] Given a completed STS SF- 002, review and determine any related Technical Specification required actions.					
Equipment Control	R, N	A7 – 2.2.13 [4.3] Given a prepared Clearance Order for 'B' Containment Cooler (SGN01B), review for approval and identify any errors.					
Radiation Control	R, M	A8 – 2.3.6 [3.8] Given a prepared LRW Radioactive Release permit, review for approval and identify any errors.					
Emergency Plan	R, N	A9 – 2.4.41 [4.6] Given plant conditions, classify the event and determine Protective Action Recommendation.					
NOTE: All items (five total) are required for SROs. RO applicants require only four items unless they are retaking only the administrative topics (which would require all five items).							
 * Type Codes and Criteria: 5 (C)ontrol room, (S)imulator, or Class(R)oom 0 (D)irect from bank (≤ 3 for ROs; ≤ 4 for SROs and RO retakes) 3/2 (N)ew or (M)odified from bank (≥ 1) 0 (P)revious 2 exams (≤ 1, randomly selected) 							

Facility: WC	NOC		Task No: _	Task No:			
	alculate water add quired following d		Job Perfor	Job Performance Measure No: <u>A1</u>			
K/A Reference	e: 2.1.25 (3.9) Al tables, etc.	pility to interp	oret reference ma	terials, such as gi	raphs, curves,		
Examinee:			NRC Exar	miner:			
Start:	Stop:		Date:				
Result: <u>Satisfa</u>	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature:				
Method of test	ing: S	imulated Per	formance	Actual Perform	mance <u>X</u>		
Classroom	X	Simu	llator	Plant			
Initial Conditions:							
Initiating Cue:		•	r directs you to d power reduction	etermine the requ	ired dilution		
Task Standard:	Applicant comple is necessary for		on and determine	ed 322.5 +/- 0.5 g	allons of water		
Required Materials:							
References:	es: WCRX-28, CONTROL ROOM OPERATING CURVES AND TABLE REFERENCE MANUAL, page 7.10 WCRX-01, BORATION DILUTION TABLES						
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min		

START TIME:

JF	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
1.	Applicant refers to Curves and tables book, page 7.10, reactivity Plan for Rapid Downpower		Applicant locates table for Dilution During 1 h Following Reduction
			S / U
2.	Dilution ppm required		Applicant referenced the table section for a 1%/min power reduction to 90% and determined 7.0 ppm is required S / U
3.			
5.	C Orrect table located in Boron Dilution tables		Applicant used the Boron- Dilution tables and determined T_{avg} to be 580°F for 90% and went to page 154/192 for the correct table
			S / U
4.	© Dilution volume required	<u>CUE:</u> The JPM is complete.	Applicant determined from Boron-Dilution tables that the 2 and 5 ppm values will be used at 1420 initial boron
		RECORD STOP TIME	concentration
		BELOW.	2 ppm = 92.1 gal of Water 5 ppm = 230.4 gal of Water
		Examiner Note: Margin is +/- 0.5 gallons to allow for Applicant to interpolate 5 ppm	92.1 + 230.4 = 322.5 +/- 0.5 gal of Water
		addition after 2 ppm addition changes boron	
		concentration	S/U
	minating cue: The JPM Is comple	to when the Applicant colou	

Terminating cue: The JPM Is complete when the Applicant calculates the amount of water required for the dilution

STOP TIME:

Initial Conditions: Reactor and Turbine Power have been reduced to 90% at 1%/min due to a steam leak in the Turbine Building. OFN MA-038, RAPID PLANT SHUTDOWN, was used to reduce power. RCS boron concentration is 1420 ppm after the power reduction, T_{avg} is 580°F and stable. Curator is unavailable for database upgrades

Initiating Cue: The Control Room Supervisor directs you to determine the required dilution amount for one hour after the power reduction

Water Volume Required: _____

Wolf Creek Generating Station

Cycle 23

Reactivity Plan for Rapid Downpower

Valid for Burnups from:	18,500	to	19,500	MWD/MTU
Estimated Date Range:	08/19/19	to	09/13/19	

Boration / Dilution during Power Reduction

		0.5%/min			1%/min			3%/min			Final Rod
Power ⁽²⁾	ppm	gal(1)*	gpm*	ppm	gal(1)*	gpm* '	ppm	ga!(1)*	gpm*	Time ⁽³⁾	^o Step
90%	19.0	169	8.5	19.6	174	17.4	20.0	178	53.3	0:01:58	193
80%	15.6	140	7.0	17.2	153	15.3	18.3	164	49.1	0:01:49	164
60%	6.9	61	1.5	12.4	111	5.5	16.6	149	22.4	0:01:39	84
48%	1.1	10	0.4	5.6	50	4.2	9 .2	83	20.8	0:00:55	61
30%	0.3	3	0.1	8.3	74	4.1	15.4	139	23.1	0:01:33	24
0%	(44.4)			(25.3)			(7.4)			0:39:25	C@50

Note 1: Boration Values are Positive and Dilution Values are (Negative)

Note 2: Sum boration volumes for total gallons.

Note 3: Time of Boration Based on 90 gpm

Dilution During 1 h Following Reduction

		0.5%/min		\frown	1%/min			3%/min	
Power	ppm	gal*	gpm*	ppm	gal*	gpm*	ppm	gal*	gpm*
90%	6.7			7.0	ŝ.		7.0		
80%	12.6			13.5	2 2		14.1		
60%	22.7			25.6			27.9	<u></u>	
48%	28.1		5	32.5			35.9		
30%	35.9			42.8			48.1		
0%	49.9			60.8		J	69.2		

Assumptions and Values

1. Power Reduction Started at 100% Power

2. Starting Rod Position was 230 Steps

3. Boration / Dilution are at a constant rate,

4. BAT Boron Concentration of 7400 ppm was used for all boration calculations.
5. B10 Correction Factor = 0.86

6. Axial Offset is Controlled During Downpower to HFP Axial Offset

7. Dilution Flows based on Reactivity Calculations, but may not be physically achievable

NOTE: These assumptions may vary from actual plant conditions, thus the results should be

treated as approximate values.

* Calculate using measured RCS boron concentration and given ppm dilution.

EVALVATOR QUICK REFERENC m

PPM CONC PAGE 11620 11640 11680 11680 11680 11680 11700 11700 11720 11720 11720 11720 11720 11720 1440 1440 1460 1500 1500 1500 1500 1500 1500 4 TO BORATE 1 PPM 111.99 112.04 112.04 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 112.10 111.99 1.000 11.440 11.440 11.440 11.440 9506273 WOLF CREEK BORON-DILUTION TABLES O GAL OF WATER DILUTE 1 PPM 53.6 52.7 51.9 48.0 REOD ACID TO BORATE 2 PPM 23.99 24.08 24.17 24.26 9879554322 0-245689-3 GAL GAL TO WATER 107.2 PPP 102.9 PP 88992.4 902.4 55777666665 6422223 58.04 58.04 58.04 58.04 58.04 58.04 ACID TO S PPM 55555566665 ល ល ល ល ល ល ល ល ល ហ ហ ហ 004410 0783 O GAL OF WATER TO Dilute 5 PPN 240. 237.1 233.7 1858.0022470045 68 4 Ui 7 -115.72 116.56 116.98 117.41 117.84 REQD (ACID TD BORATE 10 PPM 120.03 120.48 120.48 121.38 121.38 121.85 122.31 122.31 122.77 123.24 123.72 123.72 6666 N0400 14-00 58 10 1 GAL OF WATER TO DILUTE 10 PPM 537.6 528.9 520.5 404.4 3389.0 3385.4 3376.9 3476.9 347 168 240.28 241.18 242.09 243.09 243.90 243.90 244.85 244.85 244.85 244.85 244.85 244.85 244.67 248.67 248.63 2223.61 2225.91 2225.91 2226.76 2229.16 229.16 229.18 229.18 229.82 229.18 229.18 229.82 229.83 200.82 BORATE 20 PPM ACIO _iå 13285 100 Q O GAL OF WATER TO Dilute YO PPM 1079_6 1062.1 1028 997 913.5 913.5 900.9 900.9 900.9 900.9 890.9 890.9 886.7 886.7 886.7 885.1 852.6 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 832.1 835.10 77782.3 7782.3 7782.3 7782.3 7782.3 7782.3 7785.1 729.8 .5 953 JUNJO 602.40 604.66 611-9.294 616.29 616.29 620.97 620.97 "OTAL PAGES = 597. 185 582 REQU (ACID TO BORATE 50 PPM 88 7 52835 GAL OF TO DILUTE 50 PPM 22127.8 2073.7 2073.7 2027.7 2027.7 2027.4 1927.6 1927.6 1927.5 1927.5 1927.5 1927.5 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1926.9 1927.0 1920.0 1 2341.4 2308.3 2276.1 2244.8 2214.4 25561 2446 2446 2375 2733 2688 2644 2155 2127 2100 2073 25602. 152 ងហេត 4 2 0 ò

SECTION

1.16

SYSTEM TEMPERATURE

ij

580.00

DEGF

WC-2019-11			JPM A2	Form ES-C-1			
Facility: WC	NOC		Task No:				
	etermine Final Ac ressure per OFN I		Job Perfo	rmance Measure	No: <u>A2</u>		
K/A Reference	e: <u>2.1.20 (4.6)</u> A	bility to interp	oret and execute	procedure steps			
Examinee:			NRC Exa	miner:			
Start:	Stop:		Date:				
Result: <u>Satisfa</u>	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature:				
Method of test	ing: S	imulated Per	formance	Actual Perfor	mance X		
Classroom	Х	Simu	ulator	Plant			
Initial Conditions:	when a loss of R The crew entere to inject Accumu	CS level oco d OFN EJ-0 llators 'B' and	curred. Narrow F 15, LOSS OF RH d 'C' to cool the c		s <+5 inches. are preparing		
	as follows:	s 5 psig, initia	al pressure and v	olume for both ac	cumulators is		
	'B' SI Accumulat		-				
	'C' SI Accumulat	tor – 620 psig	g and 51% level				
Initiating Cue:			5	letermine final acc OOLING, steps E			
Task Standard:	Applicant determined final pressure for 'B' and 'C' Accumulators per OFN EJ- 015, LOSS OF RHR COOLING, steps E1 through E4 'B' Accumulator: 220 – 226 psig 'C' Accumulator: 221 – 227 psig						
Required Materials:			-	ATTACHMENT E			
References:	OFN EJ-015, LC	SS OF RHR	COOLING				
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min		

START TIME:						
JPM STEP / PROCEDURE STEP	CUE	STANDARD				
 Step E1.a: E1. Check if SI Accumulators are Available: a. Check Accumulator Pressures – ANY GREATER THAN RCS PRESSURE b. Check Accumulator Levels – ANY GREATER THAN 0% 		Applicant referred to the initial conditions and determined that 'B' & 'C' accumulator pressures are above RCS pressure				
 Step E1.b: b. Check Accumulator Levels ANY GREATER THAN 0% 		Applicant referred to the initial conditions and determined that 'B' & 'C' accumulator levels are greater than 0% S / U				
3. <u>NOTE:</u> Initial accumulator pressure and level refer to current accumulator conditions		Applicant read and understood NOTE, place kept and proceeded to the next step S / U				

WC-2019-11

JPM A2

Form ES-C-1

I	G<u>Step E2.a:</u> E2. Determine Initial Accumulator Pressure: a. Record initial accumulator pressure (P) in table below:	Applicant records initial accumulator pressure (P) for both 'B' & 'C' in the table provided Acc. B = 612 psig Acc. C = 620 psig S / U
l t	G<u>Step E2.b:</u> b. Convert initial pressure (P) to absolute pressure (P1) and record in table above	Applicant converts initial accumulator pressure (P) for both 'B' & 'C' accumulator to absolute pressure (P1) and records in the table provided $P_1 = P + 14.7$ Acc. $B = 612 + 14.7$ $= 626.7 \text{ psia}$ Acc. $C = 620 + 14.7$ $= 634.7 \text{ psia}$ S/U
I	G<u>Step E3.a:</u> E3. Determine Initial Accumulator Volume: a. Record initial accumulator level (L) in table below	Applicant records initial accumulator level (L) for both 'B' & 'C' in the table provided Acc. B = 47% Acc. C = 51% S / U

7.	© <u>Step E3.b:</u>	
••	b. Convert initial level (L) to	Applicant converts initial accumulator level (L) for both
	initial water volume (Vw) in	'B' & 'C' accumulator to initial
	gallons and record in table	water volume (Vw) and
	above	records in the table provided
		Vw = (L x 8.52) + 5931
		Acc. B = (47 x 8.52) + 5931
		= 6331.44 gallons
		Acc. C = (51 x 8.52) +5931
		= 6365.52 gallons
		S/U
8.	©Step E3.c:	Applicant converts initial
	c. Convert initial water volume	
		water volume (Vw) for both
	(Vw) to initial gas volume (V1) and record in table above	'B' & 'C' accumulator to initial
	(Vw) to initial gas volume (V1)	
	(Vw) to initial gas volume (V1)	'B' & 'C' accumulator to initial gas volume (V1) and records
	(Vw) to initial gas volume (V1)	'B' & 'C' accumulator to initial gas volume (V1) and records in table provided
	(Vw) to initial gas volume (V1)	'B' & 'C' accumulator to initial gas volume (V1) and records in table provided
	(Vw) to initial gas volume (V1)	'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 – Vw
	(Vw) to initial gas volume (V1)	 'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 - Vw Acc. B = 10223 - 6331.44
	(Vw) to initial gas volume (V1)	 'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 - Vw Acc. B = 10223 - 6331.44 = 3891.56 gallons
	(Vw) to initial gas volume (V1)	 'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 - Vw Acc. B = 10223 - 6331.44 = 3891.56 gallons Acc. C = 10223 - 6365.52 = 3857.48 gallons
	(Vw) to initial gas volume (V1)	 'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 - Vw Acc. B = 10223 - 6331.44 = 3891.56 gallons Acc. C = 10223 - 6365.52 = 3857.48 gallons <u>Acceptable range:</u>
	(Vw) to initial gas volume (V1)	 'B' & 'C' accumulator to initial gas volume (V1) and records in table provided V1 = 10223 - Vw Acc. B = 10223 - 6331.44 = 3891.56 gallons Acc. C = 10223 - 6365.52 = 3857.48 gallons

JPM A2

WC-2019-11

Form ES-C-1

W	C-2	01	9-	11
---	-----	----	----	----

JPM A2

9.	©<u>Step E4.a:</u> E4. Determine Final Accumulator Pressure a. Determine final accumulator pressure (P2) in psia and record in table below:	Applicant determined final accumulator pressure (P2) for both 'B' & 'C' accumulators and records in table provided
	below.	P2 = P1 x (V1 / 10223)
		Acc. B = 626.7 x
		(3891.56/10223)
		= 238.56 psia
		Acc. C = 634.7 x
		(3857.48/10223)
		= 239.49 psia
		Acceptable range:
		B – 236 – 240 psia
		C – 237 – 243 psia
		S / U

10.	€ <u>Step E4.b:</u>		Applicant determined
	b. Convert final pressure (P2) to minimum pressure (Pm) in psig and record in table		minimum accumulator pressure (Pm) for both 'B' & 'C' accumulators and records
	above		in table provided
			Pm = P2 – 14.7
			Acc. B = 238.56 – 14.7
			= 223.86 psig
			Acc. C = 239.49 – 14.7
			= 224.79 psig
			Acceptable range:
			B – 220 – 226 psig
			C – 221 – 227 psig
			S / U
11.	Notify the CRS that final accumulator pressure has been determined	<u>CUE:</u> The JPM is complete.	
		RECORD STOP TIME BELOW.	

JPM A2

Form ES-C-1

Terminating cue: The JPM Is complete when the applicant has calculated final pressure in the 'B' & 'C' accumulators

STOP TIME:

WC-2019-11

Initial Conditions: The unit was stable in MODE 5, at mid-loop, with 'B' Train RHR operating when a loss of RCS level occurred. Narrow Range RCS level is <+5 inches. The crew entered OFN EJ-015, LOSS OF RHR COOLING and are preparing to inject Accumulators 'B' and 'C' to cool the core.

RCS Pressure is 5 psig, initial pressure and volume for both accumulators is as follows:

- 'B' SI Accumulator 612 psig and 47% level
- 'C' SI Accumulator 620 psig and 51% level
- Initiating Cue: The Control Room Supervisor directs you to determine final accumulator pressures per OFN EJ-015, LOSS OF RHR COOLING, steps E1 through E4



CLEARANCE ORDER CONTINUATION SHEET

Clearance Number:

		Page:							
	Required to Clear Equipment		ement S				Restora	ation	
Component Tagged	Component Description	Position	Seq.	Tagged By	Verified By	Position	Seq.	Removed By	Verified By
NG00208	CTMT COOLER FAN B FEEDER BREAKER	OPEN RACKED OUT							
GNV0002	CTMT COOLER BESWOUTLET FLOW CONTROL VALVE	CLOSED							
GNV0040	CTMT COOLER B ESW SUPPLY ISOLATION	CLOSED							
		-							

WC-2019-11			JPM A3		Form ES-C-1			
Facility: <u>WC</u>	NOC		Task No:					
	evelop a Clearanc ontainment Coole		Job Perfo	Job Performance Measure No: A3				
K/A Reference	:: <u>2.2.13 (4.1) K</u>	nowledge of	tagging and clea	rance procedures				
Examinee:			NRC Exar	miner:				
Start:	Stop:		Date:					
Result: Satisfa	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature:					
Method of test	ing: S	imulated Per	formance	Actual Perfor	mance X			
Classroom	X	Simu	ulator	Plant				
Initial Conditions:			o power. The 'B' drostatic testing	Containment Cool	ler (SGN01B)			
Initiating Cue:		ts you to det		VAILABLE. The ance Order bound				
			earance order ite g and prevent far	m(s), the instruction rotation"	ons from the			
	On the attached required HANG		RECORD the RE	QUIRED ITEM(S)	, and the			
Task Standard:	1: NG00208, Con 2: GNV0002, Con	ainment Cool tainment Cool	ler B, ESW Outlet I	tion: reaker (OPEN, RAC Flow Control Valve (Isolation (CLOSED	(CLOSED)			
Required Materials:1. M-12BL01, P&ID Reactor Makeup Water System 2. M-12GN01, P&ID Containment Cooling System 3. E-13GN02A, Schematic Diagram Containment Cooler Fans B & D 4. E-13NG01A, Low Voltage Class IE 480V 2-Line M&R 5. APF 21E-001-01, Clearance Order 6. APF 21E-001-02, Clearance Order Continuation Sheet 7. AFP 21E-001-06, Work Package Task Addition Sheet 8. APF 21E-001 -11, Clearance Order Summary Sheet								
References:	AP 21E-001, CL	EARANCE (ORDERS					
Time Critical:	No	Alternate Path:	No	Validation Time:	30 min			

START TIME:

W	C-20	19-1	1
---	------	------	---

J	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
1.	Refer to the provided prints	IF Applicant asks for a work order or Clearance Order Worksheet (COW), <u>THEN,</u> <u>CUE:</u> All information listed on these documents are included in the initiating cue.	 Applicant referred to the following provided drawings: M-12BL01, P&ID Reactor Makeup Water System M-12GN01, P&ID Containment Cooling System E-13GN02A, Schematic Diagram Containment Cooler Fans B & D E-13NG01A, Low Voltage Class IE 480V 2-Line M&R
2.	© Determine Mechanical isolation points for Containment Cooler 'B'	 Examiner Note: Applicant may identify additional isolation points, including vents and drain valves which exceed minimum requirements. Component Description column is NOT required to be filled out. 	Applicant determines the following valves must be placed in the CLOSED position at a minimum : GNV0002 – 'B' Containment Cooler, ESW Outlet Flow Control Valve GNV0040 – 'B' Containment Cooler, ESW Supply Isolation S / U

WC-2019-11

J	PM STEP / PROCEDURE STEP ଢ - CRITICAL STEP	CUE	STANDARD
3.	c Determine Electrical isolation for Containment Cooler 'B'	Examiner Note: Applicant may also include sequence or handswitch position, but this exceeds minimum requirements of this JPM	Applicant determines the following breaker must be OPENED and RACKED OUT NG00208 – 'B' Containment Cooler Feeder Breaker
			S / U
4.	Notify the CRS that the clearance is complete	<u>CUE:</u> The JPM is complete.	
		RECORD STOP TIME BELOW.	
Ter	minating cue: The JPM Is comple	ete when the Applicant make	es notification that the

Terminating cue: The JPM Is complete when the Applicant makes notification that the clearance is complete

STOP TIME:

WC-2019-11	JPM A3	Form ES-C-1
Initial Conditior	ns: The unit is in MODE 1, 100% power. The 'B' Containment Co (SGN01B) needs to be tagged out for hydrostatic testing	ooler
Initiating Cue:	Due to computer problems, ESOMS IS NOT AVAILABLE. The C Room Supervisor directs you to determine the Clearance Order b while ESOMS is unavailable	
	DETERMINE the required clearance order item(s), the instruction the planner are to "Isolate cooling and prevent fan rotation"	s from
	On the attached worksheet, RECORD the REQUIRED ITEM(S), a required HANG POSITION	and the

WC-2019-11 JPM A4					Form ES-C-1		
Facility: WC	NOC		Task No:				
	ost Emergency ev ontrol and personr	•		Job Performance Measure No: <u>A4</u>			
K/A Reference	e: 2.3.13 (3.2) K conditions	nowledge of	radiation exposu	re limits under nor	mal or emergency		
Examinee:		miner:					
Start: Stop: Date:							
Result: <u>Satisfa</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature:				
Method of test	ing: S	imulated Per	formance	Actual Perforr	nance X		
Classroom	X	Simu	ılator	Plant			
Initial Conditions:	has occurred an	d a Site Area	Emergency has	Coolant Accident. been declared. C year is 1350 mR.			
Initiating Cue:	asked you to ma	ke a Contair	ment entry to de	ager. The Shift Ma termine if debris is ge line inside conta	blocking Mini-		
		(IMUM dose		R/hr in the area re lowed for this entry			
Task Standard:							
Required Materials:							
References:	EPP-06-013, EX	POSURE C	ONTROL AND P	ERSONNEL PRO	TECTION		
Time Critical:	No	Alternate Path:	No	Validation Time:	5 min		

START TIME:

J	PM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
1.	Administrative limits do not apply		Applicant determines from precautions and limitations that administrative limits are not in effect during an emergency and does not apply the 1350 mR to the calculation S / U
2.	G MAXIMUM dose allowed		Applicant determined per Attachment A, Corrective or Protective actions = 10 REM TEDE S / U
3.	€ Calculate maximum stay time	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	Applicant calculated stay time based on radiation levels and MAXIMUM allowed dose 10 R / 6 R/hr = 1.67 hour 1.67 hour x 60 min/hr = 100 min S / U

Terminating cue: The JPM Is complete when the Applicant determines maximum required dose and stay time

STOP TIME:

WC-2019-11	JPM A4	Form ES-C-1			
Initial Condition	s: The unit tripped due to a Small Break Loss of Coolant Accident damage has occurred and a Site Area Emergency has been de Conditions are continuing to degrade. Your total dose for the y 1350 mR.	clared.			
Initiating Cue:	You have volunteered to assist the Shift Manager. The Shift Mana asked you to make a Containment entry to determine if debris is ble Mini-Purge damper GT HZ-041 and if the Mini-Purge line inside containment can be isolated.	-			
	Radiation Protection reports dose rates are 6 R/hr in the area required access. What is the MAXIMUM dose TEDE you are allowed for this and what is the maximum stay time	•			
MAXIMUM DOSE:					

MAXIMUM stay time: _____

WC-2019-11		JPM A5	;	Form ES-C-1		
Facility: <u>WC</u>	NOC	Tas	sk No:		_	
	eview completed 1/m plot and valuate for further actions	Job	Performa	ance Mea	asure No:	A5
K/A Reference	e: 2.1.37 (4.6) Knowledge of p reactivity management	rocedure	s, guidelii	nes, or lin	nitations	associated with
Examinee:		NR	C Examir	ner:		
Start:	Stop:	Dat	te:			
Result: <u>Satisfa</u>	<u>ctory / Unsatisfactory</u> Exam	niner Sigr	nature:			
Method of test	ing: Simulated Perfo	ormance		Actual F	Performa	nce X
Classroom	X Simula	ator		_ Pla	ant	
Initial Conditions:	The unit is in Hot Standby follo Crew is performing a reactor s STANDBY TO MINIMUM LOA	tartup in				
Initiating Cue:	As the Control Room Supervis any/all follow up actions and w was used during the startup:					
	Maximum rod height Estimated critical position Minimum rod height Initial Count rate		Bank D at Bank D at Bank C at 520	29 steps 72 steps		
	Source Range NI-31 response to				ſ	
	Rod Position Channel NI 31	A50 SR 31	A100 SR 31	B35 SR 31	B85 SR 31	B135 SR 31
	Final Counts (Cf)	592	735	852	1020	2600
Task Standard:	Applicant reviewed the comple ~55 steps on Control Group 'C steps). Determined follow up	,' BELO				
	 INFORM Reactor Enginee MAINTAIN stable Reactor ENSURE control rod positi CALCULATE another estir DETERMINATION OF EST 	Conditio ons and nated cri	RCS boro tical posit	ion, using	J STS RE	

WC	-201	9-11
----	------	------

Required Materials:	 GEN 00-003, HOT STANDBY TO MINIMUM LOAD Completed GEN 00-003, FIGURE 1, 1/M Plot 				
References:	GEN 00-003, HOT STANDBY TO MINIMUM LOAD				
Time Critical:	No	Alternate Path:	No	Validation Time:	20 min

START TIME:

J	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
1.	Applicant reviews data entered matched data obtained during the startup		Applicant ensured data entered into 1/M plot was accurate
			S / U
2.	Applicant calculates 1/M and determines critical rod position		Applicant determines calculations are correct and estimated critical positions are accurate
			S / U

JPM STEP / PROCEDURE STEP @ - CRITICAL STEP	CUE	STANDARD
3. CApplicant determines follow up actions	CUE: The JPM is complete. RECORD STOP TIME BELOW.	Applicant determined that estimated critical position is BELOW minimum rod height (BANK C at 72 steps) AND Count rate has doubled 520 x 2 = 1040 counts Documents actions required per step E.22.5.3 of GEN 00-003 Follow-up actions: INFORM Reactor Engineering MAINTAIN stable Reactor Conditions ENSURE control rod positions and RCS boron concentration are correct CALCULATE another estimated critical position, using STS RE-002, DETERMINATION OF ESTIMATED CRITICAL POSITION

Terminating cue: The JPM Is complete when the Applicant has completed the review, Identified ECP is below minimum rod height, and determined the required follow up actions.

STOP TIME:

WC-2019-11 JPM		JPM A5	Form ES-C-1
Initial Condition		y following a forced outage a a reactor startup in accordan MINIMUM LOAD.	
Initiating Cue:	As the Control Room Superv determine any/all follow up a following data was used duri	ctions and why the actions a	•
	Maximum rod height Estimated critical position Minimum rod height Initial Count rate	Bank D at 81 steps Bank D at 29 steps Bank C at 72 steps 520 cps	6
		020 000	

Source Range NI-31 response to rod withdrawal


Rod Position	A50	A100	B35	B85	B135
Channel NI 31	SR 31	SR 31	SR 31	SR 31	SR 31
Final Counts (Cf)	592	735	852	1020	2600

Follow up action(s), if any and why:

Revision: 103

GEN 00-003

Page 105 of 106



Continuous Use



WC-2019-11		JPM A6	Form ES-C-1
Facility: WC	NOC	Task No:	
FI	eview STS SF-002, Core Axial ux difference, and determine ny T.S. required actions	Job Performance Measure No:	A6
K/A Reference	tables etc	et reference materials, such as graphs	, curves,
Examinee: _		NRC Examiner:	
Start:	Stop:	Date:	
Result: <u>Satisfa</u> <u>Method of test</u>		niner Signature: ormance Actual Performanc	
Classroom	X Simul	ator Plant	
Initial Conditions:	A unit downpower to 90% has Condensate Pump.	just been completed due to the loss of	a Main
	Core life is 20,142 MWD/MTU		
	NPIS became unavailable foll	owing the downpower at 1950.	
	A Reactor Operator has perfo DIFFERENCE.	rmed STS SF-002, CORE AXIAL FLUX	(
	STN RJ-001, VERIFICATION is being performed at 2116.	OF COMPUTER OPERABILITY PROC	CESSES,
Initiating Cue:	•	-002, CORE AXIAL FLUX DIFFEREN and Technical Requirements compliand	
Task Standard:		Reactor Operator failed to recognize tv out of acceptable band in the COLR and 3.2.3, Condition A applies.	
Required Materials:	 Completed STS SF-002 CORE OPERATING LIMITION Technical Specifications 	REPORT (COLR)	
References:	STS SF-002, CORE AXIAL FI	LUX DIFFERENCE	
	CORE OPERATING LIMIT RE		
	Technical Specification 3.2.3,	Condition A	

W	C-20	19-	11
---	------	-----	----

Time No Critical:	Alternate Path:	No	Validation Time:	10 min
----------------------	--------------------	----	---------------------	--------

START TIME:

Form ES-C-1

J	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
1.	Review completed surveillance		Applicant reviewed steps in procedure and reviewed completion of table in Attachment A, Axial Flux Difference Log
			S / U
2.	© Determine two Nis are unacceptable (NI 41B and NI 42B)		From COLR Figure 2.5, Applicant determined that SE NI-41B and SE NI-42B are UNACCEPTABLE by plotting points on the graph
			OR
			By calculating max power range flux:
			Limit: (29-15)/50% = 0.28/%
			0.28/% x 40% = 11.2
			At 90%: -29 + 11.2 = -17.8 maximum power range flux difference
			S / U
3.	© Determine LCO 3.2.3, Condition 'A' applies (Reduce power to within 30 minutes to less than 50%)	<u>CUE:</u> The JPM is complete.	Applicant determined LCO 3.2.3, Condition A, AFD not within limits, applies.
	less than 50%)	RECORD STOP TIME BELOW.	<u>Required Action</u> : reduce thermal power to <50% rated thermal power
			S / U
			570

Terminating cue: The JPM Is complete when the Applicant has completed the review and determined Technical Specification applicability

STOP TIME:

WC-2019-11	JPM A6	Form ES-C-1
Initial Conditions	 A unit downpower to 90% has just been completed due to the Main Condensate Pump 	he loss of a
	Core life is 20,142 MWD/MTU	
	NPIS became unavailable following the downpower at 1950).
	A Reactor Operator has performed STS SF-002, CORE AX DIFFERENCE.	IAL FLUX
	STN RJ-001, VERIFICATION OF COMPUTER OPERABILI PROCESSES, is being performed at 2116.	ΤY
Initiating Cue:	Review the completed STS SF-002, CORE AXIAL FLUX DIFFE verify Technical Specification and Technical Requirements com	

Technical Specification and Technical Requirements Compliance: Yes / No

Applicable Conditions (if any) and actions required:


EXAMINER QUICK REFERENCE



Wolf Creek Generating Station Cycle 23 Core Operating Limits Report Revision 0

2.5 <u>AXIAL FLUX DIFFERENCE (AFD) (Relaxed Axial Offset Control (RAOC)</u> <u>Methodology</u>) (LCO 3.2.3)

The indicated AXIAL FLUX DIFFERENCE (AFD) allowed operational space is defined by Figure 2.5.



Page 6 of 16

EXAMINER QUICK REFERENCE

WC-2019-11	JPM A7		Form ES-C-1
	Tasl	 {	
Facility: WC	NOC No:		
	eview a completed Job earance Order No:	Performance Measure	A7
K/A Reference:	2.2.13 (4.3): Knowledge of tagging	and clearance procedures	3
Examinee:	NRC	Examiner:	
Start:	Stop: Date	2:	
Result: <u>Satisf</u>	actory / Unsatisfactory Examiner S	Signature:	
Method of tes	ting: Simulated Performance	Actual Performance	<u>_X</u>
Classroom	X Simulator	Plant	
Initial Conditions:	The unit is operating at 100% power (SGN01B) needs to be tagged out fo		oler
Initiating Cue:	Review the completed Clearance Or the Tagging Authority per AP 21E-00		
	1. Identify ALL errors on the CO Tag Sheet.	List, if any, and record on	the Cue
	2. Circle Approve or Disapprove or	n the Cue Sheet.	
	The Clearance Order Checklist and are provided for REFERENCE ONL		r Sheet
Task Standard:	Applicant identified the three critical clearance order per AP 21E-001, CL 1. Identify Mechanical Isolation Error and UNCAPPED. Placement Configuration is to prevent pressure building 2. Identify Mechanical Isolation Error CLOSED instead of OPEN. 3. Identify Mechanical Isolation Error GNV0008 should be GNV0040.	EARANCE ORDERS. <u>Valve GNB0064 should</u> self-contradicting. Cannot be both "Cl o after isolation." Must be deconflicted. , Valve GNV0056 should	

WC-20	19-11
-------	-------

Description	1. M-12BL01, P&ID Reactor Makeup Water System					
Required Materials:	2. M-12GN01, P&ID Containment Cooling System					
Materials.	3. E-13GN02A, Schematic Diagram Containment Cooler Fans B & D					
	4. E-13NG01A, Low Voltage Class IE 480V 2-Line M&R					
	5. Clearance Order Coversheet					
	6. Clearance Order Tag List					
	7. APF 21E-001-15, CLEARANCE ORDER CHECKLIST					
References:	M-12BL01, P&ID Reactor Makeup Water System					
	M-12GN01, P&ID Containment Cooling System					
	E-13GN02A, Schematic Diagram Containment Cooler Fans B & D					
	E-13NG01A, Low Voltage Class IE 480V 2-Line M&R					
	AP 21E-001, CLEARANCE ORDER					
Time	No	Alternate	No	Validation	20 min	
Critical:		Path:		Time:		

START TIME: WC-2019-11

Form ES-C-1

JP	M STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD	
1.	GReview clearance order for correct Placement Configuration	Applicant identified GNV0064 Placement Configuration is self- contradicting. States "Closed Uncapped" but then states "*Left open to prevent pressure buildup after isolation." Must be deconflicted.	Applicant identified GNV0064 is in the incorrect position The CO Tag list identifies GNV0064 in the closed position and it should be open and uncapped. Applicant identified GNV0056 is in the incorrect position The CO Tag List identifies GNV0056 in the open position and it should be closed.	
			S/U	
2. G Review clearance order for correct mechanical isolation			Applicant identified GNV0004 is not correct for isolation	
			The CO Tag List identifies GNV0008 for DANGER tag isolation and it should be GNV0040.	
		S/U		
3. G Approve or Disapprove Clearance Order		<u>CUE:</u> The JPM is complete.	Circle Disapprove	
		RECORD STOP TIME BELOW.	S / U	
TerminatingThe JPM Is complete when the Applicant has completed identifyingcue:and recording errors and determining approval or disapproval status				

STOP TIME:

WC-2019-11	JPM A7	Form ES-C-1
Initial Conditio	ons: The unit is operating at 100% power. The 'B' Containment (SGN01B) needs to be tagged out for hydrostatic testing.	t Cooler
Initiating Cue:	Review the completed Clearance Order (CO) proposal for appr as the Tagging Authority per AP 21E-001, CLEARANCE ORD 1. Identify ALL errors on the CO Tag List, if any, and record on Cue Sheet.	ERS.
	2. Circle Approve or Disapprove on the Cue Sheet.	
	The Clearance Order Checklist and the Clearance Order Cove Sheet are provided for REFERENCE ONLY.	r

APPROVE / DISAPPROVE

WC-2019-11			JPM A8		Form ES-C-1
Facility: <u>WC</u>	NOC		Task No:		
	eview submitted ease permit for			ormance Measur	re <u>A8</u>
K/A Reference:	2.3.6 (3.8) Ab	oility to appr	ove release pei	rmits.	
Examinee:			_ NRC Exa	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	actory / Unsatis	factory E	Examiner Signa	ture:	
Method of tes		mulated erformance		Actual Performance	e <u>X</u>
Classroom	X	Simu	llator	Plant	
Initial Conditions:				paration are bei Tank, THF04B.	ing made to
Initiating Cue:	Monitor Tank E	8 (THF04B)	Release Permi	d Secondary Liq t. Identify ALL e horize this relea	errors, if any,
Task Standard:	following errors 1. In RELEAS (HFL456) is gre	and circle E CONDITIO eater than th IZATION/R	"Not Authorized ONS Section, E ne Low Setpoin ELEASE DATA	Expected Monito	r Response
Required Materials:	1. Completed				
References:	AI 07B-019, IN	STRUCTIO	NS FOR LIQUI	D RELEASE PE	RMITS
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min
		START			

TIME:

Form ES-C-1

JPM STEP / PROCEDURE STEP @ - CRITICAL STEP	CUE	STANDARD
 G Reviews the presented APF 07B-001-02-13 THF04 Release Permit for authorization. RELEASE CONDITIONS Section. 		Applicant identified that the Expected Monitor Response (HFL456) is higher than the Low Setpoint S / U
2. G Reviews the presented AFP 07B-001-02-13 THF04 Release Permit for authorization. AUTHORIZATION / RELEASE DATA Section		Applicant identified Check Source Test has not been completed S / U
3. C Release Authorization	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	Applicant determined based on the errors identified to NOT authorize the release S / U

Terminating The JPM Is complete when the Applicant authorizes/does not authorize the Release and any/all errors have been identified.

STOP TIME:

WC-2019-11	JPM A8	Form ES-C-1
Initial Conditior	ns: The unit is operating at 100% power. Preparation are to release Secondary Liquid Waste Monitor Tank, TH	
Initiating Cue:	As the Shift Manager, review the provided Secondary Liq Monitor Tank 'B' (THF04B) Release Permit. Identify ALL any, and specify whether or not you would authorize this Record ALL errors, if any, in the space provided below.	errors, if
	Release permit is (CIRCLE ONE): Authorized / NOT Authorized	

_

APF 07B-001-02-13 Page 1 of 2

THF04	B RELEASE PERMIT
	ek Nuclear Operating Corp.
	RP No. <u>u1LBZ019-1</u> 7B
Da	ate <u>12/10/2019</u>
	K04-013
	LEASE CONDITIONS
[Commitment 3.2.2]	
	000 gallons
	<u>.00</u> gpm
Minimum Dilution Flow Rate12_4	,000 gpm ERROR
Minimum No. of Pumps/Type	Circor Service GREATER THAN
Expected Monitor Response (HFL456) (2.21e-5 uCi/ml
NOTE: Setpoint changes are done on t	he "Supervisor RM-80 Database" screen IAW SYS SP-121.
Liquid Radwaste SP056A Nu	
(HF RE 45) HFL45	ϕ ϕ
	$\frac{\partial}{\partial c} = \frac{\partial}{\partial c} \left[\frac{\partial}{\partial c} + \frac{\partial}{\partial c} \right]$ (challer item 010) $\frac{\partial}{\partial c} = \frac{\partial}{\partial c} \left[\frac{\partial}{\partial c} + \frac{\partial}{\partial c} \right]$
	$\alpha \cdots \alpha \mu c \eta m \alpha \alpha \cdot \sigma \eta c \mu c \eta m$
	CIAL INSTRUCTIONS
1. Concurrent batch releases allowed	Yes No
2. Concurrent continous releases allow	ved using Circ/Service Water as Yes/No
dilution:	C
Comments:	
AUTHORIZATI	ION/RELEASE DATA SECTION:
	undialize on the matrix
Release Permit Initiated by:	/ 12/10/19 Chemistry Technician
Release Permit Verified by: <u>Scutten</u>	/ <u>17/10/19</u> Chemistry Technician or Supervisor
	ERROR # Z NOT COMPLETE / Operator
Check Source Test per STN SP-001	
Supervisor RM-80 database Setpoints	
Supervisor RM-80 database Setpoints	
Release Approved by	Shift Manager
HFRE45 Reading Prior to Release:	
HFRE45 Reading During Release:	
Release Start Date/Time	
ReleaseEnd Date/Time	
ReleaseEnd Date/Time Waste Volume Discharge	gallons
Number of Circ Water Pumps	
Lake Level EFL0027 or Local (circle)	ft.
Circ Water DP (psig) 1PI-CW005, 1PI-C	CW006, 1PI-CW007 / /
or with 3 pumps 1PI-CW012A	/////
Other dilution if circ is unavailable	
	2 OPEN/CLOSED (circle)
Release Packet Data verified by Chem.	Supervisor or Designee/Date:/

WC-2019-11	JP	PM A9 Form ES		
Facility: <u>WCN</u>	<u>IOC</u>	Task No:		
	ssify an event and ermine PARs	Job Performance Measure <u>A</u> No:	.9	
K/A Reference:	2.4.41 (4.6) Knowledge of en classifications	nergency action level thresholds a	and	
Examinee:		NRC Examiner:		
Start:	Stop:	Date:		
Method of testi	ng: Simulated Performance	hiner Signature: Actual Performance	<u>_X_</u>	
Classroom	X Simulato	r Plant	—	
	 the Wolf Creek Switchyard. C A complete loss of off-site p 'A' Emergency Diesel Genereplacement. 'B' Emergency Diesel Generetripped, two unsuccessful a The Control Room Supervision No RED or ORANGE path 	oower occurred. erator is tagged out for governor erator came up to speed and imm ttempts have been made to resta sor has declared an ELAP conditi	ediately art it. ion.	

	1								
Initiating	THIS IS A TIME CRITICAL JPM								
Cue:	As the Shift Manager,								
	1. Determine Emergency Classification. Once classification is determined, present to examiner for time critical action assessment.								
	2. Once handed EPF 06-007-02, WCGS IMMEDIATE EMERGENCY NOTIFICATION, correctly (without errors) complete the form to include identifying the correct Protective Action Recommendations, if any. Codeword is WILDCAT.								
Task Standard:	Applicant determines a General Emergency exists per APF 06-002-02 / 03, EMERGENCY ACTION LEVELS TECHNICAL BASIS / EAL CLASSIFICATION MATRIX. Applicant classified SG1.1 and made Protective action Recommendation to Evacuate JRR, CCL, and CTR								
Required Materials:	 EPP 06-005, EMERGENCY CLASSIFICATION EPP 06-006, PROTECTIVE ACTION RECOMMENDATIONS APF 06-002-03, EAL CLASSIFICATION MATRIX APF 06-002-02, EMERGENCY ACTION LEVELS TECHNICAL BASIS EPF 06-007-02, WCGS IMMEDIATE EMERGENCY NOTIFICATION 								
References:	EPP 06-001, CONTROL ROOM OPERATIONS EPP 06-005, EMERGENCY CLASSIFICATION EPP 06-006, PROTECTIVE ACTION RECOMMENDATIONS EPP 06-007, EMERGENCY NOTIFICATIONS APF 06-002-03, EAL CLASSIFICATION MATRIX APF 06-002-02, EMERGENCY ACTION LEVELS TECHNICAL BASIS EPF 06-007-02, WCGS IMMEDIATE EMERGENCY NOTIFICATION								
Time Critical:	Yes	Alternate Path:	No	Validation Time:	Part 1: 15 min Part 2: 15 min				

START

TIME:

JP	M STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
1.	Record Time T-0 when cue sheet is provided.	<u>Cue:</u> (Hand Applicant the cue sheet) Time Critical Action starts Now. <u>Examiner Note:</u> Record Time T-0 (Start Time) when cue sheet provided to Applicant. Time T-0	Examiner Note: Time Zero (T-0) for the 15 minute requirement to complete the declaration begins when the cue sheet is provided
2.	© Per EPP 06-005, APF 06- 002-02 and APF 06-002-03, determine correct Emergency Classification.	Examiner Note: When the Applicant determines Emergency Classification, Record Time T-1 (Classification Time) Time T-1	Applicant determines classification is a GENERAL EMERGENCY SG1.1 S / U
3.	€ Applicant Classified within the required time frame.	Examiner: Record Classification time. T1 - T0 = min	Examiner Note: The Applicant must classify correctly within 15 minutes from Start Time to meet Time Critical Action for Classification. S / U

JP	M STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
4.	Record Time T-2 when second cue and notification worksheet is provided.	Cue: (Hand Applicant the second cue sheet and notification form) Time Critical Action starts Now. Examiner: Record Time T-2 (Start Time) when cue sheet and blank form provided to Applicant. Time T-2	Examiner Note: Time T-2 for the 15 minute requirement to complete the Notification Form begins when the cue sheet and blank form is provided. Applicant completed the Immediate Emergency Notification form, in accordance with the key: critical tasks marked with a RED asterisk
5.	C Applicant completed Immediate Emergency Notification Form within the required time frame.	Examiner: Record Notification time. T3 - T2 =	S / U <u>Examiner Note:</u> The Applicant must fill out Emergency Notification
		min	Form, with PARs, correctly
		<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	within 15 minutes from Classification Time to meet Time Critical Action for Notification.
		<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u>	within 15 minutes from Classification Time to meet Time Critical Action for

cue: completed the Immediate Notification form to include PARs

STOP TIME:

WC-2019-11	JPM A9	Form ES-C-1
Initial Conditions:	The unit was operating at 100% power, when a torna through the Wolf Creek Switchyard. Conditions as fo	•
	 A complete loss of off-site power occurred. 'A' Emergency Diesel Generator is tagged out for replacement. 'B' Emergency Diesel Generator came up to spee immediately tripped, two unsuccessful attempts harmade to restart it. The Control Room Supervisor has declared an EL No RED or ORANGE path conditions exist. Meteorological Conditions: Stability Class = D, W Wind from 150° to 330° 	ed and ave been _AP condition.
1 st Initiating	THIS IS A TIME CRITICAL JPM	
Cue:	As the Shift Manager, determine Emergency Classification classification is determined, present to the examiner for taction assessment.	
	Record the Emergency Classification in the space provid	

Emergency Classification: _____

2nd Initiating Cue: **THIS IS A TIME CRITICAL JPM**

Once handed a blank EPF 06-007-02, WCGS IMMEDIATE EMERGENCY NOTIFICATION, correctly (without errors) complete the form with the previously identified information to include identification of the correct Protective Action Recommendations (PARs), if any. Codeword is WILDCAT. EPF 06-007-02 Rev 0B

Т	IME OF NOTIFICATION:	ST	ATE				(FOR COMMU	INICATOR US	E ONLY)	
-	WCG	GS	IM	ME	DIATE	EME	RGENCY	NOTI	FICATI	ON
¥		_	0	0						

100											
2.	STATUS: 🗌 ACTUAL 🛛 🖾 DRILL										
₩3.	CODE WORD (County/State Only):										
★4. ★5. ★6. ₹7. ★9. ★10.	A. EMERGENCY CLASSIFICATION: Image: Stream of the										
	AUTOMATIC: X JRR & CCL (Evacuate at Site Area or General) 0 - 2 MILES: X CTR 2 - 5 MILES: N-1 NE-1 E-1 SE-1 S-1 SW-1 N 5 - 10 MILES: N-2 NE-2 NE-3 E-2 SE-2 SE-3 S SW-2 W-2 NW-2 NW-2 NW-2 SE-3 S S										
12.	COMMENTS: ANY COMMENTS										
¥13.	APPROVAL: NAME SIGNATURE TITLE PRINT SIGNATURE TITLE	today. DATE									

NOTIFICATIONS: (FOR COMMUNICATOR USE ONLY)

	PRIMARY CONTACTS			ALTERNATE	CONTACTS	PERSON / TIME
KANSAS DIVISION OF EMERGENCY MGMT	785-291-3333 LEAVE MESSAGE	STATE EOC ACTIVATED 785-646-2000		KHP 785-493-0438	SATELLITE PHONE	
COFFEY COUNTY SHERIFF	620	-364-2123		STATION RADIO	KHP 785-493-0438	
NRC RESIDENT INSPECTOR	OFFICE EXT. 4574 / 4575	Senior Resident: Cell 816-682-1278 Resident: Cell 301-717-3058 Region IV Duty Officer: Cell 817-917-1210				
WESTAR GENERATION OPERATIONS	785-575	-6070		785-575-60	71	
ANI (ALERT OR HIGHER)	877-680	0-2644		N/A		
INPO (ALERT OR HIGHER)	404-290	-3980		404-290-39	77	

ES-301

Control Room/In-Plant Systems Outline

Form ES-301-2

Facility: Wolf Creek	Date of E	Examination:	Dec 2019
Exam Level: RO 🖉 SRO-I 🛛 SRO-U	_ ☑ Operatin	g Test Number:	
Control Room Systems * 8 for RO, 7 for SRO-I, and 2	2 or 3 for SRO-U		
System/JPM Title		Type Code*	Safety Function
S1 Perform a Manual Dilution per SYS BG-200 to temperature during startup.	maintain	L, M, S	1
S2 Manually align Containment Spray per EMG E- F12 [Previous use on 2017 NRC S6]	-0, ATT F, Step	A, D, E, EN, P, S	5
S3 Establish Hot Leg Recirculation per EMG ES-13.		A, E, EN, N, S	2
S4 Start up 'A' Train CCW and transfer Service Loop 201, Section 6.1	per SYS EG-	N, S	8
S5 Cycle PORV Block Valve per STS BB-201A, Sect	tion 8.1	D, L, S	3
S6 Restore AFW after LSP Actuation per ALR 00-12	7A	A, D, E, EN, S	4S
S7 Restore RCP Cooling per OFN BB-005		A, D, E, S	4P
S8 Change RM11 Process Rad Monitor Setpoint		<i>M,</i> S	9
In-Plant Systems: [*] 3 for RO, 3 for SRO-I, and 3 or 2	for SRO-U	<u> </u>	
P1 Line up 'A' EDG for Autostart per SYS KJ-121,	Section 6.1	A, D, EN	6
P2 Open Reactor Trip Breakers as directed by EN	IG FR-S1	E, N, R	7
P3 Locally close valves to Isolate RCP Seals per 1 16.	EMG C-0, Step	D, E, R	4P
 * All RO and SRO-I control room (and in-plant) sys functions, all five SRO-U systems must serve dif functions may overlap those tested in the control 	ferent safety function		
* Type Codes	Criteria f	or RO /SRO-I/SRO	-U

Control Room/In-Plant Systems Outline

Form ES-301-2

4–6 /4–6 /2–3
≤ 9 /≤ 8/≤ 4
≥ 9/≥ 0/≥ 4 ≥ 1/≥ 1/≥ 1
$\geq 1/\geq 1/\geq 1$ (control room system)
$\geq 1/\geq 1/\geq 1$
≥ 1/2 1/2 1 ≥ 2/≥ 2/≥ 1
$\leq 3/\leq 3/\leq 2$ (randomly selected)
$\geq 1/\geq 1/\geq 1$
_ <i>i</i> /= <i>i</i> /= <i>i</i>

S1: The unit in MODE 2 at approximately 4% power. The applicant is tasked with performing a manual dilution in accordance with the Reactivity Plan. The applicant must correctly operate the Chemical and Volume Control System to add 120 gallons of water to the Volume Control Tank in accordance with SYS BG-200, REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION, Step 6.2.

S2: A Large Break LOCA resulted in a Reactor Trip and Safety Injection Actuation. The applicant is tasked with performing EMG E-0, REACTOR TRIP OR SAFETY INJECTION, Attachment F, to verify proper automatic actuations. The applicant must recognize the 'A' Train of Containment Spray System failed to Auto Actuate and take proper action manually align the system for operation per step F12.

S3: The unit is aligned for Cold Leg Recirculation due to a Large Break LOCA and Safety Injection Actuation, which occurred 10 hours earlier. The applicant is tasked with performing Steps 1-8 of EMG ES-13, TRANSFER HOT LEG RECIRCULATION. During performance of this task, EJ HV-8840, RHR HOT LEG RECIRC VLV, will not open. The applicant must re-align the Residual Heat Removal System for Cold Leg Recirculation while proceeding to align the Safety Injection System for Hot Leg Recirculation.

S4: The unit operating at 100% power with Yellow Train equipment in service when corrective maintenance on the 'A' Centrifugal Charging Pump is complete and a post-maintenance test run is required. The applicant is tasked with starting up the 'A' Train of Component Cooling Water System and transferring the Service Loop to the 'A' train per SYS EG-201, TRANSFERRING SUPPLY OF CCW SERVICE LOOP AND CCW TRAIN SHUTDOWN, Step 6.1, to support the 'A' Centrifugal Charging pump run.

S5: The unit is in MODE 2 at approximately 4% power. The applicant is tasked to perform an operability test of the 'B' Power Operated Relief Valve Block Valve per STS BB-201A, CYCLE TEST OF PORV BLOCK VALVE.

S6: A Tornado has gone through the protected area causing a Unit Trip and damage to the Condensate Water Storage Tank. The applicant is tasked with performing ALR 00-127A, AFP SUCT PRESS LO. While performing this task, the applicant will discover the 'A' Train of Low Suction Pressure failed to actuate, requiring the applicant to manually align ESW to the 'A" MD AFW Pump Suction.

ES-301

ES-301 Control Room/In-Plant Systems Outline Form ES-301-2

S7: The unit is operating at 100% power when the crew entered OFN BB-005, RCP MALFUNCTIONS due to numerous alarms associated with the Reactor Coolant Pump thermal barriers. The applicant is tasked with performing Steps 7 & 8. The applicant will discover that one of the Component Cooling Water containment isolation valves has closed, requiring the action to bypass the valve to restore flow before Reactor Coolant Pump trip criteria is met

S8: The unit is operating at 100% power, when Chemistry issued a Gas Release Permit which requires a change to the Radwaste Effluent Radiation Monitor setpoints. The applicant is tasked to change the setpoint per given release permit, APF 07B-001-11-07, and SYS SP-121, OPERATION OF THE G.A. MONITOR SYSTEM, Step 6.3.

P1: The unit is in MODE 4, and a surveillance run of the 'A' Emergency Diesel Generator has just been completed. The applicant is tasked with aligning the 'A' Emergency Diesel Generator for automatic operation per SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, Step 6.1. The applicant will discover that the lockout relays will require manual reset and that the Engine Driven Jacket Water Pump Air isolation must be opened to properly align the Emergency Diesel Generator for Automatic Operation.

P2: A Turbine Trip occurred from 100% power, but the Reactor failed to trip in both Automatic and Manual. The crew is performing EMG FR-S1, RESPONSE TO NUCLEAR POWER GENERATION/ATWS. The applicant is tasked to locally open the Reactor Trip and Bypass Breakers. The applicant will locate and open the breakers.

P3: The unit tripped due to a complete loss of AC power and the crew is responding per EMG C-0, LOSS OF ALL AC POWER. The applicant is tasked with performing EMG C-0, Step 16 to isolate the Reactor Coolant Pump Seals. The applicant will enter the RCA to locate and close the five valves specified in the procedure step.

WC-2019-11	JPM S1			Form ES-C-1	
Task Title: Pe	<u>NOC</u> erform manual dilu YS BG-200 to mai mperature during	ntain		rmance Measure I	No: <u>S1</u>
K/A Reference	: 004/A4.07 (3.9 room: Boratio		y to manually ope	erate and/or monit	or in the control
Examinee:			NRC Exar	miner:	
Start:	Stop:		- /		
Result: <u>Satisfa</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature:		
Method of test	ing: S	imulated Per	formance	Actual Perfor	mance X
Classroom		Simu	ulator X	Plant	
Initial Conditions:	MODE 2, Reacto	or power is ~		eactor Startup. Th activity Maneuver I e next hour.	
Initiating Cue:	The Control Room Supervisor directs you to add 120 gallons of water at 80 gpm, per SYS BG-200, REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION, step 6.2. All pre-requisites are complete.				
Task Standard:	The Applicant ac SYS BG-200, Se		5 gallons of wate	er to the VCT at 80) +/- 3 gpm per
Required Materials:	1. SYS BG-200 OPERATION			ROL SYSTEM N	ORMAL
	Board for FW H	TR DUMP V		Alarms written o EATER DRN TK ss	
	JPM Initial Con	ditions set t	o run concurrer	ntly with S5 JPM	
	BG FY-111B thu performance	umbwheel n	nust be verified	at random value	prior to
References:	SYS BG-200, RE OPERATION	EACTOR MA	KEUP CONTRO	L SYSTEM NOR	MAL
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min

START TIME:

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 Step 6.2.1: IF frequent dilutions are being performed that could exceed motor start limits, THEN START the second Reactor Makeup Water Transfer Pump * BL HIS-3 – NORMAL-AFTER-RUN * BL HIS-4 – NORMAL-AFTER-RUN * BL HIS-4 – NORMAL-AFTER-RUN * BL HIS-4 – NORMAL-AFTER-RUN * BL HIS-4 – NORMAL-AFTER-RUN	IF Applicant asks if frequent dilutions will be performed, <u>THEN:</u> <u>CUE:</u> Frequent dilutions will be performed	On Panel RL001, Applicant determined that both Reactor Makeup Water Transfer Pump(s) are running (BL HIS-3/4) (RED light LIT, GREEN light OUT) S / U
 Step 6.2.2: (ρ) IF required to ensure RCS and Pressurizer Boron Concentrations are within 50 ppm, THEN TURN on PZR HTR B/U GROUP A and/or PZR HTR B/U GROUP B, using SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS, to mix Reactor Coolant System with Pressurizer water 	IF Applicant asks if RCS and Pressurizer Boron Concentrations are within 50 ppm, THEN: CUE: Concentrations are within 50 ppm	On Panel RL002, Applicant recognized that BOTH pressurizer heater groups were already energized and proceeded to the next step S / U
 3. <u>Step 6.2.3:</u> 3. Momentarily PLACE BG HS-26, RCS M/U CTRL in stop and spring return to normal BG HS-26 – IN STOP AND SPRING RETURN TO NORMAL 		On Panel RL002, Applicant located and placed BG HS- 26 in STOP and allowed to spring return to normal S / U

Form ES-C-1
On Panel RL002, Applicant located and placed BG HS- 25 in DILUTE
S / U
Applicant read and understood NOTES, place kept and proceeded to next step S / U
On Panel RL002, Applicant located BG FK-111, and set to 80 gpm per the initiating cue Potentiometer set to 5.0 S / U

WC-2019-11		JPM S1	Form ES-C-1
7. <u>Step 6.2.6:</u> VERFY BG FK- REACTOR M/L CTRL in autom o BG FK-1 AUTOM	J WTR FLOW atic 11 – IN		On Panel RL002, Applicant located BG FK-111 and verified it was in automatic (RED AUTO light LIT, RED MAN Light OUT) S / U
8. <u>CAUTION:</u> BG FY-111B, C M/U & BA COU 1 gallon increm are no tenth of increments on t	INTER is set in ents. There a gallon		Applicant read and understood CAUTION, place kept and proceeded to next step
	U & BA lal to the r of gallons to		S / U On Panel RL002, Applicant located BG FY-111B and set the counter to 120 gallons
10. <u>Step 6.2.8:</u> 8. RESET BG COMBINED M/ COUNTER low o BG FY-1	'U & BA		S / U On Panel RL002, Applicant located BG FY-111B and reset the counter S / U

WC-2019-11	JPM S1	Form ES-C-1
 11. G<u>Step 6.2.9:</u> 9. (ρ) Momentarily PLACE BG HS-26, RCS M/U CTRL in run and spring return to normal BG HS-26 – IN RUN AND SPRING RETURN TO NORMAL 		On Panel RL002, Applicant located BG HS-26, placed it in RUN and allowed it to SPRING RETURN to NORMAL
 12. <u>Step 6.2.10.1:</u> 10. VERIFY proper Reactor Makeup Water Control System operation: 1. <u>IF</u> NOT already running, <u>THEN</u> ENSURE at least one REACTOR MAKEUP WATER TRANSFER PUMP starts * BL HIS-3 – STARTED * BL HIS-4 – STARTED 		Applicant recognized from step 6.2.1 that both REACTOR MAKEUP WATER TRANSFER PUMP(S) were running On Panel RL001, Applicant verified both REACTOR MAKEUP WATER TRANSFER PUMP(S) are running (RED light LIT, GREEN light OUT) S / U
 13. <u>Step 6.2.10.2:</u> 2. BG HIS-111B, MAKEUP TO VCT INLET opens BG HIS-111B - OPEN 		On Panel RL001, Applicant located and verified BG HIS- 111B OPEN (RED light LIT, GREEN Light OUT) S / U

WC-2019-11	JPM S1	Form ES-C-1
 14. <u>Step 6.2.10.3:</u> 3. BG HIS-111A, REACTOR M/U WTR TO BA BLENDING TEE THROTTLES 0 BG HIS-111A – THROTTLED 		On Panel RL001, Applicant located BG HIS-111A and verified throttled (RED light LIT AND GREEN LIGHT LIT)
 15. <u>Step 6.2.10.4:</u> 4. VERIFY proper dilution flow rate on BG FR-110, BA BLENDING FLOW RECORDER BG FR-110 – AT PROPER DILUTION FLOW RATE 		On Panel RL002, Applicant located BG FR-110, and verified TOTAL MAKEUP FLOW ~80 gpm
16. NOTE: When the Dilute Mode is used with 120 gpm letdown inservice, it is recommended that a maximum dilution rate of 90 gpm be set on BG FK-111. This is based on observation that insufficient pump head is available to provide 120 gpm flow against the higher Letdown line back pressure and system resistance		Applicant read and understood NOTE, place kept and proceeded to next step
		S / U

WC-2019-11	JPM S1	Form ES-C-1	
17. C<u>Step 6.2.10.5:</u> IF proper dilution flow rate is		At Panel RL002, Applicant located BG FK-111 and	
NOT obtained, <u>THEN</u> ADJUST BG FK-111, REACTOR M/U WTR FLOW		adjusted as necessary to maintain 80 gpm of flow	
CTRL potentiometer, as necessary, to obtain desired flow rate			
 BG FK-111 – SET AT DESIRED FLOW 			
RATE		S / U	
 Callon +/- 5 gallons of Makeup water were added to the RCS at 80 +/- 3 gpm 	<u>CUE:</u> The JPM is complete.		
	RECORD STOP TIME BELOW.		
Terminating cue: The JPM Is complete when the Applicant has established and verified 80 gpm of makeup water flow			

STOP TIME:

WC-2019-11	JPM S1	Form ES-C-1
Initial Condition	 Power ascension is in progress following a Reactor Startup. in MODE 2, Reactor power is ~4%. Per the Reactivity Mane 420 gallons of water will need to be added over the next hou 	euver Plan,
Initiating Cue:	The Control Room Supervisor directs you to add 120 gallons of gpm, per SYS BG-200, REACTOR MAKEUP CONTROL SYSTI OPERATION, step 6.2. All pre-requisites are complete.	

WC-2019-11	JPM S2			Form ES-C-1	
Facility: <u>WC</u>	NOC		Task No:		
Title: Sp	anually align Cor ray per EMG E- ep F12.		Job Perfo No: -	ormance Measure	e <u>S2</u>
K/A Reference:	026/A4.01 (4. control room:	•		operate and/or m	nonitor in the
Examinee:			NRC Exa	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	ictory / Unsatis	factory E	Examiner Signa	ture:	
Method of tes		mulated erformance		Actual Performance	<u></u>
Classroom		Simu	llator X	Plant	
Initial Conditions:	A Large Break L REACTOR TRIF			is performing EM	G E-0,
Initiating Cue:				ted to complete E CATION. You are	
Task Standard:					
Required Materials:					
References:	EMG E-0, REACTOR TRIP OR SAFETY INJECTION				
Time Critical:	No	Alternate Path:	Yes	Validation Time:	5 min

START TIME:

JP	M STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
1.	Step F12.a: F12. Verify Containment Spray Not Required a. Containment pressure – HAS REMAINED LESS THAN 27 PSIG: o Annunciator 00-59A, CSAS – NOT LIT o Annunciator 00-59B, CSIB – NOT LIT o GN PR-934		Applicant recognizes that Containment Pressure HAS NOT remained less than 27 PSIG and proceeds to RNO step.
			S / U
2.	Step F.12.1 RNO: Perform the following: 1. Stop all RCPs		On panel RL021, Applicant recognizes that all RCPs have already been tripped. S / U
3.	 GStep F.12.2 RNO: 2. IF containment spray has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment spray. SB HS-43 <u>AND</u> SB HS-45 SB HS-44 <u>AND</u> SB HS-46 *Commence Alternate Path* <u>'A' Containment Spray</u> <u>Pump not aligned and running</u> 	Examiner Note: Actuation of CSAS is a two-handed operation, switches must be turned simultaneously.	On panel RL018, Applicant attempted to manually initiate containment spray by placing the following switches to 'ACTUATE'

Form ES-C-1

		Г
Step F.12.3 RNO: 3. Check ESFAS status panel CSAS section – ALL WHITE LIGHTS LIT • Red Train • Yellow Train		On ESF SYS STATUS INDICATION SA 066-Y Applicant recognizes that the YELLOW Train lights are LIT On ESF SYS STATUS INDICATION SA 066-X Applicant recognizes that the RED Train lights are NOT LIT and continues to the next step S/U
G <u>Step F.12.4 RNO:</u> 4. <u>IF</u> any CSAS component <u>NOT</u> properly aligned, <u>THEN</u> manually align associated component.	Examiner Note: Applicant <u>MAY</u> place ESF PANEL SA-066X MODE SEL SA HS-23 in Pull-To-Lock to see White Light indication of repositioned ESF equipment during the alignment.	On panel RL017, Applicant recognized that the 'A' train of Containment Spray did not align and manually aligned them in any order: STARTS CTMT SPRAY PUMP A • EN HIS-3 – PLACED IN RUN (Red light ON, Green light OFF) OPENS CTMT SPRAY PUMP A DISCH VLV • EN HIS-6 – OPEN (Red light ON, Green light OFF)
	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	OPENS CTMT SPRAY A ADDITIVE SPLY • EN HIS-15 – OPEN (Red light ON, Green light OFF) S / U

Terminating cue:

The JPM Is complete when the Applicant has manually aligned 'A' Containment Spray Pump for operation.

STOP TIME:

WC-2019-11	JPM S2	Form ES-C-1
Initial Condit	ions: A Large Break LOCA has occurred. The crew is perfo E-0, REACTOR TRIP OR SAFETY INJECTION.	rming EMG
Initiating Cue:	You are the Reactor Operator and were directed to comple attachment F, AUTOMATIC SIGNAL VERIFICATION. You Step F12.	

WC-2019-11			JPM S3		Form ES-C-1
Facility: WC	NOC		Task No:		
	stablish Hot Leg F er EMG ES-13	Recirculation	Job Perfo	rmance Measure	No: <u>S3</u>
K/A Reference	e: 006/A4.02 (4.0 room	0/3.08): Abil	ity to manually op	perate and/or mor	nitor in the control
Examinee:			NRC Exa	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature:		
Method of test	<u>ing:</u> S	imulated Per	formance	Actual Perfor	mance X
Classroom		Simu	ulator <u>X</u>	Plant	
Initial Conditions:	•			Leg Recirculations the Safety Inject	
Initiating Cue:			isor directs you OT LEG RECIR	to perform steps CULATION.	s 1-8 of EMG
Task Standard:					
Required Materials: EMG ES-13, TRANSFER TO HOT LEG RECIRCULATION Simulator Setup: <u>IC 308</u> , IC 30, IMF mBB06A f:27.5 ICM movEJHV8840.cmf t:2, all actions of EMG E-0 and E-1 to this point have been taken, EMG ES-12 actions have been completed			/ to this point		
References:	EMG ES-13, T	RANSFER		ECIRCULATIO	N
Time Critical:	No	Alternate Path:	Yes	Validation Time:	15 min

START TIME:

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 <u>NOTE:</u> Foldout page shall be monitored throughout this procedure 		Applicant read and understood NOTE, place kept and proceeded to next step
		S / U
 2. <u>Step 1.a:</u> 1. Align Red Train RHR for Hot Leg Recirculation: a. Place power lockout for EJ HV-8809A in NON-ISO position o EJ HIS-8809AA 		On Panel RL017, Applicant depressed EJ HIS-8809AA NON-ISO pushbutton, verified locked down with WHITE light lit
		S / U
 3. <u>Step 1.b:</u> 1.b. Close RHR to Accumulator Injection Loops 1 & 2 valve ○ EJ HIS-8809A 		On Panel RL017, Applicant depressed CLOSE pushbutton on EJ HIS-8809A (GREEN light LIT, RED light OUT)
		S / U
 4. <u>Step 1.c:</u> 1.c. Place power lockout for EJ HV-8809A in ISO position ○ EJ HIS-8809AA 		On Panel RL017, Applicant depressed EJ HIS-8809AA ISO pushbutton, verified NON-ISO button released and WHITE light NOT lit
		S / U

J	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
5.	<u>Step 1.d:</u> 1.d. Open RHR Train A Hot Leg Recirc valve ○ EJ HIS-8716A		On Panel RL017, Applicant depressed OPEN pushbutton on EJ HIS-8716A (RED light LIT, GREEN light OUT) S / U
6.	Step 2.a: 2. Align Yellow Train RHR for Hot Leg Recirculation: a. Place power lockout for EJ HV-8809B in NON-ISO position o EJ HIS-8809BA		On Panel RL017, Applicant depressed EJ HIS-8809BA NON-ISO pushbutton, verified locked down with WHITE light lit
7.	Step 2.b: 2.b. Close RHR to Accumulator Injection Loops 3 & 4 valve		On Panel RL017, Applicant depressed CLOSE pushbutton on EJ HIS-8809B (GREEN light LIT, RED light OUT) S / U
8.	Step 2.c: 2.c. Place power lockout for EJ HV-8809B in ISO position © EJ HIS-8809BA		On Panel RL017, Applicant depressed EJ HIS-8809BA ISO pushbutton, verified NON-ISO button released and WHITE light NOT lit S / U

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 9. <u>Step 2.d:</u> 2.d. Open RHR Train A Hot Leg Recirc valve ○ EJ HIS-8716B 		On Panel RL017, Applicant depressed OPEN pushbutton on EJ HIS-8716B (RED light LIT, GREEN light OUT) S / U
 10. <u>Step 3.a:</u> 3. Establish RHR Hot Leg Recirculation: a. Place power lockout for EJ HV-8840 in NON-ISO position o EJ HIS-8840A 		On Panel RL017, Applicant depressed EJ HIS-8840A NON-ISO pushbutton, verified locked down with WHITE light lit
 11. <u>Step 3.b:</u> 3.b. Open RHR Hot Leg Recirc Valve ○ EJ HIS-8840 		On panel RL017, Applicant depressed OPEN pushbutton on EJ HIS-8840 Recognized valve does not respond, proceeded to RNO step S / U
 12. *COMMENCE ALTERNATE <u>PATH*</u> RNO Step 3.b.1: RNO 3.b. Perform the following: IF radiation levels permit, THEN locally open valve FJ HV-8840 (2000' AUX BLDG. SOUTH PIPE PEN ROOM FAR RIGHT HAND CORNER) 	WHEN Applicant discusses contacting RP or CRS about radiation levels, <u>THEN:</u> <u>Cue:</u> TSC reports radiation levels are too high to permit local valve operation of EJ HV-8840	Applicant contacted RP or CRS and determined that radiation levels were too high for local operation and proceeded to next RNO step S / U

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 13. CRNO Step 3.b.2.a: RNO 2) If RHR hot leg recirculation can NOT be established, THEN reestablish RHR cold leg recirculation: a) Place power lockout for EJ HV-8809A/B switches in NON-ISO position EJ HIS-8809AA EJ HIS-8809BA 		On Panel RL017, Applicant depressed EJ HIS-8809AA NON-ISO pushbutton, verified locked down with WHITE light lit Depressed EJ HIS-8809BA NON-ISO pushbutton, verified locked down with WHITE light lit
 14. GRNO Step 3.b.2.b: RNO b) Open RHR to Accumulator Injection Loops 1 & 2 and 3 & 4 valves • EJ HIS-8809A • EJ HIS-8809B 		On Panel RL017, Applicant depressed OPEN pushbutton on EJ HIS-8809A (RED light LIT, GREEN light OUT) Depressed OPEN pushbutton on EJ HIS-8809B (RED light LIT, GREEN light OUT) S / U
 15. <u>RNO Step 3.b.2.c:</u> RNO c) Place power lockout for EJ HV-8809A/B switches in ISO position EJ HIS-8809AA EJ HIS-8809BA 		On Panel RL017, Applicant depressed EJ HV-8809AA ISO pushbutton, verified NON-ISO button released with WHITE light NOT lit Depressed EJ HV-8809BA ISO pushbutton, verified NON-ISO button released with WHITE light NOT lit S / U

JPM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
16. C<u>RNO Step 3.b.2.d:</u> RNO d) Close RHR train A Hot Leg Recirc valve ○ EJ HIS-8716A		On Panel RL017, Applicant depressed CLOSE pushbutton on EJ HIS-8716A (GREEN light LIT, RED light OUT) S / U
17. ₢ RNO Step 3.b.2.e: RNO e) Close RHR train B Hot Leg Recirc Isolation valve ○ EJ HIS-8716B		On Panel RL017, Applicant depressed CLOSE pushbutton on EJ HIS-8716B (GREEN light LIT, RED light OUT) S / U
 18. <u>Step 3.c:</u> c. Place power lockout for EJ HV-8840 in ISO position o EJ HIS-8840A 	IF Applicant reports failure and asks for direction, THEN: Cue: Acknowledge report and continue with procedure	On Panel RL017, Applicant depressed EJ HV-8840 ISO pushbutton, verified NON- ISO button released with WHITE light NOT lit S / U
 19. <u>Step 4:</u> 4. Check RHR Hot Leg Recirc Flow – FLOW INDICATED o EJ FI-988 	IF Applicant reports failure and asks for direction, <u>THEN:</u> <u>Cue:</u> Acknowledge report and continue with procedure	Applicant recognized that no flow exists from actions taken on previous steps and proceeds to RNO step S / U
20. <u>RNO Step 4.a:</u> Perform the following RNO a. Start pumps and align valves, as necessary, to establish RHR hot leg recirculation flow	IF Applicant reports failure and asks for direction, <u>THEN:</u> <u>Cue:</u> Acknowledge report and continue with procedure	Applicant recognized that this was attempted during step 3, and could not be established and proceeds to next RNO step S / U

JPM STEP / PROCEDURE STEP ଢ - CRITICAL STEP	CUE	STANDARD
 21. <u>RNO Step 4.b:</u> b. IF RHR hot leg recirculation can NOT be established, THEN start pumps and align valves, as necessary, to establish RHR cold leg recirculation 	IF Applicant reports failure and asks for direction, THEN: Cue: Acknowledge report and continue with procedure	Applicant recognized that this was completed during step 3 RNO, and proceeded to next procedure step S / U
 22. C<u>Step 5.a:</u> 5. Align Red Train SI for Hot Leg Recirculation: a. Stop SI pump A O EM HIS-4 		On Panel RL017, Applicant placed EM HIS-4 in NORMAL-AFTER-STOP (GREEN light LIT, RED light OUT) S / U
 23. CStep 5.b: 5.b. Close SI Pump A discharge to Cold Leg Injection valve • EM HIS-8821A 		On Panel RL017, Applicant depressed CLOSE pushbutton on EM HIS- 8821A (GREEN light LIT, RED light OUT) S / U
24. € <u>Step 5.c:</u> 5.c. Place power lockout for EM HV-8802A in NON-ISO position ○ EM HIS-8802AA		On Panel RL017, Applicant depressed EM HV-8802A NON-ISO pushbutton, verified locked down with WHITE light LIT S / U
 25. C<u>Step 5.d:</u> 5.d. Open SI Pump A discharge to Hot Leg Injection valve • EM HIS-8802A 		On Panel RL017, Applicant depressed OPEN pushbutton on EM HIS-8802A (RED light LIT, GREEN light OUT) S / U

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
26. ©<u>Step 5.e:</u> 5.e. Place power lockout for EM HV-8802A in ISO position ○ EM HIS-8802AA		On Panel RL017, Applicant depressed EM HV-8802A ISO pushbutton, verified NON-ISO button released with WHITE light NOT lit
27. ₢ <mark>Step 5.f:</mark> 5.f. Start SI pump A ○ EM HIS-4		S / U On Panel RL017, Applicant placed EM HIS-4 in NORMAL-AFTER-RUN (RED light LIT, GREEN light OUT)
		Verified flow and pressure on EM FI-918 and EM PI-919 S / U
 28. CStep 6.a: 6. Align Yellow Train SI for Hot Leg Recirculation: a. Stop SI pump B EM HIS-5 		On Panel RL017, Applicant placed EM HIS-5 in NORMAL-AFTER-STOP (GREEN light LIT, RED light OUT)
 29. @<u>Step 6.b:</u> 6.b. Close SI Pump B discharge to Cold Leg Injection valve • EM HIS-8821B 		S / U On Panel RL017, Applicant depressed CLOSE pushbutton on EM HIS- 8821B (GREEN light LIT, RED light OUT)
		S / U

JPM STEP / PROCEDURE STEP	CUE	STANDARD
30. ₢ <u>Step 6.c:</u> 6.c. Place power lockout for EM HV-8802B in NON-ISO position ○ EM HIS-8802BA		On Panel RL017, Applicant depressed EM HV-8802B NON-ISO pushbutton, verified locked down with WHITE light LIT
		S / U
31. C <u>Step 6.d:</u> 6.d. Open SI Pump B discharge to Hot Leg Injection		On Panel RL017, Applicant depressed OPEN pushbutton on EM HIS-8802B
valve ○ EM HIS-8802B		(RED light LIT, GREEN light OUT)
		S / U
 32. CStep 6.e: 6.e. Place power lockout for EM HV-8802B in ISO position EM HIS-8802BA 		On Panel RL017, Applicant depressed EM HV-8802B ISO pushbutton, verified NON-ISO button released with WHITE light NOT lit
		S / U
33. ₢ <u>Step 6.f:</u> 6.f. Start SI pump B ○ EM HIS-5		On Panel RL017, Applicant placed EM HIS-5 in NORMAL-AFTER-RUN
		(RED light LIT, GREEN light OUT)
		Verified flow and pressure on EM FI-918 and EM PI-919
		S / U

Form ES-C-1

JPM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
 34. C<u>Step 7.a:</u> 7. Isolate SI Pump Cold Leg Injection: a. Place the power lockout for EM HV-8835 in NON-ISO position EM HIS-8835A 		On Panel RL017, Applicant depressed EM HIS-8835A NON-ISO pushbutton, verified locked down with WHITE light lit
		S/U
 35. €<u>Step 7.b:</u> 7.b. Close SI Pumps To Cold Leg Injection valve ○ EM HIS-8835 		On Panel RL017, Applicant depressed CLOSE pushbutton on EM HIS-8835 (GREEN light LIT, RED light OUT)
		S / U
 36. CStep 7.c: 7.c. Place power lockout for EM HV-8835 in ISO position O EM HIS-8835A 		On Panel RL017, Applicant depressed EM HIS-8835A ISO pushbutton, verified NON-ISO button released with WHITE light NOT lit
		S / U
 37. <u>Step 8:</u> 8. Check SI Pump Discharge Flow – FLOW INDICATED • EM FI-918 	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> BELOW.	On Panel RL017, Applicant checked EM FI-918 and EM FI-922, SI Pump Discharge flow indicated
• EM HI-922	<u>BELOW.</u>	S / U

Terminating cue: The JPM is complete when the Applicant established Hot Leg Recirculation using the Safety Injection pumps and verified flow

WC-2019-11	JPM S3	Form ES-C-1
Initial Condition	ns: A Large Break LOCA has occurred. Cold Leg Recircula been aligned, and 6.5 hours have elapsed since the Sa Injection Actuation.	
Initiating Cue:	The Control Room Supervisor directs you to perform steps ES-13, TRANSFER TO HOT LEG RECIRCULATION.	1-8 of EMG

WC-2019-11			JPM S4		Form ES-C-1
Facility: WC	NOC		Task No:		
tra	art up 'A' Train Co ansfer Service Loo G-201, Section 6.	op per SYS	Job Perfo	ormance Measure	No: <u>S4</u>
K/A Reference	e: 008/A4.01 (3.3 room: CCW in			erate and/or moni	tor in the control
Examinee:			NRC Exa	miner:	
Start:	Stop:		Date: _		
Result: <u>Satisfa</u>	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature		
Method of test	<u>ing:</u> S	imulated Per	rformance	Actual Perfor	mance X
Classroom		Simu	ulator <u>X</u>	Plant	
Initial Conditions:	The unit is operating at 100% power. Yellow Train in service. Emergent maintenance was just completed on the 'A' Centrifugal Charging Pump (CCP) and a test run is required.				
Initiating Cue:	The Control Room Supervisor directs you to transfer the Component Cooling Water (CCW) Service Loop to Train 'A' per SYS EG-201, TRANSFERRING SUPPLY OF CCW SERVICE LOOP AND CCW TRAIN SHUTDOWN, step 6.1. to support 'A' CCP post maintenance testing. 'A' CCW pump shall be started. All prerequisites are complete.				
Task Standard:	The Applicant st the 'A' train per s			transferred the So	ervice Loop to
Required Materials:	SYS EG-201, TRANSFERRING SUPPLY OF CCW SERVICE LOOP AND CCW TRAIN SHUTDOWN, Section 6.1 Simulator Setup: <u>IC 309</u> , IC31 JPM Initial Conditions set to run concurrently with S8 JPM				
References:	SYS EG-201, TRANSFERRING SUPPLY OF CCW SERVICE LOOP AND CCW TRAIN SHUTDOWN			LOOP AND	
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min

START TIME:

J	PM STEP / PROCEDURE STEP		
	© - CRITICAL STEP	CUE	STANDARD
1.	NOTE: Bypassing Demins during BTRS operation, may cause the BTRS Chiller to trip on low suction pressure due to the reduced heat load		Applicant read and understood NOTE, place kept and proceeded to the next step
			S / U
2.	Step 6.1.1: 1. <u>IF</u> desired, <u>THEN</u> PLACE BG HIS-129, CVCS DEMIN INLET DIVERT VLV TO VCT POSTION o BG HIS-129 – VCT	IF Applicant asks CRS if desired, <u>THEN:</u> <u>CUE:</u> The CRS desires BG HIS-129 be placed in the VCT position.	On Panel RL001 Applicant located and placed BG HIS- 129 in VCT position. VCT Red Light LIT, DEMIN Red Light OUT S / U
3.	Step 6.1.2.1: 2. IF a train A CCW Pump is NOT running, THEN START desired Train A CCW Pump: 1. TURN OFF motor space heater supply breaker for CCW Pump to be started * TURN OFF PG19NJF118, COMP COOLING WATER PUMP SPACE HEATER DPEG01A	WHEN Applicant requests building operator to turn off the motor space heater supply breaker, <u>THEN:</u> <u>CUE:</u> Space heater is OFF	Applicant recognized from initial conditions that the 'A' CCW pump is to be started and requested building operator turn off the motor space heater supply breaker for that pump
			S / U

WC-2019	-11
---------	-----

4.	NOTE: The trend is monitored prior to and during pump starts, to ensure any indication of voiding, such as unexpected fluctuating parameters is observed and compensatory measures can be accomplished prior to damage occurring	Applicant read and understood NOTE, place kept and proceeded to the next step S/U
5.	Step 6.1.2.2: 2. Prior to starting an A Train CCW Pump, a NPIS computer trend shall be STARTED and MONITORED to ensure proper pump operation and system response. The following are points that need to be monitored. Any other available points that monitor pump operation may be monitored * CCW PUMP A: • EGI009 CCW Pump A Amp • EGF0095 CCW PMP A DISCH FLOW • EGP0077 A CCW DISCH PRESS • EGE0023 CCW PMP C STATUS	At a NPIS terminal, Applicant brought up and displayed points to monitor the 'A CCW pump Examiner Note: Applicant may bring up additional data points but the 4 listed must be displayed at a minimum
		S / U

WC	-2019-11	JPM S4	Form ES-C-1
6.	Step 6.1.2.3: 3. RECORD EG LI-1, CCW SURGE TANK A LEV OR NPIS computer point EGL0001 *EG LI-1		On Panel RL019, Applicant located EG LI-1 and recorded level (~58%) OR At a NPIS terminal, Applicant brought up computer point EGL0001 and recorded level (~58%)
			S / U
7.	NOTE: Annunciators 00-052B, CCW PMP A/C PRESS LO and 00- 51C, CCW PMP A FLOW LO or 00-052C, CCW PMP C FLOW LO will alarm upon pump start and should clear once pump is running		Applicant read and understood NOTE, place kept and proceeded to the next step
			S / U
8.	€<u>Step 6.1.2.4:</u> 4. START desired CCW Pump *START PEG01A, using EG HIS-21, CCW PUMP A ○ EG HIS-21 – AUTO- AFTER-RUN		On Panel RL019, Applicant placed EG HIS-21 in AUTO- AFTER-RUN, and verified pump start (RED light LIT, GREEN light OUT)
			S / U

WC	C-20 1	19-11
----	---------------	-------

 9. Step 6.1.2.5: 5. VERIFY operating CCW Pump discharge flow is greater than 1.5 E6 lbs/hr (3000 gpm) *EG FI-95 Or EGF0095 For CCW Pump A – GREATER THAN 1.5 e6 LBS/HR (3000 GPM) 	IF Applicant contacts building operator for flow indication, THEN: CUE: Indicated flow is 2.3 E6 LBS/HR	Applicant contacted building operator and requested flow indication on EG FI-95 Or At a NPIS terminal, Applicant brought up computer point EGF0095 And verified greater than 1.5 E6 LBS/HR S / U
10. <u>Step 6.1.2.7:</u> 7. RECORD EG LI-1, CCW SURGE TANK A LEV <u>OR</u> NPIS computer point EGL0001 *EG LI-1 *EGL0001		On Panel RL019, Applicant located EG LI-1 and recorded level (~58%) OR At a NPIS terminal, Applicant brought up computer point EGL0001 and recorded level (~58%) S / U
 11. <u>Step 6.1.3:</u> 3. Locally VERIFY CCW Train A Pump Room Cooler running ○ SGL11A - RUNNING 	WHEN Applicant requests building operator to verify room cooler operation, THEN: CUE: Room Cooler is running	Applicant contacted building operator and verified CCW Train A Pump Room Cooler is running
		S / U

 12. <u>Step 6.1.4.1 / 2:</u> 4. <u>IF</u> CCW Pump / started, <u>THEN</u> VE proper room cooler alignment: 1. Locally CHE D156, CCW P Room Cooler Discharge Isol Damper open GL-D15 2. Locally CHE D157, CCW P Room Cooler Discharge Isol Damper Close GL-D15 	A was re RIFY of r damper ro ECK GL- ump A <u>C</u> 11A pr ation 66 – OPEN ECK GL- ump C 11A ation d	VHEN_Applicant equests building operator to proper oom cooler damper lignment, <u>THEN:</u> CUE: Dampers are properly aligned	Applicant contacted building operator and verified proper room cooler damper alignment
CLOSE	D		S / U
13. <u>Step 6.1.5.1 / 2:</u> 5. <u>IF</u> CCW Pump of started, <u>THEN</u> VE proper room coole alignment:	RIFY		Applicant recognizes from initial conditions and previous steps that the 'C' CCW pump was NOT started and proceeded to the next step
			S / U
14. NOTE: Rad Monitor EG R see a reduced flow a low differential p exists across the 0 Exchanger. This of most common dur winter months who temperature contro TV-029 is full oper will perform its des	v rate when ressure CCW Heat condition is ing the en of valve EG n. EG RE-9 sign		Applicant read and understood NOTE, place kept and proceeded to the next step S / U
function during lov conditions			

7. IF RHR Train B is NOT inservice, THEN ENSURE EC HV-12 is open, using EC HIS- 12, SFP HX B CCW OUTLET VLV, to provide a flow path for CCW Train B o EC HIS-12 – OPEN (F 17. Step 6.1.8: A	S / U On Panel RL021, Applicant located EC HIS-12 and ensured it was open (RED light LIT, GREEN light OUT)
7. IF RHR Train B is NOT inservice, THEN ENSURE EC HV-12 is open, using EC HIS- 12, SFP HX B CCW OUTLET VLV, to provide a flow path for CCW Train B o EC HIS-12 – OPEN (F 17. Step 6.1.8: A	ocated EC HIS-12 and ensured it was open (RED light LIT, GREEN light OUT)
for CCW Train B • EC HIS-12 – OPEN 17. <u>Step 6.1.8:</u>	
17. <u>Step 6.1.8:</u>	_
	S / U
AND SFP Hx A is NOT	Applicant determined that RHR Train A is NOT inservice and proceeded to the next step S / U
9. CLOSE CCW Surge Tank A and B Vent Valves CLOSE EG RV-9, using EG HIS-9, CCW SURGE TANK A VENT VALVE o EG HIS-9 – CLOSED (C	On Panel RL019, Applicant located EG HIS-9 and 10 Applicant depressed CLOSE pushbutton(s), verified valve is/are closed (GREEN light LIT, RED light OUT)

W	C-2()19	-11
---	------	-----	-----

 19. NOTES: Annunciator 00-051F, CCW SPLY RTN VLVS MISALIGN will alarm until Step 6.1.11 is completed If the RCP thermal barriers isolate and Seal Injection is available, thermal barrier cooling should be established after the trains have been swapped and flows are stable RCP thermal barriers are NOT expected to close on flow oscillations. A condition report should be initiated if thermal barriers isolate Refer to TS 3.7.7 to determine if Tech Spec entry is required on loss of power to BB HV- 13/14/15/16, RCP THERMAL BARRIER CCW RETURN ISO'S 	Applicant read and understood NOTEs, place kept and proceeded to the next step
	S/U
20. G<u>Step 6.1.10:</u> 10. (ρ) OPEN CCW TRN A SPLY/RETURN VLVS, using EG HS-15, CCW TRN A SPLY/RETURN VLVS ο EG HS-15 – OPEN	On Panel RL019, Applicant located EG HIS-15 and depressed OPEN pushbutton, verified EG ZL- 53 and 15 OPEN (RED light LIT, GREEN light OUT)
	S / U

21. G <u>Step 6.1.11:</u> 11. CLOSE CCW TRN B SPLY/RETURN VLVS, using EG HS-16, CCW TRN B SPLY/RETURN VLVS o EG HS-16		On Panel RL019, Applicant located EG HIS-16 and depressed CLOSE pushbutton, verified EG ZL- 54 and 16 CLOSED (GREEN light LIT, RED light OUT) S / U
 22. <u>Step 6.1.12:</u> 12. VERIFY EG FI-55A, CCW TO RW & RCS FLOW indication EG FI-55A – BETWEEN 1.6 E6 AND 4.3 E6 LBM/HR 		On Panel RL019, Applicant located flow indication EG FI-55A, and verified flow between 1.6 E6 – 4.3 E6 lbm/hr (~3.1 - 3.2 E6 lbm/hr)
		S / U
 23. G<u>Step 6.1.13:</u> 13. OPEN CCW Surge Tank A and B Vent Valves OPEN EG RV-9, using EG HIS-9, CCW SURGE TANK A VENT VLV EG HIS-9 – OPEN OPEN EG RV-10, using EG HIS-10, CCW SURGE TANK B VENT VLV EG HIS-10 – OPEN 		On Panel RL019, Applicant located EG HIS-9 and 10 Applicant depressed OPEN pushbutton until valve(s) indicated OPEN (RED light LIT, GREEN light OUT) S / U
24. Applicant completes step	CUE: The JPM is	
		1
6.1.13	complete.	

Terminating cue: The JPM Is complete when the Applicant completes step 6.1.13 of SYS EG-201

W	C-2	01	9-	11
---	-----	----	----	----

- Initial Conditions: The unit is operating at 100% power. Yellow Train in service. Emergent maintenance was just completed on the 'A' Centrifugal Charging Pump (CCP) and a test run is required.
- Initiating Cue: The Control Room Supervisor directs you to transfer the Component Cooling Water (CCW) Service Loop to Train 'A' per SYS EG-201, TRANSFERRING SUPPLY OF CCW SERVICE LOOP AND CCW TRAIN SHUTDOWN, step 6.1. to support 'A' CCP post maintenance testing.
 - 'A' CCW pump shall be started.
 - All prerequisites are complete.

WC-2019-11	11 JPM S5			Form ES-C-1		
Facility: <u>W</u>	CNOC		Task No:			
Title: 0	Perform PORV Bl Cycle test per STS Section 8.1.		-	ormance Measure	e <u>S5</u>	
K/A Reference:		•	lity to manually d block valves	operate and/or m	nonitor in the	
Examinee:			NRC Exa	aminer:		
Start:	Stop:		Date:			
Result: <u>Satis</u>	factory / Unsatis	sfactory	Examiner Signa	ature:		
Method of te		imulated erformance		_ Actual Performance	<u></u>	
Classroom		Sim	ulator X	Plant		
Initial Conditions:	The Unit is in MO	DDE 2, Read	ctor power is ~4%	, 0.		
Initiating Cue:	8000A using ST	The Control Room Supervisor directs you to test the operability of BB HV- 8000A using STS BB-201A, CYCLE TEST OF PORV BLOCK VALVE, Section 8.1, All prerequisites have been completed.				
Task Standard:	ard: The Applicant tested the operability of BB HV-8000A by arming Cold O/P, isolating the PORV, cycling the PORV, and restoring system to original alignment.					
Required Materials:						
References: Time Critical:	STS BB-201A, C No	Alternate Path:	OF PORV BLO	CK VALVE Validation Time:	10 min	

START
TIME:

JPM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
 Step 8.1.1: 8.1 Cycle of B HV-8000A, PORV BLOCK VALVE 8.1.1 Verify BB PCV-455A is closed, using BB HIS 455A, PZR PORV BB HIS-455A - CLOSED 		On Panel RL021, Applicant verified BB PCV-455A is closed using BB HIS 455A (GREEN light LIT, RED light OUT) S / U
 2. <u>NOTES:</u> When BB HV-8000A, PORV BLOCK VALVE is closed, placing BB HS- 8000A to ARM will cause annunciator 00-046A, COLD O/P BLOCK VLV NOT OPEN to alarm BB PCV-455A, PZR POWER OPERATED RELIEF VALVE should remain closed after COLD O/P PROTECTION is ARMED 		Applicant read and understood NOTE(s), place kept and proceeded to the next step S / U
3. G<u>Step 8.1.2:</u> 8.1.2 PLACE BB HS-8000A, TRN A COLD O/P BLOCK/ARM in ARM ○ BB HS-8000A - ARM		On Panel RL021, Applicant depressed ARM pushbutton for BB HS-8000A S / U

Form ES-C-1

JPM STEP / PROCEDURE STEP		
© - CRITICAL STEP	CUE	STANDARD
4. <u>Step 8.1.3:</u> 8.1.3 ENSURE BB HV- 8000A is open, using BB HIS- 8000A, PORV BLOCK VALVE ○ BB HIS-8000A - OPEN		On Panel RL021, Applicant ensured BB HV-8000A was OPEN using BB HIS-8000A (RED light LIT, GREEN light OUT)
		S / U
 5. <u>Step 8.1.4:</u> 8.1.4 CHECK the following open indications: Green light on BB HIS-8000A is NOT lit Red light on BB HIS-8000A is lit Computer point BBD8000A indicates 		On Panel RL021, Applicant checked GREEN light on BB HIS-8000A is NOT lit Red light on BB HIS-8000A is lit On a NPIS terminal, Applicant checked computer
open		point BBD8000A indicated OPEN S / U
 <u>NOTE:</u> Closing BB HIS-8000A will cause annunciator 00-034C, PZR PORV BLOCK alarm 		Applicant read and understood NOTE, place kept and proceeded to the next step S / U
7. € <u>Step 8.1.5:</u> 8.1.5 CLOSE BB HV-8000A, using BB HIS-8000A, PORV BLOCK VALVE ○ BB HIS-8000A – CLOSED		On Panel RL021, Applicant depressed closed pushbutton on BB HIS- 8000A and verified valve closed (GREEN light LIT, RED light OUT)
		S / U

Form ES-C-1

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 8. <u>Step 8.1.6:</u> 8.1.6 CHECK the following closed indications: Green light on BB HIS-8000A is lit Red light on BB HIS-8000A is NOT lit Computer point BBD8000A indicates NOPEN 		On Panel RL021, Applicant checked GREEN light on BB HIS-8000A is lit Red light on BB HIS-8000A is NOT lit On a NPIS terminal, Applicant checked computer point BBD8000A indicated NOPEN
9. € <u>Step 8.1.7:</u> 8.1.7 OPEN BB HV-8000A, by placing BB HIS-8000A, PORV BLOCK VALVE in auto ○ BB HIS-8000A – AUTO	WHEN Applicant asks for an IV, <u>THEN:</u> Cue: another Applicant has IV'd the valve	S / U On Panel RL021, Applicant depressed AUTO pushbutton on BB HIS-8000A
10. <u>Step 8.1.8:</u> 8.1.8 VERIFY BB HV-8000A is open, using BB HIS-8000A, PORV BLOCK VALVE	WHEN Applicant asks for an IV, <u>THEN:</u> Cue: another Applicant has IV'd the valve	On Panel RL021, Applicant verified BB HV-8000A is open, using BB HIS-8000A (RED light LIT, GREEN light OUT) S / U
11. C <u>Step 8.1.9:</u> 8.1.9 IF the BB HS-8000A, TRN A COLD O/P BLOCK/ARM was found in BLOCK in step 7.1, THEN PLACE TRN A COLD O/P BLOCK/ARM in the BLOCK BB HS-8000A - BLOCK	Cue: BB HS-8000A was found in BLOCK in step 7.1 WHEN Applicant asks for an IV, THEN: Cue: another Applicant has IV'd the valve	On Panel RL021, Applicant depressed BLOCK pushbutton on BB HS-8000A S / U

Form ES-C-1

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
12. Applicant completed section 8.1 of STS BB-201A	<u>CUE:</u> The JPM is complete.	
	RECORD STOP TIME BELOW.	

Terminating cue: The JPM is complete when the Applicant completes Section 8.1 of STS BB-201A

WC-2019-11	JPM S5	Form ES-C-1
Initial Conditions:	The Unit is in MODE 2, Reactor power is ~4%.	

Initiating Cue: The Control Room Supervisor directs you to test the operability of BB HV-8000A using STS BB-201A, CYCLE TEST OF PORV BLOCK VALVE, Section 8.1, All prerequisites have been completed.

WC-2019-11		JPM S6 Form			Form ES-C-1
Facility: WC	NOC		Task No:		
	estore AFW after -127A	LSP per ALF	R Job Perfo	rmance Measure I	No: <u>S6</u>
K/A Reference	or operations to correct, cor	on the AFW; itrol, or mitig	and (b) based or	n those predication ences of those ma	llowing malfunctions ns, use procedures lfunctions or
Examinee:			_ NRC Exa	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfac</u>	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature:		
Method of test	ing: S	imulated Per	formance	Actual Perfor	mance X
Classroom		Simu	ulator <u>X</u>	Plant	
Initial Conditions:	5 5 1 5 1				
Initiating Cue:	The Control Roc SUCT PRESS L		or directs you to r	espond to ALR 00	-127A, AFP
Task Standard:	The Applicant manually aligned ESW to supply 'A' train of Auxiliary Feedwater per ALR 00-127A, AFP SUCT PRESS LO				
Required Materials:					
References:	ALR 00-127A, A	FP SUCT PI	RESS LO		
Time Critical:	No	Alternate Path:	Yes	Validation Time:	10 min

START TIME:

Form ES-C-1

J	PM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
1.	Step 1: 1. Determine Affected Auxiliary Feedwater Pump(s): o Check AFW pump suction pressure - LESS THAN 12.1 PSIA *AL PI-24A for pump B *AL PI-25A for pump A *AL PI-26A for TD AFW pump		On Panel RL005, Applicant determined 'A' pump suction pressure on Al PI-25A is less than 12.1 psia
			S / U
2.	 Step 2: Verify Affected AFW Pump Suction Pressure Low: Check affected AFW pump(s) Discharge Pressure – LOW for the current status of the affected pump(s) *AL PI-15A for pump B *AL PI-18A for pump A *AL PI-21A for TD AFW pump 		On Panel RL005, Applicant determined discharge pressure for 'A' MDAFWP is low and oscillating on AL PI- 18A S / U
3.	© <u>Step 3:</u>		On Panel RL005, Applicant
5.	3. Secure affected Auxiliary Feedwater Pump(s): *Place affected Motor Driven AFW pump in Pull-to-lock *AL HIS-23A for Pump A		placed AL HIS-23A in Pull-to- Lock (ALL LIGHTS OUT)
			S / U

JPM STEP / PROCEDURE STEP © - CRITICAL STEP		CUE	STANDARD
4.	Step 4: 4. Refer to Technical Specification 3.7.5	IF Applicant informs CRS about Technical Specifications, <u>THEN:</u>	Applicant informs CRS of Tech Spec reference
		Cue: acknowledge report	S/U
5.	 <u>Step 5.a:</u> 5. Determine desired AFW pump suction alignment: a. Check either of the following: *EMGs – IN EFFECT <u>OR</u> *AFAS - ACTUATED 		Applicant determined form initial conditions that EMGs are in effect <u>OR</u> Applicant determined from ESAS status panels that AFAS has actuated
6.	Step 5.b: 5.b. Check CST To AFP Suction Header Pressure – GREATER THAN 2.6 PSIG o AL PI-37 o AL PI-38 o AL PI-39		S / U On Panel RL026, Applicant checked ALL CST to AFP suction header pressure LESS than 2.6 PSIG and proceeded to RNO step
			S / U

JPM STEP / PROCEDURE STEP		0 11 -	
	C - CRITICAL STEP	CUE	STANDARD
7.	*COMMENCE ALTERNATE PATH* ©RNO Step 5.b.1: RNO 5.b Ensure ESW supply to affected AFW pumps: 1) Ensure ESW to affected pump suction valve – OPEN *AL HIS-30A for pump B *AL HIS-31A for pump A *AL HIS-32A or AL	Examiner Note: Even though ESW is being supplied to the TDAFWP via the 'B' train, Applicant may open the 'A' train ESW supply to the TDAFWP as well per the procedure step	On Panel RL005, Applicant depressed OPEN pushbutton on AL HIS-31A and ensured valve OPEN Applicant may open AL HIS- 32A for the TDAFWP, <i>this</i> <i>does not represent a</i> <i>critical task</i> (RED light(s) LIT, GREEN light(s) OUT)
	HIS-33A for TD pump		S / U
8.	ିଙ୍ RNO Step 5.b.2: RNO 5.b.2) Ensure ESW pumps – RUNNING		On Panel RL019, Applicant ensured 'A' & 'B' ESW pump running
			'A' ESW is not running (GREEN light LIT, RED light OUT), placed EF HIS-55A in RUN and ensured running
			(RED light LIT, GREEN light OUT)
			S/U
9.	RNO 5.b.3) Go to Step 6		Applicant proceeded to step 6
			S / U

JPM STEP / PROCEDURE STEP		
© - CRITICAL STEP	CUE	STANDARD
 <u>Step 6:</u> Locally vent affected Auxiliary Feedwater Pump(s) suction and discharge 	WHEN Applicant contacts Turbine Building Watch to vent Auxiliary Feedwater Pump 'A' suction and discharge, <u>THEN:</u>	Applicant contacts Turbine Building Watch to vent 'A' MDAFWP suction and discharge.
	<u>Cue:</u> Time compression is being used, the 'A' MDAFWP suction and discharge have been vented.	
		S/U
 11. <u>Step 7:</u> 7. Check AFW Pump(s) suction pressure – GREATER THAN 12.1 PSIA AL PI-24A for pump B AL PI-25A for pump A AL PI-26A for TD AFW pump 		On Panel RL005, Applicant checked AL PI-25A pressure GREATER THAN 12.1 PSIA S / U
 12. C<u>Step 8:</u> 8. Restart affected Auxiliary Feedwater Pump(s) *Start affected Motor Driven AFW pump(s) *AL HIS-23A for pump A 		On Panel RL005, Applicant place AL HIS-23A in RUN and verified pump started (RED light LIT, GREEN light OUT) Discharge pressure AL PI- 18A rising
		S / U

JPM STEP / PROCEDURE STEP @ - CRITICAL STEP	CUE	STANDARD
 13. <u>Step 9:</u> 9. Return to procedure and step in effect 	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	

Terminating cue: The JPM Is complete when the Applicant has completed ALR 00-127A and aligned ESW to supply 'A' train of Auxiliary Feedwater

WC-2019-11	JPM S6	Form ES-C-1
Initial Conditions:	A tornado has gone through the protected area causing a crew has completed actions of EMG E-0, REACTOR TRI INJECTION, and have transitioned to EMG ES-02, REAC RESPONSE.	P OR SAFETY

Initiating Cue: The Control Room Supervisor directs you to respond to ALR 00-127A, AFP SUCT PRESS LO.

WC-2019-11 JF		JPM S7		Form ES-C-1	
Facility: WC	NOC		Task No: _		
	estore RCP coolir 3-005	ng per OFN	Job Perfor	rmance Measure	No: <u>S7</u>
K/A Reference	e: 003/A4.08 (3.2 room: RCP co			rate and/or monito	or in the control
Examinee:			NRC Exar	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	<u>ctory / Unsatisfa</u>	<u>ctory</u> Exa	miner Signature:		
Method of test	ing: S	imulated Per	formance	Actual Perfor	mance X
Classroom		Simu	ulator <u>X</u>	Plant _	
Initial Conditions:	005, RCP MAL	FUNCTION	IS due to annun	crew has entere ciators 074A, R P THRM BAR C	CP MTR CCW
Initiating Cue:	The Control Ro OFN BB-005.	oom Supervi	isor directed yo	u to perform step	os 7 & 8 of
Task Standard:					
Required Materials:1. OFN BB-005, RCP MAL.FUNCTIONS, Steps 7 and 8Simulator Setup: IC 311, IC 31, ICM movEGHV0071.cmf t:2 inserted, EG HIS-58 is closed, but can be opened.				f t:2 inserted,	
References:	References: OFN BB-005, RCP MALFUNCTIONS				
Time Critical:	No	Alternate Path:	Yes	Validation Time:	10 min

	START TIME:			
J	PM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD	
1.	CAUTION: A Dedicated Applicant cannot be used to maintain Operability for valves that receive a CISB signal. Refer to AP 26C-004, OPERABILITY DETERMINATION AND FUNCTIONALITY ASSESSMENT	IF Applicant discusses CAUTION with CRS, THEN: Cue: Acknowledge report	Applicant reads and understands CAUTION, place keeps and proceeds to next step	
			S / U	
2.	Step 7.a: 7. Check CCW to Service Loop and Containment – NOT IN SERVICE a. Ensure CCW pumps – AT LEAST ONE RUNNING		On Panel RL019, Applicant ensured at least one CCW pump is running (RED light LIT, GREN light OUT)	
			S / U	
3.	Step 7.b: b. Ensure One Pair of CCW Service Loop Supply and Return Valves for an Operating CCW Pump – OPEN *EG ZL-15 And EG ZL- 53 <u>OR</u> *EG ZL-16 And EG ZL- 54		On Panel RL019, Applicant ensured at least one set of RED lights were lit (RED light(s) LIT, GREEN light(s) OUT) S / U	

4. GStep 7.c: c. Ensure CCW to and from RCS Isolation valves – OPEN • EG HIS-58 • EG HIS-59 • EG HIS-60 • EG HIS-71	On Panel RL019, Applicant verified the following: Verified RED light NOT lit on EG HIS-58 • Depressed OPEN pushbutton for EG HIS-58 and recognized valve is OPEN (RED light LIT, GREEN light OUT) Verified RED light lit on EG HIS-59 Verified RED light lit on EG HIS-60 Verified RED light NOT lit on EG HIS-71 • Depressed OPEN pushbutton for EG HIS-71 and recognized the GREEN light is still lit, valve DID NOT open Continued with RNO step

JPM S7

5.	*COMMENCE ALTERNATE PATH* CRNO Step 7.c.1: c. Perform the following: 1) IF any valve can NOT be opened, THEN reenergize and open associated bypass valve *EG HIS-126A And EG HIS-126 For EG HIS- 71		On Panel RL020, Applicant depressed NON-ISO pushbutton on EG HIS-126A and verified WHITE light lit Depressed the OPEN pushbutton on EG HIS-126 and verified open (RED light LIT, GREEN light OUT) S / U
6.	RNO Step 7.c.2:2) IF any bypass valve is open THEN perform the following:oRefer to Tech Spec 3.6.3 and 3.7.7oAssign an Applicant to close all bypass valves if containment isolation phase B occurs	WHEN Applicant reports to CRS, <u>THEN:</u> <u>Cue:</u> An Applicant will be stationed at the panel	Applicant notified CRS to assign a dedicated Applicant S / U
7.	RNO Step 7.c.3: 3) <u>IF</u> CCW to and from RCS can <u>NOT</u> be established, <u>THEN</u> shutdown affected RCP(s) within 5 minutes, using ATTACHMENT B, Step B1		Applicant recognized that CCW was flowing to RCPs and N/A'd this step S / U

WC-2019-11		JPM S7	Form ES-C-1
8.	Step 8.a: 8. Verify adequate CCW flow to Thermal Barriers: a. Check CCW Thermal Barrier Flow Annunciators – CLEAR 00-070C, RCP A THRM BAR CCW FLOW 00-071C, RCP B THRM BAR CCW FLOW 00-072C, RCP C THRM BAR CCW FLOW 00-073C, RCP D THRM BAR CCW FLOW 00-074C, RCP THRM BAR CCW FLOW		Applicant checked all annunciators clear
			S / U
9.	Applicant reported step(s) 7 & 8 complete	THE JPM IS COMPLETE	

Terminating cue: The JPM Is complete when the applicant has completed steps 7 and 8.

WC-2019-11	JPM S7	Form ES-C-1
Initial Conditions:	The unit is operating at 100% power. The crew has ent BB-005, RCP MALFUNCTIONS due to annunciators 07 MTR CCW FLOW HILO and 070C, 71C, 72C, 73C, RCI BAR CCW FLOW.	4A, RCP
•	he Control Room Supervisor directed you to perform step: FN BB-005.	s 7 & 8 of

WC-2019-11			JPM S8		Form ES-C-1
Facility: WC	NOC		Task No:		
Task Title: Set RM-11R Setpoints for a Job Performance Measure No: Set				No: <u>S8</u>	
K/A Reference		of process	radiation monitor	rate and/or monito alarms, automatio	c functions, and
Examinee:			NRC Exar	miner:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature:		
Method of test	<u>ing:</u> S	imulated Per	formance	Actual Perfor	mance X
Classroom		Simu	ulator <u>X</u>	Plant	
Initial Conditions:					
Initiating Cue:		using SYS S		enter the Supervi ON OF THE G.A.	
Task Standard:					
Required Materials:				GAS RELEASE P MONITOR SYST	
	Simulator Setup: <u>IC 309</u> , IC 31				
	JPM Initial Con	ditions set t	o run concurrer	ntly with S4 JPM	
References:				S RELEASE PERI	ИІТ
	SYS SP-121, OF	PERATION (DF THE G.A. MO	NTIOR SYSTEM	
Time Critical:	No	Alternate Path:	No	Validation Time:	10 min

START TIME:

Form ES-C-1

JPM STEP / PROCEDURE STEP © - CRITICAL STEP		CUE	STANDARD
1.	<u>Step 6.3:</u> Channel Item & Release Setpoint Operations using RM-11 (SP056A)		Applicant located correct step in procedure and continued with this section
			S / U
2.	Step 6.3.1: 1. IF grid 1 is NOT selected THEN SELECT grid 1 from the MASTER MENU		On Panel SP056A, Applicant verified that grid 1 was selected
			S/U
3.	Step 6.3.2.1: 2. To change the value of a Current RM-80 Database Channel Item, PERFORM the following: 1. SELECT LOGIN, located in the MASTER	Examiner Note: Applicant may click on the channel (GHE 103) from Grid 1 to check current setpoint prior to logging on to make the change	On Panel SP056A, Applicant selects LOGIN from the MASTER MENU
	MENU section		S / U
4.	Step 6.3.2.2: 2. User login pop up window will appear, requesting user name (super) and the password		On Panel SP056A, Applicant verified that the User Login pop-up appears
			S / U
5.	NOTE: The password is located in the Shift Managers note book.	<u>CUE:</u> (as Shift Manager) The password is password	Applicant read and understood NOTE, place kept and proceeded to the next step
			S / U

WC	-201	9-11
----	------	------

6	CStop 6 2 2 2:	On Panel SP056A, Applicant
6.	© <u>Step 6.3.2.3:</u>	enters user name (super)
	3. ENTER the user name	and password (password) in
	(super) and the password in	the User Login pop up box
	the User Login pop up box	
		S / U
7.	NOTE:	Applicant read and
	When RM-11 is in	understood NOTE, place
	SUPERVISOR mode the	kept and proceeded to the
	word SUPERVISOR is	next step
	displayed above the MASTER	
	MENU and a green border	
	appears around the page	
		S / U
8.	© <u>Step 6.3.2.4:</u>	On Panel SP056A, Applicant
	4. SELECT ok	selects ok
		-
		S / U
9.	<u>Step 6.3.2.5:</u>	On Panel SP056A, Applicant
	5. ENSURE SUPERVISOR	verified SUPERVISOR is
	is selected by verifying that:	selected by noting
	○ The word	SUPERVISOR in the upper
	SUPERVISOR is	right corner of the MASTER
	displayed in upper right	MENU screen and the green
	hand corner of the	border appeared
	MASTER MENU	
	screen	
	 The green border 	
	appears around the	
	page	-
		S/U
10.	© <u>Step 6.3.2.6:</u>	On Panel SP056A, Applicant
	6. On grid 1, RIGHT CLICK	right clicks instrument
	the selected channel, pop up	GHE103, verified pop up box
	box will appear	appeared
		S / U
		3/0

11. G<u>Step 6.3.2.7:</u> 7. SELECT CHANNEL ITEM EDIT	On Panel SP056A, Applicant selects the channel item edit
	S / U
12. <u>Step 6.3.2.8:</u>8. CHECK desired channel is selected	On Panel SP056A, Applicant checks desired channel is selected
 <u>IF</u> desired channel is NOT selected, <u>THEN</u> SELECT channel and PRESS DATABASE in the popup box 	If channel is not selected, Applicant selected desired channel and PRESS DATABASE in the popup box
	S / U
13. <u>NOTE:</u> The VALUE will be bordered in red when selected	Applicant read and understood NOTE, place kept and proceeded to the next step
	S/U
 14. GStep 6.3.2.9: 9. SELECT the VALUE of the Channel Item (CI) to be changed 	On Panel SP056A, Applicant selects either channel item 009 <u>OR</u> 010, verified that it is bordered in red
	S / U

W	C-2	01	9-	11
---	-----	----	----	----

 15. GStep 6.3.2.10: 10. To open the Channel Item Editor pop up box, PERFORM either of the following: *EDIT SELECTED ITEM – SELECTED *SELECTED CHANNEL ITEM VALUE – DOUBLE CLICK 	On Panel SP056A, Applicant opens the channel item editor by either of the following: 1: Selected EDIT SELECTED ITEM OR 2: Double Clicks SELECTED CHANNEL ITEM VALUE
 16. GStep 6.3.2.11: 11. KEY in the desired Channel Item value in the correct format. Example: 5.79x10-5 is keyed in as 5, ., 7, 9, e, -, 0, 5 	S / UOn Panel SP056A, Applicant keyed in desired value:GHE103For Channel item 009 = 6.33E+04ORFor Channel item 010 = 8.93E+02
 17. G<u>Step 6.3.2.12:</u> 12. SELECT the SEND TO RM-80 immediately to the right of the NEW VALUE change field 	S / U On Panel SP056A, Applicant selected SEND to RM-80 to the right of the NEW VALUE S / U

 18. GStep 6.3.2.13: 13. A Change Monitor Item Confirmation pop up box will appear in screen: IF the data in the message area is correct, THEN PRESS the YES button IF the data in the message area is incorrect, THEN PRESS the NO buttor AND RETURN to Step 		On Panel SP056A, Applicant verified change monitor configuration pop up box appears Applicant verified data entered in Step 6.3.2.11 is correct, then pressed the YES button IF the data displayed is incorrect, Applicant pressed the NO button and returned
6.3.2.11		to step 6.3.2.11 S / U
 Step 6.3.2.14: 14. IF the entry is accepted, THEN ENSURE the message on the Alarm screen indicate the correct value 		On Panel SP056A, Applicant verified on the alarm screen that a message is displayed showing the correct value
20. <u>Step 6.3.2.15:</u> 15. IF the entry is NOT accepted, THEN VERIFY an error message is displayed		S / U On Panel SP056A, Applicant verified that entry was accepted and this step is N/A, proceeded to next step S / U
 21. GStep 6.3.3.1: 3. To change the value of a Master RM-80 Database Channel Item, PERFORM the following: KEY in the desired Channel Item value in the correct format. Example 5.79x10-5 is keyed in as 5, ., 7, 9, e, -, 0, 5)	On Panel SP056A, Applicant keyed in desired value: Keyed same values as on Step 6.3.2.11 S / U

 22. Step 6.3.3.2: 2. SELECT the SEND TO	On Panel SP056A, Applicant
MASTER box immediately to	selects SEND TO MASTER
the right of the SEND TO RM-	to the right of the SEND to
80 box	RM-80 box
 23. <u>Step 6.3.3.3:</u> 3. A Channel Change Item Confirmation pop up box will appear on screen: IF the data in the message area is correct, <u>THEN</u> PRESS the YES button IF the data in the message area is incorrect, <u>THEN</u> PRESS the NO button <u>AND</u> RETURN to step 6.3.3.1 	S / UOn Panel SP056A, Applicant verified change monitor configuration pop up box appearsApplicant verified data entered in step 6.3.3.1 is correct, then pressed the YES buttonIF the data displayed is incorrect, presses the NO button and returns to step 6.3.3.1S / U
24. <u>NOTE:</u>	Applicant read and
If RM-80 and master	understood NOTE, place
setpoints do NOT match, the	kept and proceeded to the
setpoint value will remain	next step
orange	S / U
 25. <u>Step 6.3.3.4:</u> 4. <u>IF</u> the entry is accepted, <u>THEN</u> ENSURE the message on the Alarm screen indicates the correct value 	On Panel SP056A, Applicant verified on the alarm screen that a message is displayed showing the correct value S / U

W	C- 2	20	19	-11
---	-------------	----	----	-----

accepted	<u>.3.5:</u> entry is NOT d, THEN verify an ssage is displayed		On Panel SP056A, Applicant verified that entry was accepted and this step is N/A, proceeded to next step
			S / U
out, the l	Iccessfully logged _OG OUT will ar from the screen		Applicant read and understood NOTE, place kept and proceeded to the next step
			S / U
are desir PERFOF a. CLOS ITEM ED	<u>.3.6:</u> N no further changes red, THEN RM the following: E the CHANNEL DITOR pop up box CT the LOG OUT	Examiner Note: The Applicant will attempt to enter the data for the other point. The JPM may be ended at this time.	
		<u>CUE:</u> The JPM is complete.	
		RECORD STOP TIME BELOW.	

Terminating cue: The JPM Is complete when the Applicant has completed entering the first setpoint change in the RM-11R

WC-2019-11	JPM S8	Form ES-C-1
Initial Condition	s: The Unit is operating at 100% power. Chemistry has presen 07B-001-11-07, RADWASTE VENT GAS RELEASE PERMI control room for a planned release.	
Initiating Cue:	The Control Room Supervisor directed you to enter the Supervis Setpoints listed using SYS SP-121, OPERATION OF THE G.A. SYSTEM, step 6.3	

Facility: WC	CNOC Task No:				
	ne up EDG for Auto start per Job Performance Measure No: P1A YS KJ-121				
K/A Reference	K/A Reference: 064/A4.05 (3.1/3.2): Ability to manually operate and/or monitor in the control room: Transfer of ED/G control between manual and automatic				
Examinee:			NRC Exa	aminer:	
Start:	Stop:		Date:		
Result: <u>Satisfa</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature	:	
Method of test	ing: S	imulated Pe	rformance X	Actual Perfo	ormance
Classroom		Simi	ulator	Plant	<u>X</u>
Initial Conditions:	The unit is stable in MODE 4. Maintenance has just been completed on the 'A' Emergency Diesel Generator.				
Initiating Cue:	The Control Room Supervisor directs you to place 'A' Emergency Diesel Generator in standby for automatic operation in accordance with SYS KJ- 121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, Section 6.1				
	The Jacket Wate were NOT drain		ystem and Interc	ooler Cooling Wa	ter System
	The governor oil	was NOT d	rained.		
	The EDG will NO	•			
	Prerequisites are	e completed.			
Task Standard:	The applicant placed the 'A' EDG in standby per SYS KJ-121, Section 6.1.				
Required Materials:	SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION				
References:	SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION				
Time Critical:	No	Alternate Path:	Yes	Validation Time:	20 min

START TIME: _____

JPM STEP / PROC © - CRITICA		CUE	STANDARD
		sks for or questions IV(s) orm once you have comp	, state that another Operator is pleted
1. <u>Step 6.1.1:</u> IF EDG NE01 J Cooling System Intercooler Cool System have be THEN VENT EE Intercooler and Heat Exchange	OR ing Water een drained, DG NE01 Jacket Water		Applicant recognized from initiating cue this step is N/A and proceeded to the next step
			S / U
2. NOTE If EDG NE01 is for maintenance 6.1.2 and 6.1.3 marked N/A. Th temperature rec must be met pri- the EDG operation performing STS operability. The temperature for Jacket Water te 105°F. The alar 135°F	e testing Steps may be nese minimum uirements or to declaring ole of 's to prove minimum operability for mperature is		Applicant read and understood NOTE, place kept and proceeded to next step S / U
 Step 6.1.2: VERIFY Jack temperature FR is greater than of 135°F. Jacket Water Temperature FR 	OM ENGINE or equal to	<u>When</u> Applicant locates gage and describes reading it, <u>Then:</u> <u>CUE:</u> Point to 140°F	On Panel KJ121, Applicant located Jacket Water temperature and verified temperature, recorded in space provided S / U

4.	Step 6.1.3: 3. VERIFY Lube Oil temperature TO ENGINE is greater than or equal to 115°F.	<u>When</u> Applicant locates gage and describes reading it, <u>Then:</u> <u>CUE:</u> Point to 120°F	On Panel KJ121, Applicant located Lube Oil temperature and verified temperature, recorded in space provided
	Lube Oil TempºF		S / U
5.	Step 6.1.4: 4. VERIFY Fuel Oil Storage Tank TJE01A level is greater than or equal to 82% (88,170 gallons), as indicated by JE LI-5A or computer point JEL005	<u>When</u> Applicant locates indicator and describes reading it, <u>Then:</u> <u>CUE:</u> As indicated	On southeast wall of the DG room, Applicant Located Fuel Oil Storage Tank level and verified level, recorded in space provided
	TJE01A Level%		S / U
6.	Step 6.1.5: 5. VERIFY Emergency Fuel Oil Day Tank TJE02A level is greater than 61%.	When Applicant locates indicator and describes reading it, <u>Then:</u>	On Panel KJ121, Applicant Located Day Tank level and verified level, recorded in space provided
	TJE02A Level%	CUE: Point to 70%	S / U
7.	Step 6.1.6: 6. ENSURE NB0111, FDR EMER DG NE01 is racked up	When discussed <u>Then:</u> <u>CUE:</u> Another Operator has performed this step and it has been verified.	Applicant acknowledged cue and proceeded to the next step S / U
8.	CAUTION If governor oil level is out of sight glass high or low, the EDG is inoperable		Applicant reads and acknowledges caution, place keeps, and proceeds to next step
			S / U

 9. <u>Step 6.1.7:</u> 7. ENSURE EDG NE01 governor oil level is satisfactory in sight glass Oil level - BETWEEN 1/2 AND 3/4 FULL 	<u>When</u> Applicant locates indication and describes reading it, <u>Then:</u> <u>CUE:</u> 3/4	Applicant Located the sight glass on the engine side of the governor. Checked that oil is visible in the sight glass. Realized from the cues that the engine has been run since the governor was drained last
		S / U
10 <u>Step 6.1.8:</u> 8. RECORD NE01 Governor Speed Set	When Applicant locates speed set and describes reading it, Then:	Applicant located speed set knob on governor and verified position, recorded in space provided
 <u>IF</u> Governor Speed Set is <u>NOT</u> as per CKL ZL-004, TURBINE BUILDING READING SHEETS, <u>THEN</u>, NOTIFY the 	<u>CUE:</u> As indicated <u>When</u> Applicant discusses comparing readings, <u>Then:</u>	
SM <u>AND</u> CONSULT System Engineering	<u>CUE:</u> Governor Speed Set matches logs	S / U

 11 NOTES When closing petcocks, do NOT use excessive force. Torque applied should NOT be greater than the torque generated using either a open or closed end box wrench with a momentarm if no greater than 5" Petcocks are reverse seating and rise away from the valve block when turned in the clockwise direction to close the valve 		Applicant reads and acknowledges note, place keeps, and proceeds to next step
		S / U
 12 <u>Step 6.1.9:</u> 9. ENSURE EDG NE01 cylinder petcocks closed. o Petcocks - CLOSED 	WhenApplicant has located the wrench and as each petcock is tested in turn, Then:CUE:No movement occurred.CUE:How many petcocks need to be checked?	With an open end box wrench Applicant simulated turning first petcock in the clockwise direction to verify no movement. Applicant responded that there are 14 petcocks
	CUE: All 14 petcocks are closed.	S / U

 13 G<u>Step 6.1.10:</u> 10. CHECK both EDG NE01 lockout relays RESET: I<u>F</u> either EDG NE01 lockout relay blue light NOT lit, <u>THEN</u> RESET affected lockout relay Lockout Relay Blue Lights - LIT *Commence Alternate Path* Lockout Relays Require manual Reset	WhenApplicantlocateslockout relays,Then:CUE:CUE:Neither light islitWhenApplicantdescribes how to resetthe lockout relays,Then:CUE:As each relay isreset,BLUE light litIFApplicant contactsthe control room,Then:	On Panel NE107, Applicant located the lights and each Lockout Relay, determined they were not reset, and simulated resetting the relays 186-1/DG and 186-2/DG by turning switch to the right and allowing it to return to the 12'oclock position. Applicant may contact the control room to inform them of the required reset.
	<u>CUE:</u> acknowledge report	S/U
14 ©<u>Step 6.1.11:</u> 11. At NE107, DEPRESS KJ HS-12, ENGINE SHUTDOWN RESET ○ KJ HS-12 – DEPRESSED	<u>When</u> the Applicant locates the Shutdown reset, <u>Then:</u> <u>CUE:</u> Button depressed	On Panel NE107, Applicant located ENGINE SHUTDOWN RESET pushbutton and simulated depressing
		S / U
15 <u>Step 6.1.12:</u> 12. At NG03DBF3, ENSURE KJ HS-89, DPKJ02A STANDBY DIESEL ROCKER ARM PRE-LUBE PUMP	<u>When</u> Applicant locates switch and describes position, <u>Then:</u>	At MCC NG03D, Applicant located control switch on breaker BF3 and verified it is in AUTO
MOTOR is in auto o KJ HS-89 – AUTO	CUE: Control switch indicates AUTO	S / U

16 NOTE Placing KJ HS-9, MASTER TRANSFER SWITCH to local will cause annunciator 00- 020E, DG NE01 OOS to alarm and make the EDG inoperable		Applicant reads and acknowledges note, place keeps, and proceeds to next step S / U
 17 <u>Step 6.1.13:</u> 13. IF Exciter Shutdown amber light is lit, THEN RESET Exciter Shutdown, by performing the following: 	<u>When</u> Applicant locates and discusses amber light, <u>Then:</u> <u>CUE:</u> Amber light is NOT lit	On Panel NE107, Applicant locates Exciter Shutdown amber light and determines it is NOT lit
		S / U
 18 <u>Step 6.1.14:</u> 14. ENSURE all target relays with dropped flags are reset 	<u>When</u> Applicant locates and discusses relays, <u>Then:</u>	On Panel NE107, Applicant locates relays and determines all relays are reset
	<u>CUE:</u> All flags are reset	S / U
19 <u>Step 6.1.15:</u> 15. At NE107, ENSURE KJ HS-9, MASTER TRANSFER SWITCH in auto. ○ KJ HS-9 – AUTO	<u>When</u> Applicant locates and discusses switch, <u>Then:</u> <u>CUE:</u> Switch	On Panel NE107, Applicant located KJ HS-9 and determined switch is in the AUTO position
	indicates AUTO	S / 11
 20 <u>Step 6.1.16:</u> 16. ENSURE KJ HS-73, FIELD FLASHING CONTROL SW is in rated position KJ HS-73 – RATED/AUTO FLASH 	<u>When</u> Applicant locates and discusses switch, <u>Then:</u> <u>CUE:</u> Switch indicates RATED/AUTO FLASH	S / U On Panel NE107, Applicant located KJ HS-73 and verified it is in the RATED position S / U

 21 <u>Step 6.1.17:</u> 17. ENSURE EDG NE01 barring device is removed. o Barring Device - REMOVED 	WhenApplicantlocates and describesbarring device block,Then:CUE:Barring deviceis NOT present	On the Diesel engine, Applicant located the area where the barring device is inserted, on the side of the engine below the fuel racks and verifies the device is removed
		S / U
22 @ <u>Step 6.1.18:</u> 18. ENSURE KJ-V775A, ENGINE DRIVEN JACKET WATER PUMP 6A PT-64 INSTRUMENT AIR ISO is open o KJ-V775A – OPEN	WhenApplicantlocates and discusseschecking the valveopen, Then:CUE:Valve does notmove in the clockwisedirection	Applicant located Air Iso to PT-64, Starting Air Skid – On East Wall, and determined the valve was closed, simulates opening the valve Applicant may contact the control room to report valve
<u>*Commence Alternate Path*</u>		found out of position
KJ-V775A should be open	<u>When</u> Applicant discuss opening the valve, <u>Then:</u>	
	<u>CUE:</u> Valve handwheel is moving, handwheel stops moving, valve is open	
	IF Applicant calls control room to report valve out of position, <u>Then:</u>	
	<u>Cue:</u> Acknowledge report	S/U

 23 Step 6.1.19: 19. CHECK all EDG NE01 alarms clear: Local Panel KJ121 – ALL ANNUNCIATORS CLEAR Main Control Board – ALL EDG A ANUNCIATORS CLEAR 	WhenApplicantdiscusses checkingKJ-121 alarm panel,Then CUE:Noalarms presentWhenApplicantdiscusses contactingthe Main ControlRoom,Then:CUE:No alarmspresent in the MainControl Room	On Panel KJ-121, Applicant verified all alarms clear Applicant simulates contacting the Main Control Room and determined all alarms clear in the Main Control Room
		S / U
24 <u>Step 6.1.20:</u> 20. CHECK fuse indication lights on panel NE107 are lit: ○ IL-7 – LIGHT ON ○ IL-8 – LIGHT ON ○ IL-9 – LIGHT ON ○ IL-10 – LIGHT ON ○ IL-11 – LIGHT ON	When Applicant locates and describes the indication of the fuse lamps, <u>Then:</u> As each is checked, <u>CUE:</u> Light is Lit	On Panel NE107, Applicant verifies all fuse lights are lit S / U
<u>05.010404</u>		
 25 <u>Step 6.1.21:</u> 21. ENSURE KJBS0001A, BASKET STRAINER FUEL OIL PUMP is aligned to one side of the duplex strainer 	WhenApplicantlocates and describeschecking how thestrainer is aligned,Then:CUE:As indicated.	Applicant locates Fuel Oil Pump Basket Strainer and verifies alignment S / U
26 Applicant completed Step 6.1.21.	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	
Terminating The JPM Is complete when the Applicant has successfully completed step		

Terminating
cue:The JPM Is complete when the Applicant has successfully completed step
6.1.21 of SYS KJ-121

Plant equipment shall not be operated, if you have a question about the task or need clarification do not hesitate to ask your evaluator. JPM's are considered "open reference", therefore reference material that is normally available to you in the plant (including the Control Room) is available during this JPM. If you desire to use a reference, ask your evaluator if it is acceptable to do so for the task under consideration. You **may not** solicit technical information from other operators, engineers or technical advisors.

- Initial Conditions: The unit is stable in MODE 4. Maintenance has just been completed on the 'A' Emergency Diesel Generator.
- Initiating Cue: The Control Room Supervisor directs you to place 'A' Emergency Diesel Generator in standby for automatic operation in accordance with SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, Section 6.1

The Jacket Water Cooling System and Intercooler Cooling Water System were NOT drained

The governor oil was NOT drained.

The EDG will not be run again.

Prerequisites are completed.

WC-2019-11	JPM P1B			Form ES-C-1	
Facility: WC	NOC		Task No:		
	ne up EDG for Au ⁄S KJ-121	ito start per	Job Perf	ormance Measure	e No: <u>P1B</u>
K/A Reference				erate and/or mon nanual and auton	
Examinee:			NRC Exa	aminer:	
Start:	Stop:		Date:		
Result: <u>Satisfac</u>	ctory / Unsatisfa	<u>ctory</u> Exa	miner Signature	::	
Method of testi	<u>ng:</u> S	imulated Pe	rformance X	Actual Perfo	ormance
Classroom		Sim	ulator	Plant	<u>X</u>
Initial Conditions:	The unit is stable in MODE 4. Maintenance has just been completed on the 'B' Emergency Diesel Generator.				
Initiating Cue:	The Control Room Supervisor directs you to place 'B' Emergency Diesel Generator in standby for automatic operation in accordance with SYS KJ- 121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, Section 6.2				
	The Jacket Water Cooling System and Intercooler Cooling Water System were NOT drained				
	The governor oil	was NOT d	rained.		
	The EDG will NOT be run again.				
	Prerequisites are completed.				
Task Standard:					
Required Materials:					
References:	es: SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION				
Time Critical:	No	Alternate Path:	Yes	Validation Time:	20 min

START TIME:

JPM STEP / PROCEDURE STEP @ - CRITICAL STEP	CUE	STANDARD		
Examiner Note: If Applicant asks for or questions IV(s), state that another Operator is waiting in the relief area to perform once you have completed				
1. <u>Step 6.2.1:</u> IF EDG NE02 Jacket Water Cooling System OR Intercooler Cooling Water System have been drained, THEN VENT EDG NE02 Intercooler and Jacket Water Heat Exchangers:		Applicant recognized from initiating cue this step is N/A and proceeded to the next step		
		S/U		
 NOTE If EDG NE02 is to be started for maintenance testing Steps 6.2.2 and 6.2.3 may be marked N/A. These minimum temperature requirements must be met prior to declaring the EDG operable of performing STS's to prove operability. The minimum temperature for operability for Jacket Water temperature is 105°F. The alarm setpoint is 135°E 		Applicant read and understood NOTE, place kept and proceeded to next step S / U		
135°F		370		
 Step 6.2.2: 2. VERIFY Jacket Water temperature FROM ENGINE is greater than or equal to 135°F. Jacket Water Temp°F 	When Applicant locates gage and describes reading it, <u>Then:</u> <u>CUE:</u> Point to 140°F	On Panel KJ121, Applicant located Jacket Water temperature and verified temperature, recorded in space provided S / U		

 Step 6.2.3: VERIFY Lube Oil temperature TO ENGINE is greater than or equal to 115°F. 	<u>When</u> Applicant locates gage and describes reading it, <u>Then:</u> <u>CUE:</u> Point to 120°F	On Panel KJ121, Applicant located Lube Oil temperature and verified temperature, recorded in space provided
Lube Oil TempºF		S / U
 <u>Step 6.2.4:</u> VERIFY Fuel Oil Storage Tank TJE01B level is greater than or equal to 82% (88,170 gallons), as indicated by JE LI-25A or computer point JEL0025 	When Applicant locates indicator and describes reading it, <u>Then:</u> <u>CUE:</u> As indicated	On southeast wall of the DG room, Applicant Located Fuel Oil Storage Tank level and verified level, recorded in space provided
TJE01B Level%		S / U
 <u>Step 6.2.5:</u> VERIFY Emergency Fuel Oil Day Tank TJE02B level is greater than 61%. 	When Applicant locates indicator and describes reading it, <u>Then:</u> <u>CUE:</u> Point to 70%	On Panel KJ121, Applicant Located Day Tank level and verified level, recorded in space provided
TJE02B Level%	<u>COE.</u> Form to 70 %	S / U
 7. <u>Step 6.2.6:</u> 6. ENSURE NB0211, FDR EMER DG NE01 is racked up ○ NB0111 - RACKED UP 	<u>When</u> discussed <u>Then</u> : <u>CUE:</u> Another Operator has performed this step and it has been verified.	Applicant acknowledged cue and proceeded to the next step S / U

8. <u>CAUTION</u> If governor oil level is out of sight glass high or low, the EDG is inoperable		Applicant reads and acknowledges caution, place keeps, and proceeds to next step
		S / U
 9. <u>Step 6.2.7:</u> 7. ENSURE EDG NE02 governor oil level is satisfactory in sight glass Oil level - BETWEEN 1/2 AND 3/4 FULL 	When Applicant locates indication and describes reading it, <u>Then:</u> <u>CUE:</u> 3/4	Applicant Located the sight glass on the engine side of the governor. Checked that oil is visible in the sight glass. Realized from the cues that the engine has been run since the governor was drained last
		S / U
10 <u>Step 6.2.8:</u> 8. RECORD NE02 Governor Speed Set	When Applicant locates speed set and describes reading it, <u>Then:</u>	Applicant located speed set knob on governor and verified position, recorded in space provided
 <u>IF</u> Governor Speed Set is <u>NOT</u> as per CKL ZL-004, TURBINE BUILDING READING 	<u>CUE:</u> As indicated <u>When</u> Applicant discusses comparing	
SHEETS, <u>THEN</u> , NOTIFY the	readings, <u>Then:</u>	

 11 NOTES When closing petcocks, do NOT use excessive force. Torque applied should NOT be greater than the torque generated using either a open or closed end box wrench with a momentarm if no greater than 5" Petcocks are reverse seating and rise away from the valve block when turned in the clockwise direction to close the valve 		Applicant reads and acknowledges note, place keeps, and proceeds to next step
		S / U
 12 <u>Step 6.2.9:</u> 9. ENSURE EDG NE02 cylinder petcocks closed. o Petcocks - CLOSED 	WhenApplicant has located the wrench and as each petcock is tested in turn, Then:CUE:No movement occurred.CUE:How many petcocks need to be checked?	With an open end box wrench Applicant simulated turning first petcock in the clockwise direction to verify no movement. Applicant responded that there are 14 petcocks
	CUE: All 14 petcocks are closed	S / U

13 GStop 6 2 10:	Mileon Analisont	On Danal NE100 Applicant
13 G <u>Step 6.2.10:</u> 10. CHECK both EDG NE02	<u>When</u> Applicant locates lockout relays,	On Panel NE106, Applicant located the lights and each
lockout relays RESET:	Then:	Lockout Relay, determined
1. IF either EDG NE02		they were not reset, and
lockout relay blue light		simulated resetting the relays
NOT lit, <u>THEN</u> RESET	<u>CUE:</u> Neither light is lit	186-1/DG and 186-2/DG by
affected lockout relay		turning switch to the right and
2. Lockout Relay Blue		allowing it to return to the
Lights - LIT	When Applicant	12'oclock position
C	describes how to reset	
<u>*Commence Alternate Path*</u>	the lockout relays, Then:	Applicant may contact the
		control room to inform them of
Lockout Relays Require		the required reset.
manual Reset	CUE: As each relay is	
	reset, BLUE light lit	
	IF Applicant contacts	
	the control room,	
	Then:	
	CUE: acknowledge	S / II
	report	S/U
14 G Step 6.2.11:	<u>When</u> the Applicant	On Panel NE106, Applicant
11. At NE106, DEPRESS KJ	locates the Shutdown	located ENGINE
HS-112, ENGINE	reset, <u>Then:</u>	SHUTDOWN RESET
SHUTDOWN RESET		pushbutton and simulated
• KJ HS-112 –	CUE: Button	depressing
DEPRESSED	depressed	
		S (11
		S / U
15 Step 6.2.12:	<u>When</u> Applicant	At MCC NG04D, Applicant
12. At NG04DBF3, ENSURE	locates switch and	located control switch on
KJ HS-189, DPKJ02B	describes position,	breaker BF3 and verified it is
STANDBY DIESEL ROCKER	Then:	in AUTO
ARM PRE-LUBE PUMP		
MOTOR is in auto	CUE: Control switch	
• KJ HS-189 – AUTO	indicates AUTO	S / U

16 NOTE Placing KJ HS-109, MASTER TRANSFER SWITCH to local will cause annunciator 00- 023E, DG NE02 OOS to alarm and make the EDG inoperable		Applicant reads and acknowledges note, place keeps, and proceeds to next step S / U
 17 <u>Step 6.2.13:</u> 13. IF Exciter Shutdown amber light is lit, THEN RESET Exciter Shutdown, by performing the following: 	<u>When</u> Applicant locates and discusses amber light, <u>Then:</u> <u>CUE:</u> Amber light is NOT lit	On Panel NE106, Applicant locates Exciter Shutdown amber light and determines it is NOT lit
		S / U
 18 <u>Step 6.2.14:</u> 14. ENSURE all target relays with dropped flags are reset 	<u>When</u> Applicant locates and discusses relays, <u>Then:</u>	On Panel NE106, Applicant locates relays and determines all relays are reset
	<u>CUE:</u> All flags are reset	S / U
19 <u>Step 6.2.15:</u> 15. At NE106, ENSURE KJ HS-109, MASTER TRANSFER SWITCH in auto. ○ KJ HS-109 – AUTO	When Applicant locates and discusses switch, <u>Then:</u> CUE: Switch	On Panel NE106, Applicant located KJ HS-109 and determined switch is in the AUTO position
	indicates AUTO	S / U
 20 <u>Step 6.2.16:</u> 16. ENSURE KJ HS-173, FIELD FLASHING CONTROL SW is in rated 	When Applicant locates and discusses switch, <u>Then:</u>	On Panel NE106, Applicant located KJ HS-173 and verified it is in the RATED position
position o KJ HS-173 – RATED/AUTO FLASH	CUE: Switch indicates RATED/AUTO FLASH	S / U

 21 <u>Step 6.2.17:</u> 17. ENSURE EDG NE02 barring device is removed. o Barring Device - REMOVED 	WhenApplicantlocates and describesbarring device block,Then:CUE:Barring deviceis NOT present	On the Diesel engine, Applicant located the area where the barring device is inserted, on the side of the engine below the fuel racks and verifies the device is removed
		S / U
22 @ <u>Step 6.2.18:</u> 18. ENSURE KJ-V775B, ENGINE DRIVEN JACKET WATER PUMP 6B PT-164 INSTRUMENT AIR ISO is open ° KJ-V775B – OPEN	 When Applicant locates and discusses checking the valve open, <u>Then:</u> <u>CUE:</u> Valve does not move in the clockwise direction 	Applicant located Air Iso to PT-164, Starting Air Skid – On East Wall, and determined the valve was closed, simulates opening the valve Applicant may contact the control room to report valve
Commence Alternate Path		found out of position
KJ-V775A should be open	<u>When</u> Applicant discuss opening the valve, <u>Then:</u>	
	<u>CUE:</u> Valve handwheel is moving, handwheel stops moving, valve is open	
	IF Applicant calls control room to report valve out of position, Then:	
	<u>Cue:</u> Acknowledge report	S / U

 23 <u>Step 6.2.19:</u> 19. CHECK all EDG NE02 alarms clear: Local Panel KJ122 – ALL ANNUNCIATORS CLEAR Main Control Board – ALL EDG B ANUNCIATORS CLEAR 	 <u>When</u> Applicant discusses checking KJ-122 alarm panel, <u>Then:</u> <u>CUE:</u> No alarms present <u>When</u> Applicant discusses contacting the Main Control Room, <u>Then:</u> 	On Panel KJ-122, Applicant verified all alarms clear Applicant simulates contacting the Main Control Room and determined all alarms clear in the Main Control Room
	<u>CUE:</u> No alarms present in the Main Control Room	S/U
 24 <u>Step 6.2.20:</u> 20. CHECK fuse indication lights on panel NE106 are lit: ○ IL-7 - LIGHT ON ○ IL-8 - LIGHT ON 	When Applicant locates and describes the indication of the fuse lamps, <u>Then:</u> As each is checked, <u>CUE:</u> Light is Lit	On Panel NE106, Applicant verifies all fuse lights are lit
 IL-9 – LIGHT ON IL-10 – LIGHT ON IL-11 – LIGHT ON 		S / U
25 <u>Step 6.2.21:</u> 21. ENSURE KJBS0101A, BASKET STRAINER FUEL OIL PUMP is aligned to one side of the duplex strainer	<u>When</u> Applicant locates and describes checking how the strainer is aligned, <u>Then:</u> <u>CUE:</u> As indicated.	Applicant locates Fuel Oil Pump Basket Strainer and verifies alignment S / U
26 Applicant completed Step 6.2.21.	<u>CUE:</u> The JPM is complete. <u>RECORD STOP TIME</u> <u>BELOW.</u>	
Terminating The JPM Is complete when the Applicant has successfully completed step		

cue:

TerminatingThe JF M IS Sourcescue:6.2.21 of SYS KJ-121 I is complete when the Applicant has successfully completed step

Plant equipment shall not be operated, if you have a question about the task or need clarification do not hesitate to ask your evaluator. JPM's are considered "open reference", therefore reference material that is normally available to you in the plant (including the Control Room) is available during this JPM. If you desire to use a reference, ask your evaluator if it is acceptable to do so for the task under consideration. You **may not** solicit technical information from other operators, engineers or technical advisors.

- Initial Conditions: The unit is stable in MODE 4. Maintenance has just been completed on the 'B' Emergency Diesel Generator.
- Initiating Cue: The Control Room Supervisor directs you to place 'B' Emergency Diesel Generator in standby for automatic operation in accordance with SYS KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, Section 6.2

The Jacket Water Cooling System and Intercooler Cooling Water System were NOT drained

The governor oil was NOT drained.

The EDG will NOT be run again.

Prerequisites are completed

	WC-2019-11			JPM P2		
Facility: WCN	00		Task No:			
	n Reactor Trip I cted by EMG FF		Job Perfor	rmance Measure I	No: <u>P2</u>	
K/A Reference:	012/2.130 (4.4 controls	l/4.0) Ability	to locate and ope	erate components	, including local	
Examinee:			_ NRC Exar	miner:		
Start:	Stop:		Date:			
Result: <u>Satisfacto</u>	ory / Unsatisfa	<u>ctory</u> Exa	miner Signature:			
Method of testing	<u>g:</u> S	imulated Per	formance X	Actual Perfor	mance	
Classroom		Simu	ılator	Plant 2	х	
Conditions: a		anual. The	crew is performin	d the Reactor faile g EMG FR-S1, R		
٩	lo testing was ir	n progress at	the time of Turb	ine Trip		
	The Control Roo oypass breakers		r directs you to lo	ocally open reacto	or trip and	
Task Standard:	Applicant locally	opened both	n reactor trip and	bypass breakers		
Required N Materials:	lone					
References: E	EMG FR-S1, RE	SPONSE TO	D NUCLEAR PO	WER GENERATIO	ON/ATWS	
Time N Critical:	lo	Alternate Path:	No	Validation Time:	10 min	

START TIME:

JI	PM STEP / PROCEDURE STEP ଢ - CRITICAL STEP	CUE	STANDARD				
	Examiner Note: JPM steps 2-5 may be performed in any order, Bypass breakers in the given plant conditions should already be open. Cue: DO NOT remove breaker <i>trip switch dust covers.</i> If at any time the Applicant discusses opening the cabinet door to verify breaker position, THEN Show picture and Cue: Breaker position as <i>indicated.</i>						
1.	Operator dispatched to locally open reactor trip and bypass breakers		Applicant proceeded to the 2026' Level of the Auxiliary Building and entered the Rod Drive M/G Room				
			S/U				
2.	Locally open reactor trip and bypass breakers ©Open Reactor Trip Breaker 'A'	<u>WHEN</u> Applicant simulates depressing the TRIP pushbutton, <u>THEN:</u>	On Panel SB102B, Applicant located Reactor Trip Breaker 'A', removed MANUAL TRIP COVER and depressed TRIP pushbutton.				
		<u>CUE:</u> Breaker trip sound is heard.					
			S / U				
3.	Locally open reactor trip and bypass breakers ©Open Reactor Trip Breaker 'B'	WHEN Applicant simulates depressing the TRIP pushbutton, THEN:	On Panel SB102B, Applicant located Reactor Trip Breaker 'B', removed MANUAL TRIP COVER and depressed TRIP pushbutton.				
		<u>CUE:</u> Breaker trip sound is heard	S / U				

JPM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
 4. Locally open reactor trip and bypass breakers Bypass Breaker 'A' 	IF Applicant simulates removing manual trip cover to verify breaker is open, <u>THEN:</u> <u>CUE:</u> No sound is heard.	Applicant determined from initial conditions that the Bypass Breaker was open OR On Panel SB102A, Applicant located Bypass Breaker 'A', removed MANUAL TRIP COVER, and depressed TRIP pushbutton.
5. <u>Locally open reactor trip</u> and bypass breakers Bypass Breaker 'B'	IF Applicant simulates removing manual trip cover to verify breaker is open, <u>THEN:</u> CUE: No sound is heard.	Applicant determined from initial conditions that the Bypass Breaker was open OR On Panel SB102A, Applicant located Bypass Breaker 'B', removed MANUAL TRIP COVER, and depressed TRIP pushbutton. S / U
6. Control Room notified that Reactor Trip and Bypass Breakers are Open	CUE: The JPM is complete. RECORD STOP TIME BELOW.	Applicant contacted the control room and reported that Reactor Trip and Bypass Breakers are open S / U
Terminating cue: The JPM Is comple	te when the applicant has o	nened the Reactor Trin

Terminating cue: The JPM Is complete when the applicant has opened the Reactor Trip Breakers

WC-2	019-11
------	--------

Plant equipment shall not be operated, if you have a question about the task or need clarification do not hesitate to ask your evaluator. JPM's are considered "open reference", therefore reference material that is normally available to you in the plant (including the Control Room) is available during this JPM. If you desire to use a reference, ask your evaluator if it is acceptable to do so for the task under consideration. You **may not** solicit technical information from other operators, engineers or technical advisors.

Initial Conditions: A Turbine trip occurred from 100% power, and the Reactor failed to trip in both automatic and manual. The crew is performing EMG FR-S1, RESPONSE TO NUCLEAR POWER GENERATION/ATWS

No testing was in progress at the time of Turbine Trip

Initiating Cue: The Control Room Supervisor directs you to locally open reactor trip and bypass breakers

WC-2019-11			JPM P3		Form ES-C-1	
Facility: WC	NOC		Task No [.]			
Facility: WCNOC Task No: Task Title: Isolate RCP seals per EMG C-0, Step 16 Job Performance Me					No: <u>P3</u>	
K/A Reference	e: 003/A4.01 (3.3 room: Seal inj	, · ·	[,] to manually ope	rate and/or monito	or in the control	
Examinee:			NRC Exar	miner:		
Start:	Stop:		Date:			
Result: <u>Satisfa</u> <u>Method of test</u> Classroom		imulated Per	C C	Actual Perform	nance	
Initial Conditions:	The unit tripped EMG C-0, LOSS			AC power. The cro	ew has entered	
Initiating Cue:				ou to perform EMG valves to isolate l		
Task Standard:				V105, EG HV-61, S OF ALL AC POW		
Required Materials:						
References:	EMG C-0, LOSS OF ALL AC POWER					
Time Critical:	No	Alternate Path:	No	Validation Time:	15 min	

START TIME:

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 Carbon Step 16.a: 16. Dispatch Personnel To Locally Close Valves to Isolate RCP Seals: a. Seal Water Return 	<u>When</u> the Applicant locates the valve and discusses engaging the declutch <u>Then:</u>	Applicant located valve BG HV-8100 in the Aux Building, 2000' level, South Penetration Room
Containment Isolation Valve o BG HV-8100 (2000'AUX BLDG, SOUTH PIPE PEN ROOM LOWER LEVEL)	<u>CUE:</u> Declutch lever is engaged <u>When</u> the Applicant discusses closing the valve <u>Then:</u>	Applicant simulated disengaging clutch lever while turning the handwheel in a clockwise direction Declutch lever may be released once it engages
	<u>CUE:</u> Handwheel is turning in the clockwise direction Stem is inserting	Applicant continued turning the handwheel clockwise until the stem was fully inserted and the handwheel stopped turning
	Handwheel stops turning	
	Stem is inserted	
		S / U

JPM STEP / PROCEDURE STEP © - CRITICAL STEP	CUE	STANDARD
 2. <u>GStep 16.b:</u> b. Seal Water Injection Filters Inlet Isolations BG-V101 (2000' AUX BLDG., DEMIN ALLEY BA/SEAL INJ FILTER A VALVE ROOM) BG-V105 (2000' AUX BLDG, DEMIN ALLEY CTMT COOLANT FILTER/SEAL INJ FILTER/SEAL INJ FILTER B VALVE ROOM) 	Examiner Note: reach rods are disconnected IF the Applicant discusses having to reach across a contaminated boundary Then: CUE: Rubber gloves have been obtained and donned When the Applicant locates the valve(s) and discusses closing the valve(s) Then: CUE: T-handle is turning in the clockwise direction Stem is inserting T-handle stops turning Stem is inserted	Applicant located valve BG- V101 T-handle operator in the Aux Building, 2000' level in the Demin Alley BA/Seal Inj Filter A Valve Room Applicant turned the operator clockwise until the operator stopped turning and noted the stem position Applicant located valve BG- V105 T-handle operator in the Aux Building, 2000' level in the Demin Alley CTMT Coolant Filter/Seal Inj Filter B Valve Room Applicant may discuss allowances of RWP 19-005 to reach across Contaminated Area Boundary postings Applicant turned the operator clockwise until the operator stopped turning and noted the stem position.
		S / U

JPM STEP / PROCEDURE STEP & - CRITICAL STEP	CUE	STANDARD
 3. G<u>Step 16.c:</u> c. CCW Return From RCS Isolation Valve O EG HV-61 (2000' AUX BLDG NORTH PIPE 	<u>When</u> the Applicant locates the valve and discusses engaging the declutch <u>Then:</u>	Applicant located valve EG HV-61 in the Aux Building, 2000' level, North Penetration Room
PEN ROOM)	CUE: Declutch lever is engaged	Applicant simulated disengaging clutch lever while turning the handwheel
	<u>When</u> the Applicant discusses closing the valve <u>Then:</u>	in a clockwise direction Declutch lever may be released once it engages
	<u>CUE:</u> Handwheel is turning in the clockwise direction	Applicant continued turning the handwheel clockwise until the stem was fully
	Stem is inserting	inserted and the handwheel stopped turning
	Handwheel stops turning	
	Stem is inserted	
		S / U

J	PM STEP / PROCEDURE STEP ଢ - CRITICAL STEP	CUE	STANDARD
4.	©<u>Step 16.d:</u> d. CCW From RCS CTMT Isolation Valve Bypass EG HV-133 (2000' AUX BLDG NORTH PIPE PEN ROOM)	When the Applicant locates the valve and discusses engaging the declutch <u>Then:</u> <u>CUE:</u> Declutch lever is engaged	Applicant located valve EG HV-133 in the Aux Building, 2000' level, North Penetration Room
		<u>When</u> the Applicant discusses closing the valve <u>Then:</u>	Applicant simulated disengaging clutch lever while turning the handwheel in a clockwise direction
		<u>CUE:</u> Handwheel is turning in the clockwise direction	Declutch lever may be released once it engages Applicant continued turning the handwheel clockwise
		Stem is inserting Handwheel stops	until the stem was fully inserted and the handwheel stopped turning
		turning	
		Stem is inserted	S / U
5.	Inform the Control Room that step 16 of EMG C-0 has been completed	<u>When</u> the Applicant contacts the Control Room <u>Then:</u>	Applicant informed the Control Room that step 16 of EMG C-0 is complete
		<u>CUE:</u> Acknowledge report	
		<u>CUE:</u> The JPM is complete.	S/U
		RECORD STOP TIME BELOW.	

Terminating cue: The JPM Is complete when the Applicant has successfully completed step 16 of EMG C-0, LOSS OF ALL AC POWER

WC-2	019-11
------	--------

Plant equipment shall not be operated, if you have a question about the task or need clarification do not hesitate to ask your evaluator. JPM's are considered "open reference", therefore reference material that is normally available to you in the plant (including the Control Room) is available during this JPM. If you desire to use a reference, ask your evaluator if it is acceptable to do so for the task under consideration. You **may not** solicit technical information from other operators, engineers or technical advisors.

- Initial Conditions: The unit tripped due to a complete loss of all AC power. The crew has entered EMG C-0, LOSS OF ALL AC POWER.
- Initiating Cue: The Control Room Supervisor has directed you to perform EMG C-0, LOSS OF ALL AC POWER, Step 16, to locally close valves to isolate RCP seals.

Appendix D

Scenario Outline

Facility:		ek Sc	anario No :	1	Op-Test N	o : De	ombor (2010	
Facility.					Op-rest N	0 <u>Dec</u>		2019	
Examiners: Operators:									
		nit is in MODE 2,							
		s operating in MC MINIMUM LOAD							
		fs entry to MODE							
		nnunciators 103D							
		1 Close either BG CCW Pump withi							
		tion before RWS							
open.	-								
Event	Malf.	Event Type*			Event				
No.	No.				scription				
1				ump 'A' Trips					
		(BOP/CRS) C), Section 6.2.1 120 VAC Instrur	ment Bus N	N03. O	FN NN-	021	
2		(ATC/CRS)	LCO 3.8.7 C	OND A, LCO 3.8					
		Tech Specs		OND A (DNBR) CSAS on Red Tr	ain				
3		(ATC/CRS)	LCO 3.6.6 C	OND A, 3.3.2, F		COND	A & C		
		Tech Specs	ALR 00-059/	A, OFN EN-049 Steam Dump Coc		l faile	HIGH in	Auto	
4		(All)	AP15C-003,	OFN AB-041					
5		M (All)	Earthquake, EMG E-0, EI	Large Break LO	CA (18") or	Loop 4	4 Cold L	eg	
		C	Valves BG H	IV-8160, BG HV-	-8152, and	KA HIS	-29B fai	l to	
6		(ATC/CRS)	Auto Close o	on CISA TT F, Step F3					
		с	'B' CCW pur	np trips, 'A', 'C',	and 'D' CC	W Pum	ps fail to		
7		(BOP/CRS)	autostart on	SIS IT F, Step F6					
		С	EJ HV-8811	B, CTMT SUMP	TO RHR P	UMP S	UCTION	fails	
8		(All)	to open on R EMG ES-12	WST LOLO					
*	(N)ormal,	(R)eactivity, (I)nst	rument, (C)omp	oonent, (M)ajor					
Targ	et Quantitativ	ve Attributes per Sce	enario (See	Actual Attributes	ES-301-5	CRS	ATC	BOP	
		Section D.5.d)					-		
1. Ma	alfunctions after	er EOP entry (1–2)		3	Rx	0	0	0	
2. Ab	normal events	s (2–4)		4	Nor	0	0	0	
3. Major transients (1–2)				1	I/C	7	5	4	
4. EC	Ps entered/re	equiring substantive ad	ctions (1–2)	2	Maj	1	1	1	
	try into a cont 1 per scenario	ingency EOP with sub o set)	stantive actions	0	TS	2	0	0	
6. Pre	6. Preidentified critical tasks (≥ 2) 3								

Critical Task	Critical Task Safety Significance		Measurable Performance Indicators	Performance Feedback
CT1 : Close either BG HIS-8160 or BG HIS-8152 containment isolation valves before completion of EMG E-0, Attachment F.	The non-essential containment penetrations are isolated to prevent potential release of radioactive materials from containment. With both BG HIS- 8160 and BG HIS- 8152 open, a release path to the environment exists. KA HIS-29B is failed open to prevent these valves from failing closed.	tial Red lights lit on *BG HIS-8160 e *BG HIS-8152 RL001, Depress cLOSE on: *BG HIS-8152 ent e of ESFAS Status pANEL CISA section White Lights NOT LIT. iS- lease *BGHV8152 (Red) *BGHV8160(Yellow)		Green lights lit on *BG HIS-8160 *BG HIS-8152 ESFAS Status Panel ICSA Section White Lights LIT for Yellow Train if BG HV8160 closed. Red Train White Lights require both BG HV8152 and KA HIS28B closed.
CT2: Manually start 'A', 'C', or 'D' CCW pump to cool one Train of ECCS equipment within 30 minutes of SIS to prevent the loss of CCP or SI pumps.	Failure to maintain CCW flow to ECCS components would result in a reduction of margin of safety due to loss of all CCW flow only by improper crew response. AI 21- 016 specifies TSA to trip CCPs and SIPs on a loss of CCW cooling within 30 minutes.	Green lights are lit on CCW hand switches * EG HIS-21 <u>and</u> * EG HIS-23 <u>and</u> * EG HIS-24 Amber light lit on CCW hand switch * EG HIS-22	On Panel RL- 019, Manually start one Red or Yellow Train CCW Pump. Either: * EG HIS-21 <u>or</u> * EG HIS-23 <u>or</u> * EG HIS-24	Red Light on the manipulated hand switch, * EG HIS-21 <u>or</u> * EG HIS-23 <u>or</u> * EG HIS-24
CT3 : Realign from ECCS injection mode to cold leg recirculation before RWST level reaches 6% with a failure of EJ HV-8811B to automatically open.	Unnecessary loss/reduction of core cooling. ECCS pumps taking suction from the RWST are required to be stopped when RWST level reaches 6% in order to prevent loss of suction flow to the pumps and potential pump damage.	RWST Level <36% Annunciator 047D On Panel RL-017, Green Light Remains Lit on * EJ HIS-8811B.	On Panel RL- 017, Manipulates controls: * EJ HIS-2 to Stop * BN HIS- 8812B to CLOSE * EJ HIS-8811B to OPEN * EJ HIS-2 to Run	- Green Light on EJ HIS-2 - Green light on BN HIS-8812B - Red Light on EJ HIS-8811B - Red Light on EJ HIS-2 - 'B' RHR Restoration conditions: Pressure * EJ PI-615 Flow * EJ FI-619

Note: Causing an unnecessary plant trip or ESF actuation may constitute a Critical Task failure. Actions taken by the applicant(s) will be validated using the methodology for critical tasks in Appendix D to NUREG-1021.

Scenario Outline

Form ES-D-1

SCENARIO # 1 NARRATIVE

Turnover: The Unit is in MODE 2, operating at 4% power, BOL with 'A' MFP in service. Maintain current power level while the crew briefs for entering MODE 1. Annunciators 103D and 103E are written on the White Board.

Event 1: 'A' Condenser Mechanical Vacuum Pump Trips. A NPIS alarm will the first indication of pump trip as vacuum will not degrade very fast. The crew may use section 6.2 of SYS CG-120 to start a standby condenser vacuum pump. If Vacuum degrades to Ovation alarm setpoint of 4 inches, the crew may perform OFN AF-025, Attachment F. Step F6 directs using SYS CG-120 to start standby condenser vacuum pumps. Once a standby condenser vacuum pump is started and at the direction of the lead evaluator, the next will start.

Event 2: Loss of bus NN03. Annunciators 027A and 027C will actuate, indicating a loss of instrument bus power, as well as multiple annunciators that are symptoms of that power loss. Partial Trip Status PERMIS/BLOC Panel, SB-069, will also show columns of white lights for the loss of NN03 powered equipment. The CRS will direct "Select out Blue" which will prompt which will prompt ATC and BOP Operators to select alternate channels as memory actions. The ATC will select manual on the PZR Master Pressure Controller before selecting an alternate channel to prevent lifting a PORV. The BOP will manually isolate 'C' ARV. The crew will perform OFN NN-021 and dispatch the Turbine Building Watch to investigate the loss of power, which was due to a maintenance worker inadvertently bumping open breaker NN0301. Closing this breaker restores power to NN03. Once the crew has reenergized the bus and determined applicable technical specifications, the next event will start as directed by the Lead Examiner.

Event 3: Inadvertent CSAS. An inadvertent CSAS will actuate on 'A' Train and annunciator 059A will alarm. The crew will place EN HIS-3 in Pull-to-Lock as a Memory Action Step per OFN EN-049. The CSAS signal will NOT be able to be reset for the given failure, so the crew will have to evaluate LCO 3.6.3, 3.6.6, 3.6.7, 3.7.7 and 3.03 per step 16. Once Technical Specifications have been evaluated, Event 2 will start at the direction of the Lead Examiner.

Event 4: AB UK-33, Steam Dump Cooldown Controller fails HIGH in Auto. Controller Failure will be diagnosed by AB UK-33 output rising to 100% and the three Steam Dump Valves, AB UV34, AB UV-45 and AB UV41 fully opening. As a result of the steam dump valves opening, Tavg will drop, adding positive reactivity which will cause inadvertent MODE change to MODE 1 without prompt Operator Action. S/G Levels rise due to swell causing MCB Annunciators 109B-111B to actuate. The BOP should take manual control of the failed AB UK-33 controller per AP15C-003, Manual Back-up to stabilize plant conditions. Once plant conditions are stable, the Major event will start as directed by the Lead Examiner.

Event 5: Earthquake, Large Break LOCA (18") on Loop 4 Cold Leg. The earthquake will be felt and associated annunciators will all actuate (98B, 98D, 98E). The crew will diagnose RCS pressure and PZR Level lowering, as well as degrading conditions in CTMT, and manually trip the Reactor, actuate SI and perform EMG E-0 Immediate Actions. The next three post-trip events will also be addressed by the crew.

Event 6: Three CTMT Isolation Valves fail to close on CISA. (BG HV-8160 LTDN SYS INNER CTMT ISO VLV, BG HV-8152 LTDN SYS OUTER CTMT ISO VLV, and KA HIS-29 INST AIR SPLY CTMT ISO VLV). This failure will be indicated on the ESF SYS Status Indication boards. The ATC, while performing EMG E-0, ATTACHMENT F should manually close one of the two valves Letdown valves to isolate the open path from CTMT while performing Step F3. The failure of KA HIS-29 supports the critical task as BG HIS-8160 fails closed on a loss of air to containment.

CT1: Close either BG HV-8152 or BG HV-8160 containment Phase-A isolation valves to isolate a relief path from containment prior to completion of EMG E-0, Attachment F.

Scenario Outline

Event 7: 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. The BOP, after completing Immediate Actions, should note no operating CCW Pump running to cool Red or Yellow Train Safety Loads and manually start either 'A', 'C', or 'D' CCW Pumps. The ATC also has guidance per EMG E-0, ATTACHMENT F, Step F6, to manually start one of the two pumps in each train if one is NOT running at that time.

CT2: Manually start 'A', 'C', or 'D' CCW pump to cool one Train of ECCS equipment within 30 minutes of SIS to prevent the loss of CCP or SI pumps.

Event 8: EJ HV-8811B, CTMT SUMP TO RHR PUMP SUCTION fails to open on RWST LOLO The crew will perform actions of EMG E-1, until RWST level drops to 36% and Annunciator 47D, RWST LEV LOLO1 AUTO XFR actuates. EJ HIS-8811B fails to auto open and because of RHR pump suction interlocks, the crew will have to Stop B RHR Pump, Close BN HIS-8812B, Open EJ HIS-8811B and restart B RHR Pump to complete the lineup for Cold Leg recirc on B Train. CT3: Realign from ECCS injection mode to cold leg recirculation before RWST level reaches 6% with a failure of EJ HV-8811B to automatically open.

The scenario is complete when the crew completed procedure EMG ES-12 and verified cold leg recirculation.

Scenario Outline

SIMULATOR SCENARIO FILES

;2019 ILO NRC Exam, Scenario 1 (IC 301)

;Initial Conditions – IC301,4% Power, BOL, RHR Pump 'A' OOS for emergent work (For Scenario) ICR bkrNB00101 t:2

;Event 1 – Key 1 - Condenser Vacuum Pump Trips ICR mtrDCCG01A t:1 k:1

;Event 2 – Key 2 - Loss of Bus NN03 (ATC/CRS, Tech Specs) IMF mNN03 i:-1 f:-1 k:2

;Event 3 – Key 3 – Inadvertent CSAS on Red Train (ATC/CRS – TS) IMF mSA02A k:3

;Event 4 – Key 4 – AB UK-33, Steam Dump Cooldown CTRL fails HIGH in Auto (Reactivity) ICM cntABUK0033 f:75 r:120 k:4

;Event 5 - Key 5 - Earthquake, Large Break LOCA (18") on Loop 4 Cold Leg (Major) IMF mSG01 f:60 k:5 IMF mBB06D f:18 r:60 k:5

;Event 6 – Three CISA Valves fail to Auto Close (ATC - CT) IMF mSA27KA01 IMF mSA27BG07 IMF mSA27BG08

;Event 7 – 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS (BOP - CT) IMF mEG14A IMF mEG14C IMF mEG14D {jpplsi} ICM bkrDPEG01B.cmf t:1

;Event 8 – EJ HV-8811B, CTMT SUMP TO RHR PUMP SUCTION fails to open on RWST LOLO {jpplsi} IMF mSA27EJ07B

;Local Action – **Key 9** - Reenergize Bus NN03 {Key[9]} DMF mNN03

;Local Action – **Key 10 -** Turbine Building Watch Locally closes breakers for BAT pumps. IRF rBG40A f:1 k:10 IRF rBG40B f:1 d:30 k:10

;Local Action - **Key 11 -** Aux Building Watch locally closes breaker for BG HV-8104 IRF rBG41 f:1 k:11

;Local Action – **Key 12** – Align 'A' Emergency Diesel Generator for AUTO {Key[12]} scn SimGroup\EDGA_STBY

;Local Action – **Key 13** – Align 'B' Emergency Diesel Generator for AUTO {Key[13]} scn SimGroup\EDGB_STBY

Appen	dix	D
-------	-----	---

Scenario Outline

Booth Instructions

Ensure NRC Exam Security Established per AIF 30B-015-09, and AIF 30B-015-18

Ensure the following procedures are available, free of markings and are the most recent revision in Curator (11/04/19):

- GEN 00-003, HOT STANDBY TO MINIMUM LOAD (Rev 102)
- □ SYS CG-120, ESTABLISHING MAIN CONDENSER VACUUM (REV 24)
- □ ALR 00-059A, CSAS (Rev 12)
- □ ALR 00-109B, SG B LEV DEV (Rev 10A)
- □ ALR 00-109C, SG B FLOW MISMATCH (Rev 11A)
- □ OFN NN-021, LOSS OF VITAL 120 VAC INSTRUMENT BUS (Rev 29)
- □ OFN EN-049, SPURIOUS CSAS AND CISB RECOVERY (Rev 2)
- □ EMG E-0, REACTOR TRIP OR SAFETY INJECTION (Rev 41A)
- □ EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT (Rev 30)
- □ EMG ES-12, TRANSFER TO COLD LEG RECIRCULATION (Rev 23)

NOTE: All events are loaded into snap IC301

Ensure malfunctions, including severity levels match scenario.

Ensure scenario runs for at least 10-15 minutes to allow data trends to populate

Ensure marked up copy of GEN 00-003 is available to the CRS, up to step 6.10

Ensure critical parameter white board is displayed with RCS T_{avg} control band 555°F – 560°F

Ensure all meters, lamps, bistables and annunciators are correct for the initial setup. <u>Blue</u> <u>Placard is on the 'A' CCP. 103D and 103E written on the white board</u>

Ensure soft panel display in back is set to <u>RP312 RCP Vibration</u> on left screen and <u>AMSAC</u> on right screen.

Ensure no discernable history from RM11, Ovation screens, paper trend recorders, etc.

Ensure all laminated brief sheets, foldout pages, E plan boards are wiped clean.

Ensure all follow-up buttons are removed from the boards and trash cans and recycle bins are free of any potential exam material.

Ensure communications are established with the lead examiner, fresh batteries, radio check sat.

Appendix D	Scenario Outline
------------	------------------

Critical Parameter Data to be collected:

Time from SIS Actuation until either 'A', 'C' or 'D' CCW Pump is Manually Started. The crew must manually start a CCW Pump on at least one safety train within 30 minutes to restore Red Train ECCS cooling.

Form ES-D-1

RWST Level, BN LR-930. The crew must complete Swap to Cold Leg Recirc per EMG ES-12 prior to RWST level lowering to 6% to prevent loss of ECCS pump suction.

Ensure Horns are ON and machine is in RUN

Insert Key 1 for Event 1 (Cond Vacuum Pump Trips)

Insert Key 2 for Event 2 (Loss of Bus NN03). <u>When directed</u> to shut breaker NN0301, Insert Key 9 <u>When directed</u> to Locally Acknowledge alarms on NK03, Soft Panel

Insert Key 3 for Event 3 (Inadvertent Containment Spray on Red Train)

Insert Key 4 for Event 4 (AB UK-33 fails HIGH in Auto)

Insert Key 5 for Major Event (Earthquake, Large Break LOCA on D Cold Leg, CISA valves fail to close, Red Train CCW Pumps fail to auto start on SI, EJ HV-8811B fails to open on RWST LOLO)

When directed to reset and close breakers for BAT pumps, Insert Key 10

When directed to reset and close breaker for BG HV-8104, Insert Key 11

When directed to align 'A' EDGs for AUTO start, **Insert Key 12**

When directed to align 'B' EDGs for AUTO start, Insert Key 13

Op Test	No.: Dec 2019	Scenario No.: 1 Event No.: 1 Total No Pages 27		
Event De	escription: Cond	enser Vacuum Pump A Trips		
Time	Position	Applicant's Actions or Behavior		
Simulator Operator: Insert Key 1 at the lead examiners direction Diagnostics: NPIS Alarm, Amber light lit on CG HIS-1, If pump trip is not recognized in a timely manner, Vacuum degrades, as indicated on TCS ovation screen.				
Annuncia	ators: None Crew	Recognized Pump Trip and directs starting of standby pumps or goes to SYS CG-120 to address		
 Simulator Operator: IF contacted as TB Watch to investigate, acknowledge requests, Wait 2 minutes and report pump casing is hot to touch and the pump is NOT running. WHEN contacted as TB Watch to verify Condenser vacuum pumps B or C, report pump-pre-start checks are Satisfactory WHEN contacted as TB Watch to verify suction valves opened for the Condenser Pump that was started, Report CG PV-2 is OPEN for B Pump, and/or CG PV-3 is OPEN for C Pump. 				
• <u>IF</u> CC		M, Or Call Supt, acknowledge requests. G-120, ESTABLISHING MAIN CONDENSER VACUUM		
	ВОР	 6.2 Condenser Vacuum Pump Operations 6.2.1 IF starting a Condenser Vacuum Pump, THEN perform the following: 1. ENSURE starting conditions are satisfactory for the Condenser Vacuum Pump being started * CCG01B, CONDENSER VACUUM PUMP - SAT * CCG01C, CONDENSER VACUUM PUMP - SAT 2. START desired Condenser Vacuum Pump(s). * Start CCG01B, using CG HIS-2, COND VAC PUMP B. O CG HIS-2 NORMAL-AFTER-RUN * Start CCG01C, using CG HIS-3, COND VAC PUMP C 		
		 CG HIS-3 NORMAL-AFTER-RUN VERIFY Condenser Mechanical Vac Pump Suction valves opened for the Condenser Vacuum Pumps that were started. * Verify CG PV-2, CONDENSER MECHANICAL VAC PMP 1B SUCT PNEU ISO is open. CG PV-2 - OPEN * Verify CG PV-3, CONDENSER MECHANICAL VAC PMP 1C SUCT PNEU ISO is open. CG PV-3 - OPEN 		

 Op Test No.: Dec 2019
 Scenario No.: 1
 Event No.: 1
 Total No Pages 27

 Event Description: Condenser Vacuum Pump A Trips

 Event Termination:
 After a Cond Vacuum Pump is started and/or at the direction of the lead examiner.

 Simulator Operator:
 Insert Key 2 at direction of the Lead Examiner.

Op-Tes	t No.: Dec 2019	Scenario No	o.: 1	Event No.: 2	Tota	l No Pages 27
Event D	escription: Loss	of Vital 120 VA	C Instrument	Bus NN03		
Time	Position		Applica	nt's Actions or	Behavior	
Simulato	Simulator Operator: Insert Key 2 at direction of Lead Examiner.					
-	tics: Multiple alar equipment	ms, alarm pane	SB069 will sh	low columns of	white lights for	the NN03
Annunci	ators: Multiple, ir	ncluding 027A ar	nd 027B			
	CREW	Diagnoses fail	ure of bus NN	03		
Operator color to s channels	Examiner Note: The NN alarms and associated instruments have color placards to assist the Operators in identifying the affected instruments. The Crew will communicate which instrument bus color to select away from, e.g. "Select Out Blue." The ATC and RO will select away from blue channels prior to entering the ALR or OFN. Delay in selecting away from the affected instruments could result in reactor trip.			nstrument bus om blue		
	CRS	Enters and directs either ALR 00-027A or OFN NN-021				
		ALR 00-	027A, NN03 I	NST BUS UV		
Step 1 i	s a Memory Act	ion step	<u>NOTE</u>			
	ATC 1. Ensure PZR Control Signals – USING UNAFFECTED CHANNELS a. Check alternate channel selection required – Yes b. Check pressurizer pressure channel affected – Yes c. Place Pressurizer Master Controller in manual o BB PK-455A – IN MANUAL d. Select alternate channel, using table below			HANNELS		
		AFFECTED BUS	P2 PRES	R SURE	PZ LEV	
			SWITCH	SELECT CHANNEL	SWITCH	SELECT CHANNEL
		NN03 BLUE TRAIN	PS-455F	P455/P456	LS-459D	L459/L460
		e. Return F BB PK-455		ster Controller to	b auto, as dire	cted by CRS
	ATC/BOP	2. Dispatch Op actions as dire			s with Interloc	k Key to perform

Event De		Scenario No.: 1		t No.: 2 1N03	Total No Pages 27
Time	Position		Applicant's Actions or Behavior		
	CRS	3. Refer to Technical	Specifications	s 3.8.9, 3.8.10 ai	nd 3.3.1
		Enters LCO 3.8.9 Di hrs	stribution Sy	stems – Operat	ing, Condition C – 2
		CRS may also enter A – 2 hours (for DN		Reactor Coolar	nt System, Condition
	CRS	4. Go To OFN NN-02 Step 1	21, LOSS OF \	/ITAL 120 VAC	INSTRUMENT BUS,
	OFN	NN-021, LOSS OF VIT	AL 120 VAC I	NSTRUMENT E	BUS
		∆ done in any order mory Action steps	<u>IOTES</u>		
	ATC	1. Loss of NN01 or N	IN02 with Conf	rol Rods insertir	ng – No
		RNO Go to step 2			
	BOP	2. Ensure S/G Contro	ol Systems are	using Unaffecte	ed Channels: - Yes
		No blue channels or	n the S/G Cont	trol Systems	
	ATC	3. Ensure PRESSUR Unaffected Channels a. Check pressuri b. Place Pressuri o BB PK-45 c. Select alternate	: izer pressure c zer Master Coi 55A	hannel affected htroller in manua	– Yes
			PZR PI	RESSURE	
		AFFECTED BUS	SWITCH	SELECT CHANNEL	
		NN01 RED TRAIN	PS-455F	P457/P456	
		NN02 WHITE TRAIN	PS-455F	P455/P458	
		NN03 BLUE TRAIN	PS-455F	P455/P456	
		NN04 YELLOW TRAIN	PS-455F	P455/P456	
		o BB PK-45 e. Return Pressur	55A – ADJUST	ED	e pressure to normal as directed by CRS
	ATC	4. Ensure PZR Level a. Check pressurizer			ted Channels:
		RNO Go to step 5			

Time	Position	Applicant's Actions or Behavior
Simulator Operator: Contact the Control Room and report that maintenance worker bumped open NN0301. There is no apparent damage to the bus		
	ATC ATC/BOP	 5. (ρ) Check RWST Switchover has occurred: - No * "A" Train Swapped over BG HIS-112B – CLOSED BG HIS-112D – OPEN OR * "B" Train Swapped over BG HIS-112C – CLOSED BG HIS-112E – OPEN RNO Perform one of the following: IF letdown has isolated, THEN go to step 6 * IF letdown is NOT isolated, THEN go to step 7 7. Stabilize Plant:
		a. Stop any plant operations requiring rod motion b. (ρ) Adjust turbine load, as necessary, to maintain T _{avg} within 3°F or T _{ref}
	CRS	 8. Go to appropriate Attachment: Loss of NN01 – ATTACHMENT A Loss of NN02 – ATTACHMENT B Loss of NN03 – ATTACHMENT C – Yes Loss of NN04 – ATTACHMENT D
	ATTACHME	NT C, LOSS OF VITAL INSTRUMENT BUS NN03 (BLUE TRAIN)
	ATC	 C1. Defeat RCS Temperature Control for Loop 3: a. Position Loop Tavg Control Signal to – T432 o BB TS-412T b. Position Loop ΔT Control signal to – T431 o BB TS-411F
	BOP	C2. Lock S/G C Atmospheric Relief Valve Manual Drive Lever in Closed Position • AB PIC-3A
	CREW	C3. Determine NN03 Status: a. Check NN03 Bus – NO APPARENT DAMAGE – Yes b. Ensure NN03 normal feeder breaker closed o NN0301 – CLOSED

Op-Test	No.: Dec 2019	Scenario No.: 1 Event No.: 2 Total No Pages 27
Event De	escription: Loss	of Vital 120 VAC Instrument Bus NN03
Time	Position	Applicant's Actions or Behavior
	ATC	C4. Check NN03 – POWERED FROM INVERTER NN13 PRIOR TO BUS LOSS
		a. Check Inverter NN13 System Output Volts normal b. Go to step C8
		EN contacted as Turbine Building Watch to report NN13 System Output st and report NN13 output voltage is 120 volts AC
		NOTE
Inverter (Output indication	(amps) is bypassed with the Maintenance Bypass switch in Bypass Position
	CRS	C8. Refer to Applicable Technical Specifications: *3.8.7, Inverters – Operating *3.8.8, Inverters – Shutdown *3.8.9, Distribution Systems – Operating *3.8.10, Distribution Systems – Shutdown
		Enters LCO 3.8.7 Inverters – Operating, Condition A – 24 hours Enters LCO 3.8.9 Distribution Systems – Operating, Condition C – 2 hours
		Examiner Note: LCO 3.8.7 & 3.8.9 applies while breaker NN0301 was open. The LCO would be logged into, and exited, once NN0301 was reclosed
	CRS	C9. Verify Protection and Control Interlocks are in their correct states per Tech Spec LCOs LCO 3.3.1 Condition S and T LCO 3.3.3 Condition L
	ATC	C10. Check Charging and Letdown Flow – AFFECTED BY NN BUS LOSS – No
		RNO Go to step C15
	ATC	C15. Check if PZR Variable Heaters can be energized: a. PZR Level – GREATER THAN 20% - Yes b. Reset and energize variable heaters o BB HIS-50 c. Ensure PZR Level – STABLE AT OR TRENDING TO PRGRAMMED VALUE – Yes

Op-Test	No.: Dec 2019	Scenario No.: 1 Event No.: 2 Total No Pages 27
Event De	escription: Loss	s of Vital 120 VAC Instrument Bus NN03
Time	Position	Applicant's Actions or Behavior
	ATC	C16. Verify PZR Pressure Control Established: a. Spray Valves – MODULATE, AS NECESSARY, TO CONTROL PRESSURE – Yes b. PZR Pressure – STABLE – Yes c. PZR Heaters – ENERGIZE, AS NECESSARY, TO CONTROL PRESSURE d. PZR PORVs – AT LEAST ONE AVAILABLE – Yes o BB HIS-455A o BB HIS-456A
	ATC	C17. Check NN03 – DEENERGIZED – No RNO Go to Step C27
	ATC	C27. Check NN03 – ENERGIZED – Yes
	BOP	C28. Position S/G C Atmospheric Relief valve to Automatic: a. Depress auto pushbutton o AB PIC-3A b. Return manual drive lever to mid position
	ATC	 C29. Return RCS Temperature Control to Normal: a. Position Loop Tavg Control Signal to – NORMAL o BB TS-412T b. Position Loop ΔT Control Signal to – NORMAL o BB TS-411F
	BOP	C30. Check C-16 Hold Active: o On Graphic 5570, LOAD CONTROL LOOP REJECTED – NOT RED – Yes
	BOP	C31. On Drawer N43A, Reset Neutron Flux Rate Trips: • Reset on rate mode switch
	BOP	C32. At Detector Current Comparator Drawer, ensure Rod Stop Bypass Switch for N43 in Operate Position
	ATC	C33. Check T _{avg} – Within 1oF of T _{ref} a. (ρ) Place Control Rods In Automatic with CRS concurrence ο SE HS-9 – AUTO
	CREW	C34. Return equipment to normal alignment, as directed by Shift Manager/Control Room Supervisor
	CREW	C35. Return to Procedure and Step in Effect

Event termination: After the crew has restored NN03, N43A rate trip is reset and/or at the direction of the Lead Examiner

Simulator Operator: Insert Key 3 at direction of the Lead Examiner.

Op-Tes	t No.: Dec 201	9 Scenario No.: 1 Event No.: 3 Total No Pages 27			
Event D	Event Description: Inadvertent CSAS on Red Train				
Time	Position	Applicant's Actions or Behavior			
Simulato	Simulator Operator: Insert Key 3 at direction of Lead Examiner.				
	s tics : Containme TON Panel SA 0	nt Spray Pump 'A' starts, WHITE LIGHTS for CSAS on ESF SYS STATUS 66-X			
Annunc	iators: 059A, 03				
	CRS	Enters and Directs either ALR 00-059A or OFN EN-049 directly.			
	Crew	Reviews ALR if OFN EN-049 is entered directly.			
crew she		w may place both pumps in PTL, in which case LCO 3.0.3 is applicable. The re LCO 3.0.3, or remove 'B' Containment Spray pump from PTL after ns.			
		ALR 00-059A CSAS			
		NOTE:			
Step 1 is	s a Memory Actio	· · ·			
	ATC	 Check Containment Spray required: - No RNO: Perform the following a. Place affected Containment Spray Pump(s) in Pull To Lock * EN HIS-3 – YES * EN HIS-9 b. Go to Step 4. 			
	ATC	4. Check Containment Spray – ACTUATED – Yes			
		<u>NOTE:</u> if RCP bearing temperature is greater than or equal to 195°F or RCP motor ire is greater than or equal to 299°F.			
	ATC	 5. Restore Yellow Train CCW Flow To RCP Bearings And Air Coolers And RCP Thermal Barriers Using Bypass Valves. a. Check CCW Flow – ISOLATED – <i>No</i> RNO Go To Step 5.c. c. Check CCW Flow – ISOLATED – <i>No</i> RNO Go to Step 6 			
		NOTE			
	RCPs should be tripped if RCP bearing temperature is \geq 195°F or RCP motor stator winding temperature is \geq 299°F.				
	ATC	 6. Restore Red Train CCW Flow To RCP Bearings And Air Coolers And RCP Thermal Barriers Using Bypass Valves. a. Check CCW Flow – ISOLATED – <i>No</i> RNO Go To Step 6.c. c. Check CCW Flow – ISOLATED – <i>No</i> RNO Go to Step 7 			
	ATC/CRS	7. Go To OFN EN-049, SPURIOUS CONTAINMENT SPRAY AND CONTAINMENT PHASE B ISOLATION			

Op-Tes	t No.: Dec 201	9 Scenario No.: 1 Event No.: 3 Total No Pages 27		
•	Event Description: Inadvertent CSAS on Red Train			
Time	Position	Applicant's Actions or Behavior		
OFN	OFN EN-049, SPURIOUS CONTAINMENT SPRAY AND CONTAINMENT PHASE B ISOLATION RECOVERY			
		<u>NOTE</u>		
Step 1 is	a Memory Acti	on Step		
	ATC	 Check Containment Spray – ACTUATED – Yes a. Place Affected Containment Spray Pump(s) In Pull To Lock: *EN HIS-3, CTMT SPRAY PUMP A – Yes *EN HIS-9, CTMT SPRAY PUMP B 		
	ATC	 Check annunciator 00-059B, CISB – LIT – No RNO Go To Step 6 		
	ATC	 6. Check if ESW Pumps Should Be Started: a. Check LOCA Sequencer Actuated on Either Train: *Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – LIT – Yes *Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – LIT – No b. Start Both ESW Pumps o EF HIS-55A For Pump A o EF HIS-56A For Pump B c. Open Essential Service Water To Ultimate Heat Sink Valves o EF HIS-37 For Train A o EF HIS-38 For Train B d. Close Essential Service Water To Service Water System Valves o EF HIS-39 For Train A o EF HIS-41 For Train A o EF HIS-40 For Train B o EF HIS-42 For Train B e. Close Service Water/ESW Cross Connect Valves o EF HIS-23 For Train A o EF HIS-24 For Train A o EF HIS-24 For Train B o EF HIS-26 For Train B 		
	BOP	7. Check RCP Seal Injection – BETWEEN 8 AND 13 GPM – Yes		
	ATC	 8. Ensure RCS to Excess Letdown Heat Exchanger valves – CLOSED BG HIS-8153A – Yes BG HIS-8153B – Yes BG HIS-8154A – Yes BG HIS-8154B – Yes 		
	ATC	9. Check Annunciator 00-059A, CSAS – LIT – Yes		

10

Form ES-D-2

•		Scenario No.: 1 vertent CSAS on Red T	Event No.: 3	Total No Pages 27
Time	Position	Applicant's Actions or Behavior		
NOTES • The CSAS and CISB reset circuits are designed to allow resetting their respective automatic signals with the actuation signal present. Subsequent automatic actions will be inhibited until the failure is corrected. • If the LOCA sequencers alarms 00-030A and 00-031A do NOT reset, I&C should be contacted to promptly correct the problem. This is important since the sequencers will time out, and a subsequent Safety Injection would start all ECCS pumps at the same time resulting in a under voltage load shed of the affected XNB01/XNB02 transformer. ATC 10. Restore Containment Spray System: a. Reset Containment Spray System: a. Reset Containment Spray System: b. Check Containment Spray Signal – RESET – No RNO Step 10.b: 1) Contact I&C 2) <u>WHEN</u> Step 10.b is complete, <u>THEN</u> perform steps 10.c through 10.e				
Simulat acknowl	or Operator: IF edge status. ATC		owledge requests. <u>IF</u> contaction of the contact	cted as Call Supt.,
	ATC 15. Check RCP Parameters – NORMAL – Yes CRS 16: Refer to Technical Specifications LCO 3.6.3, 3.6.6, 3.6.7, 3.7.7 And 3.0.3, As Applicable Determine that only LCO 3.6.6, Containment Spray and Cooling Systems, COND A is applicable. Required Action is to Restore Containment Spray Train to OPERABLE status within 72 hours AND 10 days from discovery of failure to meet the LCO. Also based on note prior to step 10, Enters LCO 3.3.2, Function 2b, COND A – Immediate and C – 24 hours NOTE: IF the crew places BOTH Containment Spray Pumps in PTL, THEN enter LCO 3.0.3 and recognize that only 'A' Train actuated and return 'B' Spray Pump to standby and exit LCO 3.0.3 Examiner Note: ALR 00-019F, ESF SWGR RM A TEMP HI, will come into alarm due to the load shed			
unsucce Event Te	from the inadvertent sequencer actuation. This condition cannot be cleared until the sequencer is repaired or a valid CRVIS is received. Applicants may attempt to restore using the ALR but will be unsuccessful. Event Termination: After the crew has stabilized the plant and/or at the direction of the lead examiner. Simulator Operator: Insert Key 4 at direction of Lead Examiner.			

Op-Test	No.: Dec 201	9 Scenario No.: 1 Event No.: 4 Total No Pages 27		
Event Description: AB UK-33, Steam Dump Cooldown CTRL fails HIGH in Auto				
Time	Position	Applicant's Actions or Behavior		
Simulato	or Operator: Ins	sert Key 4 at direction of Lead Examiner.		
Diagnost in all S/G		sure and Temperature lowering slowly, S/G Pressure lowering and Level rising		
Annunci		o include 065E, 033C, and 108-111A		
	CREW	Recognize changing plant conditions and diagnoses that steam dump control is failing and steam dump is opening		
	BOP	 Stops excessive steam flow by taking Manual Control of Steam dumps by any of the following: 1. STEAM HDR PRESS CTRL AB PK-507 – MANUAL 2. STEAM DUMP COOLDOWN CONTROL 3. STEAM DUMP BYPASS INTERLOCK, AB HS-63 OR 64, placed in OFF (This will close the Steam Dump terminating flow) 		
actuation operator	Examiner Note: In accordance with AP 15C-003, Step 6.1.4 Manual Backup: If an automatic trip, actuation, or control signal has reached or exceeded its setpoint for actuation and not actuated, the operator shall manually initiate the signal.			
	al Operator exp	the Steam Dump controller in the event of failure is an example of this ectation		
	ATC/BOP	Stabilize plant conditions to include RCS pressure, Temperature, PZR level, and S/G Level.		
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.			
	Event termination: After the crew has taken manual control of the Steam Dumps and/or at the discretion of the Lead Examiner.			
Simulator operator: Insert Key 5 at the lead examiners direction.				

On-Tes	st No · Dec 2019	9 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27		
Op 100				
Event D	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves			
fail to A	Auto CLOSE on (CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart		
on SIS.	EJ HV-8811B fa	ails to open on RWST LOLO.		
Time	Position	Applicant's Actions or Behavior		
Simulato	or Operator: Inse	ert Key 5 at direction of Lead Examiner.		
Diagnos	tics: Loud rumblin	ng sound heard and felt, RCS pressure and PZR level lowering rapidly		
Annunci		include 0908B/D/E & 030A, 031A		
	CREW	Recognizes earthquake and lowering RCS pressure and PZR level, diagnosis LOCA		
	CRS	Directs manual Reactor Trip and Safety Injection		
		EMG E-0, REACTOR TRIP OR SAFETY INJECTION		
		NOTE		
o Step	os 1 through 4 are	e immediate action steps		
o Fold	lout page shall be	e monitored throughout this procedure		
	ATC	1. Verify Reactor Trip: Yes		
		a. Check all rod bottom lights – LIT		
		 b. Check reactor trip breakers and bypass breakers – OPEN 		
		o SB ZL-1		
		 SB ZL-2 SB ZL-3 		
		o SB ZL-4		
		c. Check intermediate range neutron flux – DECREASING		
		 SE NI-35B [GAMMA METRICS] 		
		 SE NI-36B [GAMMA METRICS] 		
	BOP	2. Verify Turbine Trip: Yes		
		a. Check Main Stop Valves – ALL CLOSED		
	ATC	<u>3.</u> Check AC Emergency Busses – AT LEAST ONE ENERGIZED – Yes *NB01 – ENERGIZED *NB02 – ENERGIZED		

Op-Tes	st No.: Dec 2019	O Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27		
Event F				
	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart			
		ails to open on RWST LOLO.		
011 313.		ans to open on RWST LOLO.		
Time	Position	Applicant's Actions or Behavior		
	ATC	4. Check if Safety Injection is Actuated:		
		a. Check any indication SI is actuated – LIT – Yes		
		*Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – LIT		
		*Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – LIT *ESFAS status panel SIS section – ANY WHITE LIGHTS LIT		
		*Partial Trip Status Permissive/Block status panel – SI RED		
		LIGHT LIT		
		b. Check both trains of SI actuated – Yes		
		 Ann 00-030A, NF039A LOCA SEQ ACTUATED – LIT Ann 00-031A, NF039B LOCA SEQ ACTUATED – LIT 		
		CAUTION		
	equired configurat			
	ATC	 5. (t) Check if SI required: * SI was manually actuated AND was required – Yes * Containment pressure is currently or has been – GREATER THAN OR EQUAL TO 3.5 PSIG – Yes * RCS pressure is currently or has been – LESS THAN OR EQUAL TO 1830 PSIG – Yes * Any S/G pressure is currently or has been – LESS THAN OR EQUAL TO 615 PSIG – No 		
	BOP	FOLDOUT PAGE Step 1.RCP TRIP CRITERIAIF all conditions listed below occur, THEN trip all RCPs:oRCS pressure – LESS THAN 1400 PSIG – YesoCCPs or SI pumps – AT LEAST ONE RUNNING – YesoOperator controlled cooldown – NOT IN PROGRESS – Yes		
	BOP	FOLDOUT PAGE Step 7. RCS TEMPERATURE CONTROL o IF a Loss-Of-Offsite Power has occurred, THEN close MSIVs *AB HS-79 *AB HS-80 o IF no RCPS are running AND off-site power is available, THEN select STM PRESS mode on the steam dumps o AB US-500Z o IF RCS C/L temperature is less than 557°F AND decreasing, THEN control total feed flow to limit RCS cooldown o Maintain total feed flow greater than 270,000 lbm/hr until narrow range is greater than 6% [29%] in at least one S/G		

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27			
Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.				
Time	Position	Applicant's Actions or Behavior		
	ATC	6. Verify Automatic Actions using Attachment F, AUTOMATIC SIGNAL VERIFICATION		
		Examiner Note: See Attachment 1 for complete list of actions		
		 F3. Verify Containment Isolation Phase A: a. Check ESFAS status panel CISA section – ALL WHITE LIGHTS LIT o Red train – No o Yellow train – No 		
		 RNO a. Perform the following: 1) IF containment isolation phase A has NOT actuated, THEN manually actuate containment isolation phase A – NO SB HS-47 SB HS-48 2) IF any CISA valve NOT closed, THEN manually close valve. IF valve(s) can NOT be closed, THEN manually or locally isolate affected containment penetration. Refer to ATTACHMENT B VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE A 		
		CT1 : Close either BG HIS-8160 or BG HIS-8152 containment isolation valves before completion of EMG E-0, Attachment F.		
		 F6. Verify CCW Alignment: a. Check CCW pumps – ONE RUNNING IN EACH TRAIN – NO RNO a. Manually start CCW pumps as necessary to establish one running in each train o EG HIS-21 or EG HIS-23 for red train – Yes 		
		 EG HIS-22 or EG HIS-24 for yellow train – Yes 		
		CT2: Manually start 'A', 'C', or 'D' CCW pump to cool one Train of ECCS equipment within 30 minutes of SIS to prevent the loss of CCP or SI pumps.		

Op-Te:	st No.: Dec 201	9 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27	
fail to A	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.		
Time	Position	Applicant's Actions or Behavior	
	BOP	 7. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes MA ZL-3A MA ZL-4A MA ZL-2 	
	BOP	8. Check Total AFW Flow – GREATER THAN 270,000 LBM/HR – Yes	
	вор	 <u>9.</u> Check RCS Cold Leg Temperatures: *Stable at or trending to 557°F for condenser steam dumps or S/G ARVs *Stable at or trending to a range of 553°F to 557°F for S/G ARVs if recovering from an inadvertent SI 	
	BOP	 10. Establish S/G Pressure Control: a. Check condenser – AVAILABLE – Yes C-9 LIT MSIV – OPEN Circulating water pumps - RUNNING b. Place Steam Header Pressure Control in Manual AB PK-507 c. Manually set Steam Header Pressure Control output to zero AB PK-507 d. Place Steam Dump Select Switch in STEAM PRESS position AB US-500Z e. Place Steam Header Pressure Control in Automatic AB PK-507 	
	ATC	 11. Check PZR PORVs a. Check PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A b. Power to block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B c. RCS pressure – LESS THAN 2185 PSIG 	
	ATC	 12. Check Normal PZR Spray Valves – CLOSED – Yes BB ZL-455B BB ZL-455C 	

Op-Tes	st No.: Dec 2019	9 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27	
<u>Event Description:</u> Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.			
Time	Position	Applicant's Actions or Behavior	
	ATC	 13. Check PZR Safety Valves – CLOSED – Yes BB ZL-8010A BB ZL-8010B BB ZL-8010C 	
		<u>NOTE</u>	
Seal inje	ection flow shall b	be maintained to all RCPs	
	ATC/BOP	14. Check if RCPs should be stopped: a. Check RCPs – ANY RUNNING – No	
		RNO a. Go to Step 15	
	CRS	15. Direct operator to Monitor Critical Safety Functions Using EMG F-0, CRITICAL SAFETY FUNCTION STATUS TREES (CSFST)	
	BOP	 16. Check if S/Gs are not Faulted: - Yes a. Check pressures in all S/Gs – NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER NO S/G COMPLETELY DEPRESSURIZED 	
	BOP	 17. (t) Check if S/G tubes are intact: Check S/G Levels – NOT INCREASING IN AN UNCONTROLLED MANNER – Yes Narrow range Wide range Condenser air discharge radiation – NORMAL BEFORE ISOLATION – Yes GEG 925 S/G blowdown and sample radiation – NORMAL BEFORE ISOLATION – Yes GBU 256 SJL 026 Turbine driven auxiliary feedwater pump exhaust radiation – NORMAL – Yes FCT 381 S/G steamline radiation – NORMAL – Yes ABS 114 for S/G A ABS 112 for S/G C ABS 111 for S/G D 	

Op-Tes	st No.: Dec 2019	Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27	
Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves			
		CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart	
on SIS.	EJ HV-8811B fa	hils to open on RWST LOLO.	
Time	Position	Applicant's Actions or Behavior	
	ATC	 18. Check if RCS is intact in Containment: - NO Containment radiation – NORMAL BEFORE ISOLATION GTP 311 GTI 312 GTG 313 GTP 321 GTI 322 GTA 591 GTA 601 Containment pressure – NORMAL GN PI-934 GN PI-935 GN PI-936 GN PI-937 GT PDI-40 GN PR-934 Containment sump level – NORMAL EJ LI-7 EJ LI-8 EJ LR-6 LF LI-10 RNO Perform the following: a. Ensure BIT Inlet AND Outlet Valves are open – Yes EM HIS-8803A EM HIS-8801A EM HIS-8801B b. Go to EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT, Step 1 	
	CRS	Conducts brief and transitions to EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT	
	EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT		
	NOTES		
 Seal injection flow shall be maintained to all RCPs 			

Op-Tes	st No.: Dec 201	9 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27
<u>Event Description:</u> Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.		
Time	Position	Applicant's Actions or Behavior
	ATC/BOP	 Check if RCPs should be stopped: a. Check RCPs – ANY RUNNING – No
	BOP	 RNO a. Go to Step 2 2. Check if S/Gs are not Faulted: - Yes a. Check pressures in all S/Gs – NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER NO S/G COMPLETELY DEPRESSURIZED
	BOP	 <u>3.</u> Check intact S/G Levels: a. Check Narrow Range Level in at Least One S/G – GREATER THAN 6% [29%] b. Control feed flow to maintain narrow range level in all S/Gs between 6% [29%] and 50%
	e power is lost aft equired configura	<u>CAUTION</u> ter SI reset, manual action may be required to restore safeguards equipment ation
	ATC	4. Reset SI o SB HS-42A o SB HS-43A
	ATC	5. Reset Containment Isolation Phase A and Phase B o SB HS-56 For Phase A o SB HS-53 For Phase A o SB HS-55 For Phase B o SB HS-52 For Phase B
<u>CAUTION</u> If steamlines in Area 5 of Auxiliary Building are not intact extreme caution will be necessary when performing local surveys		

Op-Tes	st No.: Dec 2019	9 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27		
fail to A	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.			
Time	Position	Applicant's Actions or Behavior		
	BOP	 6. Determine Secondary Radiation Levels: a. Direct Health Physics to survey steamlines in Area 5 of the Aux Bldg b. Check S/G Sampling ISOLATED – Yes c. Check Instrument Air Pressure – GREATER THAN 105 PSIG – Yes KA PI-40 d. Open CCW to Radwaste System Isolation Valves EG HS-69 EG HS-70 e. Open all S/G sample isolation valves BM HIS-65 for S/G A BM HIS-36 for S/G B BM HIS-36 for S/G B BM HIS-67 for S/G C BM HIS-37 for S/G C BM HIS-38 for S/G D BM HIS-38 for S/G D 		
	BOP	 7. Check Secondary Radiation – NORMAL a. Condenser Air Discharge Radiation – NORMAL BEFORE ISOLATION Yes GEG 925 b. S/G Blowdown Radiation – NORMAL BEFORE ISOLATION – Yes BML 256 c. S/G Sample Radiation – NORMAL – Yes SJL 026 Sample results d. Turbine Driven Auxiliary Feedwater Pump Exhaust Radiation – NORMAL – Yes FCT 381 e. S/G Steamline Radiation – NORMAL – Yes ABS 114 For S/G A ABS 113 For S/G B ABS 111 For S/G D Local Surveys 		
<u>Simula</u>	Simulator Operator: WHEN contacted as HP and Chemistry, acknowledge requests			
CAUTION If any PZR PORV opens because of high PZR pressure, the PORV shall be monitored to ensure it recloses after pressure decreases to less than 2335 psig				

Op-Tes	t No.: Dec 2019	Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27		
fail to A	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.			
Time	Position	Applicant's Actions or Behavior		
	BOP	 <u>8.</u> Check PORVs and Block Valves a. Power to block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B b. Check PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A c. RCS pressure – LESS THAN 2185 PSIG 		
		<u>NOTE</u>		
COMPF valve, o	Locally opening EF-HV-43, ESW A TO AIR COMPRESSOR or EG HV-44, ESW B TO AIR COMPRESSOR requires the associated ESW train to be declared inoperable. Local opening of the valve, on 2000' NORTH END AUX BLDG, will preclude it from automatically isolating on a high flow condition			
	BOP	 9. Verify Instrument Air Compressor is Running: a. Ensure at least one ESW TRN TO AIR COMPRESSOR Valve – OPEN – Yes *EF HIS-43 *EF HIS-44 b. Check AIR COMPRESSOR BRKR RESET switch associated with open ESW Valve(s) – CLOSED – No *KA HIS-3C *KA HIS-3C *KA HIS-2C RNO b. Reset and close AIR COMPRESSIR BRKR RESET Switch *KA HIS-3C *KA HIS-2C c. Check INST AIR PRESS – GREATER THAN 105 PSIG – Yes KA PI-40 d. Check neither ESW TO AIR COMPRESSOR Valve – Locally Opened – No EF HV-43 EF HV-44 e. Check both ESW TRN TO AIR COMPRESSOR Valves – OPEN – Yes EF HIS-43 EF HIS-44 f. Check both AIR COMPRESSOR BRKR RESET switches – CLOSED – Yes KA HIS-3C 		

Op-Tes	st No.: Dec 2019	O Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27	
fail to A	<u>Event Description:</u> Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.		
Time	Position	Applicant's Actions or Behavior	
	BOP	 10. Verify Instrument Air to Containment: a. Check PZR PRESS MASTER CTRL Output – LESS THAN 55% - Yes BB PK-455A b. Open INST AIR SPLY CTMT ISO VLV KA HIS-29 	
	ATC	 <u>11.</u> Check if ECCS Flow should be reduced: - No a. RCS Subcooling – GREATER THAN 30°F [45°F] b. Secondary heat sink:	
	tor Operator: Co be left running un	ontact Control Room as the TSC and recommend maintaining both Spray	
Paulo	ATC	<u>12.</u> Check if Containment Spray should be stopped: a. Check Spray Pumps – ANY RUNNING – Yes	
		CAUTION	
After RI	After RHR pumps have been stopped, RCS pressure shall be monitored for RHR pump restart criteria		
	ATC	 <u>13.</u> Check if RHR Pumps Should be stopped: a. Check RHR Pumps – ANY RUNNING – <i>No</i> RNO Go to step 14 	
	ATC	 14. Check RCS and S/G Pressures: a. Check RCS Pressure STABLE OR DECREASING – Yes b. Check Pressure in All S/Gs – STABLE OR INCREASING – Yes 	

Op-Tes	st No.: Dec 2019	O Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27			
	<u>Event Description:</u> Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart				
on SIS.	EJ HV-8811B fa	ails to open on RWST LOLO.			
Time	Position	Applicant's Actions or Behavior			
	ATC	 <u>15.</u> Check if Diesel Generators should be stopped: a. Check NB01 – ENERGIZED BY OFFSITE POWER – Yes b. Depress START/RESET pushbutton for Diesel Generator NE01 KJ HS-8A c. Depress STOP pushbutton for Diesel Generator NE01 KJ HS-8A d. Place EDG NE01 in standby using KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, while continuing with this procedure e. Check NB02 – ENERGIZED BY OFFSITE POWER – Yes f. Depress START/RESET pushbutton for Diesel Generator NE02 KJ HS-108A g. Depress STOP pushbutton for Diesel Generator NE01 KJ HS-108A h. Place EDG NE02 in standby using KJ-121, DIESEL GENERATOR NE01 AND NE02 LINEUP FOR AUTOMATIC OPERATION, while continuing with this procedure 			
 Wait oper Wait 	t 2 min and Insert ration	IEN contacted as the Building Watch, acknowledge request: Key 12, contact control room and report EDG A is lined up for automatic Key 13, contact control room and report EDG B is lined up for automatic			
	ATC	 16. Load Equipment on Energized AC Emergency Busses: a. Locally reset and close Boric Acid Transfer Pump beakers NG01AHF4 For Pump A NG02AAF4 For Pump B b. Locally reset and close emergency borate valve breaker NG04CPF2 For BG HV-8104 			
request ○ Wait Bori ○ Wait	: t 2 min and Insert c Acid Transfer p	Key 11, contact control room and report breaker is reset and closed for live			
	AIC	 17. Close Non-Class 1E Battery Charger Breakers PK HIS-2 For PK-21 PK HIS-3 For PK-22 PK HIS-4 For PK-23 PK HIS-5 For PK-24 			

Op-Te:	at No.: Dec 2019	O Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27		
fail to A	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.			
Time	Position	Applicant's Actions or Behavior		
	ATC	 18. Check ALL non-class 1E AC Busses and Load Centers – ENERGIZED BY OFFSITE POWER PA PB PG SL 		
	BOP	 19. Place Hydrogen Analyzers Inservice a. On RL011, place power lockout switches for containment sample valves in NON-ISO position GS HIS-40 GS HIS-41 GS HIS-42 GS HIS-43 b. On RL011, open one Hydrogen Analyzer Supply Inner Containment Isolation Valve per train GS HIS-13 <u>OR</u> GS HIS-14 For Red Train GS HIS-4 <u>OR</u> GS HIS-5 For Yellow Train c. On RL011, open remaining hydrogen analyzer containment isolation valves GS HIS-12 GS HIS-17 GS HIS-18 GS HIS-3 GS HIS-9 d. On RL020, place containment hydrogen analyzer control switches in ANALYZE position GS HIS-16A GS HIS-11A e. On RL020, monitor containment hydrogen concentration GS AI-19 GS AI-10 		
	BOP	20. Verify Cold Leg Recirculation Capability: - Yes		
	ATC	 21. Check Fuel/Auxiliary Building Radiation – NORMAL a. Shift Fuel/Auxiliary Building Exhaust sample to EMERGENCY. o GG HIS-27 o GG HIS-27 b. Direct Health Physics to survey Fuel and Auxiliary Buildings with priority being pipe penetration areas and piping tunnels. c. Check Fuel/Auxiliary Building Radiation Monitors – NONE ALARMING – Yes 		

	T (N) D 004					
Op-	Op-Test No.: Dec 2019 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27					
fail	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.					
Tim	ne Position	Applicant's Actions or Behavior				
	BOP	 22. Obtain Samples a. Request Chemistry to obtain boron and activity samples for the following: RCS PZR Liquid Space				
	SM/STA 23. Initiate Evaluation of Plant Status:					
	BOP	 24. Check if RCS Cooldown and Depressurization is Required: a. Check RCS Pressure >325 psig – No RNO: Perform the following: 1) Ensure RHR Pumps – RUNNING - Yes 2) IF either RHR Pump flow >1000 gpm, THEN go to step 25. * EJ FI-618 - Yes OR * EJ FI-619 – Yes 				
	ATC	 25. Check if Transfer to Cold Leg Recirculation is Required: a. Check RWST Level <36% - NO RNO: Return to step 20 b. Go to EMG ES-12 				
	EMG ES-12, TRANSFER TO COLD LEG RECIRCULATION					
 <u>CAUTION</u> ECCS recirculation flow to RCS must be maintained at all times to provide core cooling. If offsite power is lost after SI reset, manual action may be required to restore safeguards equipment to the required configuration. Switchover to recirculation may cause high radiation in the Auxiliary Building. 						
	<u>NOTE</u>					
0 0	 Steps 1 through 10 and step 13, if applicable, shall be performed without delay. CSF status trees shall be monitored for information only. Function Restoration (FR) Procedures shall not be implemented prior to completion of step 10. 					

Op-Test No.: Dec 2019Scenario No.: 1Event Nos.: 5/6/7/8Total No Pages 27Event Description:Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valvesfail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostarton SIS. EJ HV-8811B fails to open on RWST LOLO.				
Time	Position	Applicant's Actions or Behavior		
	ATC/CRS	 Reset All SI Signals: SB HS-42A For SIS (previously accomplished) SB HS-43A For SIS (previously accomplished) SB HIS-62 For RWST Switchover SB HIS-63 For RWST Switchover 		
	ATC/CRS	 2. Verify CCW Flow To RHR Heat Exchangers: a. Check At Least One Red Train CCW Pump – RUNNING b. Check At Least One Yellow Train CCW Pump – RUNNING c. Ensure Both CCW To RHR Heat Exchanger Valves – OPEN o EG HIS-101 o EG HIS-102 		
	ATC/CRS	 Ensure Both CCW From Spent Fuel Pool Heat Exchangers – CLOSED EC HIS-11 EC HIS-12 		
	ATC/CRS	 4. Verify Red Train RWST Switchover Has Occurred: a. Check Containment Recirc Sump To RHR Pump A Suction – OPEN EJ HIS-8811A - Yes b. Check RWST To RHR Pump B Suction – CLOSED BN HIS-8812A - Yes 		

Ор-Те	Op-Test No.: Dec 2019 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27					
fail to A	Event Description: Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.					
Time	Position	Applicant's Actions or Behavior				
	ATC/CRS	 5. Verify Yellow Train RWST Switchover Has Occurred: a. Check Containment Recirc Sump To RHR Pump B Suction – OPEN o EJ HIS-8811B – No RNO: <u>IF</u> Yellow train RHR is operating, <u>THEN</u> manually align yellow train RHR to recirc sump by performing the following steps: 1. Stop RHR Pump B by placing handswitch in PTL. o EJ HIS-2 2. Close RWST To RHR Pump B Suction. o BN HIS-8812B 3. <u>IF</u> BN HV-8812B is open, <u>THEN</u> close Containment Recirc Sump To RHR Pump B Suction. o EJ HIS-8811B 4. <u>IF</u> BN HV-8812A is closed, <u>THEN</u> open Containment Recirc Sump To RHR Pump B Suction. o EJ HIS-8811B CT3: Realign from ECCS injection mode to cold leg recirculation before RWST level reaches 6% with a failure of EJ HV-8811B to automatically open.				
	ATC/CRS	 6. Check RHR Pumps – BOTH RUNNING EJ HIS-1 - Yes EJ HIS-2 – No. RNO: Start RHR Pumps with suction aligned to the containment sump. 				
	ATC/CRS	 7. Close Both RHR Train Hot Leg Recirc Valves. o EJ HIS-8716A o EJ HIS-8716B 				
	ATC/CRS	 8. Isolate SI Pump Mini-flow To RWST: a. Check Each SI Pump Injection Flow – GREATER THAN 35 GPM b. Close both SI Pump Recirc To RWST valves. o EM HIS-8814A o EM HIS-8814B c. Ensure SI Pump Mini-flow – ISOLATED 				

<u>Event I</u> fail to A	Op-Test No.: Dec 2019 Scenario No.: 1 Event Nos.: 5/6/7/8 Total No Pages 27 <u>Event Description:</u> Earthquake causes Large Break LOCA (6") on Loop 4 Cold Leg. 3 valves fail to Auto CLOSE on CISA. 'B' CCW pump trips, 'A', 'C', and 'D' CCW Pumps fail to autostart on SIS. EJ HV-8811B fails to open on RWST LOLO.				
Time	Position Applicant's Actions or Behavior				
	ATC/CRS	 9. Align CCP And SI Pump Suctions To RHR Pump Discharge: a. Open both RHR to CCP and SI Pump suction valves. o EJ HIS-8804A o EJ HIS-8804B b. Open both CVCS To SI Pump Suction valves. o EM HIS-8807A o EM HIS-8807B 			
	ATC/CRS	 10. Isolate RWST From Charging And SI Pumps: a. Close both RWST To SI Pump Suction valves. o BN HIS-8806A o BN HIS-8806B b. Close both CCP Suction From RWST valves. o BN HIS-112D o BN HIS-112E 			
<u>Scenario Termination</u> : After crew has completed step 10 of EMG ES-12 or at the discretion of the Lead Examiner terminate the scenario <u>Simulator Operator</u> : FREEZE					

ATTACHMENT 1

Revision: 41A		REACTOR TRIP OR SAFETY INJECTION		EMG E-0		
Continuous Use				TNUECITON	Page 79 of 103	
STEP ACTION/		/EXPECTED RESPONSE	\mathbf{H}	RESPONSE NOT	OBTAINED	
ATTACHMENT F (Page 1 of 13) AUTOMATIC SIGNAL VERIFICATION						
F1.	Check AC	Emergency Busses - D:				
	o NB01 -	ENERGIZED	0	Depress START pushbutton fo		
				o KJ HS-8A		
	o NB02 -	ENERGIZED	0	Depress START pushbutton fo		
				o KJ HS-108A		

Continuous Use

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 81 of 103

L						
STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED				
ATTACHMENT F (Page 2 of 13) AUTOMATIC SIGNAL VERIFICATION						
F2.	F2. Verify Feedwater Isolation:					
	a. Main feedwater pumps - TRIPPED	a. Manually trip Main Feedwater Pumps.				
	o Annunciator 00-120A, MFP A TRIP - LIT o Annunciator 00-123A, MFP B TRIP - LIT	tripped, <u>THEN</u> depress				
		o FC HS-18A For MFWP A o FC HS-18B For MFWP A				
		o <u>IF</u> MFWP B is <u>NOT</u> tripped, <u>THEN</u> depress the following:				
		o FC HS-118A For MFWP B o FC HS-118B For MFWP B				
	b. Main feedwater reg valves - CLOSED	<pre>b. Manually close valves. * AE FK-510 for S/G A</pre>				
	o AE ZL-510 for S/G A o AE ZL-520 for S/G B o AE ZL-530 for S/G C o AE ZL-540 for S/G D	* AE FK-510 for S/G A * AE FK-520 for S/G B * AE FK-530 for S/G D * AE FK-540 for S/G D				
	c. Main feedwater reg bypass valves - CLOSED	c. Manually close valves.				
	o AE ZL-550 for S/G A o AE ZL-560 for S/G B o AE ZL-570 for S/G C o AE ZL-580 for S/G D	* AE LK-550 for S/G A * AE LK-560 for S/G B * AE LK-570 for S/G C * AE LK-580 for S/G D				
	d. Main feedwater isolation valves - CLOSED	_				
	o AE HIS-39 for S/G A o AE HIS-40 for S/G B o AE HIS-41 for S/G C o AE HIS-42 for S/G D	 Manually close valves. <u>IF</u> valves can <u>NOT</u> be closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MFIV sub-racks: o ALS-411-1 o ALS-411-2 				
	 o AE ZL-530 for S/G C o AE ZL-540 for S/G D c. Main feedwater reg bypass valves - CLOSED o AE ZL-550 for S/G A o AE ZL-560 for S/G B o AE ZL-570 for S/G C o AE ZL-580 for S/G D d. Main feedwater isolation valves - CLOSED o AE HIS-39 for S/G A o AE HIS-40 for S/G B o AE HIS-41 for S/G C 	 * AE FK-540 for S/G D c. Manually close valves. * AE LK-550 for S/G A * AE LK-560 for S/G B * AE LK-570 for S/G C * AE LK-580 for S/G D d. Perform the following: Manually close valves. 2) <u>IF</u> valves can <u>NOT</u> be closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MFIV sub-racks: ALS-411-1 				

(Step F2. continued on next page)

Revision: 41A	EMG E-0						
Continuous Use	REACTOR TRIP OR SAFETY INJECTION Page 83 of 103						
STEP ACTION	EXPECTED RESPONSE RESPONSE NOT OBTAINED						
Step F2. (cont	ATTACHMENT F (Page 3 of 13) AUTOMATIC SIGNAL VERIFICATION						
e. Main injec o AE o AE o AE	<pre>feedwater chemical tion valves - CLOSED HIS-43 for S/G A HIS-44 for S/G B HIS-46 for S/G D HIS-46 for S</pre>						
SGBSI LIGHT o Red	SOUTH OF MFIV) ESFAS status panel S section - ALL WHITE S LIT train low train Suttow train						

Continuous Use

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 85 of 103

STEP ACTION/EXPECTED	RESPONSE		RESPONSE NOT OBTAINED			
ATTACHMENT F (Page 4 of 13) AUTOMATIC SIGNAL VERIFICATION						
F3. Verify Containme Phase A:	nt Isolation					
a. Check ESFAS so CISA section of LIGHTS LIT o Red train o Yellow train	- ALL WHITE	a.	<pre>Perform the following: 1) IF containment isolation phase A has NOT actuated, THEN manually actuate containment isolation phase A. o SB HS-47 o SB HS-48 2) IF any CISA valve NOT closed, THEN manually close valve. IF valve(s) can NOT be closed, THEN manually or locally isolate affected containment penetration. Refer to ATTACHMENT B, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE A.</pre>			

Revision: 41A	REACTOR TRIP OR SAFET	EMG E-0
Continuous Use	REACIOR IRIP OR SAFE	Page 87 of 103
STEP ACTION	/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 5 of 1 AUTOMATIC SIGNAL VE	13)
F4. Verify A	FW Pumps Running:	
	motor driven AFW - BOTH RUNNING	a. Manually start pumps. o AL HIS-22A o AL HIS-23A
b. Check	turbine driven AFW	b. Perform the following:
	- RUNNING	 Check if turbine driven AFW pump should be running:
		* At least 2/4 S/G narrow range level channels on 2/4 S/Gs - LESS THAN 23.5%
		OR
		* Loss of NB01 voltage has occurred
		OR
		* Loss of NB02 voltage has occurred
		OR
		* AMSAC actuation
		2) <u>IF</u> turbine driven AFW pump should be running, <u>THEN</u> manually open steam supply valves:
		a) AB HIS-5A
		b) AB HIS-6A
		c) FC HIS-312A

Revisi	on:	41A	REACTOR TRIP OR SA	∖न्न्य	ETY INJECTION				
Contin	uous	s Use					Page 89 of 103		
STEP	A	CTION/	EXPECTED RESPONSE	$\left - \right $		RESPONSE NOT	OBTAINED		
			ATTACHME (Page 6 c AUTOMATIC SIGNAL	of 1	3)	ICATION			
F5.	Vei	cify E	CCS Pumps Running:						
	a.	Check	CCPs - BOTH RUNNING		a.	Manually sta	rt pumps.		
						o BG HIS-1A o BG HIS-2A			
	b.	Check RUNNI	SI pumps - BOTH		b.	Manually sta	rt pumps.		
		ROMNT.	NG			o EM HIS-4 o EM HIS-5			
	с.	Check RUNNI	RHR pumps - BOTH		с.	Manually sta	rt pumps.		
						o EJ HIS-1 o EJ HIS-2			
F6.	Vei	cify C	CW Alignment:						
	a.		CCW pumps - ONE NG IN EACH TRAIN		a.		rt CCW pumps to establish in each train.		
						<pre>o EG HIS-21 for red tr o EG HIS-22 for yellow</pre>	ain or EG HIS-24		
	b.	servi Retur:	one pair of CCW ce loop Supply And n Valves for an ting CCW pump - OPEN		b.	Manually ali necessary to flow to serv containment.	establish CCW ice loop and		
		* EG	ZL-15 AND EG ZL-53						
		<u>0</u>]	<u>R</u>						
		* EG	ZL-16 AND EG ZL-54						
F7.		eck ES NNING	W Pumps - BOTH		Mar	nually start	pumps.		
	1.01					EF HIS-55A EF HIS-56A			

Revision: 41A		EMG E-0							
Continuous Use	REACTOR TRIP OR SAFET	Page 91 of 103							
STEP ACTION	EXPECTED RESPONSE	RESPONSE NOT OBTAINED							
	ATTACHMENT F (Page 7 of 13) AUTOMATIC SIGNAL VERIFICATION								
	ntainment Fan Coolers G IN SLOW SPEED	Perform the following for each Containment Cooler Fan that is still running in Fast or is not running:							
		a. Manually stop ANY Containment Cooler Fans running in fast.							
		* GN HIS-5 For Cooler 1A							
		* GN HIS-9 For Cooler 1B							
		* GN HIS-13 For Cooler 1C							
		* GN HIS-17 For Cooler 1D							
		b. Place Containment Cooler Fan Speed Selector switches in Slow.							
		* GN HS-5 for cooler 1A							
		* GN HS-9 for cooler 1B							
		* GN HS-13 for cooler 1C							
		* GN HS-17 for cooler 1D							
		c. Manually start containment cooler fans.							
		* GN HIS-5 for cooler 1A							
		* GN HIS-9 for cooler 1B							
		* GN HIS-13 for cooler 1C							
		* GN HIS-17 for cooler 1D							

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 93 of 103

STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED ATTACHMENT F (Page 8 of 13) AUTOMATIC SIGNAL VERIFICATION F9. Verify Containment Purge Isolation: a. Perform the following: a. Check ESFAS status panel CPIS section - ALL WHITE LIGHTS LIT 1) <u>IF</u> containment purge isolation has NOT o Red train actuated, THEN manually o Yellow train actuate containment purge isolation. o SA HS-11 o SA HS-15 2) IF any CPIS component NOT properly aligned, THEN manually align component. 3) IF component(s) can NOT be manually aligned, THEN locally isolate instrument air to affected containment penetration. Refer to ATTACHMENT C, VALVES CLOSED BY CONTAINMENT PURGE ISOLATION SIGNAL.

Revision: 41AEMG E-0Continuous UseREACTOR TRIP OR SAFETY INJECTIONPage 95 of 1				
	evision: 41A	REACTOR TRIP OR SA		- 0
	ontinuous Use			103
STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED	TEP ACTION	I/EXPECTED RESPONSE	RESPONSE NOT OBTAINED	
ATTACHMENT F (Page 9 of 13) AUTOMATIC SIGNAL VERIFICATION F10. Verify Both Trains Of Control		(Page 9 c AUTOMATIC SIGNAL Both Trains Of Control	of 13) L VERIFICATION	
Room Ventilation Isolation: a. Check ESFAS status panel CRVIS section - ALL WHITE LIGHTS LIT o Red train o Yellow train a. Perform the following: b. Red train o Yellow train a. Perform the following: a. Perform the following: a. Perform the following: b. Red train o Yellow train a. Perform the following: b. Red train o Yellow train b. Red train o Yellow train c. Yellow train c. Yellow train c. Yellow train c. Yellow train b. Yellow train c. SA HS-9 o SA HS-13 c. J. JF any CRVIS componen NOT properly aligned, THEN manually align associated component. c. J. JF neither train of CRVIS is in service, THEN establish one in service train of CRVI using SYS GK-122, MANUAL CRVIS LINE-UP. 4) IF only one train of CRVIS LINE-UP. 4) IF only one train of SYS GK-122, MANUAL CRVIS LINE-UP.	a. Check CRVI LIGH o Red	k ESFAS status panel S section - ALL WHITE IS LIT d train	 <u>IF</u> control room ventilation isolati has <u>NOT</u> actuated, <u>I</u> manually actuate control room ventilation isolati o SA HS-9 o SA HS-13 <u>IF</u> any CRVIS comport <u>NOT</u> properly aligned <u>THEN</u> manually aligned <u>THEN</u> manually aligned <u>THEN</u> manually aligned <u>THEN</u> manually aligned <u>THEN</u> establish one service train of CRVIS is in serviced <u>THEN</u> establish one service train of CF using SYS GK-122, MANUAL CRVIS LINE-U <u>IF</u> only one train of CRVIS can be placed service, <u>THEN</u> withi minutes (76.5 minut control room and 13 minutes local operator), isolate of service train us SYS GK-122, MANUAL 	on THEN On. on. ent ed, in VIS JP. of in n 90 ces 3.5 out

door - CLOSED

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 97 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMEN (Page 10 c AUTOMATIC SIGNAL	of 13)
F11.		Verify steamline isolation:
	a. Check containment pressure - HAS REMAINED LESS THAN 17 PSIG	 If any main steamline isolation valve is <u>NOT</u> closed, <u>THEN</u> perform the following:
	0 GN PR-934	a) Close main steamline isolation valves.
	 b. Check either condition below - SATISFIED: * Low steamline pressure SI - NOT BLOCKED <u>AND</u> steamline pressure - HAS REMAINED GREATER THAN 615 PSIG <u>OR</u> * Low steamline pressure SI - BLOCKED <u>AND</u> steamline pressure rate - HAS REMAINED LESS THAN 100 PSI/50 SEC 	<pre>isolation valves. * AB HS-79 * AB HS-80 b) IF any MSIV is still <u>NOT</u> closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MSIV sub-rack: 0 ALS-411-1 0 ALS-411-2 2. Check ESFAS status panel SLIS section - ALL WHITE LIGHTS LIT 0 Red Train 0 Yellow Train</pre>
		3. <u>IF</u> any SLIS valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected steamline. Refer to ATTACHMENT D, VALVES CLOSED BY STEAMLINE ISOLATION SIGNAL.

Rev	is	ion	:	41A

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 99 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHME (Page 11 c AUTOMATIC SIGNAL	of 13)
F <u>12.</u>	Verify Containment Spray Not	Perform the following:
	Required:	1. Stop all RCPs.
	 a. Containment pressure - HAS REMAINED LESS THAN 27 PSIG: o Annunciator 00-059A, CSAS - NOT LIT 	 <u>IF</u> containment spray has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment spray.
	o Annunciator 00-059B, CISB - NOT LIT o GN PR-934	o SB HS-43 <u>AND</u> SB HS-45 o SB HS-44 <u>AND</u> SB HS-46
		3. Check ESFAS status panel CSAS section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		 <u>IF</u> any CSAS component <u>NOT</u> properly aligned, <u>THEN</u> manually align associated component.
		5. Check ESFAS status panel CISB section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		6. <u>IF</u> any CISB valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT E, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE B.

Revisi	Revision: 41A EMG E-0								
Contin	uous Use				ge 101 of 103				
STEP	ACTION	/EXPECTED RESPONSE		RESPONSE NOT OF	BTAINED				
		ATTACHMEN (Page 12 of AUTOMATIC SIGNAL V	E 13)	ICATION					
F13.	Verify E	CCS Flow:							
	Pumps Tank INDIC o EM	Centrifugal Charging To Boron Injection Flow meters - FLOW ATED FI-917A FI-917B	a.	1) <u>IF</u> BIT valv	res have <u>NOT</u> by operator <u>N</u> manually and align res are perator				
		RCS pressure - LESS 1725 PSIG	b.	Go to Step F14					
	Flow INDIC	SI Pump Discharge meters - FLOW ATED FI-918	c.	Manually start align valves.	pumps and				
		FI-922							
		RCS pressure - LESS 325 PSIG	d.	Go to Step F14					
	Injec	RHR TO Accumulator tion Loop Flow meters W INDICATED	e.	Manually start align valves.	pumps and				
		FI-618 FI-619							
F14.	Verify A ALIGNED:	FW Valves - PROPERLY	NO	any AFAS secti <u>I</u> properly alig	ned, <u>THEN</u>				
		ESFAS status panel section - ALL WHITE S LIT	CO	nually align as mponent to esta sired AFAS line	blish				
	statu	white train ESFAS s panel AFAS section WHITE LIGHTS LIT							

Revi	si	on:	41A
		O 11 •	I I

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 103 of 103

CONCIN	uous ose	rage 105 OI 105
STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 13 of AUTOMATIC SIGNAL VI	13)
F15.	Verify SI Valves - PROPERLY ALIGNED:	<u>IF</u> any SIS section component <u>NOT</u> properly aligned, <u>THEN</u>
	a. Check ESFAS status panel SIS section - SYSTEM LEVEL WHITE LIGHTS ALL LIT	manually align associated component to establish proper SIS lineup.
	o Red train o Yellow train	
F16.	Check If NCP Should Be Stopped:	
	a. CCPs - ANY RUNNING	a. Go to Step F17
	b. Stop NCP	
	o BG HIS-3	
F17.	Check FBIS Is <u>NOT</u> ACTUATED:	Perform the following:
	o Annunciator 00-062D, FBIS - <u>NOT</u> LIT	a. Ensure NO movement of irradiated fuel assemblies in the fuel building.
		b. Bypass GG RE-27 and GG RE-28.
		c. Reset FBIS:
		o sa hs-10
		o SA HS-14
		d. Ensure FUEL BLD EMERG EXH DAMPERS are closed:
		o GG HIS-40
		o GG HIS-43
F18.	Return To Procedure And Step In Effect	
	-END-	

Facility: Wolf Creek Scenario No.: 2 Op-Test No.: December 2019 Examiners: Operators:								
Examine	Initial Conditions: 100% Power, MOL, Yellow Train In Service, 'A' EDG Out service, LCO 3.8.1, COND							
Initial Co	nditions: <u>1(</u>	00% Power, MOL,	Yellow Train Ir	n Service, 'A' ED	<u>G Out serv</u>	ice, LC	<u>O 3.8.1,</u>	COND
<u>B is ente</u>	B is entered.							
service of	Turnover: <u>The unit is operating at 100% power, MOL Yellow Train is in Service, 'A' EDG is out of</u> service due to repairs on the Auxiliary Lube Oil Pump. LCO 3.8.1 Condition B is entered (Actions B.1 and B.2 are current. STS NB-005 was performed 3 hours ago).							
	Critical Tasks: CT-1 Manually Trip the Reactor per EMG FR-S1, Step 1, Immediate Actions CT-2 Isolate Feed flow to Faulted 'A' S/G. CT-3 Terminate SI prior to Rupturing PRT.							
EventMalf.Event Type*EventNo.No.Description								
1		C (ATC/CRS) Tech Specs Breaker 4-16 to Non-Safety 4.16 KV Bus SL-41 Trips, Loss of power to 'A' SW Pump. ALR 00-011D, ALR 00-08B, TR 3.7.8, COND A						
2		l (BOP/CRS)	AE FI-520, E OFN SB-008	S/G Feed Flow	Channel fa	ils LOV	V.	
3		C (All)	'B' HDP Trip OFN AF-025	s, Downpower to , OFN MA-038				
4		l (BOP/CRS) Tech Specs	OFN SB-008 LCO 3.3.1, F	unction 18.f, Co	nditions A,	т		W
5		C (ATC/CRS)	Letdown Orit ALR 00-0032	fice valve BG HIS 2D	S-8149BA f	ails clo	sed	
6		M (All)	'D' RCP Trip (ATWS) EMG FR-S1	s, Reactor Fails	·	oth Auto	o and Ma	anual
7		C (BOP/CRS)	'A' MDAFW EMG FR-S1	Pump fails to Au Step 3	to start			
8		M	Three S/G S	afeties on 'A' S/0 MG E-2, EMG E	G fail open	(Faulte	d S/G),	
9		(ALL)	SI Actuates	on 'A' Train ONL				
	(N)ormal, ((ATC/CRS) (R)eactivity, (I)nstru	EMG E-0, St ument, (C)omp	ep 4 oonent, (M)ajor				
Targ		ve Attributes per Scen Section D.5.d)	nario (See	Actual Attributes	ES-301-5	CRS	ATC	BOP
1. Ma	Ifunctions afte	er EOP entry (1–2)		2	Rx	0	0	0
2. Ab							0	
3. Major transients (1–2) 2 I/C 7 4 4					4			
4. EOPs entered/requiring substantive actions (1–2)				3	Maj	2	2	2
	try into a conti 1 per scenaric	ingency EOP with subs o set)	tantive actions	1	TS	2	0	0
6. Pre	eidentified criti	ical tasks (<u>></u> 2)		3				

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 2, Rev 2

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT 1: Given an ATWS, insert maximum negative reactivity into the core by manually inserting control rods and de- energizing the control rod drive MG sets within 1 minute of the need to trip the reactor.	Failure to insert negative reactivity by one of the methods listed can result in the needless continuation of an extreme or a severe challenge to the subcriticality CSF. The safeguards systems that protect the plant during accidents are designed assuming that only decay heat and pump heat are being added to the RCS.	 Red first out annunciator 86A lit with indications of loss of RCS flow on one loop. On Panel RL- 004, Red lights lit for Reactor Trip Breakers *SB ZL-1 *SB ZL-2 On DRPI panel, ALL Rods out. Reactor Not Manually Tripped after actuating Handswitches *SB HS-1 *SB HS-42 Reactor Power ≥5% 	On Panel RL- 004 RO inserts rods in MANUAL using * SF HS-2 On Panel RL- 016, BOP/3 rd RO opens red handled breakers: *PG HIS-16 *PG HIS-18	 On DRPI panel, All Rod Bottom lights lit. Reactor Power <5% on PR NIs. Reactor power lowering on IR NI detectors * SE NI-34B SE NI-34B SE NI-36B Negative IR SUR *SE NI-35D SE NI-36D
CT 2: Isolate feed flow into the Faulted 'A' S/G by closing AL HK-7A and AL HK-8A, AFW REG VLV CTRLs before ANY RCS Cold Leg temperature reaches 240°F.	Failure to isolate steam from and feed to a faulted S/G causes an unnecessary and avoidable challenge to the Integrity CSF due only to improper response by the crew.	S/G pressures, flows and level indications will make it possible to identify 'A' S/G as the faulted S/G. Reports from the field help identify safety valves have lifted.	Manipulates closed the following hand switches On Panel RL- 005, o AL HK-7A, SG A MD AFP AFW Reg VLV CTRL o AL HK-8A, SG A TD AFP AFW REG VLV CTRL	On panel RL- 005, AL HK-7A and 8A in the left latch detent position. Indicated flow on AL FI-2A is 0 lbm/hr

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT 3: Isolate high head ECCS flow through the BIT before overfill of the RCS results in a rupturing of the pressurizer relief tank (PRT) at 91 psig.	Continued maximum injection causes RCS to go solid and PORV to open, passing excess inventory through PORVs to the PRT. Failure to terminate ECCS flow when it is possible to do so results in a rupture of the PRT, spread of radioactive coolant into Containment, and constitutes an avoidable degradation of a fission product barrier, as well as additional risk of stuck open PORV (SBLOCA).	RCS pressure and pressurizer level rise. PORVs open, flow indicated. PRT level, pressure, and temperature rise. When PRT ruptures at ~91 psig, PRT pressure drops and equalizes with Containment Pressure.	The Operator will isolate the BIT per EMG ES-03, Step 13, by Manipulation of the following handswitches on Panel RL018. *EM HIS-8803A *EM HIS-8803B *EM HIS-8801A *EM HIS-8801B	Green lights LIT and red lights extinguished for the following valves: *EM HIS-8803A *EM HIS-8803B *EM HIS-8801A *EM HIS-8801B CCP To BIT Flow indicators drop to 0 GPM. *EM FI-917A *EM FI-917B

Note: Causing an unnecessary plant trip or ESF actuation may constitute a Critical Task failure. Actions taken by the applicant(s) will be validated using the methodology for critical tasks in Appendix D to NUREG-1021.

Appendix D

Scenario Outline

SCENARIO # 2 NARRATIVE

Turnover: The Unit is operating at 100% power. Yellow Train is in service. 'A' EDG is out of service due to repairs on the Auxiliary Lube Oil pump. LCO 3.8.1 Condition B is entered (Actions B.1 and B.2 are current. STS NB-005 was performed 3 hours ago)

Event 1: Breaker 4-16 to 4.16 KV, Non-Safety, Bus SL-41Trips, Loss of power to 'A' SW Pump. The crew will dispatch an Operator to investigate loss of bus SL-41 per ALR 00-011D and start 'B' SW pump per ALR 00-08B to restore Service Water System pressure to >85 psig. Once the CRS has determined TRM 3.7.8 is applicable for loss of 'A' SW Pump, the next event will start as directed by the Lead Examiner.

Event 2: B S/G Feed Flow Channel indicator AE FI-520 fails LOW. The crew will respond by taking manual control of AE FK-520, B FRV to match feed and steam flows per ALR 00-109C and then address the instrument failure per OFN SB-008, ATT C. Once the Crew has restored automatic control, the next event will start as directed by the Lead Examiner.

Event 3: 'B' HDP Trips. Per OFN AF-025, ATTACHMENT A, Maximum unit load is at 95% for one HDP out of service. The crew will reduce load per OFN MA-038 and beginning of shift reactivity brief. Once reactor power has stabilized at the new lower power level, the next event will start as directed by the Lead Examiner.

Event 4: Turbine First Stage Pressure indictor AC PT-505 fails LOW. After control rods reach 204 steps in automatic, AC PT-505 will fail low. After confirming no load reject is in progress, the ATC operator will take rods to manual to stop inward rod motion. The crew will address the failure per OFN SB-008, ATT D. Once the CRS has determined applicable technical specifications, the next event will start at the direction of the Lead Examiner.

Event 5: Letdown Orifice valve BG HIS-8149BA fails closed: ATC will recognize loss of Letdown flow and Pressurizer Level rising. The ATC will address the failure by charging to seals only, and restoring Letdown using one of the other valves. ALR 00-032D may be initiated to control pressurizer level. The next event will start following restoration of Letdown or at the direction of the Lead Examiner

Event 6: 'D' RCP spuriously trips and the Reactor fails to Trip in BOTH Auto and Manual. The loss of flow causes multiple MCB alarms, including a Red First Out 86A, which indicates the reactor should have tripped due to RCS flow <89.9% on 3/3 loop flow instruments on1/4 RCS Loops while Reactor Power >48% (P8). After the crew attempts to manually trip the reactor unsuccessfully, they will perform Immediate Actions of EMG FR-S1, to open RDMG breaker power supplies for PG19 and PG20 to trip the Reactor.

CT 1: Given an ATWS, insert maximum negative reactivity into the core by manually Inserting control rods and deenergizing the control rod drive MG sets within 1 minute of the need to trip the reactor.

Event 7: 'A' MD AFW Pump fails to Auto Start. The BOP will manually start 'A' MDAFW Pump per EMG FR-S1, Step 3 RNO.

Event 8: Three S/G Safety Valves will fail open on 'A' S/G and SI will actuate on 'A' Train ONLY: As soon as the Reactor trips. Safety valves will lift on 'A', 'B' and 'C' S/Gs. The Safety valves will reseat on 'B' and 'C' S/Gs, while three 'A' S/G safety valves stick open. Steam flow noises will be heard in the control room. Once the crew closes MSIVs, the faulted 'A' S/G will be more evident, and they will transition to EMG E-2 to address the faulted 'A' S/G.

Appendix D	Scenario Outline	Form ES-D-1

CT 2: Isolate feed flow into the Faulted 'A' S/G by closing AL HK-7A, SG A MD AFP AFW REG VLV CTRL and AL HK-8A SG A TD AFP AFW REG VLV CTRL before ANY RCS Cold Leg temperature reaches 240°F.

Once the crew isolates the Faulted S/G per EMG E-2, they will transition to EMG ES-03 to terminate SI. **CT 3:** Isolate high head ECCS flow through the BIT before overfilling the RCS resulting in a rupture of the pressurizer relief tank (PRT) at 91 psig.

Event 9: SI fails to actuate on 'A' Train ONLY: SI will actuate on 'A' Train ONLY, The ATC will Manually Actuate SI on 'B' Train during performance of EMG E-0 Immediate actions before the crew continues in EMG E-0 to verify proper SI Auto actuation.

The scenario is complete when the crew has Terminated SI flow and verified ECCS Flow is NOT required per EMG ES-03, Step 18 and/or at the discretion of the Lead Examiner.

Appendix D

Scenario Outline

SIMULATOR SCENARIO FILES

;2019 ILO NRC Exam, Scenario 2 (IC 302)

;Initial Conditions – 'A' EDG Out of Service for TSEO, LCO 3.8.1, Cond B is entered. (For Predictability) scn SimGroup\TAGDGA

;Event 1 – Key 1 – Loss of Bus SL-41 ('A' SW Pump) (ATC/CRS-TS) ICM bkrSL4_16.cmf t:1 k:1

;Event 2 – Key 2 – AE FI-520, 'B' S/G Feed Flow fails LOW (BOP/CRS) ICM trAEFT0529.cmf t:3 k:2 r:60 f:0

;Event 3 – Key 3 – 'B' HDP Trips (BOP/ATC/CRS) ICM bkrDPAF01B.cmf t:1 k:3

;Event 4 – Key 4 – AC PT-505 fails LOW (BOP/CRS - TS) ICM trACPT0505.cmf t:3 k:4 f:0

;**Event 5 – Key 5** – Letdown Orifice valve BG HIS-8149BA fails closed (ATC) ICM aovBGHV8149B.cmf t:2 k:5

;Event 6 – Key 6 – 'D' RCP Spuriously Trips, Reactor Fails to Trip in Auto and Manual (Major) ICM bkrPA00204.cmf t:1 k:6 IMF mSF17A IMF mSF17B

;Event 7 – 'A' MD AFW Pump fails to start on Reactor Trip (BOP – Not CT) IMF mAL04A

;**Event 8** – Three S/G Safeties on 'A' S/G fail to reseat after opening on ATWS. {abp0514>1100} IMF mAB05A r:15 i:o f:300

;Event 9 - SI Train B Fails to Auto Actuate (ATC – Not CT) IMF mSA14B f:AUTO

;Local Action – **Key 10** – Close AF V234 IRF rAF02B k:10 r:60 f:0

;Local Action – Key 11 – Open Reactor Trip Breakers IRF rSF03A k:11 f:OPEN IRF rSF03B k:11 d:10 f:OPEN

Appendix D	Ap	per	ndix	D
------------	----	-----	------	---

Scenario Outline

Booth Instructions

Ensure NRC Exam Security Established per AIF 30B-015-09, and AIF 30B-015-18

Ensure the following procedures are available, free of markings and are the most recent revision in Curator (10/31/19):

- □ ALR 00-008B, SERV WTR PRESS HILO (Rev 18)
- □ ALR 00-011D, SL41 BUS TROUBLE (Rev 6)
- □ ALR 00-109B, SG B LEV DEV (Rev 10A)
- □ ALR 00-109C, SG B FLOW MISMATCH (Rev 11A)
- □ ALR 00-032D, PZR HI LEV DEV HTRS ON (Rev 11)
- □ ALR 00-042A, CHG LINE FLOW HILO (Rev 17)
- □ OFN SB-008, INSTRUMENT MALFUNCTIONS (Rev 49)
- OFN SB-008, ATTACHMENT D, TURBINE IMPULSE PRESSURE CHANNEL MALFUNCTION (Rev 49)
- **OFN SB-008, ATTACHMENT E, FEEDWATER FLOW CHANNEL MALFUNCTION (Rev 49)**
- OFN AF-025, UNIT LIMITATIONS (Rev 56)
- OFN MA-038, RAPID PLANT SHUTDOWN (Rev 30)
- **EMG FR-S1, RESPONSE TO NUCLEAR POWER GENERATION/ATWS (Rev 23B)**
- **EMG E-0, REACTOR TRIP OR SAFETY INJECTION (Rev 41A)**
- □ EMG E-2, FAULTED STEAM GENERATOR ISOLATION (Rev 22)
- **EMG ES-03, SI TERMINATION (Rev 26)**

NOTE: All events are loaded into snap IC302

Ensure malfunctions, including severity levels match scenario.

Ensure all meters, lamps, bistables and annunciators are correct for the initial setup. <u>Blue Placard is on</u> the 'A' CCP and Caution Tags hanging for 'A' EDG on KJ HS-8A, and NE HIS-25 (in PTL). Green placard for STS NB-005 posted, showing time due in 5 hours.

Ensure soft panel display in back is set to <u>RP312 RCP Vibration</u> on left screen and <u>AMSAC</u> on right screen.

Ensure no discernable history from RM11, Ovation screens, paper trend recorders, etc.

Ensure all laminated brief sheets, foldout pages, E plan boards are wiped clean.

Ensure all follow-up buttons are removed from the boards and trash cans and recycle bins are free of any potential exam material.

Ensure communications are established with the lead examiner, fresh batteries, radio check sat.

Critical Parameter Data to be collected:

- Cold Leg Temperature. The crew must isolate feed flow to faulted 'A' S/G prior to RCS Cold Leg Temperatures reach 240°F.
- PRT Pressure The crew must terminate SI by closing the BIT Isolation valves before rupturing the PRT at 91 psig.
- □ The crew must also trip the Reactor per EMG FR-S1 prior to dispatching an Operator to locally open the Reactor Trip Breakers.

Ensure Horns are ON and machine is in RUN

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 2, Rev 2

Appendix D

Scenario Outline

Insert Key 1 for Event 1 (Breaker 4-16, feeder to bus SL-4 Trips, 'A' SW Pump without power).

Insert Key 2 for Event 2 ('B' S/G Feed Flow fails LOW).

Insert Key 3 for Event 3 ('B' Heater Drain Pump Trips)

Insert Key 4 for Event 4 (AC PT-505 fails LOW)

Insert Key 5 for Event 5 (BG HIS-8149BA Fails closed)

Insert Key 6 for Major Event ('D' RCP Spuriously trips, Reactor fails to trip, 'A' MDAFW Pump fails to auto start, Three Safeties on 'A' S/G fail open, 'B' SI fails to Auto Actuate)

When directed to close AF V234, Insert Key 10 When directed to open RTBs, Insert Key 11

Op Test	No.: Dec 2019	Scenario No.: 2 Event No.: 1 Total No Pages 37			
<u>Event [</u>	Event Description: Breaker 4-16 to Non-Safety 4.16 KV Bus SL-41Trips, Loss of power to 'A' SW Pump				
Time	Position	Applicant's Actions or Behavior			
<u>Simulato</u>	r Operator: Inser	t Key 1 at the lead examiners direction			
Diagnost	tics: Service Wat	er Pump discharge pressure lowering, 1PI-WS009A			
Annuncia	ators: 008B and (
	CREW	Recognizes alarms affecting Service Water and bus SL-41			
	CRS	Directs operator to perform ALR 00-008B, SERV WTR PRESS HI LO			
		ALR 00-008B, SERV WTR PRESS HI LO			
		NOTE			
	Service Water pressure low alarm is sensed downstream of Service Water Strainers. Service Water discharge indication is sensed upstream of Service Water Strainers at the pump discharge				
	ATC 1. Check Service Water Pumps Discharge Pressure – LESS THAN 80 PSIG – Yes o 1PI-WS009A				
	ATC 2. Check Liquid Waste Release using Service Water System for dilution flow – NOT IN PROGRESS – Yes				
	ATC	3. Verify Service Water System Leakage is not the cause of the Service Water Low Pressure – Yes			
	or Operator: WH cknowledge reque	EN contacted as Site Watch to investigate SL-41 and the 'A' Service Water est			
	ATC ATC 4. Start Standby Service Water Pumps, As necessary, to establish discharge pressure greater than 85 PSIG 0 1HS-WS002A For Pump B (SL-31, SL-3, PA01) – Yes				
	ATC	 5. Check Service Water Pumps discharge pressure – GREATER THAN OR EQUAL TO 85 PSIG – Yes 1PI-WS009A 			

Op Test		Scenario No.: 2	Event No.: 1	Total No Pages 37
Event Description: Breaker 4-16 to Non-Safety 4.16 KV Bus SL-41Trips, Loss of power to 'A' SW Pump				
Time	Position	Α	pplicant's Actions or Beh	avior
	ATC	6. Check Service Wate 140 PSIG – No	er Pumps discharge pressu	re – GREATER THAN
		RNO Return to proced	ure and step in effect	
	CRS	Enters TRM 3.7.8, CO	NDITION A – 60 days	
Event Termination: After the crew has established adequate Service Water discharge pressure and/or at the direction of the Lead Examiner				
Simulato	r Operator: Inser	t Key 2		

Op-Test	t No.: Dec 2019	Scenario No.: 2 Event No.: 2 Total No Pages 37		
Event Description: AE FI-520, 'B' S/G Feed Flow Fails LOW				
Time	Position	Applicant's Actions or Behavior		
Simulato	or Operator: Inse	ert Key 2 at direction of Lead Examiner.		
Diagnostics: Level rising in the 'B' S/G, indicated feedwater flow to the 'B' S/G lowering, 'B' MFRV opening Annunciators: 109C				
		Discusses follows of (D) O/O level control and takes means a stimula of ALD		
	CREW	Diagnoses failure of 'B' S/G level control and takes memory actions of ALR 00-109C,		
	CRS	Enters and/or directs either ALR 00-109C or OFN SB-008		
		ALR 00-109C, SG B FLOW MISMATCH		
		NOTE		
o A slig	ght step change	re Memory Action steps on the Feedwater reg Valve controller's output could occur during a auto and manual		
BOP 1. Check difference between Steam Generator B Steam Flow and Feed Flow – GREATER THAN 0.7 MPPH – Yes • AB FI-522A For Steam Flow • AB FI-523A For Steam Flow • AB FI-520A For Feed Flow • AB FI-521A For Feed Flow • AB FI-521A For Feed Flow				
	BOP	 2. Check for Instrument Operating properly: Steam Generator B Controlling Steam Pressure Channel – WITHIN 100 PSIG OF REMAINING CHANNELS – Yes *AB PI-524A *AB PI-525A Steam Generator B Controlling Feedwater Flow Channel – WITHIN 0.2 MPPH OF OTHER CHANNEL – No Steam Generator B Controlling Steam Flow Channel – WITHIN 0.2 MPPH OF OTHER CHANNEL – Yes RNO Perform the following: a. Place Feedwater Reg Valve in manual AE FK-520 b. Adjust Feedwater Reg Valve, as necessary, to establish Steam Generator level at program value AE FK-520 c. Go to OFN SB-008, INSTRUMENT MALFUNCTIONS, Step 1		

Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 2 Total No Pages 37 Event Description: AE FI-520, 'B' S/G Feed Flow Fails LOW					
Time	Position	Applicant's Actions or Behavior			
	CRS Transitions to OFN SB-008, INSTRUMENT MALFUNCTIONS, Step 1				
	OFN SB-008, INSTRUMENT MALFUCNTIONS				
	BOP, CRS 1. Check for Malfunction * Check if Secondary System Instrument Channel is Malfunctioning a. Perform appropriate attachment for malfunctioning channel from table below:				
		Feedwater FLow F-521, F-530, F-531 ATTACHMENT E (AE) F-540, F-541 ATTACHMENT E			
	ATTACH	MENT E, FEEDWATER FLOW CHANNEL MALFUNCTION			
		CAUTION			
	cause the thermal power program to be inaccurate <u>NOTE</u> Steps E1 through E3 are Memory Action steps				
	BOP	BOP E1. Identify failed Instrument Channel: a. Compare feedwater flow indications to confirm feedwater flow channel failure: *AE FI-520A			
	BOP	E2. Check Failed Feedwater Flow channel selected on SG FW FLOW CHANNEL SEL switch: *AE FS-520C – Yes			
		NOTE			
	step change on th auto and manua	e Feedwater Reg Value controllers output, could occur during the transfer			
	BOP E3. Check Main Feed Reg Valves in Control: a. Place Affected SG MFW REG VLV CTRL – IN MANUAL *AE FK-520 b. Adjust affected S/G MFW REG VLV CTRL, as necessary, to establish Steam Generator level at program: *AE FK-520				

Op-Tes	t No.: Dec 2019	Scenario No.: 2 Event No.: 2 Total No Pages 37			
Event D	Event Description: AE FI-520, 'B' S/G Feed Flow Fails LOW				
Time	Position	Applicant's Actions or Behavior			
	BOP	E4. Select Alternate Feedwater Flow Channel on the SG FW FLOW CHANNEL SEL switch: *AE FS-520C			
		<u>NOTE</u>			
Feedwa	ter flow is required	d to perform daily secondary calorimetric above 15% of rated thermal power			
	CRS E5. Request I&C to repair failed channel				
	CRS	E6. Check S/G Feedwater Flow Channel Failure – REPAIRED OR ALTERNATE CHANNEL SELECTED			
	RNO <u>WHEN</u> the S/G feedwater flow channel failure is repaired <u>OR</u> alternate channel is selected, THEN go to step E7				
	BOP	E7. Restore affected S/G MFW REG VLV CTRL to – AUTO			
	CRS	E8. Return to procedure and step in effect			
direction	Event termination: After the crew has restored 'B' S/G Feedwater Control to Automatic and/or at the direction of the Lead Examiner Simulator Operator: Insert Key 3 at direction of the Lead Examiner.				

Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 3 Total No Pages 37					
Event Description: 'B' HDP trips, Downpower to 95%					
Time	Position	Applicant's Actions or Behavior			
Simulat	or Operator: Ins	sert Key 3 at direction of Lead Examiner.			
Diagnos	tics : Main Gene	rator load trending down			
Annunc	iators: 103E				
Examiner Note: It takes 60-70 seconds for alarm to actuate if crew does not see NPIS alarm. The trip of the Heater Drain Pump will change plant efficiency. The crew should reduce turbine load to maintain reactor power within limits. This action is NOT addressed in the ALR and the crew may either discuss lowering turbine load 30 MW using "FAST LOAD DECREASE" IAW Pre-shift reactivity brief actions, or formally enter OFN AF-025, UNIT LIMITATIONS AND/OR OFN MA-038, RAPID PLANT SHUTDOWN in accomplishing the task of reducing power within limits. Actions for boration during down power can be found in Attachment 2					
	CREW	Diagnoses HDP Trip and performs ALR 103E			
		ALR 00-103E, HEATER DRN TK DUMP			
<u>NOTE</u> A red light on the front panel of the controller will indicate a problem with the controller's microprocessor					
	BOP	 1. Check Heater Drain Dump Valves, Using NPIS Computer – OPEN – Yes o AFD0074A for AF LV-74A o AFD0074B for AF LV-74B 			
		<u>NOTE:</u>			
		o valves are not designed for continuous operation. If dump valves are open System Engineering should be notified for erosion/corrosion concerns.			
	BOP	 2. Check If Dump Valves Should Be - OPEN Locally Check Heater Drain Tank Level - HIGHER THAN 20 INCHES ABOVE CENTERLINE 			
	or Operator:				
 WHEN contacted To determine level in Heater Drain Tank acknowledge request, WAIT 2 minutes and REPORT: "Level is above 25" and slowly rising" IF asked about pump status, report breaker overcurrent flag is dropped. IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status. 					
	BOP	3. Check Turbine Power – Less than or equal to 25% - No			
		RNO Go to step 5.			

•		9 Scenario No.: 2 Event No.: 3 Total No Pages 37 HDP trips, Downpower to 95%			
Time	Position	Applicant's Actions or Behavior			
	BOP	5. Check Heater Drain Pumps – RUNNING – No			
	 RNO Perform the following: a. <u>IF</u> a Heater Drain Pump has tripped, <u>THEN</u> perform the following: Notify Electrical Maintenance to determine and correct cause. Complete shutdown of affected Heater Drain Pump per SYS AF- 121, HEATER DRAIN PUMP OPERATION** 				
		**SYS AF-121, paragraph 6.4.5 directs locally closing AF-V234, HEATER DRAIN PUMP B DISCH LV-71B OUTLET ISO valve.			
		NOTE			
A red ind micropro		the front panel of the controller will indicate a problem with the controller's			
	ATC 6. Locally Check Heater Drain Tank Level Control Valves - OPEN AF LV-71A AF LV-71B - No RNO Perform the following: a. Stop the affected HDP – Tripped b. Locally close affected level control isolation valve AF-V234 for AF LV-71B c. Notify I&C to determine and correct cause of valve failure. 				
 WH REI WH report Wh 	PORT valve AF EN directed to loort AF V234 is c en directed to in	check AF LV-71A and 71B, acknowledge request, WAIT 2 minutes and LV-71B is closed ocally close level control isolation valve, INSERT Key 10, WAIT 2 minutes and losed westigate Heater Drain Pump 'B', WAIT 2 minutes and report "Pump is hot to iker is tripped with overcurrent flag dropped."			
		NOTE			
At low p		h Condensate Pump discharge pressure may reduce Heater Drain Pump flow			
	ATC	7. Check Plant Operating At A Low Power Level – NO			
		RNO Go To Step 9			
	ATC	 9. Verify Heater Drain Pump – RECIRCULATION FLOW a. ENSURE Heater Drain Pump Recirculation Controllers – SET AT 0.55 x10⁶ LMB/HR o AF FIC-72B For Pump 'A' o AF FIC-73B For Pump 'B' 			

Op-Tes	t No.: Dec 2019	9 Scenario No.: 2 Eve	ent No.: 3 Total No Pag	ges 37	
Event D	escription: 'B' l	HDP trips, Downpower to 95%			
Time	Position	Applicant's Actions or Behavior			
	CRS	10. Return To Procedure And Step in Effect			
		OFN AF-025, UNIT LIMIT	ATIONS		
		NOTE			
Steps 1	through 12 may	be done in any order			
		 a. Determine maximum unit load, using ATTACHMENT A, UNIT LOAD LIMITS. b. Reduce unit load, as necessary, to satisfy load limits using the appropriate procedure: *GEN 00-004, POWER OPERATION <u>OR</u> *GEN 00-005, MINIMUM LOAD TO HOT STANDBY <u>OR</u> *OFN MA-038, RAPID PLANT SHUTDOWN – Yes <u>OR</u> *ATTACHMENT D, TURBINE/GENERATOR LOAD DECREASE USING STEAM DUMPS 			
	CRS	Enters ATTACHMENT A, UNIT LO	AD LIMITS		
	CRS	FEED AND COND	ENSATE (CONT.)		
		CONDITION REQUIRING LOAD REDUCTION	MAXIMUM UNIT LOAD		
		One main feed pump out of service	760 MWE 62%		
		One condensate pump out of service	1102 MWE 90% (1) (2)		
		One Htr Drain Pump out of service	3385 MWT 95% (3) (4) (5)		
		Two Htr Drain Pumps out of service	2140 MWT 60%		
		instructions and operating p OOS.(4) If Reactor Power is greater Pumps are running.	DRAIN PUMP OPERATION for shutdow restrictions with one Heater Drai than 60%, ensure all three Conde than 65%, ensure no Low Pressure	n Pump nsate	

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 3 Total No Pages 37				
Event D	Event Description: 'B' HDP trips, Downpower to 95%				
	<u></u>				
Time	Time Position Applicant's Actions or Behavior				
	CRS Enters and directs OFN MA-038, RAPID PLANT SHUTDOWN				
		OFN MA-038, RAPID	PLANT SHUTDOWN		
		<u>CAU</u>	TION:		
Fast unl	oading rates mag	y result in increased turbine	vibration		
		NOT	ES:		
o Loa	d reduction at gr	e monitored throughout this eater than 65 MW (5%)/min Memory Action Steps.		am dumps.	
	CRS Provide reactivity brief and bounding order for the load reduction, including unloading rate and boration rate. Examiner Note: The initial reactivity brief for a 10% load reduction and/or shedding of 30 MW is performed prior at turnover and may not be repeated here. The Applicants have been trained to use FAST LOAD				
			per step 3, but either met		
	BOP	a. Check Desired Un MW/MINUTE (5%) –	bading Method To Be Used oading Rate – LESS THAN Yes, 3%/min Turbine Unloading Desired -	OR EQUAL TO 65	
		<u>NO</u>	ES:		
 If the High Limiter Active on Graphic 5551 is in alarm, load can only be decreased with the Load Control selected to Open Loop. When High Limiter Active is cleared as indicated by the alarm changing to Limiter Activated, the Load Control Mode may be changed. The following is the preferred Mode of Load Control, unless otherwise directed by another procedure: 					
MW FSF	- If making Turb	Turbine Load is not being cl ine Load changes where th v side transient requires cha table.	ere is no ongoing secondar	y side transient	

•	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 3 Total No Pages 37 Event Description: 'B' HDP trips, Downpower to 95%				
Time	Position	Applicant's Actions or Behavior			
	BOP, ATC	 2. (ρ) Reduce Turbine Load In Automatic: a. From Graphic 5551, TURBINE CONTROL SYSTEM – OPERATION PANEL, LOAD CONTROL section – Select method of Load Control, as directed by CRS/SM. *Open Loop b. Perform the following steps to reduce Turbine Load: Select CHANGE. Enter TARGET MW (greater than or equal to 90% if in Open Loop) and select ENTER. Enter RATE – DEC and select ENTER. Select GO. c. (ρ) Energize PZR Backup Heaters, IAW SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS. BB HIS-51A BB HIS-52A d. (ρ) Borate RCS And Adjust Control Rods, As Necessary, To Maintain The Following: Target Tavg/Tref Temperature Error Between 0°F And +5°F Control Rods Above The Rod Insertion Limits e. Maintain desired turbine unloading rate f. Go to step 4. 			
		NOTES			
o The	 When the FAST LOAD DECREASE button is depressed, Turbine load reduction will be at 2.2 MW/sec (132 MW/min) 				
	BOP, ATC 3. (p) Reduce Turbine Load Manually. a. From Graphic 5551, TURBINE CONTROL SYSTEM – OPERATION PANEL, SETPOINTS section – select FAST LOAD DECREASE. b. On Popup 7009, FAST LOAD DECREASE, depress and hold FAST LOAD DECREASE button until desired CURRENT REF (MW) is indicated. c. (p) Borate RCS and adjust control rods, as necessary, to maintain the following. o Target Tavg/Tref Temperature Error Between 0F and +5F o BB HIS-51A o BB HIS-52A				

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 3 Total No Pages 37					
Event Description: 'B' HDP trips, Downpower to 95%						
Time	Position	Applicant's Actions or Behavior				
	ATC	4. Check PZR PORVs: a. RCS Pressure – LESS b. PZR PORVs – CLOSEE o BB HIS-455A o BB HIS-456A c. RCS Pressure – GREA d. PORV Block Valves – C o BB HIS-8000A o BB HIS-8000B) – Yes TER THAN 2185 PSI			
	ATC	5. Check PZR Pressure – STA	BLE AT OR TRENDI	NG TO 2235 PSIG - Yes		
	ATC	6. Check PZR Level – STABLE Yes	EAT OR TRENDING	TO PROGRAM LEVEL -		
	BOP	7. Check S/G Levels – CONTF	ROLLING BETWEEN	45% AND 55% – Yes		
	BOP	 8. Notify Radiation Protection To Perform The Following: Monitor RCS and other connecting systems for increasing Radiatic levels due to unplanned crud burst. Notify all personnel in the affected areas. 				
	BOP 9. Check If Sampling Is Required: a. Check if one of the following conditions is met: - No * Thermal Power Change – GREATER THAN 15% IN 1 HOUR * MODE Change From 2 To 3					
Simulator Operator: o If contacted as WWM, acknowledge requests. o If contacted as Call Supt., acknowledge status. o If contacted as RP, acknowledge request. o If contacted as Chemistry, acknowledge request.						
Event Termination: After Control Bank D reaches 205 steps in Automatic and/or at the direction of the lead examiner. Simulator Operator: Insert Key 4 at direction of Lead Examiner.						

Op-Test	No.: Dec 2019	Scenario No.: 2 Ev	vent No.: 4	Total No Pages 37	
Event De	Event Description: AC PT-505, Turbine Impulse Pressure Channel fails LOW				
Time	Position	Applicant'	s Actions or Beha	vior	
Simulator	<u>r Operator:</u> Inse	ert Key 4 at direction of Lead Exa	miner.		
Diagnost	i cs : AC PT-505 t	rending down slow. Rods step IN	due to temperature	error	
Annuncia	tors: 065E				
	CREW Diagnoses Failure. BOP Communicates no runback in progress and ATC places Rods in Manual as a memory action per OFN SB-008, ATT D.				
	CRS	Enters and directs ALR 00-065E	, and/or OFN SB-0	08	
		ALR 00-065E, T REF/T /	AUCT LO		
		NOTE			
		ip with a positive moderator temp eam dumps open, then this alarm		reactor power greater	
	ATC	1. Check Tavg – GREATER TH *BB TI-412 *BB TI-422	AN OR EQUAL TO	551°F – Yes	
	ATC ATC ATC 2. Check For Turbine Runback: *Generator Load MW – LOWERING - No *Generator Load Set MW – LOWERING – No RNO Go to Step 4.				
	ATC 4. Check Tref – 3° LOWER THAN AUTIONEERED HIGH TAVG – Yes *BB TR-412 <u>OR</u> *NPIS computer points o BBT0499A for Tavg o BBT0496A for Tref				

Op-Test	No.: Dec 2019	Scenario No.: 2	Event No.: 4	Total No Pages 37	
Event Description: AC PT-505, Turbine Impulse Pressure Channel fails LOW					
Time	Position	A	pplicant's Actions or Beha	vior	
	ATC	o BB TI-4 o BB TI-4 o BB TI-4 o BB TI-4 b. Check HP Turb o AC PI-5 o AC PI-5	annels – NORMAL – Yes 12 22 32		
	CRS	Transitions to OFN SB	-008, INSTRUMENT MALFU	INCTIONS	
		OFN SB-008, INSTRU	JMENT MALFUNCTIONS		
	CRS	a. Perform ap the table below Turbine Impulse Pressure (AC)	ary System Instrument Channer propriate attachment for male w: P-505 P-506	ATTACHMENT D	
ATTACHMENT D, TURBINE IMPULSE PRESSURE CHANNEL MALFUNCTION					
Steps D1	and D2 are Men	Nory Action steps.	IOTE		
	ATC D1. Identify Failed Instrument Channel o AC PI-505 – Yes o AC PI-506				
	ATC D2. Place ROD BANK AUTO/MAN SEL In Manual. • SE HS-9				
	CAUTION				
If PT-505 has failed low, a continuous (Tref-Tavg) mismatch will exist. If steam dumps arm, the mismatch signal may cause the dump valves to open. If this happens, the dump valves will have to be switched to off to stop the steam release.					

Op-Test	No.: Dec 2019	Scenario No.: 2 Event No.: 4 Total No Pages 37				
<u>Event De</u>	Event Description: AC PT-505, Turbine Impulse Pressure Channel fails LOW					
Time	Position	Applicant's Actions or Behavior				
	BOP	D3. Check Failed HP TURBINE 1 ST STG PRESS Channel Selected On HP TURB 1ST STG PRESS SEL Switch. o AC PS-505Z				
		<u>NOTE</u>				
Tref. T	his will be corre	be available if the failed impulse pressure channel is being used to develop cted by switching the impulse pressure selector to the alternate channel. and signal is derived from AC PT-505 and cannot be changed.				
	BOP	 D4. Select Alternate HP TURBINE 1ST STG PRESS Channel, Using HP TURB 1ST STG PRESS SEL Switch. a. AC PS-505Z b. Check Tref indication – NORMAL – Yes *NPIS point BBT0496A *BB TR-412				
	ATC	D5. Check Tavg – WITHIN 1°F OF TREF RNO (ρ) Adjust rods, as necessary, to maintain Tavg within 1°F of Tref.				
	ATC	D6. Place ROD BANK AUTO/MAN SEL In Auto. o SE HS-9				
	ATC	D7. Place STEAM DUMP BYPASS INTERLOCK To – OFF o AB HS-63 o AB HS-64				
	ATC	D8. Monitor Rod Control Response To Ensure Proper Control				
	<u>NOTE</u> It may take several minutes for the C-7 Loss Of Load interlock to clear after the failed channel is selected out. The time is dependent on how AC PT-506 failed.					
	BOP	D9. Check C-7 Loss Of Load Interlock – NOT LIT - Yes				
	BOP	D10. Select Steam Pressure Mode: a. Set STEAM HDR PRESS CTRL to 7.28. o AB PK-507				

Op-Test	No.: Dec 2019	Scenario No.: 2	Event No.: 4	Total No Pages 37			
Event De	Event Description: AC PT-505, Turbine Impulse Pressure Channel fails LOW						
Time	Position	Ар	plicant's Actions or Beh	avior			
	вор	D11. Place STEAM DU o AB HS-63 o AB HS-64	MP BYPASS INTERLOCK	To – ON			
	CRS D12. Monitor The Following Technical Specification For LCOs And Comply With Action Statements, As Appropriate: o 3.3.1, REACTOR TRIP SYSTEM INSTRUMENTATION, Table 3.3.1-1, Function 18.f Enters LCO 3.3.1, COND A – IMMEDIATE, COND T 1 hour						
	ATC	Verifies P-13 interlock in 1 hour action.	n proper state to comply w	ith LCO 3.3.1, Condition T			
	<u>NOTE</u>						
o When	the bistable for	the affected instrument is	tripped, the output to that	control board indication			
 If time includi 	ing a determinat		ould trouble shoot and obt affected. M-767-00310,				
<u>Simulato</u>	r Operator: IF	contacted as WWM or Ca	Il Supt, acknowledge reque	ests.			
	D13. Place The Trip/Safeguards Bistables For Failed Channel In TRIPPED Mode:						
		Examiner Note: Bistat	oles will NOT be tripped.				
	BOP	D14. Check C-16 Hold o On Graphic 557 RED	Active: 70, LOAD CONTROL LOO	P REJECTED – NOT			
	<u>NOTE</u>						
	For AMSAC to be armed, the LOGIC TEST INPUT switch associated with the OPERATING BYPASS switch must be placed in the LOGIC 1 position. The LOGIC 0 position may be used to disable AMSAC						

	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 4 Total No Pages 37 Event Description: AC PT-505, Turbine Impulse Pressure Channel fails LOW					
Time	Position	Applicant's Actions or Behavior				
	BOP	D15. At AMSAC TEST/BYPASS Panel, Place Turbine Impulse Pressure Channel In Proper Condition For AMSAC: a. Select OPERATING BYPASS SWITCH to position associated with failed pressure channel from table below: FAILED OPERATING BYPASS SWITCH CHANNEL P-505 PTI1 b. Check Reactor Power – GREATER THAN OR EQUAL TO 35% c. Place the OPERATING BYPASS toggle switch to the right hand position.				
	CRS	D16. Request I&C To Repair Failed Channel				
	ATC	 D17. Check Control Rods In Parked Position RNO <u>WHEN</u> plant conditions allow, <u>THEN</u> perform the following to return Control Rods to their parked position: a. Place ROD BANK AUTO/MAN SEL In Manual. SE HS-9 b. (ρ) Return Control Rods to their parked position, using MAN ROD CTRL joystick. SF HS-2 c. <u>WHEN</u> Tavg is within 1°F of Tref, <u>THEN</u> place ROD BANK AUTO/MAN SEL in auto. SE HS-9 				
	CRS D18. Return To Procedure And Step In Effect					
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.					
Event termination: After the crew has identified Technical Specifications and/or at the discretion of the Lead Examiner. Simulator Operator: Insert Key 5 at the lead examiners direction.						

Op-Te:	st No.: Dec 2019	Scenario No.: 2	Event No.: 5	Total No Pages 37	
<u>Event [</u>	Event Description: Letdown Orifice valve BG HIS-8149BA fails closed				
Time	ne Position Applicant's Actions or Behavior				
Simulat	tor Operator: Ins	ert Key 5 at direction of L	ead Examiner.		
energize	e when PZR Leve	l is 5% above program lev	Depending on crew responel.	nse, PZR Heaters will	
Annund	ciators: 042A & 03				
	ATC	Determine Letdown has	isolated and reports indica	tion	
	CRS	Directs charging to seals	only		
discove	red quickly. Once		HTRS ON, may be entered eals only, ALR 00-042A, Cl the same way.		
		ALR 00-042A, CH0	G LINE FLOW HILO		
	inding of pumps is S, should be consi	suspected, performance	<u>TION</u> of OFN BG-045, GAS BIN	DING OF CCPS OR SI	
	NOTE				
Step 1 i	is a memory actio				
	ATC 1. Check Charging Pumps – ANY RUNNING – Yes *BG HIS-1A For CCP A *BG HIS-2A For CCP B *BG HIS-3 for NCP				
	2. Check Charging Header flow GREATER THAN OR EQUAL TO 150 GPM – No ATC o BG FI-121A RNO Go to Step 7				
	ATC o BG FI-121A				

Appendix D

Op-Tes	Op-Test No.: Dec 2019Scenario No.: 2Event No.: 5Total No Pages 37					
Event D	Event Description: Letdown Orifice valve BG HIS-8149BA fails closed					
Time	Position	Applicant's Actions or Behavior				
	L	CAU ⁻	ΓΙΟΝ			
NCP ma	iximum flow is 15	0 gpm, CCP runout is 556	gpm			
	ATC 8. Check PZR Level – AT PROGRAM VALUE – No o BB LR-459					
		RNO Perform the following: a. Place running charging pump flow controller in manual and adjust charging flow, as necessary, to establish PZR level at program value *BG FK-121 For CCP *BG FK-462 For NCP				
	ATC	9. Check Letdown is Isola	ated – Yes			
ATC ATC 10. Reestablish Letdown: a. Check RCS Letdown to Regen HX valves open o BG HIS-459 b. Place Letdown HX Outlet Pressure Control in manual o BG PK-131 c. Open Letdown HX Outlet Pressure Control between 90%-100% o BG PK-131 d. Open desired Letdown Orifice Isolation Valve(s) *BG HIS-8149AA – Yes *BG HIS-8149BA *BG HIS-8149CA – Possible to regain level control faster e. Adjust Letdown HX Outlet Pressure Control to establish Letdow HX Outlet Pressure between 340 psig and 360 psig o BG PI-131 f. Place Letdown HX Outlet Pressure Control in auto o BG PK-131			in manual between 90%-100% ve(s) evel control faster I to establish Letdown 0 psig			
NCP MA	<u>CAUTION</u> NCP MAXIMUM flow is 150 gpm, CCP runout flow is 556 gpm					
	BOP	12. Check Charging Hea	der Flow and Letdown Flow	w – BALANCED – Yes		
I	1	<u>NO</u>	TE			
Total pu	Total pump flow should be maintained above 175 gpm to minimize effects of low flow cavitation					

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 5 Total No Pages 37					
<u>Event [</u>	Event Description: Letdown Orifice valve BG HIS-8149BA fails closed					
Time	Position Applicant's Actions or Behavior					
	вор	13. Verify CCP adequate a. Check CCPs – A RNO a. Go to Step 14				
	CRS Return to Procedure and Step in Effect					
the Lea	Event Termination: After the crew has reduced charging flow to seals only and/or at the direction of the Lead Examiner Simulator Operator: Insert Key 6 at the direction of the Lead Examiner					

<u>Event [</u> MANU/	Op-Test No.: Dec 2019Scenario No.: 2Event No.: 6/7/8/9Total No Pages 37Event Description:'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO andMANUAL.'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'S/G and SI will actuate on 'A' train ONLY.			
Time	Position	Applicant's Actions or Behavior		
Simulat	or Operator: Ins	sert Key 6 at direction of Lead Examiner.		
not tripp	Diagnostics : Reactor Coolant flow lowering, 'D' Reactor Coolant Pump tripped, Reactor and Turbine not tripped Annunciators: 86A & 83C			
	CREW Recognizes RCP 'D' tripped and diagnoses that the Reactor has not tripped			
	CRS	Directs ATC to manually trip the Reactor, upon failure directs and enters EMG FR-S1, REPSONSE TO NUCLEAR POWER GENERATION/ATWS		
EMG FR-S1, RESPONSE TO NUCLEAR POWER GENERATOR/ATWS				
o Step	 NOTE Step 1 and 2 are immediate action steps 			
o Fold	 Foldout page shall be monitored throughout this procedure 			

Op-Tes	at No.: Dec 201	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37	
Event Description: 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and			
	MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
	Position		
Time		Applicant's Actions or Behavior	
	ATC/BOP	1. Verify Reactor Trip	
		a. Check all rod bottom lights – LIT – No	
		 b. Check reactor trip breakers and bypass breakers – OPEN – No SB ZL-1 	
		o SB 2L-1 o SB ZL-2	
		o SB ZL-3	
		• SB ZL-4	
		c. Check intermediate range neutron flux – DECREASING – No	
		RNO Perform the following:	
		1. Manually trip the reactor	
		2. IF reactor will NOT trip, THEN perform the following:	
		a) Insert control in manual	
		b) Manually deenergize rod drive motor generators:	
		1) Open the following breakers:	
		 PG HIS-16 PG HIS-18 	
		2) WHEN all rod bottom lights OR reactor power is less than 5% with negative Intermediate Range SUR, THEN close the following breakers:	
		o PG HIS-16	
		• PG HIS-18	
		3) Continue with Step 2	
		CT1 : Given an ATWS, insert negative reactivity into the core by manually inserting control rods and de-energizing the control rod drive MG sets within 1 minute of the need to trip the reactor.	
		2. Verify Turbine Trip	
	BOP	a. Check Main Stop Valves – ALL CLOSED – No	
		RNO a. Perform the following:	
		1) Manually trip turbine	

Op-Tes	st No.: Dec 2019	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37	
MANUA	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior	
	BOP	 3. Verify AFW Pumps Running: a. Check motor driven AFW pumps – BOTH RUNNING – <i>No</i> AL HIS-22A AL HIS-23A – No b. Check turbine driven AFW pump – RUNNING – <i>Yes</i> RNO a. Manually start pumps 	
	BOP	 4. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes MA ZL-3A MA ZL-4A MB ZL-2 	
	ATC	 5. Check SI – NOT IN PROGRESS – <i>No</i> CCPs – ALIGNED FOR NORMAL CHARGING SI pumps – NONE RUNNING IN INJECTION MODE RHR pumps – NONE RUNNING IN INJECTION MODE RNO IF total ECCS flow from RWST to RCS is greater than 90 gpm, <u>THEN</u> go to step 9 EM FI-917A for CCP A EM FI-917B for CCP B EM FI-918 for SI pump A EM FI-922 for SI Pump B EJ FI-618 for RHR pump A EJ FI-619 for RHR pump B 	
	ATC	9. Check PZR Pressure – LESS THAN 2335 PSIG – Yes	
	BOP	 10. Verify Containment Purge Isolation: a. Check ESFAS status panel CPIS section – ALL WHTE LIGHTS LIT – Yes o Red Train o Yellow Train 	

Op-Tes	st No.: Dec 201	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37		
Event [Event Description: 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and			
		pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'		
S/G and	d SI will actuate	on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior		
	BOP	 <u>11.</u> Check Safety Injection Not Actuated: - No Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – CLEAR <u>AND</u> Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – CLEAR <u>AND</u> ESFAS status panel SIS section – NO WHITE LIGHTS LIT <u>AND</u> Partial Trip Status Permissive/Block status panel – SI RED LIGHT NOT LIT RNO Perform steps 1-8 of EMG E-0, REACTOR TRIP OR SAFETY INJECTION, while continuing with this procedure 		
Examin	er Note: Steps f	for EMG E-0 start on page 24		
	ATC	 12. Check if the following trips have occurred: a. Reactor Trip Check reactor trip breakers and bypass breakers – OPEN – No SB ZL-1 SB ZL-2 SB ZL-3 SB ZL-4 b. Turbine trip Check Main Stop Valves – ALL CLOSED – Yes RNO a. Dispatch operator to locally open reactor trip and bypass breakers 		
	Simulator Operator: WHEN contacted as the Auxiliary Building operator, acknowledge request, wait 2 min and Insert Key 11. Report Reactor Trip and Bypass breakers are open			
	ATC	 <u>13.</u> Verify Reactor Subcritical: a. Power range channels [GAMMA METRICS] – LESS THAN 5% - Yes b. Intermediate range channels – NEGATIVE STARTUP RATE [GAMMA METRICS – STABLE OR DECREASING] c. Go to Step 25 		
	CRS	25. Continue Boration until adequate shutdown margin is obtained		

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37		
MANUA	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior	
	ВОР	26. Check CRDM fans – ALL AVAILABLE RUNNING – Yes o GN HIS-42 o GN HIS-43 o GN HIS-44	
	CRS	 27. Determine Return Procedure a. Check EMG FR-S1, RESPONSE TO NUCLEAR POWER GENRATION/ATWT – ENTERED FROM EMG E-0, REACTOR TRIP OR SAFETY INJECTION – Yes 1) Check SI signal NOT present – No Go to EMG E-0, REACTOR TRIP OR SAFETY INJECTION, Step 1 	
		RNO 1) Go to EMG E-0, REACTOR TRIP OR SAFETY INJECTION, Step 8	
		EMG E-0, REACTOR TRIP OR SAFETY INJECTION	
o Stor	as 1 through 4 are	NOTE e immediate action steps	
-	-	e monitored throughout this procedure	
	ATC	 1. Verify Reactor Trip: Yes a. Check all rod bottom lights – LIT b. Check reactor trip breakers and bypass breakers – OPEN SB ZL-1 SB ZL-2 SB ZL-3 SB ZL-4 c. Check intermediate range neutron flux – DECREASING SE NI-35B [GAMMA METRICS] SE NI-36B [GAMMA METRICS] RNO Perform the following: *Performed in EMG FR-S1* 	
	BOP	2. Verify Turbine Trip: - Yes a. Check Main Stop Valves – ALL CLOSED	

Op-Tes	st No.: Dec 2019	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37	
<u>Event [</u> MANU/	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior	
	ATC	<u>3.</u> Check AC Emergency Busses – AT LEAST ONE ENERGIZED – Yes *NB01 – ENERGIZED *NB02 – ENERGIZED	
	ATC	 4. Check if Safety Injection is Actuated: a. Check any indication SI is actuated – LIT – Yes *Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – LIT *Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – LIT *ESFAS status panel SIS section – ANY WHITE LIGHTS LIT *Partial Trip Status Permissive/Block status panel – SI RED LIGHT LIT b. Check both trains of SI actuated – No Ann 00-030A, NF039A LOCA SEQ ACTUATED – LIT Ann 00-031A, NF039B LOCA SEQ ACTUATED – LIT Ann 00-031A, NF039B LOCA SEQ ACTUATED – LIT RNO b. Actuate both trains of SI SB HS-27 SB HS-28 	
	equired configura	CAUTION er SI reset, manual action may be required to restore safeguards equipment tion 5. (t) Check if SI required: * SI was manually actuated AND was required – Yes * Containment pressure is currently or has been – GREATER THAN OR EQUAL TO 3.5 PSIG – Yes * RCS pressure is currently or has been – LESS THAN OR EQUAL	
		* RCS pressure is currently of has been – LESS THAN OR EQUAL TO 1830 PSIG – Yes * Any S/G pressure is currently or has been – LESS THAN OR EQUAL TO 615 PSIG – Yes	

Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37 <u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior
	BOP	 <u>FOLDOUT PAGE Step 3.</u> FAULTED S/G ISOLATION CRITERIA IF any S/G pressure decreasing in an uncontrolled manner OR any S/G is completely depressurized, THEN perform the following: a. Close main steam isolation valves b. Isolate feed flow to faulted S/G(s) c. Maintain total feed flow greater than 270,000 lbm/hr until NR level in at least one S/G is greater than 6% [29%] CT2: Isolate feed flow into the Faulted 'A' S/G by closing AL HK-7A and AL HK-8A, AFW REG VLV CTRLs before ANY RCS Cold Leg temperature reaches 240°F.
	ATC BOP	 6. Verify Automatic Actions using Attachment F, AUTOMATIC SIGNAL VERIFICATION <u>Examiner Note:</u> See Attachment 1 for complete list of actions, ALL automatic actuations occur as expected in this step. 7. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes
	-	 MA ZL-3A MA ZL-4A MA ZL-2
	BOP	8. Check Total AFW Flow – GREATER THAN 270,000 LBM/HR – Yes

		9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37 RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and
		pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' on 'A' train ONLY.
Time	Position	Applicant's Actions or Behavior
	BOP	 <u>9.</u> Check RCS Cold Leg Temperatures: *Stable at or trending to 557°F for condenser steam dumps or S/G ARVs *Stable at or trending to a range of 553°F to 557°F for S/G ARVs if recovering from an inadvertent SI RNO Perform the following a. IF temperature is less than 557oF and decreasing, THEN perform the following: 1) Stop dumping steam 2) IF any MSIV is open, THEN close Main Turbine Stop And Control Valves Startup Drains o AC HIS-134 3) IF cooldown continues, THEN control feed flow to limit RCS cooldown. Maintain total feed flow greater than 270,000 lbm/hr until narrow range level greater than 6% [29%] in at least one S/G 4) IF cooldown continues due to excessive steam flow, THEN isolate main steamlines by depressing MS ISO VLV ALL CLOSE pushbutton(s) o AB HS-79 o AB HS-80 b. IF temperature is greater than 557oF and stable or increasing, THEN perform one of the following: *Dump steam to condenser *Reduce ARV setpoints to 1090 psig to control RCS C/L temperature less than or equal to 557°F
	BOP	 10. Establish S/G Pressure Control: a. Check condenser – AVAILABLE – No C-9 LIT MSIV – OPEN – No Circulating water pumps – RUNNING RNO a. Perform the following: 1) Use S/G ARVs 2) Go to Step 11
	ATC	 11. Check PZR PORVs a. Check PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A b. Power to block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B c. RCS pressure – LESS THAN 2185 PSIG – Yes

On-Teo	st No · Dec 2010	Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37		
operc	31 NO.: DCC 2010			
Event [Event Description: 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and			
MANUA	MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'			
S/G and	d SI will actuate of	on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior		
	ATC	 12. Check Normal PZR Spray Valves – CLOSED – Yes BB ZL-455B BB ZL-455C 		
	ATC	 13. Check PZR Safety Valves – CLOSED – Yes BB ZL-8010A BB ZL-8010B BB ZL-8010C 		
	1 1	NOTE		
Seal inj	ection flow shall b	e maintained to all RCPs		
	ATC/BOP	 14. Check if RCPs should be stopped: a. Check RCPs – ANY RUNNING – Yes b. Check RCS pressure – LESS THAN 1400 PSIG – No 		
	272	RNO a. Go to Step 15		
	CRS	15. Direct operator to Monitor Critical Safety Functions Using EMG F-0, CRITICAL SAFETY FUNCTION STATUS TREES (CSFST)		
	BOP	 16. Check if S/Gs are not Faulted: - No a. Check pressures in all S/Gs – NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER – No NO S/G COMPLETELY DEPRESSURIZED – No RNO a. Perform the following: 1) Ensure BIT Inlet and Outlet Valves are open – Yes EM HIS-8803A EM HIS-8803B 		
		 EM HIS-8801A EM HIS-8801B 2) Go to EMG E-2, FAULTED STEAM GENERATOR ISOLATION, Step 1 		
	EN	IG E-2, FAULTED STEAM GENERATOR ISOLATION		
		CAUTIONS		
o At le	east on S/G shall t	be maintained available for RCS cooldown		
	If you foully d 0/0 an exceedence has also been deal for D00 as aldown. If shall never in its lated			

Op-Tes	st No.: Dec 201	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37	
MANUA	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior	
Foldout	page shall be mo	NOTE onitored throughout this procedure	
	BOP	 1. Check Steamlines on all S/Gs – ISOLATED a. Ensure Main Steamline Isolation Valve(s) – CLOSED – Yes AB HIS-14 For S/G A AB HIS-17 For S/G B AB HIS-20 For S/G C AB HIS-11 For S/G D b. Ensure Main Steamline Isolation Bypass Valves – CLOSED – Yes AB ZL-15A for S/G A AB ZL-15A for S/G B AB ZL-21A for S/G C AB ZL-21A for S/G D c. Ensure Main Steamline Low Point Drain Valve(s) – CLOSED – Yes AB HIS-9 For S/G A AB HIS-9 For S/G B AB HIS-7 For S/G C AB HIS-10 For S/G D 	
	BOP	 Check if Limitations for Fault in Area 5 are Required: a. Check if steam is issuing from vent openings at 2000 foot elevation on south end of Turbine Building b. Warn local operators of adverse conditions in main steam enclosure c. Use S/G ARV pressure indicating controllers on RL006 for S/G pressure indication during subsequent recovery actions d. Use pressure and flow indications to determine valve position for valves located in the main steam enclosure e. Do not reset AFAS-TD until Turbine Driven AFW Pump shutdown is required f. Use manual initiation of AFAS-TD, as necessary, to restart Turbine Driven AFW Pump 	
Simulator Operator: WHEN contacted as the Turbine Building Watch, acknowledge request. Wait 2 minutes and report small amount of steam between the air compressors in the Turbine Building			

<u>Event [</u> MANU/	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37 <u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.		
Time	Position	Applicant's Actions or Behavior	
	BOP	3. Check if Any S/G is not Faulted – Yes a. Check pressure in all S/Gs: *ANY S/G PRESSURE STABLE <u>OR</u> *ANY S/G PRESSURE INCREASING	
	BOP	 4. Identify Faulted S/Gs: a. Check pressure in all S/Gs: *Check pressure in all S/Gs *ANY S/G PRESSURE DECREASING IN AN UNONTROLLED MANNER OR *ANY S/G COMPLETELY DEPRESURIZED 	
	<u>CAUTION</u> If the Turbine Driven AFW Pump is the only available source of feed flow, steam supply to the Turbine Driven AFW pump must be maintained from at least one S/G		
	BOP	 5. Isolate Faulted S/G(s) a. Close affected S/G(s) MD AFP Flow Control Valve(s) *AL HK-7A For S/G A b. Close affected S/G(s) TD AFWP Flow Control Valve(s) *AL HK-8A For S/G A c. Locally close steam supply to Turbine Driven AFW Pump from faulted S/G(s) d. Ensure S/G ARV on faulted S/G(s) – CLOSED *AB PIC-1A For S/G A e. Verify faulted S/G Main Steamline Isolation Valve - CLOSED CT2: Isolate feed flow into the Faulted 'A' S/G by closing AL HK-7A and AL HK-8A, AFW REG VLV CTRLs before ANY RCS Cold Leg temperature reaches 240°F. 	

Op-Tes	st No.: Dec 2019	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37	
-	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'		
		on 'A' train ONLY.	
Time	Position	Applicant's Actions or Behavior	
	BOP	 6. Verify Feedline Isolated on Faulted S/G(s) a. Main Feedwater Reg Valve – CLOSED *AE ZL-510 For S/G A b. Main Feedwater Reg Bypass Valve – CLOSED *AE ZL-550 For S/G A c. Main Feedwater Isolation Valve – CLOSED *AE HIS-39 For S/G A d. Main Feedwater Chemical Injection Valves – CLOSED *AE HIS-43 for A/G A 	
	BOP	 7. Verify Blowdown, Lower, and Upper sampling Isolated on Faulted S/Gs: a. S/G Blowdown Containment Isolation Valves – CLOSED *BM HIS-1A For S/G A b. S/G Upper Sample Isolation Valves – CLOSED *BM HIS-19 For S/G A c. S/G Lower Sample Isolation Valves – CLOSED *BM HIS-35 For S/G A 	
		CAUTION	
		because of high PZR pressure, the PORV shall be monitored to ensure it lecreases to less than 2335 psig	
	ATC	 <u>8.</u> Check PZR PORVs and Block Valves: a. Power to Block Valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B b. PZR PORVs – CLOSED** BB HIS-455A BB HIS-456A c. RCS Pressure – LESS THAN 2185 PSIG** RNO b. IF PZR pressure less than 2335 psig, THEN manually close PORV. IF any PORV can NOT be closed, THEN manually close its block valve c. IF PZR PORV is closed, THEN ensure associated block valve is open *BB HIS-8000A For BB HIS-456A 	
		**Examiner Note: Once the S/G dries out, pressure will rise and RCS pressure will be controlled on the PORVs until SI flow can be reduced and RCS pressure control regained	

Op-Te	st No.: Dec 2019	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37					
0010							
Event Description: 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and							
MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'							
S/G an	d SI will actuate	on 'A' train ONLY.					
Time	e Position Applicant's Actions or Behavior						
	9. Check if Uncontrolled Cooldown has Stopped: a. Check RCS Hot Leg Temperatures – STABLE OR INCREASING – Yes b. Perform the following to maintain stable RCS hot leg temperatures: Decrease ARV setpoints of intact S/Gs to stabilize intact S/G pressures *AB PIC-2A For S/G B *AB PIC-3A For S/G C *AB PIC-4A For S/G D Adjust AFW flow to intact S/Gs as necessary *AL HK-9A For S/G B *AL HK-11A For S/G C *AL HK-12A For S/G D *AL HK-5A For S/G D *AL HK-6A For S/G D *AL HK-6A For S/G D *AL HK-6A For S/G D *AL HK-5A For S/G D *AL HK-5A For S/G D *AL HK-6A For S/G D						
o lfof	 performing local surveys If offsite power is lost after SI reset, manual action may be required to restore safeguards equipment to the required configuration 						
10. Determine Secondary Radiation Levels: a. Direct Health Physics to survey steamlines in area 5 of Aux Bldg b. Check S/G Sampling – ISOLATED – Yes c. Ensure SI – RESET o SB HS-42A o SB HS-43A d. Check Instrument Air Pressure – GREATER THAN 105 PSIG – Yes o KA PI-40 e. Open CCW to Radwaste System Isolation Valves o EG HS-69 o EG HS-70 f. Open all S/G sample isolation valves o BM HIS-65 For S/G A o BM HIS-65 For S/G A o BM HIS-36 For S/G B o BM HIS-37 For S/G C o BM HIS-38 For S/G D o BM HIS-38 For S/G D o BM HIS-38 For S/G D							

Form ES-D-2

Op-Te	st No.: Dec 2019	9 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37						
Event Description: 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and								
MANU	MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A'							
S/G an	d SI will actuate	on 'A' train ONLY.						
Time	Position	Applicant's Actions or Behavior						
<u>Simula</u>	tor Operator: Wh	HEN contacted as HP and Chemistry, acknowledge requests						
		<u>NOTE</u>						
COMPF valve, c	RÉSSOR requires	3, ESW A TO AIR COMPRESSOR or EG HV-44, ESW B TO AIR the associated ESW train to be declared inoperable. Local opening of the END AUX BLDG, will preclude it from automatically isolating on a high flow						
	valve, on 2000' NORTH END AUX BLDG, will preclude it from automatically isolating on a high flow condition BOP 11. Verify Instrument Air Compressor is Running: a. Ensure at least one ESW TRN TO AIR COMPRESSOR Valve – OPEN – Yes *EF HIS-43 *EF HIS-44 b. Check AIR COMPRESSOR BRKR RESET switch associated with open ESW Valve(s) – CLOSED – No *KA HIS-3C *KA HIS-2C RNO b. Reset and close AIR COMPRESSIR BRKR RESET Switch *KA HIS-2C RNO b. Reset and close AIR COMPRESSIR BRKR RESET Switch *KA HIS-2C C. Check INST AIR PRESS – GREATER THAN 105 PSIG – Yes o KA PI-40 d. Check neither ESW TO AIR COMPRESSOR Valve – Locally Opened – No 0 EF HV-43 o EF HV-44 e. Check both ESW TRN TO AIR COMPRESSOR Valves – OPEN – Yes o KA HIS-3C • KA HIS-3C • KA HIS-3C • KA HIS-3C							

Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37							
MANUA	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.						
Time	me Position Applicant's Actions or Behavior						
	BOP	BOP 12. Check if S/G tubes are intact: - Yes a. Condenser Air Discharge – NORMAL BEFORE ISOLATION o GEG 925 b. S/G Blowdown and Sample Radiation – NORMAL BEFORE ISOLATION o BML 256 o o SJL 026 c. Turbine Driven Auxiliary Feedwater Pump Exhaust Radiation – NORMAL o o FCT 381 d. S/G Steamline Radiation Monitors – NORMAL o ABS 114 For S/G A o ABS 113 For S/G B o ABS 111 For S/G D o Local Surveys e. S/G levels – NO LEVEL INCREASING IN AN UNCONTROLLED MANNER					
	ATC 13. Check if Containment Spray should be stopped: a. Check Spray Pumps – ANY RUNNING – No RNO a. Go to Step 14						
	14. Check if ECCS Flow should be reduced: - Yes a. RCS Subcooling – GREATER THAN 30°F [45°F] b. Secondary heat sink: *Total Feed Flow to intact S/Gs – GREATER THAN 270,000 LBM/HR OR *Narrow Range Level in at least one intact S/G – GREATER THAN 6% [29%] c. RCS Pressure – STABLE OR INCREASING d. PZR Level – GREATER THAN 6% [32%] e. Go to EMG ES-03, SI TERMINATION, Step 1						
	EMG ES-03, SI TERMINATION						
<u>CAUTION:</u> If offsite power is lost after SI reset, manual action may be required to restore safeguards equipment to the required configuration							

Op-Tes	st No.: Dec 2019	ØScenario No.: 2Event No.: 6/7/8/9Total No Pages 37						
<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.								
Time	Time Position Applicant's Actions or Behavior							
		<u>NOTES:</u>						
o Fol	dout page shall b	e monitored throughout this procedure						
o RW	ST switchover SI	signal shall not be reset until SI flow has been terminated						
	ATC	1. Reset SI: o SB HS-42A o SB HS-43A						
	ATC 2. Reset Containment Isolation Phase A and Phase B: SB HS-56 For Phase A SB HS-53 For Phase A SB HS-55 For Phase B SB HS-52 For Phase B							
	BOP	3. Verify Instrument Air Compressor Is Running: (Previously completed)						
	BOP 4. Verify Instrument Air To Containment: a. Check PZR PRESS MASTER CTRL Output – LESS THAN 55% o BB PK-455A							
	 RNO Perform the following: Place PZR PRESS MASTER CTRL in manual. Set PZR PRESS MASTER CTRL to less than 55% output signal. <u>WHEN</u> instrument air has been established to containment <u>AND</u> pressurizer pressure control is established, <u>THEN</u> place PZR PRESS MASTER CTRL in automatic. Open INST AIR SPLY CTMT ISO VLV. KA HIS-29 							
	ATC 5. Reduce Charging Flow: a. Check Shutdown Sequencers – NOT ACTUATED o Annunciator 00-018C, NF039A S/D SEQ ACTUATED – CLEAR Annunciator 00-021C, NF039B S/D SEQ ACTUATED – CLEAR b. Stop all but one CCP and place in standby. * BG HIS-1A OR * BG HIS-2A (Discharge valve open to charging header)							

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37							
MANUA	<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.							
Time	Position	Applicant's Actions or Behavior						
	ATC	 6. Check If NCP Should Be Stopped: a. CCPs – ANY RUNNING – Yes b. Stop NCP o BG HIS-3 (Stopped in EMG E-0, ATT F) 						
	ATC	7. Check RCS Pressure – Stable or Rising - Yes						
	BOP	 8. Verify CCW To Service Loop: a. Ensure CCW Pumps – AT LEAST ONE RUNNING – Yes b. Ensure One Pair of CCW Service Loop Supply and Return Valves for an Operating CCW Pump – OPEN EG ZL-15 AND EG ZL-53 OR EG ZL-16 AND EG ZL-54. c. Open CCW To Radwaste System Isolation Valves. EG HS-69 EG HS-70 						
	BOP	 9. Verify CCW to Containment a. Check CCW To RCS Flow – LESS THAN 1.25x10⁶ LBM/HR – No o EG FI-128 o EG FI-129 RNO Go To Step 10 						
	BOP	 10. Verify RCP Thermal Barrier Cooling: a. Check ANY of the following annunciators – IN ALARM: - No 00-070C, RCP A THRM BAR CCW FLOW 00-071C, RCP B THRM BAR CCW FLOW 00-072C, RCP C THRM BAR CCW FLOW 00-073C, RCP D THRM BAR CCW FLOW RNO Go To Step 11 						

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 2 Event No.: 6/7/8/9 Total No Pages 37						
<u>Event Description:</u> 'D' RCP spuriously trips and the Reactor fails to trip in BOTH AUTO and MANUAL. 'A' MDAFW pumps fails to auto start. Three S/G Safety Valves will fail to open on 'A' S/G and SI will actuate on 'A' train ONLY.							
Time	Position	Applicant's Actions or Behavior					
	ATC	 11. Align CCPs For Normal Charging a. Check CCPs – AT LEAST ONE RUNNING – YES * BG HIS-1A * BG HIS-2A b. Check CCP Discharge To Charging Header Isolation Valve For Running CCP – OPEN * BG-8483A For CCP A (1974' AUX BLDG, CCP A ROOM) - No * BG-8483C For CCP B (1974' AUX BLDG, CCP B ROOM) - OPEN c. Reset CCP Recirc Valves. o BG HS-8110 o BG HS-8111 d. Open CCP Recirc Valves. o BG HIS-8111 12. Align Charging System: a. Throttle CCP Discharge Flow Control valve to 7% open o BG FK-121 b. Close Charging Header Back Pressure Control Valve. o BG HC-182 c. Open Charging Pumps To Regenerative Heat Exchanger Containment Isolation valves. o BG HIS-8106 d. Align Regenerative Heat Exchanger To Loop Cold Leg valves, to establish only one open. o BG HIS-8147 For Loop 4. 					
and/or a	ATC 13. Isolate BIT: a. Close BIT Inlet Valves • EM HIS-8803A • EM HIS-8803B • EM HIS-8803B b. Close BIT Outlet Valves • EM HIS-8801A • EM HIS-8801B • EM HIS-8801B CT3: Isolate high head ECCS flow through the BIT before overfill of the RCS results in a rupturing of the pressurizer relief tank (PRT) at 91 psig. Scenario Termination: After the crew has isolated 'A' S/G and isolated ECCS flow through the BIT and/or at the direction of the Lead Examiner terminate the scenario Simulator Operator: FREEZE						

ATTACHMENT 1

Revision: 41A			EMG E-0		
Continuous Use		REACTOR TRIP OR	R SAFETY INJECTION Page 79 of 103		
STEP	ACTION/	EXPECTED RESPONSE	RESPONSE NOT OBTAINED		
ATTACHMENT F (Page 1 of 13) AUTOMATIC SIGNAL VERIFICATION F1. Check AC Emergency Busses -					
	ENERGIZE				
	o NB01 -	ENERGIZED	o Depress START/RESET pushbutton for EDG A.		
			o KJ HS-8A		
	o NB02 -	ENERGIZED	o Depress START/RESET pushbutton for EDG B.		
			o KJ HS-108A		

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 81 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED						
	ATTACHMENT F (Page 2 of 13) AUTOMATIC SIGNAL VERIFICATION							
F2.	Verify Feedwater Isolation:							
	a. Main feedwater pumps - TRIPPED	a. Manually trip Main Feedwater Pumps.						
	o Annunciator 00-120A, MFP A TRIP - LIT o Annunciator 00-123A, MFP B TRIP - LIT	tripped, <u>THEN</u> depress						
		o FC HS-18A For MFWP A o FC HS-18B For MFWP A						
		o <u>IF</u> MFWP B is <u>NOT</u> tripped, <u>THEN</u> depress the following:						
		o FC HS-118A For MFWP B o FC HS-118B For MFWP B						
	b. Main feedwater reg valves - CLOSED	<pre>b. Manually close valves. * AE FK-510 for S/G A</pre>						
	o AE ZL-510 for S/G A o AE ZL-520 for S/G B o AE ZL-530 for S/G C o AE ZL-540 for S/G D	* AE FK-510 for S/G A * AE FK-520 for S/G B * AE FK-530 for S/G C * AE FK-540 for S/G D						
	c. Main feedwater reg bypass valves - CLOSED	c. Manually close valves.						
	o AE ZL-550 for S/G A o AE ZL-560 for S/G B o AE ZL-570 for S/G C o AE ZL-580 for S/G D	* AE LK-550 for S/G A * AE LK-560 for S/G B * AE LK-570 for S/G C * AE LK-580 for S/G D						
	d. Main feedwater isolation valves - CLOSED	_						
	o AE HIS-39 for S/G A o AE HIS-40 for S/G B o AE HIS-41 for S/G C o AE HIS-42 for S/G D	 Manually close valves. <u>IF</u> valves can <u>NOT</u> be closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MFIV sub-racks: o ALS-411-1 o ALS-411-2 						

(Step F2. continued on next page)

Revision: 41A	EMG E-0							
Continuous Use	REACTOR TRIP OR SAFETY INJECTION Page 83 of 103							
STEP ACTION	EXPECTED RESPONSE RESPONSE NOT OBTAINED							
Step F2. (cont	ATTACHMENT F (Page 3 of 13) AUTOMATIC SIGNAL VERIFICATION							
e. Main injec o AE o AE o AE	<pre>feedwater chemical tion valves - CLOSED</pre> e. Perform the following: 1) Manually close valve. 1) Manually close valve. 1) Manually close valve. 1) Manually close valve. 2) <u>IF</u> valve can <u>NOT</u> be closed, <u>THEN</u> locally isolate affected feedline. * AE-V129 for S/G A (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V128 for S/G B (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V131 for S/G C (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V130 for S/G D (STEAM ENCLOSURE ROOM							
SGBSI LIGHT o Red	SOUTH OF MFIV) ESFAS status panel S section - ALL WHITE S LIT train low train Suttow train							

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 85 of 103

STEP	ACTION/EXPECTED RESPONSE		RESPONSE NOT OBTAINED				
ATTACHMENT F (Page 4 of 13) AUTOMATIC SIGNAL VERIFICATION							
F3.	Verify Containment Isolation Phase A:						
	 a. Check ESFAS status panel CISA section - ALL WHITE LIGHTS LIT o Red train o Yellow train 	a.	 Perform the following: 1) <u>IF</u> containment isolation phase A has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment isolation phase A. 0 SB HS-47 o SB HS-48 2) <u>IF</u> any CISA valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT B, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE A. 				

Revision: 41A	REACTOR TRIP OR SAFET	EMG E-0
Continuous Use	REACIOR IRIP OR SAFE	Page 87 of 103
STEP ACTION	/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 5 of 1 AUTOMATIC SIGNAL VE	13)
F4. Verify A	FW Pumps Running:	
	motor driven AFW - BOTH RUNNING	a. Manually start pumps. o AL HIS-22A o AL HIS-23A
b. Check	turbine driven AFW	b. Perform the following:
	- RUNNING	 Check if turbine driven AFW pump should be running:
		* At least 2/4 S/G narrow range level channels on 2/4 S/Gs - LESS THAN 23.5%
		OR
		* Loss of NB01 voltage has occurred
		OR
		* Loss of NB02 voltage has occurred
		OR
		* AMSAC actuation
		2) <u>IF</u> turbine driven AFW pump should be running, <u>THEN</u> manually open steam supply valves:
		a) AB HIS-5A
		b) AB HIS-6A
		c) FC HIS-312A

Revision: 41A		41A	EMG E-(EMG E-0		
Continuous Use		s Use					Page 89 of 103	
STEP	ACTION/EXPECTED RESPONSE			$\left - \right $		RESPONSE NOT	OBTAINED	
ATTACHMENT F (Page 6 of 13) AUTOMATIC SIGNAL VERIFICATION								
F5.	F5. Verify ECCS Pumps Running:							
	a.	Check	CCPs - BOTH RUNNING		a. Manually start pumps.			
						o BG HIS-1A o BG HIS-2A		
	b.		SI pumps - BOTH		b. Manually start pumps.			
	RUNNI		NG			o EM HIS-4 o EM HIS-5		
	с.		RHR pumps - BOTH		с.	Manually sta	rt pumps.	
	RUNNING				o EJ HIS-1 o EJ HIS-2			
F6.	Verify CCW Alignment:							
	a.		CCW pumps - ONE NG IN EACH TRAIN		a.		rt CCW pumps to establish in each train.	
						<pre>o EG HIS-21 for red tr o EG HIS-22 for yellow</pre>	ain or EG HIS-24	
	b.	servi Retur:	one pair of CCW ce loop Supply And n Valves for an ting CCW pump - OPEN		b.	Manually ali necessary to flow to serv containment.	establish CCW ice loop and	
		* EG	ZL-15 AND EG ZL-53					
		OR						
		* EG	ZL-16 AND EG ZL-54					
F7.		eck ESW Pumps - BOTH			Manually start pumps.			
	RUNNING					EF HIS-55A EF HIS-56A		

Revision: 41A	ion: 41A REACTOR TRIP OR SAFETY INJECTION						
Continuous Use	REACTOR TRIP OR SAFET	Page 91 of 103					
STEP ACTION	EXPECTED RESPONSE	RESPONSE NOT OBTAINED					
ATTACHMENT F (Page 7 of 13) AUTOMATIC SIGNAL VERIFICATION							
	ntainment Fan Coolers G IN SLOW SPEED	Perform the following for each Containment Cooler Fan that is still running in Fast or is not running:					
		a. Manually stop ANY Containment Cooler Fans running in fast.					
		* GN HIS-5 For Cooler 1A					
		* GN HIS-9 For Cooler 1B					
		* GN HIS-13 For Cooler 1C					
		* GN HIS-17 For Cooler 1D					
		b. Place Containment Cooler Fan Speed Selector switches in Slow.					
		* GN HS-5 for cooler 1A					
		* GN HS-9 for cooler 1B					
		* GN HS-13 for cooler 1C					
		* GN HS-17 for cooler 1D					
		c. Manually start containment cooler fans.					
		* GN HIS-5 for cooler 1A					
		* GN HIS-9 for cooler 1B					
		* GN HIS-13 for cooler 1C					
		* GN HIS-17 for cooler 1D					

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 93 of 103

STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED ATTACHMENT F (Page 8 of 13) AUTOMATIC SIGNAL VERIFICATION F9. Verify Containment Purge Isolation: a. Perform the following: a. Check ESFAS status panel CPIS section - ALL WHITE LIGHTS LIT 1) <u>IF</u> containment purge isolation has NOT o Red train actuated, THEN manually o Yellow train actuate containment purge isolation. o SA HS-11 o SA HS-15 2) IF any CPIS component NOT properly aligned, THEN manually align component. 3) IF component(s) can NOT be manually aligned, THEN locally isolate instrument air to affected containment penetration. Refer to ATTACHMENT C, VALVES CLOSED BY CONTAINMENT PURGE ISOLATION SIGNAL.

Revision: 41AEMG E-0Continuous UseREACTOR TRIP OR SAFETY INJECTIONPage 95 of 1				
	evision: 41A	REACTOR TRIP OR SA		- 0
	ontinuous Use			103
STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED	TEP ACTION	I/EXPECTED RESPONSE	RESPONSE NOT OBTAINED	
ATTACHMENT F (Page 9 of 13) AUTOMATIC SIGNAL VERIFICATION F10. Verify Both Trains Of Control		(Page 9 c AUTOMATIC SIGNAL Both Trains Of Control	of 13) L VERIFICATION	
Room Ventilation Isolation: a. Check ESFAS status panel CRVIS section - ALL WHITE LIGHTS LIT o Red train o Yellow train a. Perform the following: b. Red train o Yellow train a. Perform the following: a. Perform the following: a. Perform the following: b. Red train o Yellow train a. Perform the following: b. Red train o Yellow train b. Red train o Yellow train c. Yellow train c. Yellow train c. Yellow train c. Yellow train b. Yellow train c. SA HS-9 o SA HS-13 c. J. JF any CRVIS componen NOT properly aligned, THEN manually align associated component. c. J. JF neither train of CRVIS is in service, THEN establish one in service train of CRVI using SYS GK-122, MANUAL CRVIS LINE-UP. 4) IF only one train of CRVIS LINE-UP. 4) IF only one train of SYS GK-122, MANUAL CRVIS LINE-UP.	a. Check CRVI LIGH o Red	k ESFAS status panel S section - ALL WHITE IS LIT d train	 <u>IF</u> control room ventilation isolati has <u>NOT</u> actuated, <u>I</u> manually actuate control room ventilation isolati o SA HS-9 o SA HS-13 <u>IF</u> any CRVIS comport <u>NOT</u> properly aligned <u>THEN</u> manually align associated componer <u>IF</u> neither train of CRVIS is in service <u>THEN</u> establish one service train of CF using SYS GK-122, MANUAL CRVIS LINE-U <u>IF</u> only one train of CRVIS can be placed service, <u>THEN</u> withi minutes (76.5 minut control room and 13 minutes local operator), isolate of service train us SYS GK-122, MANUAL 	on THEN On. on. ent ed, in VIS JP. of in n 90 ces 3.5 out

door - CLOSED

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 97 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMEN (Page 10 o AUTOMATIC SIGNAL	of 13)
F11.		Verify steamline isolation:
	a. Check containment pressure - HAS REMAINED LESS THAN 17 PSIG	 If any main steamline isolation valve is <u>NOT</u> closed, <u>THEN</u> perform the following:
	0 GN PR-934	a) Close main steamline isolation valves.
	 b. Check either condition below - SATISFIED: * Low steamline pressure SI - NOT BLOCKED <u>AND</u> steamline pressure - HAS REMAINED GREATER THAN 615 PSIG <u>OR</u> * Low steamline pressure SI - BLOCKED <u>AND</u> steamline pressure rate - HAS REMAINED LESS THAN 100 PSI/50 SEC 	<pre>isolation valves. * AB HS-79 * AB HS-80 b) IF any MSIV is still <u>NOT</u> closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MSIV sub-rack: 0 ALS-411-1 0 ALS-411-2 2. Check ESFAS status panel SLIS section - ALL WHITE LIGHTS LIT 0 Red Train 0 Yellow Train</pre>
		3. <u>IF</u> any SLIS valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected steamline. Refer to ATTACHMENT D, VALVES CLOSED BY STEAMLINE ISOLATION SIGNAL.

Rev	is	ion	:	41A

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 99 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHME (Page 11 c AUTOMATIC SIGNAL	of 13)
F <u>12.</u>	Verify Containment Spray Not	Perform the following:
	Required:	1. Stop all RCPs.
	 a. Containment pressure - HAS REMAINED LESS THAN 27 PSIG: o Annunciator 00-059A, CSAS - NOT LIT 	 <u>IF</u> containment spray has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment spray.
	o Annunciator 00-059B, CISB - NOT LIT o GN PR-934	o SB HS-43 <u>AND</u> SB HS-45 o SB HS-44 <u>AND</u> SB HS-46
		3. Check ESFAS status panel CSAS section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		 <u>IF</u> any CSAS component <u>NOT</u> properly aligned, <u>THEN</u> manually align associated component.
		5. Check ESFAS status panel CISB section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		6. <u>IF</u> any CISB valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT E, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE B.

Revisi	Revision: 41A EMG E-0								
Contin	uous Use				ge 101 of 103				
STEP	ACTION	/EXPECTED RESPONSE		RESPONSE NOT OF	BTAINED				
	ATTACHMENT F (Page 12 of 13) AUTOMATIC SIGNAL VERIFICATION								
F13.	Verify E	CCS Flow:							
	Pumps Tank INDIC o EM	Centrifugal Charging To Boron Injection Flow meters - FLOW ATED FI-917A FI-917B	a.	1) <u>IF</u> BIT valv	res have <u>NOT</u> by operator <u>N</u> manually and align res are perator				
		RCS pressure - LESS 1725 PSIG	b.	Go to Step F14					
	Flow INDIC	SI Pump Discharge meters - FLOW ATED FI-918	c.	Manually start align valves.	pumps and				
		FI-922							
		RCS pressure - LESS 325 PSIG	d.	Go to Step F14					
	Injec	RHR TO Accumulator tion Loop Flow meters W INDICATED	e.	Manually start align valves.	pumps and				
		FI-618 FI-619							
F14.	Verify A ALIGNED:	FW Valves - PROPERLY	NO	any AFAS secti <u>I</u> properly alig	ned, <u>THEN</u>				
		ESFAS status panel section - ALL WHITE S LIT	CO	sociated blish up.					
	statu	white train ESFAS s panel AFAS section WHITE LIGHTS LIT							

Revi	si	on:	41A
		O 11 •	I I

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 103 of 103

CONCIN	uous ose	rage 105 OI 105
STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 13 of AUTOMATIC SIGNAL VI	13)
F15.	Verify SI Valves - PROPERLY ALIGNED:	<u>IF</u> any SIS section component <u>NOT</u> properly aligned, <u>THEN</u>
	a. Check ESFAS status panel SIS section - SYSTEM LEVEL WHITE LIGHTS ALL LIT	manually align associated component to establish proper SIS lineup.
	o Red train o Yellow train	
F16.	Check If NCP Should Be Stopped:	
	a. CCPs - ANY RUNNING	a. Go to Step F17
	b. Stop NCP	
	o BG HIS-3	
F17.	Check FBIS Is <u>NOT</u> ACTUATED:	Perform the following:
	o Annunciator 00-062D, FBIS - <u>NOT</u> LIT	a. Ensure NO movement of irradiated fuel assemblies in the fuel building.
		b. Bypass GG RE-27 and GG RE-28.
		c. Reset FBIS:
		o sa hs-10
		o SA HS-14
		d. Ensure FUEL BLD EMERG EXH DAMPERS are closed:
		o GG HIS-40
		o GG HIS-43
F18.	Return To Procedure And Step In Effect	
	-END-	

Revision: 50 Continuous Use

REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION

SYS BG-200

Page 25 of 28

INIT/DATE

 \square

 \square

 \square

 \square

 \square

ATTACHMENT B (Page 1 of 2)

Boration For Temperature Adjustment In Mode 1 And 2

CAUTION

Borations of less than 1 gallon shall NOT be performed due to system limitations. Refer to Precautions/Limitations Step 4.13.

NOTE

A licensed operator shall peer check reactivity manipulations.

B.1 SETUP to borate the RCS:

- B.1.1 (p) <u>IF</u> required to ensure RCS and Pressurizer Boron Concentrations are within 50 ppm, <u>THEN</u> TURN on PZR HTR B/U GROUP A and/or PZR HTR B/U GROUP B , using SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS, to mix Reactor Coolant System with Pressurizer water. [3.2.1]
- B.1.2 BG HS-26 to Normal-After-Stop.
- B.1.3 BG HS-25 to BOR.

B.1.4 BG FK-110 in Auto at desired rate.

CAUTION

BG FY-110B, BA COUNTER can be set in tenth of a gallon increments.

B.1.5 BG FY-110B, BA COUNTER, set to obtain desired gallons.

B.2 COMMENCE boration:

B.2.1 (ρ) BG HS-26 to Normal-After-Run.

B.2.2 VERIFY:

1. One BORIC ACID TRANSFER PUMP running.

2. BG HIS-110B open.

REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION

SYS BG-200

Page 26 of 28

	ATTACHMENT B	INIT/DATE
	(Page 2 of 2)	
	Boration For Temperature Adjustment In Mode 1 And 2	
	3. BG HIS-110A throttles open.	
	4. BG FR-110 boric acid flow at proper flowrate.	
в.3	ENSURE boration stops at BG FY-110B setpoint.	
	NOTE	
Pre	essurizer Backup Heaters are normally placed in auto.	
в.4	IF PZR HTR B/U GROUP A and/or PZR HTR B/U GROUP B were turned on in Step B.1.1, THEN PLACE PZR HTR B/U GROUP A & B in desired position, after sufficient time for mixing has elapsed, using SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS.	
в.5	REALIGN for auto operation:	
	B.5.1 BG HS-26 to Normal-After-Stop.	
	B.5.2 BG HS-25 to Auto.	
	B.5.3 BG FK-110 set for Auto makeup.	
	B.5.4 BG HS-26 to Normal-After-Run.	
	B.5.5 <u>IF</u> desired, <u>THEN</u> PERFORM ATTACHMENT C, Boric Acid Potentiometer Adjustment.	
	-END-	

Appendix D

Scenario Outline

Form ES-D-1

Facility:	_Wolf Cree	ek Sce	nario No.:	3	Op-Test N	o.: <u>Dec</u>	cember 2	201 <u>9</u>
Examine	ers:		Ор	erators:				
Initial Co	Initial Conditions: 59% Power, MOL, Yellow Train In Service, Benton Line is out of service.							
		s operating at 59%						
removed	from servi	ce yesterday to rep	<u>place multiple (</u>	amaged poles e		return	tomorro	<u>N.</u>
		1 ALL CLOSE MS G, Isolate Feed flor						
EMG E-2	2, or EMG (C-31. CT-3 Comm	ence controlle	d RCS depressu				
		o overfilling the Ru	iptured 'C' S/G					
Event No.	Malf. No.	Event Type*			Event scription			
4		С		ater Pump Trips,		Vater P	ump fail	s to
1		(All)		urbine Runback C, OFN MA-001				
2		I (ATC/CRS)		oop 2 TC Instrur	ment chann	el fails	LOW	
2		Tech Specs	OFN SB-008 LCO 3.3.1, F	Functions 6 and 7	7, Condition	is A, E		
3		C (ATC/CRS)	BG TCV-130 ALR 00-039) fails closed in A B/A	Nuto			
4		l í	AE PT-508,	Feed Header Pre				
		(BOP/CRS) C	OFN SB-008 'C' S/G Tube	B, ATTB ELeak, 50 gpm				on Even
5		(ALL)	OFN BB-07A	4	4, and	IOST E	vent 5	
0		Tech Specs M	LCO 3.4.13, "C' S/G Tube	e leak grows to 4	00 gpm SG	TR		
6		(ALL)	EMG E-0, EI	MG E-3				
7		C (BOP/CRS)		to trip in both Au h Button Works.	ito and Mar	iuai, ivi	SIV ALL	
		C	EMG E-0, St		lagatar Trip	Class	o Monuc	
8		(BOP/CRS)	AP 15C-003	ns to 100% on R , EMG E-3, Step		, Close	s Manua	iiiy
*	(N)ormal, ((R)eactivity, (I)nstr	ument, (C)omp	oonent, (M)ajor				
Targ		ve Attributes per Scer Section D.5.d)	nario (See	Actual Attributes	ES-301-5	CRS	ATC	BOP
1. Ma	Ifunctions afte	er EOP entry (1–2)		2	Rx	0	0	0
2. Ab	normal events	\$ (2-4)		5	Nor	0	0	0
3. Major transients (1–2)			1	I/C	7	4	5	
4. EC	Ps entered/re	equiring substantive act	ions (1–2)	1	Maj	1	1	1
	5. Entry into a contingency EOP with substantive actions $\begin{pmatrix} 0 \\ \geq 1 \end{pmatrix}$ TS $\begin{pmatrix} 2 \\ 0 \end{pmatrix}$ $\begin{pmatrix} 0 \\ 0 \end{pmatrix}$				0			
 Preidentified critical tasks (≥ 2) 			3					

ILO 2019, NRC Operating Exam, Scenario 3, Rev 4

Appendix D

Scenario Outline

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT1 Manually ALL CLOSE main steamline isolation valves before a severe (orange- path) challenge develops to either the subcriticality (Positive IR SUR) or the integrity CSF (RCS Cold Leg Temperature <240°F)	Failure to isolate steam to the turbine given failure of auto and manual turbine trips will cause an unnecessary uncontrolled cooldown and avoidable challenges to the subcriticality and Integrity CSFs due only to lack of proper response by the crew.	Main Stop valves remain open despite reactor trip, and manual turbine trip.	On Panel RL- 006 Manipulates either of the following handswitches: * AB HS-78 * AB HS-80	Green lights LIT on AB HIS-14 AB HIS-17 AB HIS-20 AB HIS-20 AB HIS-11 Indicated steam flow will drop to 0 MPPH on all four S/Gs.
CT2 Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to * RCS Subcooling <30°F, * PZR Level <6% or * Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, ARV *AB HIS-20, MSIV *AL HK-11A MD AFW REG VLV CTRL *AL HK-12A TD AFW REG VLV CTRL *AB V087 TDAFW Steam Supply from C S/G * AB-V082, C S/G Low Point Drain	Feedwater is isolated to prevent overfill of ruptured S/G. Steam flow out of S/G is isolated to minimized radiological release. It also maintains ruptured S/G pressure higher than non-ruptured, which prevents transition from E-3, the preferred procedure, to C-31, which will release radiation to the public.	Radiation Monitor alarms, S/G levels and S/G pressures make it possible to identify S/G 'C' as ruptured.	Manipulate controls as required to: * Close AB PIC-3A, ARV * Close AB HIS-20, MSIV * Close AL HK- 11A and 12A, AFW REG VLVL CTRLS Dispatch Operator to close * AB V087 TDAFW Steam Supply * AB-V082, Low Point Drain	Green light on *AB HIS-20 0% output: *AL HK-12A *AL HK-11A *AB PIC-3A Report from Local Operator that valves are closed: *AB V-087 *AB V-082

Appendix D

Scenario Outline

Form ES-D-1

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT3: Commence controlled RCS depressurization to allow for SI termination per EMG E-3 prior to overfilling the ruptured 'C' S/G (90% WR).	Depressurizing the RCS to equalize with Ruptured S/G pressure prior to overfilling the ruptured S/G minimizes radioactive release to the environment from the ruptured S/G, minimizes stress to the Main Steam Lines, and allows for a subcooled recovery vice a potential saturated recovery.	S/G Level rising in an uncontrolled manner with feed flow isolated. Radiation monitor alarms	Manipulation of Normal Spray controls as required to depressurize the RCS. *BB PK-455A, PZR PRESS MASTER CTRL	RCS Pressure reducing in a controlled manner, subcooling maintained, leak rate to ruptured S/G drops, PZR Level >6%, Ruptured S/G Level <90% WR.

Note: Causing an unnecessary plant trip or ESF actuation may constitute a Critical Task failure. Actions taken by the applicant(s) will be validated using the methodology for critical tasks in Appendix D to NUREG-1021.

SCENARIO #3 NARRATIVE

Turnover: The Unit is operating at 59% power. Yellow Train is in service. Benton Line was removed from service yesterday to replace multiple damaged poles expected to return tomorrow

Event 1: 'B' Stator Water Pump Trips and 'A' Stator Water Pump fails to Auto start. An automatic runback of the turbine will occur. The crew will address the runback per ALR 0112C and/or OFN MA-001. Once the crew has started 'A' Stator Water Pump, and stabilized plant conditions, the next event will start at the direction of the Lead Examiner.

Event 2: Loop 2 TC instrument, BB TI-421) Fails LOW. There is no automatic plant response due to the channel failure in the low direction. Multiple MCB Annunciators will actuate, including 067D, LOOP 2 T AVG LO DEV which will help the crew diagnose which instrument failed. The crew will address the instrument failure using OFN SB-008, ATT L. Once the crew has evaluated technical specifications, the next event will start at the direction of the Lead Examiner.

Event 3: BG TCV-130 fails CLOSED in Auto. Annunciators 039B, LTDN HX DISCH TEMP HI will actuate and depending on timeliness of the crew response, Annunciator 039A may also alarm indicating letdown demineralizers have been bypassed due to high temperature. The crew will perform ALR 039B and/or 039A actions. Once crew has taken manual control of BG TCV-130 with letdown heat exchanger outlet temperature lowering, the next event will commence at the direction of the Lead Examiner.

Event 4: AE PT-508, Feed water header pressure channel fails LOW. In response to rising MFP speed, rising feed water flow and rising S/G levels, the BOP should take manual control of MFP TURBS MASTER SPEED CTRL and refer to the posted figure for programmed feedwater ΔP to manually control feedwater flow as a Memory Action. The crew will address the instrument failure per OFN SB-008, ATT B. The next event will start at the direction of the Lead Examiner.

Event 5: 'C' S/G Tube Leak. Annunciator 062A will actuate for Process Radiation levels at the ALERT level. When the crew investigates which PRM is alarming they will diagnose the S/G tube leak and enter OFN BB-07A. When S/G Tube leakage exceeds 150 gpd, the CRS will enter LCO 3.4.13, COND B.

Event 6: 'C'' S/G Tube Leak grows to 400 gpm SGTR. As the leak size grows, the crew will maximize charging, isolate letdown and Trip the Reactor and Actuate SI per foldout page direction. The next two post-trip events will also be addressed by the crew.

Event 7: Main Turbine fails to auto trip and will not trip using manual push buttons. While performing immediate actions, the BOP will note the turbine failed to trip and attempt to trip the turbine manually using the two pushbuttons. When that is unsuccessful, the BOP will use the ALL CLOSE push buttons to close MSIVs to isolate steam to the main turbine.

CT1: Manually ALL CLOSE main steamline isolation valves before a severe (orange-path) challenge develops to either the subcriticality (Positive IR SUR) or the integrity CSF (RCS Cold Leg Temperature <240°F

Appendix D

Scenario Outline

Event 8: Ruptured S/G 'C' ARV opens to 100% on Reactor Trip: The crew will identify high steam flow rate for 'C' S/G and/or open indication on 'C' ARV and the BOP will manually close the valve.

CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, ARV

*AB HIS-20, MSIV *AL HK-11A MD AFW REG VLV CTRL *AL HK-12A TD AFW REG VLVL CTRL *AB V087 TDAFW Steam Supply from C S/G *AB-V082, C S/G Low Point Drain

The crew will transition to EMG E-3 to isolate 'C' S/G and cool down and depressurize the RCS to meet SI Termination criteria to minimize break flow though 'C' S/G tube rupture.

CT3: Commence controlled RCS depressurization to allow for SI termination per EMG E-3 prior to overfilling the ruptured 'C' S/G (90% WR).

The scenario is complete when the crew has depressurized the RCS per EMG E-3 Step 25 and/or at the discretion of the Lead Examiner.

Appendix D

Scenario Outline

SIMULATOR SCENARIO FILES

;2019 ILO NRC Exam, Scenario 3 (IC 103)

;Initial Conditions - IC32,59%, Benton Line out, PZR heaters in auto, rods in auto IMF mSY03F

;Event 1 – Key 1 - 'B' Stator Water Pump Trips, 'A' Stator Water Pump Fails to Auto Start (Reactivity) ICM bkrDPCE01B.cmf t:1 k:1 ICM swCEPS0001.cmf t:1 k:1 ICM swCEPS0002.cmf t:1 k:1

;Event 2 – Key 2 – Failure of Loop 2 TC, BB TI-421 Fails LOW (ATC/CRS-TS) ICM trBBTE0421B.cmf t:3 k:2 f:510

;Event 3 – Key 3 – BG TCV-130 fails closed in auto (ATC/CRS) ICM cdBGTC-130.cmf t:5 k:3 f:0

;Event 4 – Key 4 - AE PT-508 fails LOW (BOP/CRS) ICM trAEPT0508.cmf t:1 k:4

;Event 5 – Key 5 – Steam Generator Tube Leak on 'C' S/G (BOP/ATC/CRS-TS) IMF mBB02C f:50 r:180 k:5

Event 6 – Key 6 – Steam Generator Tube Leak becomes a rupture {Key[6]} IMF mBB02C f:400

;Event 7 – Turbine fails to Trip in both Auto and Manual, MSIVs fail to Auto Close. (BOP-CT) IMF mAC02A IMF mAC02B IMF mSA27AB01 IMF mSA27AB02 IMF mSA27AB03 IMF mSA27AB04

;Event 8 – 'C' ARV fails to 100% open on plant trip in auto, manually closes. (BOP-CT) {jpplp4} ICM cntABPIC0003A t:1 f:100

;Local Action – **Key 9** – Close AB-V087 IRF rAB04B k:9 r:60 f:0

;Local Action – **Key 10** – Close AB-V082 IRF rAB03C k:10 r:60 f:0

; End

Scenario Outline

Booth Instructions

Ensure NRC Exam Security Established per AIF 30B-015-09, and AIF 30B-015-18

Ensure the following procedures are available, free of markings and are the most recent revision in Curator (10/31/19):

- □ ALR 00-039A, LTDN HX TEMP HI DIVERT (Rev 11)
- □ ALR 00-039B, LTDN HX DISCH TEMP HI (Rev 8)
- □ ALR 00-112C, AUTO TURB R/B ACT (Rev 9A)
- OFN MA-001, LOAD REJECTION OR TURBINE TRIP (Rev 25)
- OFN BB-07A, STEAM GENERATOR TUBE LEAKAGE (Rev 22)
- □ OFN SB-008, INSTRUMENT MALFUNCTIONS (Rev 48)/,
- □ OFN SB-008, ATTACHMENT B, STEAM OR FEEDWATER HEADER PRESSURE CHANNEL MALFUNCTION
- □ OFN SB-008, ATTACHMENT L, NARROW RANGE RTD MALFUNCTION
- □ EMG E-0, REACTOR TRIP OR SAFETY INJECTION (Rev 40)
- **EMG E-3, STEAM GENERATOR TUBE RUPTURE (Rev 38)**

NOTE: All events are loaded into snap IC303

Ensure malfunctions, including severity levels match scenario.

Ensure all meters, lamps, bistables and annunciators are correct for the initial setup. <u>Blue Placard is on</u> the 'A' CCP.

Ensure soft panel display in back is set to <u>RP312 RCP Vibration</u> on left screen and <u>AMSAC</u> on right screen.

Ensure no discernable history from RM11, Ovation screens, paper trend recorders, etc.

Ensure all laminated brief sheets, foldout pages, E plan boards are wiped clean.

Ensure all follow-up buttons are removed from the boards and trash cans and recycle bins are free of any potential exam material.

Ensure communications are established with the lead examiner, fresh batteries, radio check sat.

Critical Parameter Data to be collected:

- □ **<u>Cold Leg Temperature</u>**. The crew must close MSIVs to isolate steam to the Turbine before RCS Cold Leg Temperatures reach 240°F.
- <u>C'S/G WR Level.</u> The crew must depressurize the RCS to meet SI termination criteria prior to overfilling the ruptured S/G (90% WR)
- RCS Subcooling. The crew must maintain RCS Subcooling >30°F to prevent transition to EMG C-31 from EMG E-3 foldout page.
- PZR Level. The crew must maintain PZR Level >6% to prevent transition to EMG C-31 from EMG E-3 foldout page.
- □ **<u>Ruptured S/G Pressure.</u>** The crew must isolate the faulted and Ruptured 'C' S/G prior to being required to transition to EMG C-31 from EMG E-3, Step 9.

Ensure Horns are ON and machine is in RUN

- □ **Insert Key 1** for Event 1 ('B' Stator cooling water pump trips, 'A' pump fails to auto start).
- □ Insert Key 2 for Event 2 (BB TI-421, Loop 2 TC Instrument channel fails LOW).
- Insert Key 3 for Event 3 (BG TCV-130 fails closed in Auto)
- □ **Insert Key 4** for Event 4 (AE PT-508 fails LOW)
- □ **Insert Key 5** for Event 5 ('C' S/G tube leak)
- □ **Insert Key 6** for Major Event ('C' S/G tube leak grows to 400 gpm SGTR Turbine fails to trip in both Auto and Manual, Ruptured C S/G ARV opens to 100%)
- When directed to locally close AB V-087, 'C' S/G Steam Isolation to TDAFW Pump, Insert Key 9
- □ <u>When directed</u> to locally close AB V-082, 'C' S/G Main Steamline low point drain, **Insert Key 10**

ILO 2019, NRC Operating Exam, Scenario 3, Rev 4

Op-Tes	t No.: Dec 2019	Scenario No.: 3 Event No.: 1 Total No Pages 30					
Event Description: 'B' Stator Water Pump trips, 'A' Stator Water Pump fails to auto start,							
Turbine	Turbine Runback						
Time	Time Position Applicant's Actions or Behavior						
Simulato	or Operator: Inse	ert Key 1 at direction of Lead Examiner.					
Diagnos	tics : MWe load lo	wering, Runback Active red banner on Graphic 5551					
Annunci	ators: 112C & 11	5D					
Examine	er NOTE:						
o Crev	v will start the star v may note DNB v	enced, directs the crew to go to OFN MA-001. ndby Stator Cooling Water Pump per AP15C-003, Manual Backup when RCS pressure drops below 2220 psig and enter LCO 3.4.1, COND A –					
	CREW	Detects Stator Cooling pump has tripped and starts the standby pump					
	CRS Enters and directs OFN AF-025 (Step 4 & 5) or OFN MA-001						
		OFN AF-025, UNIT LIMITATIONS					
	DOD						
	BOP	 4. Check Stator Water Conductivity – LESS THAN 9.9 MICROMHOS *Annunciator 408-04B, CONDUCTIVITY ABOVE 9.9 MICROMHOS – NOT LIT *Conductivity cells are reading less than 9.9 micromhos CE-CE-6 (Inlet) CE-CE-7 (Outlet) *NPIS computer points are reading less than 9.9 micromhos – Yes CEI0006 (Inlet) CEI0007 (Outlet) 					
Simulator Operator: When directed to report Stator Water Conductivity, wait 2 minutes and report less than 0.09 Micromhos and Conductivity Annunciator is NOT LIT							
	BOP	 Check Stator Cooling Water System – Operating a. Stator Cooling Water Pumps – AT LEST ONE RUNNING – Yes b. Annunciator 408-01A, INLET FLOW LOW – NOT LIT c. Annunciator 408-02A, INLET PRESSURE LOW – NOT LIT 					
<u>Simulat</u> reset	Simulator Operator: When directed to report Stator Water Alarms, wait 2 minutes and report all are reset						

Op-Test	No.: Dec 2019	Scenario No.: 3 Event No.: 1 Total No Pages 30					
Event De	Event Description: 'B' Stator Water Pump trips, 'A' Stator Water Pump fails to auto start,						
Turbine	Turbine Runback						
Time	Time Position Applicant's Actions or Behavior						
	OFN MA-001, LOAD REJECTION OR TURBINE TRIP						
		CAUTION					
have a s		ay rise due to transient differential expansion. The rate of load reduction will on the transient differential expansion that occurs between the rotor and					
	BOP	1. Check Turbine - NOT TRIPPED - Yes					
	BOP	2. Check CWP Setback – IN PROGRESS: - No					
		RNO Go to Step 7					
	BOP 7. Check Stator Cooling: a. Stator Outlet Temperature – NORMAL – Yes o CE TI-38A b. Stator Cooling Water Inlet Temperature – NORMAL – Yes o CE TI-39 c. Stator Inlet Pressure – NORMAL – No o CE TI-38A RNO Perform the following: 1. Start second Stator Cooling Pump. *CE HIS-1 – Yes *CE HIS-2 – Tripped 2. Dispatch an operator to Stator Cooling skid and alarm panel to investigate trouble. Simulator Operator: IF contacted as turbine building watch, acknowledge requests. Wait 1 minute and report the breaker is tripped						
	<u>NOTE</u>						
	IF moderator temperature coefficient is positive and rod control is in auto, then control rods will insert initially and then withdraw to stop Tavg decrease						
	ATC 8. Ensure Rod Controller In – AUTO o Verify Rod Insertion - Yes						

Op-Tes	t No.: Dec 2019	Scenario No.: 3 Event No.: 1 Total No Pages 30				
	Event Description: 'B' Stator Water Pump trips, 'A' Stator Water Pump fails to auto start,					
Turbine	Turbine Runback					
Time	Position	Applicant's Actions or Behavior				
	ATC	9. Check PZR Pressure – STABLE AT OR TRENDING TO 2235 PSIG – Yes				
	ATC	10. Check PZR Level – STABLE AT OR TRENDING TO PROGRAM LEVEL – Yes				
	BOP	11. Check S/G Levels – STABLE BETWEEN 45% AND 55% - Yes				
	BOP	12. Check If Turbine Load Reduction/Rejection Has Stopped: - Yes				
		NOTE				
		aused by an OTDT or OPDT and Turbine load is at or below 254 MWe with ne Turbine will have to be runback manually until the condition is clear				
	BOP	 13. Check OTDT and OPDT alarms - NOT LIT - Yes Annunciator 82B – NOT LIT Annunciator 82C - NOT LIT 				
	CRS	14. Check Moderator Temperature Coefficient - ZERO OR NEGATIVE – Yes (Note prior to step 14 is N/A - Positive MTC)				
	BOP	 15. Verify S/G Atmospheric Relief Valves Closed: a. Ensure S/G ARVs set at 1125 psig – Yes AB PIC-1A AB PIC-2A AB PIC-3A AB PIC-4A b. Check S/G Pressure - ≤1125 psig – Yes c. Check S/G ARVs CLOSED – Yes 				
	BOP	 16. Check If Condenser Steam Dumps Should Be Reset: a. Check C-7 Light – LIT – No RNO Go to Step 17 				

Op-Tes	t No.: Dec 2019	Scenario No.: 3 Event No.: 1 Total No Pages 30				
Event Description: 'B' Stator Water Pump trips, 'A' Stator Water Pump fails to auto start,						
	Turbine Runback					
Time	Time Position Applicant's Actions or Behavior					
	BOP					
	BOP	17. Notify Radiation Protection To Perform The Following:				
		 Monitor RCS and other connecting systems for increasing Radiation levels due to unplanned crud burst. 				
		 Notify all personnel in the affected areas. 				
Simulat	or Operator:					
		I, acknowledge requests				
		Supt., acknowledge status cknowledge requests				
		histry, acknowledge status				
	ATC					
	AIC	18. Maintain Stable Plant Conditions:				
	 PZR Pressure – Between 2220 psig and 2250 psig. PZR Level - Within 5% of program level. 					
		 PZR Level - Within 5% of program level. SG NR Level – Between 45% and 55%. 				
	CRS					
	0110	19. Ensure Compliance With Appropriate Technical Specifications:				
		 3.1.6 Control Rod Insertion Limits – Met 				
		 3.2.3 Axial Flux Difference - Met 				
	BOP					
	201	20. Check S/G Safety Valves - REMAINED CLOSED DURING TURBINE				
	LOAD REJECTION - Yes					
	CRS/ATC	21. Check If Sampling Is Required:				
		a. Check Thermal Power Change - GREATER THAN 15% IN 1 HOUR				
		b. Direct Chemistry to take samples, as required by AP 02-007, ABNORMAL CONDITIONS GUIDELINES.				
Event termination: After the crew has started the standby Stator Water Cooling Pump, controlled the Turbine Runback, and/or at the direction of the Lead Examiner						
	Simulator Operator: Insert Key 2 at direction of the Lead Examiner.					
Chinator operator. Insert hey 2 at direction of the Lead Examiner.						

Op Test	No.: Dec 2019	Scenario No.: 3 Event No.: 2 Total No Pages 30					
Event D	Event Description: BB TI-421, Loop 2 Tc Instrument channel fails LOW						
Time	Time Position Applicant's Actions or Behavior						
Simulato	r Operator: Inse	rt Key 2 at the lead examiners direction					
progress.	C-16 Actuated, C	rms, No plant response since instrument failed low and no power ascension in $DT\Delta T/OP\Delta T$ inputs to C3 and C4 active on Panel SC066W for Channel II. Its for Loop 2 lit on Panel SB-069.					
Annuncia	ators: 066B, 067I	D, 068B, 069B, 082B, 082C, 083C, 130F					
	CREW	Recognizes failure, no load rejection in progress, and a failure of the temperature instrument					
performa	nce of OFN SB-0	that is referenced for this failure confirms an instrument failure and directs 08. If a power ascension was in progress, ALR 00-030F directs stopping 6, but that is NOT applicable in this scenario.					
	CRS Enters and directs OFN SB-008, INSTRUMENT MALFUNCTIONS						
<u> </u>	OFN SB-008, INSTRUMENT MALFUNCTIONS						
		1. Check for Malfunction:					
		*Check if Reactor Coolant System Instrument Channel or Controller is Malfunctioning:					
	CRS	 a. Perform appropriate attachment for malfunctioning channel or controller from the table below: 					
		RCS Temperature T-411, T-421, T-431 ATTACHMENT L (BB) T-441					
	ATTACHMENT L, NARROW RANGE RTD MALFUNCTION						
		NOTE:					
Steps L1 and L2 are Memory Action steps							
EXAMINI control	EXAMINER NOTE: Operating crew may energize Pressurizer Back Up heaters to assist in pressure control						
	BOP	L1. Check Load Rejection – NOT IN PROGRESS o Generator Load MW – STABLE – Yes					

Op Test	No.: Dec 2019	Scenario No.: 3	Event No.: 2	Total No Pages 30			
Event D	Event Description: BB TI-421, Loop 2 Tc Instrument channel fails LOW						
Timo	Time Position Applicant's Actions or Behavior						
	ATC L2. Switch ROD BANK AUTO/MAN SEL Switch To – MANUAL • SE HS-9						
	BOP L3. Check Steam Dumps: a. Check STEAM DUMP SEL Switch – IN TAVG MODE – Yes o AB US-500Z b. Check Steam Dumps – CLOSED – Yes						
	ATC L4. Identify Failed Instrument Channel: a. Compare loop Tavg and ΔT indications to confirm a NR RTD failure: - Loop 2						
	ATC L5. Remove Failed Temperature Channel From Tavg And dT Auctioneering Circuits, Using DELTA T DEFEAT And ROD CTRL T AVG INPUT CHANNEL DEFEAT Switches:						
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.						
	ATC	L6. Check (Tavg/Tref)	Error Signal Within 1°F - V	Yes			
	L	<u>NO</u>	TE:				
	ke several minute back to automat		ure rate circuitry outputs to	o return to normal before			
	ATC L7. Check ROD BANK AUTO/MAN SEL Switch In Auto. – No o SE HS-9 RNO – Place Rods in Auto, when Tavg within 1°F of Tref						
	ATC L8. Monitor Rod Control System Response To Ensure Proper Control						
	BOP	L9. Check, C-7 Loss O	Load Interlock – NOT LIT	T – Yes			
	BOP L10. Check STEAM DUMP BYPASS INTERLOCK Switches In – ON – Yes o AB HS-63 o AB HS-64						

Op Test N	lo.: Dec 2019	Scenario No.: 3	Event No.: 2	Total No Pages 30			
Event Description: BB TI-421, Loop 2 Tc Instrument channel fails LOW							
	BOP	L11. Monitor Steam D	ump Control System To Ei	nsure Proper Operation			
	BOP	L12. Check Failed Temperature Channel Not Selected On OP DT/OT DT LOOP RECORD SEL. – Yes (Loop 1 selected)					
	CRS	 CRS L13. Monitor The Following Technical Specification LCOs And Comply With Action Statements, As Appropriate: 3.3.1, REACTOR TRIP SYSTEM INSTRUMENTATION, Table 3.3.1-1, Functions 6 And 7 Enters LCO 3.3.1, REACTOR TRIP SYSTEM INSTRUMENTATION, Table 3.3.1-1, Functions 6 and 7, Condition A – Immediately, Condition E – 72 hrs. 					
	ATC L14. Check Control Rods In Parked Position – Yes						
	CRS Conduct Reactivity Brief.						
	BOP L15. Check C-16 Hold Active: o Graphic 5570, LOAD CONTROL LOOP REJECTED- <u>NOT</u> RED - No No RNO Acknowledge alarm condition on Graphic 5570 – MAN ACTION ALARM ACK.						
Event Termination: After the crew has identified Tech Specs and C-16 alarm acknowledged and/or at the direction of the Lead Examiner Simulator Operator: Insert Key 3 at direction of the Lead Examiner							

Op-Tes	t No.: Dec 2019	9 Scenario No.: 3 Event No.: 3 Total No Pages 30				
Event D	Event Description: BG TCV-130 Fails CLOSED in Auto					
Time	Time Position Applicant's Actions or Behavior					
Simulat	Simulator Operator: Insert Key 3 at direction of Lead Examiner.					
	Output on BG TK LTDN HX Outlet CVCS DEMIN IN	Temp BG TI-130 temperature indication higher than 120F (Green band), LET DIVERT VLV, BG HIS-129 shifts from 'DEMIN' to 'VCT' Position				
		d possibly 039A, depending on timeliness of crew action hay take manual control and bypass the demineralizers prior to alarm panel				
being lit						
	CRS	Enters and directs ALR 00-038B or ALR 00-039A				
		ALR 00-039B, LTDN HX DISCH TEMP HI				
	ATC	1. Check Letdown Heat Exchanger Outlet Temperature - >120°F o BG TI-130 Yes				
	ATC 2. Check Annunciator ALR 00-039A, LTDN HX TEMP HI DIVERT Clear • Yes – Continue to Step 3 • No – RNO Go to ALR 00-039A.					
	ATC	 3. Check Letdown Heat Exchanger Outlet Temperature Control Valve – FULLY OPEN (BG TK-130) – <i>No</i> o BG TK-130 RNO Perform the following: 				
		a. Place valve in manual and establish temperature between 110°F and 120°F.				
	ATC	 4. Check Letdown Heat Exchanger Outlet Flow <120 GPM – Yes o BG FI-132 				
	ATC	5. Check Letdown Heat Exchanger Outlet Temperature – DECREASING – Yes o BG TI-130				
	CRS	6. Return to procedure and step in effect.				
		ALR 00-039A, LTDN HX TEMP HI DIVERT				
	ATC	 Check Letdown Heat Exchanger Outlet Temperature >137°F – Yes BG TI-130 				

ο	
3	

Op-Test No.: Dec 2019 Scenario No.: 3 Event No.: 3 Total No Pages 30						
Event D	Event Description: BG TCV-130 Fails CLOSED in Auto					
Time	Position	Applicant's Actions or Behavior				
	ATC	 2. Check CVCS Demineralizer Inlet Divert Valve in VCT Position – Yes o BG HIS-129 				
	BOP	3. Check Annunciator 00-038A, LTDN REGEN HX TEMP HI – CLEAR – Yes				
	ATC	 4. Check Letdown Heat Exchanger Outlet Temperature Control Valve – Responding Properly – <i>No</i> o BG TK-130 				
	RNO Perform the following: a. Place valve in manual and establish temperature between 110°F and 120°F					
	ATC	 5. Check Letdown Heat Exchanger Outlet Flow <120 GPM – Yes o BG FI-132 				
	ATC	 6. Check Letdown Heat Exchanger Outlet Temperature DECREASING <u>OR</u> STABLE BETWEEN 110°F to 120°F − Yes o BG TI-130 				
	ATC	 7. Check Letdown Heat Exchanger Outlet Temperature <120°F – Yes o BG TI-130 				
	ATC	 8. Place BG HIS-129, CVCS Demineralizer Inlet Divert Valve in DEMIN Position BG HIS-129 				
	CRS	9. Return to Procedure and Step in Effect.				
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.					
	Event Termination: After the crew has manual control with Letdown Heat Exchanger Outlet Temperature LOWERING and/or at the direction of the Lead Examiner					
Simulator Operator: Insert Key 4 at the direction of Lead Examiner						

Op-Test	No.: Dec 2019	Scenario No.: 3	Event No.: 4	Total No Pages 30			
Event De	Event Description: AE PT-508, Feed Header Pressure channel fails LOW						
Time	Time Position Applicant's Actions or Behavior						
Simulator	r Operator: Inse	ert Key 4 at direction of Lea	d Examiner.				
Diagnosti	i cs: Both MFW p	oump speeds rise, ALL S/G I	evels rise, FRVs close, M	We lowers			
		and/or 108-111C					
<u>Examine</u>	<u>r Note:</u> Crew ma	ay take actions to control MF	Ps prior to ALR and/or Of	N entry			
	CREW Recognizes changing conditions and diagnoses failure of AE PT-508						
	CRS	Enters and directs OFN SE	3-008, INSTRUMENT MA	LFUNCTIONS			
		OFN SB-008, INSTRUME	NT MALFUCNTIONS				
	1. Check for Malfunction: *Check if Secondary System Instrument Channel is Malfunctioning a. Perform appropriate attachment for malfunctioning channel from table below:						
		Steam or Feedwater Header Pressure (AB, AE)	P-507 P-508	ATTACHMENT B			
ΑΤΤΑΟ	ATTACHMENT B, STEAM OR FEEDWATER HEADER PRESSURE CHANNEL MALFUNCTION						
NOTES							
• N/A (Failure of PT-507)							
o At full							
∘ Step⊺	 Step B1 is a Memory Action step. 						

Op-Test	No.: Dec 2019	Scenario No.: 3 Event No.: 4 Total No Pages 30		
Event De	Event Description: AE PT-508, Feed Header Pressure channel fails LOW			
Time	Position	Applicant's Actions or Behavior		
	вор	 B1. Verify Proper Main Feedwater Pump Speed Control Main Feedwater Pump speed is stable for plant conditions – <i>No</i> FC SK-88 FC SK-188 RNO : Perform the following		
		 a. Place MFP TURBS MASTER SPEED CTRL in manual. ○ FC SK-509A b. Control pump speed to PROGRAMMED FEEDWATER ΔP in accordance with programmed value. (Refer to Figure 1) ○ FC SK-509A 		
	BOP	 B2. Verify Steam Header Pressure Channel Malfunction: – No RNO Go to step B10 		
	BOP	 B10. Verify Feedwater Header Pressure Channel Malfunction: - Yes *Feed Header Pressure – ABNORMALLY HIGH OR LOW <u>OR</u> *Steam Header/Feedwater Header ΔP – ABNORMAL FOR EXISTING PLATN POWER (Refer To FIGURE 1) 		
	<u>r Operator:</u> I <u>F</u> c dge status.	ontacted as WWM, acknowledge requests. <u>IF</u> contacted as Call Supt.,		
	CRS	B11. Request I&C repair failed channel		
	BOP	B12. WHEN Failed Channel is repaired, THEN restore MFP TURBS MASTER SPEED CTRL to auto, as directed by SM/CRS FC SK-509A 		
	CRS	B13. Return to procedure and step in effect		
Examiner	Event termination: After the crew has restored S/G levels and/or at the discretion of the Lead Examiner.			
<u>Simulato</u>	<u>r operator:</u> Inse	ert Key 5 at the lead examiners direction.		

On-Teo	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 5 Total No Pages 30			
Event [Event Description:S/G 'C' Tube LeakCrew B tripped RX on Event 4 and did not get credit for this event.				
Time	Position	Applicant's Actions or Behavior			
Simulat	Simulator Operator: Insert Key 5 at direction of Lead Examiner.				
'C' \$/G		owering level and pressure in the Pressurizer, slowing rising level in the end on process rad monitors 61B			
	CREW	Recognizes alarms and indications that there is a tube leak into the 'C' S/G			
	CRS	Enters and directs OFN BB-07A			
	0	FN BB-07A, STEAM GENERATOR TUBE LEAKAGE			
	or trip or safety inj Y INJECTION, sto	<u>CAUTION</u> ection actuates during this procedure, go to EMG E-0, REACTOR TRIP OR ep 1			
	ATC	1. Check PZR Level – GREATER THAN 6% - Yes			
	ATC	2. Check PZR Level – GREATER THAN 17% - Yes			
	ATC	3. Check PZR Level – STABLE OR RISING – No RNO <u>IF</u> PZR level is less than program level, <u>THEN</u> perform the following: a. Control charging flow, as necessary, to maintain PZR level b. IF pressurizer level can NOT be maintained, THEN close letdown orifice valves, as necessary, to stabilize PZR level *BG HIS-8149AA *BG HIS-8149BA *BG HIS-8149CA			

Op-Tes	p-Test No.: Dec 2019 Scenario No.: 3 Event No.: 5 Total No Pages 30			
<u>Event [</u>	Event Description: S/G 'C' Tube Leak			
Time	Position Applicant's Actions or Behavior		ior	
	ATC			
		Monitors Foldout page Criteria:		
		1. SI ACTUATION CRITERIA		
		<u>IF</u> any condition listed occurs, <u>1</u> EMG E-0, REACTOR TRI	P OR SAFETY INJEC	CTION, Step 1.
		* RCS Subcooling based c WITH REACTOR TRIF	PPED <u>OR</u>	
		* Pressurizer Pressure – C		
		* Pressurizer Level – CAN		D >6% <u>OR</u>
		 * ALL of the following conc Normal charging is 	maximized from one	ուլար
		AND		pump.
		 Letdown is Isolated 	1	
		 <u>AND</u> Pressurizer Level is 	s lowerina.	
			0	
	ATC/BOP	4. Try To Identify Leaking S/G:		
		*Unexpected rise in any S/G	narrow range level -	Yes
		<u>OR</u>		
		*Radiation from any S/G stea	amline radiation monit	tor
		*ABS 114 For S/G A		
		*ABS 113 For S/G B		
		*ABS 112 For S/G C		
		*ABS 111 For S/G D OR		
		*Radiation from any S/G stea	amline survey	
		OR		
		*Radiation from and S/G sam	nple	
		OR		
		*Radiation from any S/G blow	wdown cation column	at RM172 (Micro-R
		meter or equivalent)		
	<u>NOTES</u>			
	If VCT level cannot be maintained, the Rx is tripped since after swapover to the RWST the high boron injection flowrate makes an orderly shutdown difficult			o the RWST the high
	If the leak rate is still within the capacity of a charging pump, after swapover to the RWST, it is not desirable to actuate SI and go to EMG E-3			

Op-Te	Op-Test No.: Dec 2019Scenario No.: 3Event No.: 5Total No Pages 30			
<u>Event l</u>	Event Description: S/G 'C' Tube Leak			
Time	Position	Position Applicant's Actions or Behavior		
	ATC	<u>5.</u> Check VCT Level – BEI	NG MAINTAINED BY N	ORMAL MAKEUP – Yes
		NOT	<u>E</u>	
		TO SECONDARY LEAKAG and also determine the leak		ill determine which steam
	6. Ensure Chemistry Is Performing the Following Procedures: o STS CH-033, PRIMARY TO SECONDARY LEAKAGE BOP DETERMINATION, o AI 21D-004, SECONDARY RADIATION MONITOR SETPOINT CALCULATIONS CALCULATIONS			Y LEAKAGE
<u>Simula</u>	tor Operator: IF	contacted as RP and/or Che	emistry, acknowledge re	quests
	NOTES			
gpd.		an 30 gpd, the YELLOW ALER greater than 30 gpd, the YELLO		
o The RE-0		only apply to GR RE-92 and car	nnot be used to adjust the s	setpoint on BM RE-24 or SJ
	 Receipt of a YELLOW ALERT indication will cause annunciator 00-061B, PROCESS RAD HI to alarm. Receipt of a RED HIGH indication will cause annunciator 00-061A, PROCESS RAD HIHI to alarm 			
	CREW	 <u>7.</u> Determine If Steam Ger Restored: a. Check S/G Total Leal – No RNO: Go to Step 9 		ampling Can Be BE LESS THAN 75 GPD

Op-Tes	st No.: Dec 201	9 Scenario No.: 3	Event No.: 5	Total No Pages 30
<u>Event [</u>	Event Description: S/G 'C' Tube Leak			
Time	Position	Аррі	icant's Actions or Beh	avior
	CRS	MONITORING, action lo directed by table b. Refer to ATTACHME TUBE LEAK	C, STEAM GENERATOF evel table and take appr NT D, GUIDANCE FOR Nn – NOT REQUIRED – 13, RCS operational Le E 3 in 6 hours and MOI	R TUBE LEAKAGE opriate actions, as OPERATION WITH SG <i>No</i> eakage, Condition B is DE 5 in 36 hours for
	Event Termination: After the crew has determined leak rate and/or at the direction of the Lead Examiner			
<u>Simula</u>	Simulator Operator: Insert Key 6 at the direction of the Lead Examiner			

Op-Tes	st No.: Dec 2019	Scenario No.: 3	Event No.: 6/7/8	Total No Pages 30
-	Event Description: S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto			
	and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applica	ant's Actions or Behav	ior
Simulat	Simulator Operator: Insert Key 6 at direction of Lead Examiner.			
		level lowering with charging f is met to trip the Reactor and		own isolated. OFN BB-
	CRS	Directs tripping the Reactor a directs EMG E-0	and Actuating Safety Inje	ection, enters and
		EMG E-0, REACTOR TRIP OF	R SAFETY INJECTION	
	-	NOTE immediate action steps monitored throughout this pro	ocedure	
	ATC ATC ATC ATC ATC 1. Verify Reactor Trip: - Yes a. Check all rod bottom lights – LIT b. Check reactor trip breakers and bypass breakers – OPEN o SB ZL-1 o SB ZL-2 o SB ZL-3 o SB ZL-3 o SB ZL-4 c. Check intermediate range neutron flux – DECREASING o SE NI-35B [GAMMA METRICS] o SE NI-36B [GAMMA METRICS]			
	BOP	RNO a. Perform the following 1) Manually trip the turk	bine – No trip, THEN close main st s valves main steamline isolation nge develops to either the	eam isolation valves valves before a e subcriticality (Positive

Op-Te	st No.: Dec 201	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's Actions or Behavior		
	ATC	3. Check AC Emergency Busses – AT LEAST ONE ENERGIZED – Yes *NB01 – ENERGIZED *NB02 – ENERGIZED		
	ATC	 4. Check if Safety Injection is Actuated: a. Check any indication SI is actuated – LIT – Yes *Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – LIT *Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – LIT *ESFAS status panel SIS section – ANY WHITE LIGHTS LIT *Partial Trip Status Permissive/Block status panel – SI RED LIGHT LIT b. Check both trains of SI actuated – Yes Ann 00-030A, NF039A LOCA SEQ ACTUATED – LIT Ann 00-031A, NF039B LOCA SEQ ACTUATED – LIT 		
	e power is lost afte equired configura	CAUTION er SI reset, manual action may be required to restore safeguards equipment tion		
	ATC	 5. (t) Check if SI required: * SI was manually actuated AND was required – Yes * Containment pressure is currently or has been – GREATER THAN OR EQUAL TO 3.5 PSIG – No * RCS pressure is currently or has been – LESS THAN OR EQUAL TO 1830 PSIG – No * Any S/G pressure is currently or has been – LESS THAN OR EQUAL 		
	BOP	TO 615 PSIG – <i>No</i> <u>Monitoring Foldout page:</u> Recognizes 'C' S/G ARV is open, takes manual control and closes the valve, reports to CRS CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, C ARV *AB HIS-20, C MSIV *AL HK-11A MD AFW REG VLV CTRL *AL HK-12A TD AFW REG VLV CTRL *AB V087 TDAFW Steam Supply from C S/G *AB-V082, C S/G Low Point Drain		

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's Actions or Behavior		
closed of	due to the type of	 6. Verify Automatic Actions using Attachment F, AUTOMATIC SIGNAL VERIFICATION <u>Examiner Note:</u> See Attachment 1 for complete list of actions, ALL automatic actuations occur as expected in this step. ding on time after trip, Main Generator and Exciter Breakers may still be Turbine Trip Failure inserted. When the applicants reach Step 7 they may 		
need to	perform RNO ac	tions.		
	BOP	 7. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes/No MA ZL-3A MA ZL-4A MA ZL-2 RNO Perform the following: a. Check major steam flow paths to the main turbine isolated Annunciator 00-115C, SEQUENTIAL TRIP LOGIC SATISFIED – LIT b. IF annunciator 00-115C, SEQUENTIAL TRIP LOGIC SATISFIED is NOT LIT, THEN perform the following: - Yes Place EHC Pumps in Pull-To-Lock: CH HIS-1A Ch HIS-1B c. Close MSIVs and MSIV Bypass Valves *AB HS-79 *AB HS-80 c. When 33 seconds have elapsed from when Generator Output has decreased to at least – 5 MW, THEN perform the following: 1) Place SWYD 345-50/60 MAN TRIP PERMIT switch to PERMIT MA HS-5 2) Ensure main generator and exciter breakers are open a) MA HS-4 C) MB HS-2 		
	BOP	8. Check Total AFW Flow – GREATER THAN 270,000 LBM/HR – Yes		
	BOP	 <u>9.</u> Check RCS Cold Leg Temperatures: *Stable at or trending to 557°F for condenser steam dumps or S/G ARVs *Stable at or trending to a range of 553°F to 557°F for S/G ARVs if recovering from an inadvertent SI 		

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30			
<u>Event [</u>	Event Description: S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto			
and Ma	nual, MSIV ALL	CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip,		
closes	manually			
Time	Position	Applicant's Actions or Behavior		
	BOP	 10. Establish S/G Pressure Control: a. Check condenser – AVAILABLE – Yes C-9 LIT MSIV – OPEN Circulating water pumps - RUNNING b. Place Steam Header Pressure Control in Manual AB PK-507 c. Manually set Steam Header Pressure Control output to zero AB PK-507 d. Place Steam Dump Select Switch in STEAM PRESS position AB US-500Z e. Place Steam Header Pressure Control in Automatic AB PK-507 		
	ATC	 11. Check PZR PORVs a. Check PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A b. Power to block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B c. RCS pressure – LESS THAN 2185 PSIG 		
	ATC	 13. Check PZR Safety Valves – CLOSED – Yes BB ZL-8010A / B / C 		
		<u>NOTE</u>		
Seal inj	ection flow shall t	pe maintained to all RCPs		
	ATC/BOP 14. Check if RCPs should be stopped: a. Check RCPs – ANY RUNNING – Yes b. Check RCS pressure – LESS THAN 1400 PSIG – No RNO b. Go to Step 15			
	CRS	15. Direct operator to Monitor Critical Safety Functions Using EMG F-0, CRITICAL SAFETY FUNCTION STATUS TREES (CSFST)		
	BOP	 16. Check if S/Gs are not Faulted: - Yes a. Check pressures in all S/Gs – NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER NO S/G COMPLETELY DEPRESSURIZED 		

Op-Test No.: Dec 2	2019 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30			
Event Description: S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto				
and Manual, MSIV	and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip,			
closes manually				
Time Position	Applicant's Actions or Behavior			
BOP				
BOP	 17. (t) Check if S/G tubes are intact: Check S/G Levels – NOT INCREASING IN AN UNCONTROLLED MANNER – No Narrow range Wide range Oradenser air discharge radiation – NORMAL BEFORE ISOLATION – No GEG 925 S/G blowdown and sample radiation – NORMAL BEFORE ISOLATION – No BML 256 SJL 026 Turbine driven auxiliary feedwater pump exhaust radiation – NORMAL – No FCT 381 S/G steamline radiation – NORMAL – No ABS 114 for S/G B ABS 112 for S/G B ABS 112 for S/G C ABS 111 for S/G D RNO Perform the following: a. Direct Health Physics to survey steamlines in Area 5 of the Auxiliary Building Ensure BIT and Outlet Valves are open – Yes EM HIS-8803A/B EM HIS-8801A/B Check S/G B or S/G C – RUPTURED – Yes 1) Dispatch operator to locally close steam supply to Turbine Driven AFW Pump from ruptured S/G(s) *AB-V087 For S/G C (MAIN STEAM ENCLOSURE BELOW GRATING) d. Go to EMG E-3, STEAM GENERATOR TUBE RUPTURE, Step 1 CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB HIS-20, C MSIV *AL HK-11A MD AFW REG VLV CTRL *AB W087 TDAFW Steam Supply for CS/G *AB-V082, C S/G Low Point Drain 			

Op-Tes	st No.: Dec 201	9 Scenario No.: 3 E	vent No.: 6/7/8	Total No Pages 30
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's	s Actions or Behavi	or
o WH o WH		Health Physics, acknowledge requ Building Watch, acknowledge requ sed		Insert Key 9, and
		EMG E-3, STEAM GENERATOR	TUBE RUPTURE	
		<u>NOTES</u>		
o Fold	lout page shall be	monitored throughout this proced	ure	
o Pers	sonnel should be	available for sampling during this p	procedure	
o Sea	l injection flow sh	all be maintained to all RCPs.		
	ATC ATC			
		CAUTION		
		ct, extreme caution will be necess		local surveys.
		····· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ···· , ·· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ··· , ·· , ··· , ··· , ··· , ·		

Op-Tes	t No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's Actions or Behavior		
	BOP	 2. Identify Ruptured S/Gs: *Level Increasing In An Uncontrolled Manner – C S/G OR *High Turbine Driven AFW exhaust radiation. FCT 381 OR *High radiation from any S/G steamline radiation ABS 114 For S/G A ABS 113 For S/G B ABS 112 For S/G C ABS 111 For S/G D OR *High Radiation From Any S/G Steamline Survey OR *High Radiation From Any S/G Sample 		
	CAUTION			
		W Pump is the only available source of feed flow, steam supply to the Turbine be maintained from at least one S/G.		
	BOP	 3. Isolate flow from Ruptured S/Gs: a. Adjust ruptured S/Gs ARV controller setpoint to 1160 psig b. Check Ruptured S/Gs ARV – CLOSED c. Locally close steam supply to Turbine Driven AFW Pump from ruptured S/G(s) *AB-V087 for S/G C (MAIN STEAM ENCLOSURE BELOW GRATING) – Already Dispatched d. Locally isolate main steamline low point drain valve(s) from ruptured S/G(s) *Close AB V-082 For S/G C (MAIN STEAM ENCLOSURE BELOW GRATING) CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, C ARV *AB HIS-20, C MSIV *AL HK-11A MD AFW REG VLV CTRL *AB V087 TDAFW Steam Supply from C S/G *AB-V082, C S/G Low Point Drain 		

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30	
	Description, S/C	"C' Tuba look groups to 400 gpm SCTD. Turking foils to trip in both Auto	
		'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto	
and Ma	nual, MSIV ALL	CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip,	
closes	manually		
Time	Position	Applicant's Actions or Behavior	
		HEN contacted to as Building Operator to close AB-V082, acknowledge wait 2 minutes are report AB-V082 closed	
	BOP	4. Verify Blowdown, Lower, and Upper Sampling Isolated on Ruptured S/G(s) – <i>verified in previous procedure</i>	
		CAUTION	
At least	one S/G shall be	e maintained available for RCS cooldown.	
		5. Isolate Steamline on Ruptured S/G(s):	
	505	a. Close main steamline isolation valve *AB HIS-20 For S/G C	
	BOP	b. Ensure Main Steamline Isolation Bypass Valves – CLOSED	
		• AB ZL-21A for S/G C	
CAUTION			
If any ruptured S/G is also faulted and the affected S/G is not needed for RCS cooldown, feed flow to that S/G shall remain isolated during subsequent recovery actions.			
		6. Check If Feed Flow Should Be Isolated to Ruptured S/G(s):	
		a. Check Ruptured S/G(s) Narrow Range Level – GREATER THAN 6% [29%] – No	
		RNO Perform the following:	
	BOP	 <u>IF</u> ruptured S/G pressure is lowering in an uncontrolled manner <u>OR</u> ruptured S/G is completely depressurized <u>THEN</u> go to step 7. 	
		2) Maintain feed flow to ruptured S/G(s), until level >6% [29%]	
		 WHEN ruptured S/G level >6% [29%], <u>THEN</u> go to step 7, continue with step 8. 	

Op-Test No.: Dec 2019 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30				
<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually				
Time	Position	Applicant's Actions or Behavior		
	BOP	 <u>7.</u> Stop Feed Flow To Ruptured S/G(s) a. Close affected S/G(s) MD AFP Flow Control Valve(s). *AL HK-11A For S/G C b. Close affected S/G(s) TD AFWP Flow Control Valve(s). *AL HK-12A For S/G C 		
		CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, C ARV *AB HIS-20, C MSIV *AL HK-11A MD AFW REG VLV CTRL *AL HK-12A TD AFW REG VLV CTRL *AB V087 TDAFW Steam Supply from C S/G *AB-V082, C S/G Low Point Drain		
	BOP	 8. Verify Ruptured S/G(s) Isolation: a. Check Ruptured S/G(s) – NOT NEEDED FOR RCS COOLDOWN b. Verify ruptured S/G(s) steamline has been isolated from at least one intact S/G: *Main Steam Isolation Valve and Bypass Valve on Ruptured S/G(s) – CLOSED <u>OR</u> *Main Steam Isolation Valve and Bypass Valve on at least on intact S/G – CLOSED c. Check Main Steam Isolation Valve and Bypass Valve on Ruptured S/G(s) – CLOSED d. Verify Steam Supply to Turbine Driven AFW Pump from Ruptured S/G(s) – CLOSED d. Verify Steam Supply to Turbine Driven AFW Pump from Ruptured SG(s) – CLOSED *AB-V085 For S/G B *AB-V087 For S/G C CT2: Given an open ARV on ruptured S/G, Isolate feed flow into and steam flow from the ruptured 'C' S/G before making an unnecessary transition to EMG E-2 from EMG E-0, Step 16 or to EMG C-31 due to RCS Subcooling <30°F, PZR Level <6% or Ruptured S/G Pressure <380 psig, by closing the following: *AB PIC-3A, C ARV *AB HIS-20, C MSIV *AL HK-11A MD AFW REG VLV CTRL *AB V087 TDAFW REG VLV CTRL *AB V087 TDAFW Steam Supply from C S/G 		

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually				
Time	Position	Applicant's Actions or Behavior		
		CAUTION		
subcritio	cality red path and	s stuck or SI flow is reduced, an inadvertent restart may occur. Symptoms for d transition to EMG FR-S1, RESPONSE TO NUCLEAR POWER hall be closely monitored during subsequent steps.		
	BOP	9. Check Ruptured S/G(s) Pressure – GREATER THAN 380 PSIG		
		NOTE		
		te setpoint (100 psi/50 sec) is exceeded after low steamline pressure SI teamline isolation will occur		
		 10. Check if Low Steamline Pressure SI should be Blocked: a. Check RCS Pressure – LESS THAN 1970 PSIG o P-11 Light – LIT 		
	BOP	RNO a. WHEN RCS pressure is less than 1970 psig, THEN block low steamline pressure SI. Continue with step 11		
		 b. Block low steamline pressure SI SB HIS-9 SB HIS-10 		
	ATC	11. Determine Target Plant Conditions from Table below: (Based on Ruptured S/G Pressure)		
<u>CAUTION</u> If RCPs are not running, the cooldown and depressurization steps may cause a red or orange path condition on the integrity status tree for the ruptured loop. Step 52 shall be completed before reevaluating the red or orange path condition and transition to EMG FR-P1, RESPONSE TO IMMINENT PRESSURIZED THERMAL SHOCK CONDITIONS, if required. NOTE				
o Afte	• After Operator initiated RCS cooldown has been started, RCP trip criteria no longer applies.			
 Once the maximum rate cooldown is started, it must be maintained until the target temperature is reached. 				
	BOP	 Determine method used to Cooldown RCS at Maximum rate: a. Check Steam Dumps – AVAILABLE – NO MSIVs are closed 		
		RNO a. Go to Step 14		

Op-Tes	st No.: Dec 2019	Scenario No.: 3	Event No.: 6/7/8	Total No Pages 30	
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually				
Time	Position	Аррі	icant's Actions or Behav	ior	
	BOP	*Use intact OR *Operate Tr b. Adjust Controller set less than or equal to se *AB PIC-1A for S *AB PIC-2A for S *AB PIC-2A for S *AB PIC-4A for S c. Check RCS Temper *Core Exit TCs Or *RCS Hot Leg R RNO c. Perform the follow 1) <u>WHEN</u> RCS to perform step 14. 2) Go to step 15 d. Check Automatic Te 1) Place ARV co 2) Adjust ARV co temperature less RNO d. Manually maintain temperature: a) Manually cont *Use intact <u>OR</u> *Operate To	 AVAILABLE at maximum rate: S/G ARVs in manual at 10 urbine Driven AFW Pump is point of each ARV used for etpoint target value from st S/G A S/G B S/G D atures – LESS THAN TAR TDs ing: emperature is less than target mperature Control – DESI ntroller IN AUTO pontrollers as needed, to mage than target temperature a RCS temperature stable I rol steam flow from intact is 	at Maximum Load or cooldown to a value tep 11 RGET TEMPERATURE rget temperature, <u>THEN</u> IRED aintain RCS below target S/Gs:	

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's Actions or Behavior		
		<u>15.</u> Check Intact S/G Levels: a. Check Narrow Range Level in at least one S/G – GREATER THAN 6% [29%]		
	BOP	RNO a. Maintain total feed flow greater than 270,000 lbm/hr, until narrow range level greater than 6% [29%] in at least one S/G		
		 b. Control feed flow to maintain narrow range level in all S/Gs between 29% [29%] and 50% 		
		CAUTION:		
	If any PZR PORV opens because of high PZR pressure, the PORV shall be monitored to ensure it recloses after pressure decreases to less than 2335 psig			
	ATC	16. Check PZR PORVs and Block Valves: a. Power to Block Valves – AVAILABLE – Yes o BB HIS-8000A o BB HIS-8000B b. PZR PORV – CLOSED – Yes o BB HIS-455A o BB HIS-456A c. RCS Pressure – LESS THAN 2185 – Yes		
	ATC	<u>17.</u> Check PZR Safety Valves – CLOSED – Yes ○ BB ZL-8010A ○ BB ZL-8010B ○ BB ZL-8010C		
		CAUTION		
If offsite power is lost after SI reset, manual action may be required to restore safeguards equipment to the required configuration				
	ATC	18. Reset SI: o SB HS-42A o SB HS-43A		

Op-Tes	t No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30			
Event Description: S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto					
		CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip,			
closes	manually				
Time	Position	Applicant's Actions or Behavior			
	ATC	19. Reset Containment Isolation Phase A and Phase B			
		 SB HS-56 For Phase A SB HS-53 For Phase A 			
		SB HS-55 For Phase B SB HS 53 For Phase B			
		 SB HS-52 For Phase B 			
		NOTE			
Locally opening EF HV-43, ESW A TO AIR COMPRESSOR or EF HV-44, ESW B TO AIR COMPRESSOR requires the associated ESW Train to be declared inoperable. Local opening of the valve, on 2000' NORTH END AUX BLDG, will preclude it from automatically isolating on a high flow condition					
	BOP	20. Verify Instrument Air Compressor Running:			
		a. Ensure At Least One ESW TRN TO AIR COMPRESSOR Valve – OPEN – Yes			
		*EF HIS-43 *EF HIS-44 b. Check AIR COMPRESOSR BRKR RESET Switch Associated With			
		Open ESW Valve(s) - No *KA HIS-3C			
		*KA HIS-2C			
		RNO: Reset and Close AIR COMPRESSOR BRKR RESET Switch *KA HIS-3C *KA HIS-2C			
		c. Check INST AIR PRESS – GREATER THAN 105 PSIG			
	 KA PI-40 – Yes d. Check Neither ESW TO AIR COMPRESSOR Valve – Locally Opened - No 				
	 EF HV-43 EF HV-44 Check Both ESW TRN TO AIR COMPRESSOR Valves – OPEN – 				
		Yes			
		 EF HIS-43 EF HIS-44 f. Check Both AIR COMPRESSOR BRKR RESET Switches – CLOSED – Yes 			
		 KA HIS-3C KA HIS-2C 			

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30		
and Ma	<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually			
Time	Position	Applicant's Actions or Behavior		
	BOP	 21. Verify Instrument Air to Containment: a. Check PZR PRESS MASTER CTRL Output – LESS THAN 55% - Yes BB PK-455A b. Open INST AIR SPLY CTMT ISO VLV KA HIS-29 		
		CAUTION		
After RH	After RHR Pumps have been stopped, RCS pressure shall be monitored for RHR Pump restart criteria			
	ATC	 <u>22.</u> Check if RHR Pumps should be Stopped: - Yes a. Check RHR Pumps – ANY RUNNING – Yes b. Check RHR System – ALIGNED FOR INJECTION – Yes c. Check RCS Pressure – GREATER THAN 325 PSIG – Yes d. Stop RHR Pumps and place in standby EJ HIS-1 EJ HIS-2 e. Check RCS pressure greater than 325 psig during subsequent recovery actions 		
	ATC 23. Check if RCS Cooldown Should be Stopped: a. Check RCS Temperatures – LESS THAN TARGET TEMPERATURES *Core Exit TCs OR *RCS Hot Leg RTDs			
	BOP	24. Check Ruptured S/G Pressure – STABLE OR INCREASING – Yes		
	ATC	25. Check RCS Subcooling – GREATER THAN 50°F [65°F] – Yes		

Op-Tes	t No.: Dec 2019	9 Scenario No.: 3 Event No.: 6/7/8 Total No Pages 30			
<u>Event Description:</u> S/G 'C' Tube leak grows to 400 gpm SGTR. Turbine fails to trip in both Auto and Manual, MSIV ALL CLOSE pushbuttons work. 'C' ARV opens to 100% on Reactor Trip, closes manually					
Time	Position	Applicant's Actions or Behavior			
	ATC	26. Depressurize RCS Using Normal Spray To Minimize Break Flow and Refill PZR:			
		a. Verify Normal PZR Spray Available. – Yes			
		b. Spray PZR with maximum available spray until any of the following conditions are satisfied:			
		* PZR Level >76% [62%] <u>OR</u>			
		* RCS Subcooling <30F [45F] <u>OR</u>			
		*Both of the following:			
		1) RCS Pressure < Ruptured S/G Pressure			
		2) PZR Level >6% [29%]			
		<u>OR</u>			
		* Both of the Following			
		1) RCS Pressure <300 psig of Ruptured S/G Pressure			
		2) PZR Level >36% [50%]			
		c. Close Normal PZR Spray Valves			
		d. Observe Caution prior to Step 32 and go to step 32.			
		CT3: Commence controlled RCS depressurization to allow for SI termination per EMG E-3 prior to overfilling the ruptured 'C' S/G (90% WR).			
Scenario Termination: After the crew has commenced RCS depressurization and/or at the direction of the Lead Examiner terminate the scenario					
Simulator Operator: FREEZE					

ATTACHMENT 1

Revision: 41A			EMG E-0			
Continuous Use		REACTOR TRIP OR	R SAFETY INJECTION Page 79 of 103	3		
STEP	ACTION/	EXPECTED RESPONSE	RESPONSE NOT OBTAINED			
 F1.	ATTACHMENT F (Page 1 of 13) AUTOMATIC SIGNAL VERIFICATION F1. Check AC Emergency Busses -					
	ENERGIZE					
	o NB01 -	ENERGIZED	o Depress START/RESET pushbutton for EDG A.			
			o KJ HS-8A			
	o NB02 -	ENERGIZED	o Depress START/RESET pushbutton for EDG B.			
			o KJ HS-108A			

Continuous Use

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 81 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 2 of AUTOMATIC SIGNAL V	13)
F2.	Verify Feedwater Isolation:	
	a. Main feedwater pumps - TRIPPED	a. Manually trip Main Feedwater Pumps.
	o Annunciator 00-120A, MFP A TRIP - LIT o Annunciator 00-123A, MFP B TRIP - LIT	tripped, <u>THEN</u> depress
		o FC HS-18A For MFWP A o FC HS-18B For MFWP A
		o <u>IF</u> MFWP B is <u>NOT</u> tripped, <u>THEN</u> depress the following:
		o FC HS-118A For MFWP B o FC HS-118B For MFWP B
	b. Main feedwater reg valves - CLOSED	<pre>b. Manually close valves. * AE FK-510 for S/G A</pre>
	o AE ZL-510 for S/G A o AE ZL-520 for S/G B o AE ZL-530 for S/G C o AE ZL-540 for S/G D	* AE FK-510 for S/G A * AE FK-520 for S/G B * AE FK-530 for S/G C * AE FK-540 for S/G D
	c. Main feedwater reg bypass valves - CLOSED	c. Manually close valves.
	o AE ZL-550 for S/G A o AE ZL-560 for S/G B o AE ZL-570 for S/G C o AE ZL-580 for S/G D	* AE LK-550 for S/G A * AE LK-560 for S/G B * AE LK-570 for S/G C * AE LK-580 for S/G D
	d. Main feedwater isolation valves - CLOSED	_
	o AE HIS-39 for S/G A o AE HIS-40 for S/G B o AE HIS-41 for S/G C o AE HIS-42 for S/G D	 Manually close valves. <u>IF</u> valves can <u>NOT</u> be closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MFIV sub-racks: o ALS-411-1 o ALS-411-2

(Step F2. continued on next page)

Revision: 41A	EMG E-0						
Continuous Use	REACTOR TRIP OR SAFETY INJECTION Page 83 of 103						
STEP ACTION	EXPECTED RESPONSE RESPONSE NOT OBTAINED						
Step F2. (cont	ATTACHMENT F (Page 3 of 13) AUTOMATIC SIGNAL VERIFICATION						
e. Main injec o AE o AE o AE	<pre>feedwater chemical tion valves - CLOSED</pre> e. Perform the following: 1) Manually close valve. 1) Manually close valve. 1) Manually close valve. 1) Manually close valve. 2) <u>IF</u> valve can <u>NOT</u> be closed, <u>THEN</u> locally isolate affected feedline. * AE-V129 for S/G A (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V128 for S/G B (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V131 for S/G C (STEAM ENCLOSURE ROOM SOUTH OF MFIV) * AE-V130 for S/G D (STEAM ENCLOSURE ROOM						
SGBSI LIGHT o Red	SOUTH OF MFIV) ESFAS status panel S section - ALL WHITE S LIT train low train Suttow train Su						

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 85 of 103

STEP	ACTION/EXPECTED RESPONSE		RESPONSE NOT OBTAINED		
ATTACHMENT F (Page 4 of 13) AUTOMATIC SIGNAL VERIFICATION					
F3.	Verify Containment Isolation Phase A:				
	 a. Check ESFAS status panel CISA section - ALL WHITE LIGHTS LIT o Red train o Yellow train 	a.	 Perform the following: 1) <u>IF</u> containment isolation phase A has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment isolation phase A. 0 SB HS-47 o SB HS-48 2) <u>IF</u> any CISA valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT B, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE A. 		

Revision: 41A REACTOR TRIP OR SAFET		EMG E-0
Continuous Use	REACIOR IRIP OR SAFE	Page 87 of 103
STEP ACTION	/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 5 of 1 AUTOMATIC SIGNAL VE	13)
F4. Verify A	FW Pumps Running:	
	motor driven AFW - BOTH RUNNING	a. Manually start pumps. o AL HIS-22A o AL HIS-23A
b. Check	turbine driven AFW	b. Perform the following:
	- RUNNING	 Check if turbine driven AFW pump should be running:
		* At least 2/4 S/G narrow range level channels on 2/4 S/Gs - LESS THAN 23.5%
		OR
		* Loss of NB01 voltage has occurred
		OR
		* Loss of NB02 voltage has occurred
		OR
		* AMSAC actuation
		2) <u>IF</u> turbine driven AFW pump should be running, <u>THEN</u> manually open steam supply valves:
		a) AB HIS-5A
		b) AB HIS-6A
		c) FC HIS-312A

Revisi	on:	41A	EMG E-(EMG E-0
Continuous Use		s Use			Page 89 of 103		
STEP	A	CTION/	EXPECTED RESPONSE	$\left - \right $		RESPONSE NOT	OBTAINED
	ATTACHMENT F (Page 6 of 13) AUTOMATIC SIGNAL VERIFICATION						
F5.	Vei	cify E	CCS Pumps Running:				
	a.	Check	CCPs - BOTH RUNNING		a.	Manually sta	rt pumps.
						o BG HIS-1A o BG HIS-2A	
	b.	Check RUNNI	SI pumps - BOTH		b.	Manually sta	rt pumps.
		ROMNT.	NG			o EM HIS-4 o EM HIS-5	
	с.		RHR pumps - BOTH		c. Manually start pumps.		rt pumps.
	RUNNING				o EJ HIS-1 o EJ HIS-2		
F6.	F6. Verify CCW Alignment:						
	a.		CCW pumps - ONE NG IN EACH TRAIN		a.		rt CCW pumps to establish in each train.
						<pre>o EG HIS-21 for red tr o EG HIS-22 for yellow</pre>	ain or EG HIS-24
	b.	servi Retur:	one pair of CCW ce loop Supply And n Valves for an ting CCW pump - OPEN		b.	Manually ali necessary to flow to serv containment.	establish CCW ice loop and
		* EG	ZL-15 AND EG ZL-53				
		<u>0</u>]	<u>R</u>				
		* EG	ZL-16 AND EG ZL-54				
F7.		eck ES NNING	W Pumps - BOTH		Mar	nually start	pumps.
	1.01					EF HIS-55A EF HIS-56A	

Revision: 41A		EMG E-0					
Continuous Use	REACTOR TRIP OR SAFET	Page 91 of 103					
STEP ACTION	EXPECTED RESPONSE	RESPONSE NOT OBTAINED					
	ATTACHMENT F (Page 7 of 13) AUTOMATIC SIGNAL VERIFICATION						
	ntainment Fan Coolers G IN SLOW SPEED	Perform the following for each Containment Cooler Fan that is still running in Fast or is not running:					
		a. Manually stop ANY Containment Cooler Fans running in fast.					
		* GN HIS-5 For Cooler 1A					
		* GN HIS-9 For Cooler 1B					
		* GN HIS-13 For Cooler 1C					
		* GN HIS-17 For Cooler 1D					
		b. Place Containment Cooler Fan Speed Selector switches in Slow.					
		* GN HS-5 for cooler 1A					
		* GN HS-9 for cooler 1B					
		* GN HS-13 for cooler 1C					
		* GN HS-17 for cooler 1D					
		c. Manually start containment cooler fans.					
		* GN HIS-5 for cooler 1A					
		* GN HIS-9 for cooler 1B					
		* GN HIS-13 for cooler 1C					
		* GN HIS-17 for cooler 1D					

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 93 of 103

STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED ATTACHMENT F (Page 8 of 13) AUTOMATIC SIGNAL VERIFICATION F9. Verify Containment Purge Isolation: a. Perform the following: a. Check ESFAS status panel CPIS section - ALL WHITE LIGHTS LIT 1) <u>IF</u> containment purge isolation has NOT o Red train actuated, THEN manually o Yellow train actuate containment purge isolation. o SA HS-11 o SA HS-15 2) IF any CPIS component NOT properly aligned, THEN manually align component. 3) IF component(s) can NOT be manually aligned, THEN locally isolate instrument air to affected containment penetration. Refer to ATTACHMENT C, VALVES CLOSED BY CONTAINMENT PURGE ISOLATION SIGNAL.

Revision: 41AEMG E-0Continuous UseREACTOR TRIP OR SAFETY INJECTIONPage 95 of 1							
	evision: 41A	REACTOR TRIP OR SA		- 0			
	ontinuous Use			103			
STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED	TEP ACTION	I/EXPECTED RESPONSE	RESPONSE NOT OBTAINED				
ATTACHMENT F (Page 9 of 13) AUTOMATIC SIGNAL VERIFICATION F10. Verify Both Trains Of Control	(Page 9 of 13) AUTOMATIC SIGNAL VERIFICATION						
Room Ventilation Isolation: a. Check ESFAS status panel CRVIS section - ALL WHITE LIGHTS LIT o Red train o Yellow train a. Perform the following: b. Red train o Yellow train a. Perform the following: a. Perform the following: a. Perform the following: b. Red train o Yellow train a. Perform the following: b. Red train o Yellow train b. Red train o Yellow train c. Yellow train c. Yellow train c. Yellow train c. Yellow train b. Yellow train c. SA HS-9 o SA HS-13 c. J. JF any CRVIS componen NOT properly aligned, THEN manually align associated component. c. J. JF neither train of CRVIS is in service, THEN establish one in service train of CRVI using SYS GK-122, MANUAL CRVIS LINE-UP. 4) IF only one train of CRVIS LINE-UP. 4) IF only one train of SYS GK-122, MANUAL CRVIS LINE-UP.	a. Check CRVI LIGH o Red	k ESFAS status panel S section - ALL WHITE IS LIT d train	 <u>IF</u> control room ventilation isolati has <u>NOT</u> actuated, <u>I</u> manually actuate control room ventilation isolati o SA HS-9 o SA HS-13 <u>IF</u> any CRVIS comport <u>NOT</u> properly aligned <u>THEN</u> manually align associated componer <u>IF</u> neither train of CRVIS is in service <u>THEN</u> establish one service train of CF using SYS GK-122, MANUAL CRVIS LINE-U <u>IF</u> only one train of CRVIS can be placed service, <u>THEN</u> withi minutes (76.5 minut control room and 13 minutes local operator), isolate of service train us SYS GK-122, MANUAL 	on THEN On. on. ent ed, in VIS JP. of in n 90 ces 3.5 out			

door - CLOSED

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 97 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED			
	ATTACHMENT F (Page 10 of 13) AUTOMATIC SIGNAL VERIFICATION				
F11.		Verify steamline isolation:			
	a. Check containment pressure - HAS REMAINED LESS THAN 17 PSIG	 If any main steamline isolation valve is <u>NOT</u> closed, <u>THEN</u> perform the following: 			
	0 GN PR-934	a) Close main steamline isolation valves.			
	 b. Check either condition below - SATISFIED: * Low steamline pressure SI - NOT BLOCKED <u>AND</u> steamline pressure - HAS REMAINED GREATER THAN 615 PSIG <u>OR</u> * Low steamline pressure SI - BLOCKED <u>AND</u> steamline pressure rate - HAS REMAINED LESS THAN 100 PSI/50 SEC 	<pre>isolation valves. * AB HS-79 * AB HS-80 b) IF any MSIV is still <u>NOT</u> closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MSIV sub-rack: 0 ALS-411-1 0 ALS-411-2 2. Check ESFAS status panel SLIS section - ALL WHITE LIGHTS LIT 0 Red Train 0 Yellow Train</pre>			
		3. <u>IF</u> any SLIS valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected steamline. Refer to ATTACHMENT D, VALVES CLOSED BY STEAMLINE ISOLATION SIGNAL.			

Rev	is	ion	:	41A

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 99 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHME (Page 11 c AUTOMATIC SIGNAL	of 13)
F <u>12.</u>	Verify Containment Spray Not	Perform the following:
	Required:	1. Stop all RCPs.
	 a. Containment pressure - HAS REMAINED LESS THAN 27 PSIG: o Annunciator 00-059A, CSAS - NOT LIT 	 <u>IF</u> containment spray has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment spray.
	o Annunciator 00-059B, CISB - NOT LIT o GN PR-934	o SB HS-43 <u>AND</u> SB HS-45 o SB HS-44 <u>AND</u> SB HS-46
		3. Check ESFAS status panel CSAS section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		 <u>IF</u> any CSAS component <u>NOT</u> properly aligned, <u>THEN</u> manually align associated component.
		5. Check ESFAS status panel CISB section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		6. <u>IF</u> any CISB valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT E, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE B.

Revision: 41A REACTOR TRIP OR SAF			EMG E-0			
Continuous Use					ge 101 of 103	
STEP	ACTION/EXPECTED RESPONSE			RESPONSE NOT OF	BTAINED	
ATTACHMENT F (Page 12 of 13) AUTOMATIC SIGNAL VERIFICATION						
F13. Verify ECCS Flow:						
	Pumps Tank INDIC o EM	Centrifugal Charging To Boron Injection Flow meters - FLOW ATED FI-917A FI-917B	a.	1) <u>IF</u> BIT valv	res have <u>NOT</u> by operator <u>N</u> manually and align res are perator	
		RCS pressure - LESS 1725 PSIG	b.	Go to Step F14		
	Flow INDIC	SI Pump Discharge meters - FLOW ATED FI-918	c.	Manually start align valves.	pumps and	
		FI-922				
		RCS pressure - LESS 325 PSIG	d.	Go to Step F14		
	Injec	RHR TO Accumulator tion Loop Flow meters W INDICATED	e.	Manually start align valves.	pumps and	
		FI-618 FI-619				
F14.	Verify A ALIGNED:				ned, <u>THEN</u>	
		ESFAS status panel section - ALL WHITE S LIT	manually align associate component to establish desired AFAS lineup.		blish	
	statu	white train ESFAS s panel AFAS section WHITE LIGHTS LIT				

Revi	si	on:	41A
		O 11 •	I I

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 103 of 103

CONCIN	uous ose	rage 105 OI 105
STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 13 of AUTOMATIC SIGNAL VI	13)
F15.	Verify SI Valves - PROPERLY ALIGNED:	<u>IF</u> any SIS section component <u>NOT</u> properly aligned, <u>THEN</u>
	a. Check ESFAS status panel SIS section - SYSTEM LEVEL WHITE LIGHTS ALL LIT	manually align associated component to establish proper SIS lineup.
	o Red train o Yellow train	
F16.	Check If NCP Should Be Stopped:	
	a. CCPs - ANY RUNNING	a. Go to Step F17
	b. Stop NCP	
	o BG HIS-3	
F17.	Check FBIS Is <u>NOT</u> ACTUATED:	Perform the following:
	o Annunciator 00-062D, FBIS - <u>NOT</u> LIT	a. Ensure NO movement of irradiated fuel assemblies in the fuel building.
		b. Bypass GG RE-27 and GG RE-28.
		c. Reset FBIS:
		o SA HS-10
		o SA HS-14
		d. Ensure FUEL BLD EMERG EXH DAMPERS are closed:
		o GG HIS-40
		o GG HIS-43
F18.	Return To Procedure And Step In Effect	
	-END-	

Facility:	Facility: _Wolf Creek Scenario No.: _4 Op-Test No.: December 2019 Examiners: Operators:						cember 2	<u>2019</u>	
Examine	ers:		Ор	erators:					
	Initial Conditions: <u>100% Power, MOL, Red Train In Service, Letdown is at 120 gpm, 'B' MD AFW</u> Pump is out of service.								
Turnover: The unit is operating at 100% power, MOL, Red Train is in Service, 'B' MD AFW Pump was									
taken out of service 12 hours ago; LCO 3.7.5, Condition B is entered.									
	Critical Tasks: <u>CT-1 Manually Start 'B' ESW Pump prior to loaded 'B' EDG Tripping on high Jacket</u> Water Temperature at 195°F. CT-2 Commence Emergency Boration before positive IR SUR develops								
CT-3 Re	store Seco	ndary Heat Sink us n 3 of 4 S/G levels	sing NS AFW F	Pump prior to bei	ng required				
Event	Malf.	Event Type*			Event				
No.	No.				scription	h ann al	faile LUC		
1		(ATC/CRS) Tech Specs	BB LI-459, Upper Selected PZR Level Channel fails HIGH. OFN SB-008, ATT J LCO 3.3.1, Functions 9, CONDs A, M				эΠ.		
2		I (BOP/CRS)	AB FT-543, OFN SB-008	D' S/G Steam Fl	low Instrum	ent fails	s LOW		
3		C	XNB02 Failu	ire which results	in AC Eme	rgency	Bus NB	02 UV.	
3		(ALL) Tech Specs	LCO 3.8.1, C						
4		C (ATC/CRS)	ALR 00-0210	np fails to Auto S C, Step 6	start on S/D	Seque	encer		
5		M (All)	Loss of Off S EMG E-0, EI	MG ES-02					
6		C (ATC/CRS)	EMG E-0, St	Rods fail to fully tep 1, EMG ES-0	2, Step 12.				
7		C (None)	TDAFW Pun	np trips and canr	not be resta	rted			
8		С	Blowdown C (BM01/2/3/4	ontainment Isola	tion valves	fail to c	close		
		(BOP/CRS) C	ÈMG FR-H1		Overcurrent	ł			
9		(All)	EMG FR-H1	, SYS AP-122		•			
*	(N)ormal,	(R)eactivity, (I)nstru	ument, (C)omp	oonent, (M)ajor	r	-			
Targ		ve Attributes per Scer Section D.5.d)	ario (See	Actual Attributes	ES-301-5	CRS	ATC	BOP	
1. Ma	alfunctions after	er EOP entry (1–2)		3	Rx	0	0	0	
2. Ab	normal events	8 (2–4)		4	Nor	0	0	0	
3. Ma	ajor transients	(1–2)		1	I/C	7	5	4	
4. EC	Ps entered/re	equiring substantive act	ions (1–2)	2	Maj	1	1	1	
	try into a cont 1 per scenario	ingency EOP with subs o set)	tantive actions	1	TS	2	0	0	
6. Pr	eidentified crit	ical tasks (<u>></u> 2)		3					

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT1: Manually start 'B' ESW pump before loaded 'B' EDG trips on High Jacket Water Temperature at 195°F.	The onsite standby power system includes the Class 1E ac and dc power for equipment used to maintain a cold shutdown of the plant and to mitigate the consequences of a DBA. Not starting the ESW pumps in a timely manner could result in the loss of the EDG.	With the EDG running loaded: Green light lit on handswitch * EF HIS-56A No indicated ESW flow on * EF FI-54 No indicated ESW pressure on *EF PI-2	On Panel RL019, Manipulation of EF HIS-56A to Run Position.	Red light lit on handswitch * EF HIS-56A Indicated ESW flow on * EF FI-54 Indicated ESW pressure on *EF PI-2
CT2: Commence Emergency Boration due to more than one control rod stuck out before Positive IR SUR develops causing the crew to transition to EMG FR-S1 on an ORANGE path challenge to subcriticality CSF.	The shutdown reactivity margin must be made up through emergency boration to account for the reactivity worth of the stuck rods. Failure to emergency borate could cause an unnecessary challenge to Subcriticality CSF.	When Bus NB01 is reenergized power to DRPI panel is restored - Rods F8, B6, K10 and M4 are not on bottom.	On Panel RL001, manipulates control as necessary to start at least one BAT Pump: * BG HIS-5A <u>OR</u> * BG HIS-6A <u>AND</u> Open * BG HIS-8104	Red lights lit for operated components: BG HIS-5A BG HIS-6A BG HIS-8104 Indicated Flow >30 gpm on BG FI-121
CT3: Restore AFW Flow >270,000 Ibm/hr using NSAFW Pump per EMG FR-H1 before 3 of 4 S/G levels degrade to <12% [28%] WR level.	Establishing at least 270,000 lbm/hr feedwater flow rate to the S/Gs before RCS bleed and feed is initiated to restore secondary heat sink and ensures the core will remain covered and adequately cooled. An otherwise preventable Bleed and Feed causes CTMT contamination and equipment damage due to rupturing PRT disk.	No Operating AFW Pumps Indicated flow at 0 Ibm/hr on: *AL FI-2A *AL FI-3A *AL FI-3A *AL FI-4A *AL FI-1A	On panel RL005, Manipulation of AFW REG VLV CTRL *AL HK-8A *AL HK-10A *AL HK-12A *AL HK-6A	On panel RL005, Combined Indicated AFW TO SG FLOW >270,000 Ibm/hr *AL FI 2A *AL FI-3A *AL FI-3A *AL FI-4A *AL FI-1A

Note: Causing an unnecessary plant trip or ESF actuation may constitute a Critical Task failure. Actions taken by the applicant(s) will be validated using the methodology for critical tasks in Appendix D to NUREG-1021.

Appendix D

Scenario Outline

SCENARIO # 4 NARRATIVE

Turnover: The Unit is operating at 100% power. Red Train is in service. 'B' MD AFW Pump was removed from service 12 hours ago for emergent work. LCO 3.7.5, Condition B is entered.

Event 1: BB LI-459, Upper Selected PZR Level Channel fails HIGH. Annunciator 032A will actuate for high PZR Level and charging flow will lower, causing actual PZR level to lower. The crew will address using OFN SB-008, ATTACHMENT J to remove the failed channel from service and restoring automatic control. Once the CRS has determined applicable Technical Specifications, the next event will start as directed by the Lead Examiner.

Event 2: AB FT-543, 'D' S/G Steam Flow instrument fails LOW. MCB Annunciator 111C will actuate due to feed/steam flow mismatch. The BOP will take manual control of AE FK-540, 'D' FRV to match steam and feed flows as a Memory Action Step. The crew will address the instrument failure using OFN SB-008, ATT A. Once AE FK-540 is restored to Automatic, the next event will start at the direction of the Lead Examiner.

Event 3: NB02 Bus Degraded Voltage leading to power interruption and S/D Sequencer Actuation. NB02 bus voltage drops to 3755v due to a fault on XNB02 transformer. Annunciator 022E will alarm once voltage is <3760v for 25 seconds. The crew will reference ALR 00-022E and in 94 seconds, the normal feeder breaker will trip open as designed. 'B' EDG will start and load. The crew will address the interruption of power to NB02 per ALR 00-21C and OFN NB-030, ATT B, including reducing turbine loading to maintain reactor power ≤99% due to AFAS-T Actuation. Once the crew has stabilized plant conditions, determined applicable Technical Specifications, and secured the TDAFW Pump, the major event will start at the direction of the Lead Examiner.

Event 4: 'B' **ESW Pump fails to Auto Start on the S/D Sequencer.** While responding to momentary loss of NB02, the ATC will note the failure of the 'B' ESW pump to auto start and manually start the pump within ~3 minutes of the EDG starting and loading to prevent the EDG from tripping on high temperature. **CT1**: Manually start 'B' ESW pump before loaded 'B' EDG trips on High Jacket Water Temperature at 195°F.

Event 5: Offsite Power is Lost. The reactor will trip and the crew will perform EMG E-0 immediate actions and transition to EMG ES-02. The next four post-trip events will also be addressed by the Crew.

Event 6: Four Control Rods fail to fully insert. The ATC, while performing EMG E-0 Immediate Actions will note the four control rods not fully inserted and manually trip the Reactor per Step 1 RNO using SB HS-1. EMG ES-02, Step 12 directs the crew to Emergency Borate per OFN BG-009 for this condition.

CT 2: Commence Emergency Boration due to more than one control rod stuck out before Positive IR SUR develops causing the crew to transition to EMG FR-S1 on an ORANGE path challenge to subcriticality CSF.

Event 7: TD AFW Pump trips and cannot be restarted. The BOP will identify the TD AFW Pump tripped. Any attempts to start manually will be unsuccessful.

Event 8: SGBSIS fails to actuate in Auto. Steam Generator Blowdown Containment Isolation Valves fail to close on S/G LoLo level immediately following the reactor trip. The crew may or may not notice the failure since there is no SIS. The crew will exit EMG E-0 without performing Attachment F, which would have prompted the crew to verify SGBSIS actuation. Both EMG ES-02, Step 1 RNO and EMG FR-H1, Step 3a directs the crew to manually close the four valves that failed to Auto Close. While not specifically a critical task, failure to manually close these valves will contribute to S/G dry-out conditions, requiring the crew to bleed and feed when WR S/G levels degrade to <12% [28%].

Appendix D

Scenario Outline

Event 9: 'A' MD AFW Pump trips on overcurrent: After the crew has commenced Emergency Boration as required per EMG ES-02, Step 12, and/or at the direction of the Lead Examiner, the 'A' MDAFW Pump will trip on overcurrent causing the crew to transition to EMG FR-H1.

The crew will be successful restoring aux feed water flow using the NS AFW Pump per SYS AP-122, NON-SAFETY AUX FEED PUMP OPERATION.

CT3: Restore AFW Flow >270,000 lbm/hr using NSAFW Pump per EMG FR-H1 before 3 of 4 S/G levels degrade to <12% [28%] WR level.

The scenario is complete when the crew has restored the Secondary Heat Sink per EMG FR-H1, Step 8 and/or at the discretion of the Lead Examiner.

Appendix D

Scenario Outline

SIMULATOR SCENARIO FILES

;2019 ILO NRC Exam, Scenario 4 (IC 304)

;Initial Conditions – IC29, 100% Red Train in Service, 'B' MDAFW Pump OOS. (LCO 3.7.5 COND B) scn SimGroup\Tag B MDAFW

;Event 1 – Key 1 – BB LI-459, Upper Selected PZR Level Channel fails HIGH (ATC/CRS, Tech Specs) ICM trBBLT0459 t:3 f:468.2 r:30 k:1

;Event 2 – Key 2 – AB FT-543, D S/G Steam Flow fails LOW (BOP/CRS) ICM trABFT0543.cmf t:3 k:2 r:30 f:0

;Event 3 – Key 3 – Degraded Bus Voltage on NB02 (XNB02 Failure) (Reactivity/CRS–TS) IMF mNB05B k:3 i:4158.69 f:3755 {bkNB00209.state=0} DMF mNB05B

;**Event 4** – 'B' ESW Pump fails to autostart (ATC - CT) IMF mEF05B

;Event 5 – Key 5 – Loss Of Offsite Power (Major) IMF mSY01 K:5

;Event 6 – Control Rods F14, P8, K8, and H8 fail to fully insert on Reactor Trip. (ATC) {Key[5]} IMF mSF12F14 f:MECH {Key[5]} IMF mSF12P8 f:MECH {Key[5]} IMF mSF12H8 f:MECH {Key[5]} IMF mSF12K8 f:MECH

;Event 7 – TDAFW Pump fails to Restart on Loss of Power, both Auto and Manual (Scenario) {Key[5]} IMF mAL01 {Key[5]} IMF mAL02

;Event 8 – SGBSIS Fails to Actuate (BOP – Not CT) IMF mSA27BM01 IMF mSA27BM02 IMF mSA27BM03 IMF mSA27BM04

;**Event 9 – Key 9** - 'A' MDAFW Pump Trips on overcurrent (Scenario) ICM bkrDPAL01A t:1 k:9

;Local Action – **Key 10** – to start NS AFW Pump per SYS AF-122 {Key[10]} scn SimGroup\Start PAP01-SBO DGs Standby

;End

Appendix D

Scenario Outline

Booth Instructions

Ensure NRC Exam Security Established per AIF 30B-015-09, and AIF 30B-015-18

Ensure the following procedures are available, free of markings and are the most recent revision in Curator (10/31/19):

- □ SYS AP-122, NON-SAFETY AUX FEED PUMP OPERATION (Rev 13)
- SYS AL-120, MOTOR DRIVEN OR TURBINE DRIVEN AFW PUMP OPERATIONS (Rev 55)
- □ ALR 00-021C, NF039B S/D SEQ ACTUATED (Rev 17)
- □ ALR 00-022E, NB02 BUS DGRD VOLT (Rev 7)
- □ ALR 00-111C, SG D FLOW MISMATCH (Rev 10A)
- OFN BG-009, EMERGENCY BORATION (Rev 27)
- □ OFN SB-008, INSTRUMENT MALFUNCTIONS (Rev 49)
- **OFN SB-008, ATTACHMENT A, STEAM FLOW CHANNEL MALFUNCTION (Rev 49)**
- OFN SB-008, ATTACHMENT J, PZR LEVEL MALFUNCTION (Rev 49)
- □ OFN NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB02) (Rev 38)
- □ EMG E-0, REACTOR TRIP OR SAFETY INJECTION (Rev 41A)
- **EMG ES-02, REACTOR TRIP RESPONSE (Rev 38)**
- □ EMG FR-H1, RESPONSE TO LOSS OF SECONDARY HEAT SINK (Rev 35)

NOTE: All events are loaded into snap **IC304**

Ensure malfunctions, including severity levels match scenario.

Ensure all meters, lamps, bistables and annunciators are correct for the initial setup. <u>Blue Placard is on</u> the 'B' CCP. 'B' MDAFW Pump handswitch, AL HIS-22A, in PTL with Caution Tag affixed.

Ensure soft panel display in back is set to <u>RP312 RCP Vibration</u> on left screen and <u>AMSAC</u> on right screen.

Ensure no discernable history from RM11, Ovation screens, paper trend recorders, etc. **Ensure** all laminated brief sheets, foldout pages, E plan boards are wiped clean.

Ensure all follow-up buttons are removed from the boards and trash cans and recycle bins are free of any potential exam material.

Ensure communications are established with the lead examiner, fresh batteries, radio check sat.

Critical Parameter Data to be collected:

- □ **IR SUR (SE NI-35D, 36D)** The crew must commence Emergency Boration per EMG ES-02, Step 12 prior to being required to transition to EMG FR-S1 on an ORANGE path due to positive SUR.
- □ <u>S/G WR Levels.</u> The crew must remove heat input to the RCS and restore secondary heat sink prior to WR S/G levels degrading to 12% [28%].
- □ The crew must also manually start 'B' ESW Pump prior to loaded 'B' EDG tripping on high temperature.

Ensure Horns are ON and machine is in RUN

- □ Insert Key 1 for Event 1 (BB LI-459, Upper Selected PZR Level Channel fails HIGH).
- □ **Insert Key 2** for Event 2 (AB FT-543, 'D' S/G Steam Flow Instrument fails LOW).
- Insert Key 3 for Events 3 and 4 (NB02 bus UV due to XNB02 failure, and failure of 'B' ESW Pump to auto start)
- □ **Insert Key 5** for First Major Event (LOOP, four control rods fail to fully insert, TDAFW Pump fails to re-start, and Blowdown Isolation Fails to Auto Actuate)

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 4, Rev 5

Append	dix D
--------	-------

Scenario Outline

□ Insert Key 9 for Second Major Event ('A' MD AFW pump trips on overcurrent)

When directed to locally start NSAFW Pump, Insert Key 10.

Op-Tes	t No.: Dec 2019	Scenario No.: 4 Event No.: 1 Total No Pages 24				
Event D	escription: BB L	I-459, Upper selected PZR Level Channel fails HIGH				
Time	Position	Applicant's Actions or Behavior				
Simulato	or Operator: Inse	ert Key 1 at direction of Lead Examiner.				
Diagnostics: BB LI-459A indicates 100%, Annunciators 32A alarms, BG FK-462 trends to 0% output, Charging flow trends down to minimum. Actual level lowers.						
Annunci	iators: 032A, 042	A, 083C				
	Examiner Note: Crew may decide to energize PZR heaters and adjust Master Pressure Controller output to crack open the spray valves for precise RCS pressure control					
	CREW	Recognizes alarms and PZR level trends, diagnosis failure of Pressurizer Level instrument, enters ALR				
	CRS	Reviews ALR or enters OFN SB-008 directly				
		ALR 00-032A, PZR LEV HI				
	ATC	1. Check PZR Level >70%				
		o BB LI-459A - Yes				
	ATC	 Check for Instrument Failure: a. Check PZR Level Channels – WITHIN 6% OF EACH OTHER – No 				
		RNO Perform the following:				
	1. <u>IF</u> failed pressurizer level channel is selected on PZR LEV CTRL SEL switch, THEN select alternative level channel.					
		• BB LS-459D – L461 over L460 position				
		2. Go to OFN SB-008, INSTRUMENT MALFUNCTIONS, Step 1				
		OFN SB-008, INSTRUMENT MALFUNCTIONS				
	BOP	 Check for Malfunction: Check if Reactor Coolant System Instrument Channel Or Controller is Malfunctioning:				

Op-Tes	t No.: Dec 2019	Scenario No.: 4 Event No.: 1 Total No Pages 24			
Event D	escription: BB L	I-459, Upper selected PZR Level Channel fails HIGH			
Time	Position	Applicant's Actions or Behavior			
ATTACHMENT J, PZR LEVEL CHANNEL MALFUNCTION					
	ATC	 J1. Identify Failed Instrument Channel: a. Compare PZR Level indications to confirm a pressurizer level channel failure: BB LI-459A – Yes BB LI-456A BB LI-461 			
	ATC	 J2. Ensure Alternate Pressurizer Level Channel On PZR LEV CTRL SEL Switch is Selected. o BB LS-459D 			
	ATC	J3. Check Failed Pressurizer Level Channel Failed LOW – No			
		RNO Go to step J8			
	ATC	J8. Monitor Pressurizer Level Response To Ensure Proper Control			
	ATC	J9. ENSURE Failed PZR Level Channel – NOT USED FOR RECORDER. – No			
		RNO select alternate pressurizer level channel as input to recorder			
	CRS	 J10. Monitor the Following Technical Specification LCOs And Comply With Action Statements, As Appropriate: LCO 3.3.1, Function 9 LCO 3.3.4, Function 12 – <i>Minimum met</i> LCO 3.3.3, Function 11 – <i>Minimum met</i> 			
		Enters LCO 3.3.1, Function 9, Cond A – Immediate and M – 72 hrs			
	I	NOTES			
	en the last bistable cation will drop to	e for the affected instrument is tripped, the output to that control board			
inclu	iding a determinat	tripping bistables, I&C should troubleshoot and obtain as found information tion of which SPS train is affected. M-767-00319, Tables 6-3 and 6-4 may SSPS train determination			
o Avoi	d introduction of 2	2/3 high pressurizer level signals, which can initiate a Rx Trip.			

Time	Position		A	oplicant's A	Actions or Bel	navior		
	BOP							
			Appropriate		rip / Safeguards	s Bistab	les for	Failed
		FAILED CHANNEL	BISTABLE	TEST SWITCH	PROTECTION SET CABINET	FRAME	CARD	SWITCH
		L-459	LB-459A	LS-459A	1	08	47	BS1
		L-460	LB-460A	LS-460A	2	08	47	BS1
		L-461	LB-461A	LS-461A	3	08	44	BS1
Simulat	or Operator: IF (contacted as	WWM, ackr	owledge re	quests. IF cont	acted as	s Call S	Supt.,
	or Operator: IF o				· _	acted as	s Call S	Supt.,
			WWM, ackr		· _	acted as	s Call s	Supt.,
	edge status.	J12. Requi	est I&C to re	epair failed on the second sec	· _			
	edge status. CRS	J12. Requi	est I&C to re w Attachme ation Requir	epair failed of the second sec	channel.	d Remo	te Shu	
	edge status. CRS CRS	J12. Requi	est I&C to re w Attachme ation Requir	epair failed of the second sec	channel. st Accident An	d Remo	te Shu	

Op Test	No.: Dec 2019	Scenario No.: 4 Event No.: 2 Total No Pages 24				
Event [Description: Al	B FT-543, 'D' S/G Steam Flow Instrument fails LOW				
Time	Position	Applicant's Actions or Behavior				
Simulator Operator: Insert Key 2 at the lead examiners direction						
Diagnostics: 'D' S/G FWRV will start closing, Level in D S/G lowers						
Annuncia	ators: 111C & 11	1B				
	CREW	Recognizes alarm and 'D' S/G level and FRV position changing, diagnoses				
		problem with steam flow instrumentation				
		ator 111B, SG D LEV DEV, may also actuate depending on timeliness of				
		111B mitigating actions to take manual control of FWRV AE FK-540 and				
initial fee		re the same. Crew may take manual control of MFPs in order to stabilize				
	CRS	Enters and directs ALR 00-111D or OFN SB-008				
	<u>1</u>	ALR 00-111C SG D FLOW MISMATCH				
		NOTE:				
		NOTE.				
Steps 1	through 3 are Me	mory Action Steps				
	BOP	 Check Difference Between Steam Generator D Steam Flow and Feed Flow >0.7 MPPH 				
		 AE FI-541A For Feed Flow – Yes 				
	BOP	2. Check For Instruments Operating Properly.				
		 SG D Controlling Feedwater Flow Channel – WITHIN 0.2 MPPH 				
		OF OTHER CHANNEL – No				
		RNO: Perform the Following:				
		a. Place AE FK-540 in Manual.				
		b. Adjust AE FK-540, as necessary, to establish S/G level at program.				
		c. Go to OFN SB-008, INSTRUMENT MALFUNCTIONS, Step 1.				
		OFN SB-008, INSTRUMENT MALFUNCTIONS				
	CRS	1. Check for Malfunction:				
		 Check if Secondary System Instrument Channel is Malfunctioning: 				
		a. Perform appropriate attachment for malfunctioning channel				
		from table below:				
		Steam Flow (AB) F-512, F-513, F-522 F-523, F-532, F-533 F-542, F-543 ATTACHMENT A				

Appen	dix D
-------	-------

Op Test	No.: Dec 2019	Scenario No.: 4	Event No.: 2	Total No Pages 24			
<u>Event D</u>	escription: A	AB FT-543, 'D' S/G Stea	m Flow Instrument fails L	-OW			
Time	Position	A	pplicant's Actions or Beh	avior			
	ATTACHMENT A, STEAM FLOW CHANNEL MALFUNCTION						
		CAU	JTION				
	Steam flow is an input to the thermal power program. A failed steam flow channel could cause the thermal power program to be inaccurate.						
failed	 NOTES The pressure compensation channel supplying the steam flow channel may be the reason for a failed steam flow indications. 						
o Step	S AT ITTOUGH AS 2	are Memory Action Steps	5.				
	вор	A1. Identify Failed Ste o Compare stea failure o AB FI 543	m flow indications to confirm	n a steam flow channel			
	BOP	A2. Check if Failed St CHANNEL SEL S o AB FS-542C		ed on SG STEAM FLOW			
		<u>N</u>	OTE				
A slight step change on the Feedwater Reg Valve controllers output, could occur during the transfer between auto and manual							
	BOP	*AE FK-540 b. Adjust affected	Reg Valves in Control: SG MFW REG VLV CTRL - S/G MFW REG VLV CTRL enerator level at program:				
	вор	A4. Select Alternate S CHANNEL SEL S *AB FS-542C	Steam Flow Channel on SG witch:	STEAM FLOW			

Op Test	No.: Dec 2019	Scenario No.: 4	Event No.: 2	Total No Pages 24		
<u>Event D</u>	Event Description: AB FT-543, 'D' S/G Steam Flow Instrument fails LOW					
	BOP	A5. Check S/G Pressu	ire Channels – OPERATIO	N NORMAL – Yes		
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.					
	CRS	A6. Request I&C To R	epair Failed Channel.			
	BOP	A7. Check Steam Flow CHANNEL SELECTE	v Channel Failure – REPAI D – Yes	RED OR ALTERNATE		
	BOP	A8. Restore affected S	6/G MFW REG VLV CTRL	To – AUTO		
	CRS	A9. Return to Procedu	re and Step In Effect.			
Event Te		the crew has returned	AE FK-540 to Auto and/or a	at the direction of the Lead		
Simulato	or Operator: Inse	ert Key 3 at direction of	the Lead Examiner			

Op-Tes	t No.: Dec 201	9 Scenario No.: 4 Event No.: 3/4 Total No Pages 24					
Event D	Event Description: AC EMERGENCY BUS NB02 UV due to XNB02 failure						
Time	Position	Applicant's Actions or Behavior					
Simulat	Simulator Operator: Insert Key 3 at direction of Lead Examiner.						
Diagnostics : Multiple annunciators. 94 Seconds after alarm Bus NB02 normal feeder trips,							
TDAFW pump starts. EDG 'B' starts, reenergized bus NB02							
	Examiner Note: The voltage has to be low for 25 seconds before annunciator alarms. Annunciators: 022E & 021C						
Annune	CRS	Enters and directs ALR 00-022E					
		ALR 00-022E, NB02 BUS DGRD VOLT					
		<u>NOTE</u>					
	If NB02 bus voltage is NOT restored to greater than the Degraded Voltage Relay (DVR) reset value of 3825.15 volts within 94 seconds of receipt of this annunciator, the normal and alternate supply breakers will trip.						
	ATC	 Check Bus NB02 Voltage - Less Than 3760 Volts. NB EI-2 - Yes 					
	ATC	 2. Check Switchyard Voltage: a. Check BKR SEL Switch – NOT IN OFF - Yes MA HS-2 b. Check SWITCHYARD VOLT NORMAL - Yes MA EI-9 					
ATC							
Fyamin	er Note: The po	Restore NB02 Voltage to normal. rmal feeder breaker opens 94 seconds after the alarm, NB02 will deenergize					
		NOT reenergize bus NB02 because NB02 Bus will be locked out					

Op-Tes	t No.: Dec 201	9 Scenario No.: 4	Event No.: 3/4	Total No Pages 24	
Event D	Event Description: AC EMERGENCY BUS NB02 UV due to XNB02 failure				
Time	Position	Appli	cant's Actions or Beha	ivior	
		ALR 00-021C, NB039B	S/D SEQ ACTUATED		
	ATC	1. Check Reactor – CRITIC Yes	AL PRIOR TO S/D SEQ	UENCER ACTUATION -	
	ATC	2. Check if Reactor – TRIP o Rod Bottom Lights o Reactor Trip and B			
		RNO Go to step 4			
	BOP	4. Check reactor Power – L	ESS THAN or EQUAL to	o 99% - No	
		RNO Perform the following: a. Ensure reactor powe	r less than or equal to 99	9%	
		*BOP will perform "Fa during pre-shift brief	st load Decrease" of 3	0 MW as discussed	
		NOT	<u>E</u>		
While train B shutdown sequencer is energized, automatic start signals for Component Cooling Water Pump B, Component Cooling water Pump D, Control Room A/C Unit B and Class IE Equipment A/C Unit B are blocked.					
	ATC	o NB HIS-4	ncer Actuation Signal – \ Supply Breaker NB0209 e Supply Breaker NB021	OPEN	
		 Bus NB02 Emerger NE HIS-26 	ncy Supply Breaker NB0	211 – CLOSED	

On-Tes	t No · Dec 201	9 Scenario No.: 4 Event No.: 3/4 Total No Pages 24
		EMERGENCY BUS NB02 UV due to XNB02 failure
<u> </u>	<u>Coulbrierr</u>	
Time	Position	Applicant's Actions or Behavior
	BOP	 6. Verify the following loads started: CCP B CCW Pump B or CCW Pump D ESW Pump B - No RNO When shutdown sequencer has timed out (≥60 sec), THEN manually start loads with times as referenced in 2.3. CT1: Manually start 'B' ESW pump before loaded 'B' EDG trips on High Jacket Water Temperature at 195°F. Control Room A/C Unit B Class 1E Equipment A/C Unit B
		 Motor Driven AFW Pump B Containment Cooling Fan B Containment Cooling Fan D
	BOP	 7. Establish Train A Essential Service Water a. Start ESW Pump A EF HIS-55A b. Open ESW to Ultimate Heat Sink Valve EF HIS-37 – OPEN c. Close ESW to Service Water Isolation Valves EF HIS-39 – CLOSED EF HIS-41 – CLOSED d. Close ESW service water cross connect valves. EF HIS-23 – CLOSED EF HIS-25 - CLOSED EF HIS-25 - CLOSED
	CRS	 8. Refer to Technical Specifications 3.8.9 and 3.8.10 Enters LCO 3.8.1, Cond A for loss of one off site circuit, 1 hour <u>Examiner Note:</u> Tech Spec 3.8.9, Condition B, 8 hours and Tech Spec 3.7.5, Condition B, 72 hours should be referenced and would be logged as entered and exited. Once the EDG is supplying NB02 3.8.9 can be exited, once the TDAFWP is returned to standby 3.7.5 can be exited
	ledge status.	contacted as WWM, acknowledge requests. <u>IF</u> contacted as Call Supt.,
	CRS	9. Go To OFN NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB01), Step 1.

Op-Tes	t No.: Dec 201	9 Scenario No.: 4 Event No.: 3/4 Total No Pages 24	
Event D	Event Description: AC EMERGENCY BUS NB02 UV due to XNB02 failure		
Time	Position	Applicant's Actions or Behavior	
	OFN	NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB02)	
	ATC		
	, no	 Check AC Emergency Buses – AT LEAST ONE ENERGIZED – Yes *NB01 Voltage – NORMAL OR *NB02 Voltage – NORMAL 	
	CRS	2. Determine Emergency Action Level, Using EPP 06-005, EMERGENCY CLASSIFICATION - <i>None</i>	
	<u>NOTE</u> "Affected" refers to an emergency bus that has experienced a loss of power or spurious Load Shedder/Sequencer actuation.		
	CRS	 Go To The Appropriate ATTACHMENT For The Affected Bus: * NB02 – ATTACHMENT B 	
		ATTACHMENT B, LOSS OF NB02	
	ATC	B1. Check Reactor Power – LESS THAN OR EQUAL TO 99% - Yes	
	ATC	 B2. Check Yellow Train AC Emergency Bus – DEENERGIZED – No RNO Perform the following: a. Ensure ESW Pump A Running 	
	Alo	 o EF HIS-55A b. Ensure ESW Train A to Ultimate Heat Sink Valve OPEN o EF HIS-37 c. Go to Step B27 	
	ATC	B27. Check Reactor Power – LESS THAN OR EQUAL TO 99% - Yes	

Op-Tes	t No.: Dec 201	9 Scenario No.: 4 Event No.: 3/4 Total No Pages 24
Event D	escription: AC	EMERGENCY BUS NB02 UV due to XNB02 failure
Time	Position	Applicant's Actions or Behavior
	BOP	
		B28. Ensure Yellow Train ESW Operation/Alignment:
		a. Ensure ESW PUMP 'B' – RUNNING
		o EF HIS-56A
		b. Ensure yellow train ESW valve alignment:
		 Ensure Yellow Train Service Water To ESW Cross-Connect Valves – CLOSED
		o EF HIS-25
		o EF HIS-26
		o EF HIS-39
		o EF HIS-40
		2) Ensure ESW Train B To Ultimate Heat Sink – OPEN
		o EF HIS-38
		CT1 : Manually start 'B' ESW pump before loaded 'B' EDG trips on High Jacket Water Temperature at 195°F.
	BOP	B29. Ensure CCW Alignment is Correct:
		 a. Check Red Train- ALIGNED to Service Loop –
		b. Ensure One Yellow Train CCW Pump is Running
		 EG HIS-22 For Pump B – Yes EG HIS-24 For Pump D
		 EG HIS-24 For Pump D c. Ensure One Yellow Train CCW Pump is in Standby
		 EG HIS-22 For Pump B
		 EG HIS-22 For Pump D – Yes
		d. Check One Pair of CCW service Loop Supply and Return Valves For an Operating CCW Pump – OPEN
		* EG ZL-15 AND EG ZL-53 – Yes

<u>OR</u>

* EG ZL-16 AND EG ZL-54

<u>NOTE</u>

Local opening of EF HV-44, ESW B TO AIR COMPRESSOR (2000' AB NE) results in ESW Train B being inoperable. Local opening of the valve, on 2000' NORTH END AUX BLDG, will preclude it from automatically isolating on a high flow condition.

Op-Tes	t No.: Dec 2019	9 Scenario No.: 4 Event No.: 3/4 Total No Pages 24		
Event Description: AC EMERGENCY BUS NB02 UV due to XNB02 failure				
Time	Position	Applicant's Actions or Behavior		
	BOP	 B30. Ensure Instrument Air Aligned to Yellow Train a. Ensure ESW TRN B TO AIR COMPRESSOR B – OPEN EF HIS-44 - Yes b. Check AIR COMPRESSOR B BKR RESET Switch CLOSED KA HIS-2C – No RNO, Reset and close switch c. Check INST AIR PRESS >105 psig KA PI-40 - Yes d. Check ESW TRN B TO AIR COMPRESSOR B – NOT LOCALLY OPENED EF HV-44 - Yes 		
Event Termination: After the crew has completed step B30 and/or at the direction of the Lead Examiner				
Simulator Operator: Insert Key 5 at the direction of Lead Examiner				

Op-Test	No.: Dec 2019	Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24	
	<u>Event Description:</u> Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.		
Time	Position	Applicant's Actions or Behavior	
		ert Key 5 at direction of Lead Examiner.	
	cs: Lights go ou tors: Multiple	t, reactor and turbine trip, EDGs begin loading onto vital buses	
Annuncia	CRS		
		Enters and directs EMG E-0, REACTOR TRIP OR SAFETY INJECTION	
	E	EMG E-0, REACTOR TRIP OR SAFETY INJECTION	
	-	<u>NOTE</u> immediate action step monitored throughout this procedure	
	ATC	 1. Verify Reactor Trip: a. Check all rod bottom lights – LIT – <i>No</i> b. Check reactor trip breakers and bypass breakers – OPEN – <i>Yes</i> SB ZL-1 SB ZL-2 SB ZL-3 SB ZL-4 c. Check intermediate range neutron flux – DECREASING – <i>Yes</i> SE NI-35B [GAMMA METRICS] SE NI-36B [GAMMA METRICS] RNO Perform the following: Manually trip reactor *SB HS-1 *SB HS-42 IF reactor power is greater than or equal to 5% OR intermediate range power is increasing, THEN go to EMG FR-S1, RESPONSE TO NUCLEAR POWER GENERATION/ATWS, Step 1	
	BOP	2. Verify Turbine Trip: - Yes a. Check Main Stop Valves – ALL CLOSED	
	ATC	<u>3.</u> Check AC Emergency Busses – AT LEAST ONE ENERGIZED – Yes *NB01 – ENERGIZED *NB02 – ENERGIZED	

Op-Test No.: Dec 2019 Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24			
<u>Event Description:</u> Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.			
Time	Position	Applicant's Actions or Behavior	
	ATC	 4. Check if Safety Injection is Actuated: a. Check any indication SI is actuated – LIT – <i>No</i> *Annunciator 00-030A, NF039A LOCA SEQ ACTUATED – LIT *Annunciator 00-031A, NF039B LOCA SEQ ACTUATED – LIT *ESFAS status panel SIS section – ANY WHITE LIGHTS LIT *Partial Trip Status Permissive/Block status panel – SI RED LIGHT LIT RNO a. Perform the following: 1) Check SI Required: *Containment pressure – GREATER THAN OR EQUAL TO 3.5 PSIG – No OR 	
		 *RCS Pressure – LESS THAN OR EQUAL TO 1830 PSIG – No OR *RCS Subcooling – LESS THAN 30°F [45°F] – No OR *Any S/G pressure – LESS THAN OR EQUAL TO 615 PSIG – No OR *PZR level – LESS THAN 6% [32%] 2) IF SI is required, THEN manually actuate SI and go to Step 6 3) IF SI is NOT required, THEN perform the following: a) Direct operator to monitor Critical Safety Functions using EMG F-0, CRITICAL SAFETY FUNCTION STATUS TREES (CSFST) b) Go to EMG ES-02, REACTOR TRIP RESPONSE, Step 1 	
EMG ES-02, REACTOR TRIP RESPONSE			
	NOTE		
Foldout page shall be monitored throughout this procedure			

Op-Test	No.: Dec 2019	O Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24
<u>Event Description:</u> Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.		
Time	Position	Applicant's Actions or Behavior
	BOP	<u>1.</u> Check RCS Temperature Control: a. Check Off-Site Power – AVAILABLE – No
		 RNO a. Perform the following: 1) Isolate main steamlines by depressing MS ISO VLV ALL CLOSE pushbutton *AB HS-79 *AB HS-80 2) Go to step 1.c
		c. Check RCS Cold Leg Temperatures – STABLE AT OR TRENDING TO 557oF – Yes
	BOP	 <u>2.</u> Check RCS Cold Leg Temperatures: a. Check RCS Cold Leg Temperatures – THREE OUT OF FOUR GREATER THAN OR EQUAL TO 530°F – Yes b. Check RCS Cold Leg Temperatures – THREE OUT OF FOUR GREATER THAN OR EQUAL TO 550°F – Yes
	BOP	 3. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes MA ZL-3A MA ZL-4A MA ZL-2
	BOP	 4. Check Feedwater Status: a. Check RCS Average Temperature – LESS THAN 564°F – Yes b. Check Main Feedwater Pumps – TRIPPED – Yes Annunciator 00-120A, MFP A TRIP – LIT Annunciator 00-123A, MFP B TRIP – LIT Check Main Feedwater Isolation Valves – CLOSED – Yes AE HIS-39 For S/G A AE HIS-40 For S/G B AE HIS-41 For S/G C AE HIS-42 For S/G D Check Total Feed Flow To S/Gs – GREATER THAN 270,000 LBM/HR – Yes
	ATC	 5. Evaluate SW/ESW Status: o Check Service Water Header Pressure – GREATER THAN 85 PSIG – Yes

Op-Test	No.: Dec 2019	Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24	
	<u>Event Description:</u> Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.		
Time	Position	Applicant's Actions or Behavior	
		<u>NOTE</u>	
COMPRE	SSOR requires	B, ESW A TO AIR COMPRESSOR or EG HV-44, ESW B TO AIR the associated ESW train to be declared inoperable. Local opening of the ND AUX BLDG, will preclude it from automatically isolating on a high flow	
	BOP	 6. Verify Instrument Air Compressor is Running: a. Ensure at least one ESW TRN TO AIR COMPRESSOR Valve – OPEN – Yes *EF HIS-43 *EF HIS-44 b. Check AIR COMPRESSOR BRKR RESET switch associated with open ESW Valve(s) – CLOSED – No *KA HIS-3C *KA HIS-3C *KA HIS-2C RNO b. Reset and close AIR COMPRESSIR BRKR RESET Switch *KA HIS-3C *KA HIS-2C c. Check INST AIR PRESS – GREATER THAN 105 PSIG – Yes KA PI-40 d. Check neither ESW TO AIR COMPRESSOR Valve – Locally Opened – No EF HV-43 EF HV-43 EF HV-44 e. Check both ESW TRN TO AIR COMPRESSOR Valves – OPEN – Yes EF HIS-43 EF HIS-44 f. Check both AIR COMPRESSOR BRKR RESET switches – CLOSED – Yes KA HIS-3C 	

Op-Test	No.: Dec 2019	Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24	
	<u>Event Description:</u> Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.		
Time	Position	Applicant's Actions or Behavior	
	BOP	 7. Verify Instrument Air to Containment: a. Check INST AIR SPLY CTMT ISO VLV – CLOSED – Yes KA HIS-29 b. Check PZR PRESS MASTER CTRL Output – LESS THAN 55% - Yes BB PK-455A C. Open INST AIR SPLY CTMT ISO VLV KA HIS-29 	
	ATC	 8. Check RCP Seal Cooling – ALWAYS IN-SERVICE DURING EVENT *CCW to ALL Thermal Barriers – IN SERVICE – Yes <u>OR</u> * Charging to RCP Seals – IN SERVICE – Yes 	
	ATC	9. Check Charging Pumps – AT LEAST ONE RUNNING – Yes *CCP A <u>OR</u> *CCP B <u>OR</u> *NCP	
	ATC	 10. Verify Charging System Aligned For Normal Injection: a. Check CCPs – ANY RUNNING – Yes b. Check CCP Discharge to Charging Header Isolation Valve for Running CCP – OPEN – Yes *BG-8483A (1974' AUX BLDG, CCP A ROOM) *BG-8483C (1974' AUX BLDG, CCP B ROOM) c. Check CCP Recirc Valves – OPEN – Yes o BG HIS-8110 o BG HIS-8111 d. Check Charging Pumps to Regenerative Heat Exchanger Containment Isolation Valves – OPEN – Yes o BG HIS-8105 o BG HIS-8106 e. Check Regenerative Heat Exchanger to Loop Cold Leg Valves – ONLY ONE OPEN – Yes *BG HIS-8146 For Loop 1 <u>OR</u> *BG HIS-8147 For Loop 4 	

Op-Test	No.: Dec 2019	Scenario No.: 4 Event No.: 5/6/7/8 Total No Pages 24		
Event De	scription. Loss	of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips,		
	SGBSIS Containment Isolation Valves fail to close.			
Time	Position	Applicant's Actions or Behavior		
	ATC	 11. Check Charging Flow – ESTABLISHED BG FI-121A – GREATER THAN 60 GPM – Yes 		
	ATC	12. Check All Control Rods – FULLY INSERTED – No		
		RNO IF two or more control rods NOT fully inserted, THEN perform the		
		following: a. Emergency borate, using OFN BG-009, EMERGENCY BORATION b. Continue with step 13		
		OFN BG-009, EMERGENCY BORATION		
	<u>NOTE</u> Prolonged Emergency Boration with the Plant at power may require the Plant to be tripped due to rapid RCS Temperature, Pressure and PZR Level decreases			
	ATC	1. Check Charging System Aligned as the operable Boron Injection Flowpath – Yes		
	ATC	 2. Align Charging Pumps for Emergency Boration: a. Ensure one Charging Pump is running *CCP A *CCP B *NCP b. (ρ) Align Boration Flow Path: 1) Ensure Boric Acid Transfer Pumps – AT LEAST ONE RUNNING 2) Open Emergency Borate to Charging Pump Suction Valve BG HIS-8104 c. Check both BATs used to satisfy TRM volume requirements d. WHEN BAT aligned to Boric Acid Transfer Pump level is less than or equal to 10%, THEN open Boric Acid Batching Tank Outlet to Boric Acid Transfer Pumps Isolation Valves BG-8465A BG-8465B 		

Event Description: Loss of Off-Site Power, Four Control Rods fail to insert, TDAFW Pump trips, SGBSIS Containment Isolation Valves fail to close.					
Time	Position	Applicant's Actions or Behavior			
	ATC	 3. Verify Charging Flow Path: a. Ensure Charging Pump to Regenerative Heat Exchanger Isolation Valves – OPEN – Yes BG HIS-8105 BG HIS-8106 b. Ensure One Regenerative Heat Exchanger to RCS Loop Cold Leg Valve – OPEN – Yes *BG HIS-8146 For Loop 1 <u>OR</u> *BG HIS-8147 For Loop 4 c. Adjust Charging Pump Flow to maintain Pressurizer level *BG FK-121 for CCP d. Adjust Charging Header Backpressure Control Valve, as necessary, to establish 8 gpm to 13 gpm seal injection flow BG HC-182 			
	ATC	 4. Check Emergency Boration from RWST – NOT REQUIRED – Yes Emergency Borate Flow – GREATER THAN 30 GPM <u>AND</u> Boron Dilution Event – NOT IN PROGRESS CT2: Commence Emergency Boration due to more than one control rod stuck out before Positive IR SUR develops causing the crew to transition to EMG FR-S1 on an ORANGE path challenge to subcriticality CSF. 			

Simulator operator: Insert Key 9 at the lead examiners direction.

Op-Tes	st No.: Dec 201	9 Scenario No.: 3 Event No.: 9 Total No Pages 24			
Event [Event Description: 'A' MDAFW Pump trips on overcurrent, loss of Secondary Heat Sink				
Time	Position	Applicant's Actions or Behavior			
Simulat	or Operator: Ins	sert Key 9 at direction of Lead Examiner.			
-	Diagnostics: Amber light lit on 'A' MDAFW pump, Auxiliary feed flow goes to zero, and RED PATH exists for heat sink				
	CREW	Recognizes indications of a loss of heat sink			
	CRS	Enters and directs EMG FR-H1			
	EMG FI	R-H1, RESPONSE TO LOSS OF SECONDARY HEAT SINK			
 <u>CAUTION</u> If total feed flow is <270,000 lbm/hr due to Operator action, this procedure shall NOT be performed If a non-faulted S/G is available, feed flow shall NOT be reestablished to any faulted S/G. 					
<u>NOTE</u>					
Foldout Page shall be monitored throughout this procedure.					
	CRS	 Check if Secondary Heat Sink is Required: a. RCS Pressure greater than any non-faulted S/G Pressure – Yes b. RCS Hot Leg Temperature >350°F. – Yes 			
	BOP	 2. Check if RCS Bleed and Feed – NOT Required a. Check WR Level in at least Two S/Gs ≥12% [28%] – Yes o AE LI-501, SG A WR LEV o AE LI-502, SG B WR LEV o AE LI-503, SG C WR LEV o AE LI-504, SG D WR LEV 			

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3	Event No.: 9	Total No Pages 24		
Event [Event Description: 'A' MDAFW Pump trips on overcurrent, loss of Secondary Heat Sink					
Time	Position	Appli	cant's Actions or Beha	avior		
	BOP	LIT – No • Red Train • Yellow Train The following • BM His • CST Level • Motor Driven A	us Panel SGBSIS Section valves indicate open: 5-1A 5-2A 5-3A 5-4A m indications for cause of AFW Pump Power Supp m AFW Pump Steam Supp ignment	bly		
 Simulator Operator: IF contacted as TB Watch to investigate loss of AFW pumps, acknowledge requests. Wait 2 minutes then report the TDAFW is not running and TTV is closed Wait 2 minutes then report Overcurrent flag dropped on 'A' MDAFW Pump power supply break IF contacted as WWM, acknowledge requests and specify a response team will be formed. 				np power supply breaker.		
	ВОР	 b. IF feed flow can Not the following: 1) Dispatch Opera 2) IF all AFW flow to prevent inad AL HK-8A AL HK-10A AL HK-12A 	: east one S/G can be ver	ified: – No t one S/G, THEN perform N Flow. ose AFW throttle valves		

Op-Tes	st No.: Dec 201	9 Scenario No.: 3 Event No.: 9 Total No Pages 24
<u>Event [</u>	Description: 'A' I	MDAFW Pump trips on overcurrent, loss of Secondary Heat Sink
Time	Position	Applicant's Actions or Behavior
	BOP	 6. Reduce Heat Input to RCS: a. Stop all RCPs: - Already Off BB HIS-37 for RCP A BB HIS-38 for RCP B BB HIS-39 for RCP C BB HIS-40 for RCP D b. Turn off all PZR heaters: - Already Off BB HIS-50 BB HIS-51A BB HIS-52A
	CREW	 7. Establish S/G Pressure Control: a. Check Condenser – Available: - No C9 LIT MSIVs OPEN CW Pumps – RUNNING RNO Perform the following: 1) Use S/G ARVs 2) Go to Step 8

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3	Event No.: 9	Total No Pages 24
Event [Description: 'A' I	MDAFW Pump trips on o	vercurrent, loss of Seco	ndary Heat Sink
Time	Position	Ар	plicant's Actions or Beha	avior
	BOP	 a. Start non-safety SAFETY AUX I <u>Control Room</u> 1. Place AD LIC a. ENSURE AD LIC 2. ENSURE AL AFW REG a. ENSURE AL AFW REF N a. ENSURE AL AFW REF N a. AL HK- 5. ENSURE AFW REG N a. AL HK- 5. ENSURE AFW REG N a. AL HK- b. Open TD AFWF S/Gs. AL H AL H 	-79B – MANUAL/CLOSEE HV-8 is closed, using AL I /LV CTRL. 8A – CLOSED HV-10 is closed, using AL /LV CTRL 10A – CLOSED AL HV-12 is closed, using EG VLV CTRL 12A – CLOSED AL HV-6 is closed, using	YS AP-122, NON- W/U LEV CTRL in HK-8A, SGA TDAFP HK-10A, SG B TD AFP AL HK-12A, SG C TD AL HK-6A, SG D TD AFP
			w >270,000 lbm/hr using N of 4 S/G levels degrade to	
 c. Go to step 17. <u>Simulator Operator:</u> WHEN contacted to Start NSAFP, acknowledge requests. Wait 2 minutes, CONTACT the Control Room to direct performance of Step 6.1.2. WHEN SYS AP-122, Step 6.1.2 Control Room Actions are complete and or at the direction of the Load Examinar INSERT Key 10. 				

Lead Examiner INSERT Key 10

• WHEN scenario file has completed (5 min 30 seconds), inform the control room that the NSAFP is running.

Op-Tes	st No.: Dec 2019	9 Scenario No.: 3	Event No.: 9	Total No Pages 24
<u>Event [</u>	Description: 'A' I	IDAFW Pump trips on o	vercurrent, loss of Seco	ndary Heat Sink
Time Position Applicant's Actions or Behavior				
	BOP	 b. Check NR Level RNO Perform the followi 1) Verify flow to S/G(s): a) Core Exit Tere b) Level in at lease 2) <u>IF</u> Feedwater flow to a set of the set of	mperatures Stable or lowe ast one S/G rising (WR or at least one S/G can <u>NOT</u> at least one S/G verified <u>T</u> >6% [29%] while returning	29%] <i>- No</i> ering <u>OR</u> NR) – Yes be verified – N/A
Event Termination: After the crew has verified AFW flow and/or at the direction of the Lead Examiner Simulator Operator: FREEZE				

Facility:	acility: <u>Wolf Creek</u> Scenario No.:				Op-Test No	o.: <u>Dec</u>	ember 2	019
Examine	ers:		Ор	erators:				
Initial Co	onditions: <u>1(</u>	00% Power, MOL,	Yellow Train ir	n Service, Letdov	wn is at 120) gpm, '	B' Safety	Y
Injection	Pump has	been tagged out for	or emergent m	aintenance.				
		s operating at 100 or emergent mainte				Letdow	n is at 7	<u>5 gpm.</u>
		-						
		Establish High He Frip RCPs within 5						
		d Injection prior to				<u>oo poig</u>		
Event	Malf.	Event Type*			Event			
No.	No.	C		Des Cooling Water Pu	scription			
1		(BOP/CRS)	ALR 00-105	A	• •			
2		C (ATC/CRS) BG PK-131, LTDN HX OUTLET PRESS CTRL Fails HIGH in AUTO, Manual Available ALR 00-039E			GH in			
3		C AC Emergency Bus NB01 Bus Lockout ALR 00-18A, OFN NB-030 (ALL) LCO 3 8 9 COND B						
		Tech Spec	LCO 3.8.7, 0		O 3.8.1,	Cond	A,B,E	
4	4 I (ATC/CRS) Tech Spec PR NI 42 fails LOW OFN SB-008, ATT R LCO 3.3.1, Functions 2,3, 5 ,6,18.b, 18.c, 18.d and 18.e 7 CONDs A, D, E, S, T, TRM 3.3.17, COND D.					7		
5		C	AD HIS-8, C	ondensate Pum	o 'A' Discha	arge val	ve fails o	closed.
6		(ALL) M	Small Break	5, OFN MA-038 LOCA in CTMT	on 'C' Cold	Leg		
		(ALL) C	EMG E-0, El BIT Inlet valv	<u>MG E-1</u> /es, EM HIS-880	3A/B fail to		OPEN	on SI
7		(BOP/CRS)	EMG E-0					
8		C (ALL)	EMG FR-C2	and BG FK-121		u		
* (N)ormal, (R)eactivity, (I)nstrument, (C)omponent, (M)ajor								
Targ	Target Quantitative Attributes per Scenario (See Section D.5.d) Actual Attributes ES-301-5 CRS ATC BOP					BOP		
1. Ma	alfunctions after	er EOP entry (1–2)		2	Rx	0	0	0
2. Ab	normal events	s (2–4)		5	Nor	0	0	0
3. Ma	ajor transients	(1–2)		1	I/C	7	5	5
4. EC	Ps entered/re	equiring substantive act	ions (1–2)	2	Maj	1	1	1
	try into a cont 1 per scenario	ingency EOP with subs o set)	tantive actions	1	TS	2	0	0
6. Pre	eidentified crit	ical tasks (<u>></u> 2)		3				

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 5, Rev 3

Critical Task	Safety Significance	Cueing	Measurable Performance Indicators	Performance Feedback
CT1: Given a failure of the BIT inlet valves to open and no available Safety Injection Pumps, establish high head injection flow to the RCS by opening EM HIS-8803B before RVLIS Forced Flow Range drops to 66% w/ 4 RCPs running AND prior to tripping RCPs	With RCPs running and RVLIS <66%, the core is significantly uncovered and a degraded core cooling exists, challenging the fuel cladding fission product barrier only due failure of the crew to take the proper action.	Green light lit on * EM HIS-8803B No indication for * EM HIS-8803A, fails as is (CLOSED) No indicated High Head ECCS Flow: * EM FI-922 * EM FI-918 * EM FI-917A * EM FI-917B	On Panel RL- 018, Open *EM HIS-8803B	Red Lights lit on the manipulated hand switch, Green light out. Charging flow through Bit: * EM FI-917A * EM FI-917B
CT2 Trip all RCPs within 5 minutes of RCS pressure going below 1400 psig per EMG E-0 foldout page step 1 AND after having established High Head Injection	During the initial stages of a SBLOCA, if selected parameter setpoints are reached, the RCPs should be tripped to avoid more serious impacts later due to core uncovery and loss of inventory caused by continued RCP Operation.	* RCS Pressure <1400 psig. (BB PI-455A/456/ 457/458) <u>AND</u> * CCP Flow or SI Pumps running with Indicated flow: (EM FI-917A/B) (EM FI-918/922) <u>AND</u> Operator Controlled Cooldown <u>NOT</u> in progress.	On Panel RL- 021, take handswitches to the STOP position: *BB HIS-37 *BB HIS-38 *BB HIS-39 *BB HIS-40	Green Lights Lit on the manipulated handswitches. Indicated RCP Amps all drop to 0 on: *BB 11-1 *BB 11-2 *BB 11-3 *BB 11-4
CT3: Establish Alternate High Head Injection per EMG FR-C2 prior to CETC temperatures rising to 712°F and a transition to the RED path condition, EMG FR-C1.	The most effective method to restore adequate core cooling is to raise RCS inventory via safety injection. The NCP is the only pump remaining that can accomplish this function. This prevents a lack of decay heat removal and a RED path condition to be entered	Red Train CCP and SI Pumps without power due to NB01 Lockout. B SI Pumps out of service for maintenance at beginning of scenario. B CCP trips. No indicated flow on: EM FI-917A/B EM FI-922/918	On Panel RL001, Manipulates controls as necessary to Open *BG HC-182, *BG HIS-8105 *BG HIS-8147 *BG FK-462	100% open indication on BG HC-182 and BG FK-462. Red Lights Lit and green lights out on BG HIS- 8105 and BG HIS-8146. On Panel RL002, Flow indicated on BG FI-121 CHG HDR FLOW

Note: Causing an unnecessary plant trip or ESF actuation may constitute a Critical Task failure. Actions taken by the applicant(s) will be validated using the methodology for critical tasks in Appendix D to NUREG-1021.

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 5, Rev 3

SCENARIO 5 NARRATIVE

Turnover: The Unit is operating at 100% power. Yellow Train is in service with letdown flow at 120 gpm, 'B' Safety Injection Pump has been tagged out for emergent maintenance. LCO 3.5.2, COND A is entered.

Event 1: Trip of 'B' TB CLCW Pump. Main Control Board Annunciators ALR 105A and 133A will both actuate. The crew should perform ALR 00-105A to restore cooling by starting 'A' CLCW pump using EB HIS-1. Once cooling is restored, the Turbine Building Watch will be dispatched to locally clear the 133A Isophase Bus Trouble Alarm. Once cooling is restored and at the direction of the Lead Examiner the next event will start.

Event 2: Letdown Outlet Pressure Controller BG PK-131 Fails HIGH in Auto. The output on Controller BG PK-131 will fail to 100% in auto, causing letdown HX high flow and Annunciator 039E to actuate. Once the ATC has taken action to manually restore proper letdown flow, the next event will start at the direction of the Lead Examiner.

Event 3: NB01 Bus Lockout: The crew will respond to a bus lockout condition per ALR 00-018A, which requires prompt action to lower turbine loading to maintain power <100% due to AFAS-T Actuation and to Start 'B' ESW pump. After plant conditions stabilize, the crew will perform OFN NB-030, ATTACHMENT A to address other equipment affected by loss of power to bus NB01. Once actions are complete and the CRS has determined technical specification implications and or at the discretion of the Lead Examiner, the next event will start.

Event 4: PRNI 42 Fails LOW. MCB Annunciators 78A and 83C will actuate. The crew will address the instrument failure using OFN SB-008, ATT R. After evaluating Technical Specifications and at the direction of the Lead Examiner, the Major event will start.

Event 5: Condensate Pump 'A' Discharge Valve (AD HIS-8) fails closed. The crew will respond using OFN AF-025 to determine maximum power with only two condensate pumps is 90% (1102 MWE) and commence rapid downpower per OFN MA-038 IAW pre-shift reactivity brief. Once plant conditions have stabilized, and at the direction of the Lead Examiner, the next event will start.

Event 6: Small Break LOCA inside CTMT. RCS leak develops on Loop 3 Cold Leg that grows to ~2.0" break over 30 seconds, crew will diagnose, Manually Trip the Reactor and Actuate Safety Injection

Event 7: BIT Inlet valves, EM HIS-8803A/B, fail to AUTO OPEN on SI. This malfunction, combined with 'B' SI pump being out of service and a bus lockout on NB01, supports the critical task to establish high head injection prior to Core Cooling conditions degrading to Orange Path CSF and before tripping RCPs. The BOP operator may identify the valve failure while monitoring foldout page actions for the RCPs. The ATC performing EMG E-0, ATTACHMENT F will also be procedurally directed to establish the correct lineup at step F13.

CT1: Given a failure of the BIT inlet valves to open and no available Safety Injection Pumps, establish high head injection flow to the RCS by opening EM HIS-8803B before RVLIS Forced Flow Range drops to 66% w/ 4 RCPs running AND prior to Tripping RCPs.

CT2: Trip all RCPs within 5 minutes of RCS pressure going below 1400 psig per EMG E-0 foldout page step 1 AND after having established High Head Injection.

Appendix D

Scenario Outline

Event 8: 'B' CCP Trips and BG FK-121 fails closed on SI. These failures, combined with initial conditions and NB01 bus lockout will cause crew to transition to EMG FR-C2 on an ORANGE PATH core cooling CSF where they will establish alternate high head injection using the NCP per ATTACHMENT A.

CT3: Establish Alternate High Head Injection per EMG FR-C2 prior to CET temperatures rising to 712°F and a transition to the RED path condition, EMG FR-C1.

The scenario is complete when the crew has transitioned to EMG FR-C2 and completed alignment of Alternate High Head Injection and/or at the discretion of the lead examiner

Appendix D

Scenario Outline

SIMULATOR SCENARIO FILES

;2019 ILO NRC Exam, Scenario 5 (IC 305)

;Initial Conditions – IC31, 100% Yellow Train in Service, Letdown flow at 75 gpm, 'B' SI pump OOS scn SimGroup\Tag B SI PMP

;Event 1 - [Key 1] TB Closed Cooling Water Pump Trips ICM bkrDPEB01B.cmf t:1 k:1

;Event 2 - [Key 2] BG PK-131 fails to 100% in Auto ICM cdBGPC-131.cmf t:5 k:2 f:100 {Key[2]} ICM vmodBGPCV0131 t:1 d:0 {bgp0131a<200} DCM vmodBGPCV0131

;Event 3 - [Key 3] NB01 Bus Lockout IMF mNB03 k:3

;Event 4 - [Key 4] PRNI 42 fails LOW IMF mSE03B k:5 r:30 i:100.042 f:0

;Event 5 - [Key 5] AD HIS-8, 'A' Cond Pump Discharge Valve Fails Closed ICM movADHV0008.cmf

;Events 6, 7 – [Key 6] SBLOCA on Loop 3 Cold leg in CTMT, BIT INLET valves fail to OPEN IMF mBB06C f:2.0 r:30 k:6 IMF mSA27EM03 IMF mSA27EM04

;Event 8 – [Key 8] 'B' CCP Trips and BG FK-121 fails closed on SI ICM bkrNB00201 t:1 k:8 ICM vIBGFCV0121 t:1 k:8 f:0

;Local Action – **[Key 9]** Locally reset ISOPHASE trouble alarm IRF rMA04 k:9 f:ACK

;Local Action – **[Key 10]** Locally secure 'A' EDG. {Key[10]} scn SimGroup\SHTDNDGA

'Local Action – **[Key 11]** Locally Close CCW Red Train Supply/Return Valves ICM movEGHV0015.cmf t:4 k:11 f:0 ICM movEGHV0053.cmf t:4 k:11 d:30 f:0

;Local Action – **[Key 12]** Locally secure 'B' EDG {Key[12]} scn SimGroup\SHTDNDGB

;Local Action – **[Key 13] -** Turbine Building Watch Locally closes breakers for BAT pumps. IRF rBG40A f:1 k:13 IRF rBG40B f:1 d:30 k:13

;Local Action - [Key 14]- Aux Building Watch locally closes breaker for BG HV-8104 IRF rBG41 f:1 k:14

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 5, Rev 3

Ap	pen	dix	D

;Local Action – **[Key 15]** – Bypass GG RE-27 and GG RE-28 IRF rSP09 f:BYPASSED k:15 IRF rSP10 f:BYPASSED k:15

;End

Appendix D	Ap	per	ndix	D
------------	----	-----	------	---

Booth Instructions

Ensure NRC Exam Security Established per AIF 30B-015-09, and AIF 30B-015-18

Ensure the following procedures are available, free of markings and are the most recent revision in Curator (10/31/19):

- □ ALR 00-018A, NB01 BUS LOCKOUT (Rev 21)
- □ ALR 00-039E, LTDN HX DISCH FLOW HI (Rev 9)
- □ ALR 00-105A, CLCL PMP FLOW LO (Rev 6)
- □ OFN SB-008, INSTRUMENT MALFUNCTIONS (Rev 49)
- □ OFN SB-008, ATTACHMENT R, PR NEUTRON FLUX CHANNEL MALFUNCTION (Rev 49)
- OFN AF-025, UNIT LIMITATIONS (Rev 56)
- □ OFN NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB02) (Rev 38)
- □ OFN MA-038, RAPID PLANT SHUTDOWN (Rev 30)
- □ EMG E-0, REACTOR TRIP OR SAFETY INJECTION (Rev 41A)
- □ EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT (Rev 30)
- □ EMG FR-C2, RESPONSE TO DEGRADED CORE COOLING (Rev 17)

NOTE: All events are loaded into snap **IC305**

Ensure malfunctions, including severity levels match scenario.

Ensure all meters, lamps, bistables and annunciators are correct for the initial setup. <u>Blue Placard is on</u> the 'A' CCP. <u>Caution Tag on 'B' SI Pump hand switch, EM HIS-5.</u>

Ensure soft panel display in back is set to <u>RP312 RCP Vibration</u> on left screen and <u>AMSAC</u> on right screen.

Ensure no discernable history from RM11, Ovation screens, paper trend recorders, etc. **Ensure** all laminated brief sheets, foldout pages, E plan boards are wiped clean.

Ensure all follow-up buttons are removed from the boards and trash cans and recycle bins are free of any potential exam material.

Ensure communications are established with the lead examiner, fresh batteries, radio check sat.

Critical Parameter Data to be collected:

- □ <u>Forced Flow RVLIS</u> BIT flow must be established prior to Forced Flow RVLIS going below 66%
- CETCs Crew must establish Alternate High Head Injection prior to CETC's rising above 712°F.
- RCS Pressure The crew must trip RCPs within 5 minutes of RCS pressure dropping <1400 psig.
- The crew must also establish BIT flow prior to securing RCPs to satisfy Critical Task 1.

Ensure Horns are ON and machine is in RUN

- □ **Insert Key 1** for Event 1 (TB CLCW Pump Trips).
- □ **Insert Key 2** for Event 2 (BG PK-131 fails HIGH in Auto).
- □ **Insert Key 3** for Event 3 (NB01 Bus Lockout)
- □ Insert Key 4 for Event 4 (PRNI 42 fails LOW)
- □ **Insert Key 5** for Event 5 (AD HIS-8, Cond Pump A Discharge Valve fails Closed)
- □ **Insert Key 6** for Major Event. (SBLOCA in CTMT, BIT Valves fail to open)
- □ **Insert Key 8** for Event 8 ('B' CCP trips and FK-121 fails closed)
- □ When directed to reset ISO PHASE trouble alarm, Insert Key 9
- □ <u>When directed</u> to locally shutdown EDGs, **Insert Key 10 & 12**

Wolf Creek ILO 2019, NRC Operating Exam, Scenario 5, Rev 3

Ap	pend	ix D
----	------	------

- □ <u>When directed</u> to Locally close CCW Red Train Supply/Return Valves, **Insert 11**
- When directed to reset and close breakers for BAT pumps, Insert Key 13
- □ <u>When directed</u> to reset and close breaker for BG HV-8104, **Insert Key 14**
- □ <u>When directed</u> to BYPASS GG RT-27 & 28, **Insert Key 15**

Event Description: Turbine Building Closed Cooling Water Pump 'B' Trips Time Position Applicant's Actions or Behavior Simulator Operator: Insert Key 1 at direction of Lead Examiner. Diagnostics: MCB Alarms, Condensate Pump bearing temperatures rise, JE no actions are taken by the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes. Annunciators: 105A & 133A Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A, first. Lock CLCW is the cooling Water Surge Tank Level Using NPIS Computer – LOW - NO ATC 0 EBD0018 RNO Go To Step 8. BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 1 Total No Pages 36				
Simulator Operator: Insert Key 1 at direction of Lead Examiner. Diagnostics: MCB Alarms, Condensate Pump bearing temperatures rise, <u>IF</u> no actions are taken by the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes. Annunciators: 105A & 133A Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A, Frst. L ALR 00-105A, CLCW PMP FLOW LOW ATC 0 ATC 0 BOP 8. Start Standby Closed Cooling Water Surge Tank Level Using NPIS Computer – LOW - NO BOP 8. Start Standby Closed Cooling Water Pump: "EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	Event D	escription: Turb	ine Building Closed Cooling Water Pump 'B' Trips			
Simulator Operator: Insert Key 1 at direction of Lead Examiner. Diagnostics: MCB Alarms, Condensate Pump bearing temperatures rise, <u>IF</u> no actions are taken by the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes. Annunciators: 105A & 133A Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A, Frst. L ALR 00-105A, CLCW PMP FLOW LOW ATC 0. EBD0018 RNO Go To Step 8. BOP BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.						
Diagnostics: MCB Alarms, Condensate Pump bearing temperatures rise, IF no actions are taken by the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes. Annunciators: 105A & 133A Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A first. Att 00-105A, CLCW PMP FLOW LOW 1. Check Closed Cooling Water Surge Tank Level Using NPIS Computer – LOW - NO ATC 0 EBD0018 RNO Go To Step 8. 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	Time	Position	Applicant's Actions or Behavior			
the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes. Annunciators: 105A & 133A Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A, CLCW PMP FLOW LOW ALR 00-105A, CLCW PMP FLOW LOU ALR 00-105A, CLCW PMP FLOW LO - CLEAR - YES CRS BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO - CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	Simulato	Simulator Operator: Insert Key 1 at direction of Lead Examiner.				
CRS Both annunciators are top tier 'A'; however the crew should recognize that CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A first. ALR 00-105A, CLCW PMP FLOW LOW I Check Closed Cooling Water Surge Tank Level Using NPIS Computer – LOW - NO ATC 0 EBD0018 RNO Go To Step 8. BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	the crew	the crew Condensate Bearing Pump temperatures will exceed alarm setpoints in less than 10 minutes.				
CLCW is the cooling medium for Isophase Bus Duct cooling and perform ALR 00-105A first. ALR 00-105A, CLCW PMP FLOW LOW 1. Check Closed Cooling Water Surge Tank Level Using NPIS Computer – LOW - NO ATC 0 EBD0018 RNO Go To Step 8. BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	Examiner Note: Crew may take actions to start a CLCW pump prior to ALR entry					
ATC 1. Check Closed Cooling Water Surge Tank Level Using NPIS Computer – LOW - NO o EBD0018 RNO Go To Step 8. BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.		CRS	CLCW is the cooling medium for Isophase Bus Duct cooling and perform			
ATC Computer – LOW - NO o EBD0018 RNO Go To Step 8. BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.	ALR 00-105A, CLCW PMP FLOW LOW					
BOP 8. Start Standby Closed Cooling Water Pump: *EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.		Computer – LOW - NO				
*EB HIS-1 For Pump A CRS 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.			RNO Go To Step 8.			
Operation 9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES CRS 10. Return to Procedure and Step in Effect.		BOP				
10. Return to Procedure and Step in Ellect.		CRS	9. Check Annunciator 00-105A, CLCW PMP FLOW LO – CLEAR - YES			
Simulator Operator:		CRS 10. Return to Procedure and Step in Effect.				
 IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status. IF contacted as TBW to investigate 'B' CLCW pump wait 2 minutes and report the breaker for 'B' pump is open with dropped overcurrent flag. IF contacted as Building Watch to investigate ISOPHASE trouble alarm, Insert Key 9, and report it was a low flow alarm that cleared after acknowledging. 						

the Lead Examiner

Simulator Operator: Insert Key 2 at direction of the Lead Examiner.

Op Test	No.: Dec 2019	Scenario No.: 5 Event No.: 2 Total No Pages 36				
Event Description: BG PK-131, Letdown Outlet Pressure Controller fails HIGH in AUTO. Manual						
Available.						
Time	Time Position Applicant's Actions or Behavior					
<u>Simulato</u>	r Operator: Inse	rt Key 2 at the lead examiners direction				
_		1 output indicates 100%, BG PI-131 LTDN HX OUTLET PRESS lowers				
Annuncia	ators: 039E					
	CREW	Recognizes higher than normal letdown flowrate, 039E may not be in alarm yet				
	CRS	Enters and directs ALR 00-039E, LTDN HX DISCH FLOW HI				
		00-039E, LTDN HX DISCH FLOW HI				
		NOTE:				
of plant o	perations, but mu nent does not exc	flow is limited to a nominal desired flow of about 120 gpm, during all modes ist be less than 130 gpm to ensure a letdown line break outside of eed offsite dose limits				
	ATC	 Check Letdown Heat Exchanger Outlet Flow – GREATER THAN 130 GPM – Yes (May be <130 gpm, so procedure directs RTPSE, but the mitigating actions are in this procedure and should still be performed) BG FI-132 				
		NOTE:				
the demir	n dP must be less	entionally maintained greater than a nominal 120 gpm but less than 130 gpm, a than 25 psid, with more frequent monitoring of dP across demineralizers vice, per engineering calculation.				
	ATC 2. Check Letdown from RHR: a. Check Letdown from RHR System – IN PROGRESS – No RNO Go to Step 3					
	ATC 3. Check Letdown Flow Using Orifice Bypass Line: a. Check Letdown Flow Using Orifice Bypass Line – IN PROGRESS - No					
		RNO Go To Step 4				
	ATC	4. Check 75 GPM Letdown Orifice Isolation Valves – ONLY ONE OPEN – Yes				
		*BG HIS-8149BA <u>OR</u> *BG HIS-8149CA				

Op Test	Op Test No.: Dec 2019 Scenario No.: 5 Event No.: 2 Total No Pages 36					
Event De Available	Event Description: BG PK-131, Letdown Outlet Pressure Controller fails HIGH in AUTO. Manual Available.					
Time	Position	Applicant's Actions or Behavior				
	ATC 5. Check Letdown Heat Exchanger Outlet Pressure Controller – OPERATING PROPERLY o BG PK-131 – No					
		 RNO Perform the following: a. Place Controller in manual b. Adjust pressure controller, as necessary to establish between 300 psig and 350 psig 				
		NOTE:				
	e swapping from /007 concurrently ATC					
	ATC 6. Check Letdown Heat Exchanger Outlet Pressure – BETWEEN 300 PSIG AND 350 PSIG – Yes o BG PI-131					
	ATC 7. Check Letdown Heat Exchanger Outlet Flow – LESS THAN 130 GPM – Yes o BG FI-132					
	CRS 8. Return to Procedure and Step in Effect					
	Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.					
	Event Termination: After the crew has restored letdown pressure control and/or at the direction of the Lead Examiner					
Simulato	or Operator: Inse	ert Key 3 at direction of the Lead Examiner				

Op-Tes	t No.: Dec 2019	9 Scenario No.: 5 Event No.: 3 Total No Pages 36					
-							
	Event Description: AC Emergency Bus NB01 Bus Lockout						
Time	Position	Applicant's Actions or Behavior					
Simulat	or Operator: In:	sert Key 3 at direction of Lead Examiner.					
Diagnos 'A' starts		nunciators. Loss of power to red train components, TDAFW pump starts. EDG					
Annunc	iators: 018A, 01	8B, 018D					
	CREW	Recognizes loss of power to RED train components and multiple alarms. Diagnoses a loss of NB01					
	CRS	Enters and directs ALR 00-018A					
		ALR 00-018A, NB01 BUS LOCKOUT					
		CAUTION					
Prior to	resetting any loc	kout, all faults should be verified to be clear.					
	BOP	1. Check CCW Service Loop Aligned to Train B. – Yes					
	BOP	2. Check Reactor Power – LESS THAN OR EQUAL TO 99% -No					
	 RNO Perform the following: a. (p) Reduce Turbine load as necessary b. ENSURE reactor power is ≤99% Examiner NOTE: Per beginning of shift reactivity brief, the BOP should "FAST LOAD DECREASE" turbine load by 30 MW. 						
	ATC						
		 3. Ensure NB01 Supply Breaker Open NB01 Normal Supply Breaker NB0112 – OPEN NB HIS-2 NB01 Alternate Supply Breaker NB0109 – OPEN NB HIS-3 NB01 Emergency Supply Breaker NB0111 – OPEN NB HIS-25 NB01 SB0 DG Supply Breaker NB0114 OPEN NB0114 					

Op-Tes	t No.: Dec 201	9 Scenario No.: 5 Event No.: 3 Total No Pages 36					
Event Description: AC Emergency Bus NB01 Bus Lockout							
Time	Position	Applicant's Actions or Behavior					
	ATC	 4. Shutdown Diesel Generator A. a. Locally place Master Transfer Switch in Local/Manual position and stop EDG B. o KJ HS-9 					
o <u>IF</u> co REF o <u>IF</u> co	REPORT – "No abnormal conditions at XNB01 transformer."						
	CRS	5. Refer to Technical Specifications • LCO 3.8.9 • LCO 3.8.1 Enters LCO 3.8.9 COND C – 2 hours LCO 3.8.1, Cond A,B,E Enters LCO 3.8.7 COND A – 24 hours <u>Examiner Note:</u> Since 'B' SI Pump was out of service at the beginning of the scenario and 'A' SI pump is now without power, crew may discuss LCO 3.5.2, COND C and entry to LCO 3.0.3.					
	CREW	6. Go To OFN NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB02), Step 1					
	OFN NB-030, LOSS OF AC EMERGENCY BUS NB01 (NB02)						
	ATC	1. Check AC Emergency Buses – AT LEAST ONE ENERGIZED - Yes					
	CRS	2. Determine Emergency Action Level, Using EPP 06-005, EMERGENCY CLASSIFICATION <u>Examiner Note</u> : No classification at this time since offsite power is still available to ESF XFMR XNB02.					

Op-Tes	t No.: Dec 201	9 Scenario No.: 5 Event No.: 3 Total No Pages 36				
Event Description: AC Emergency Bus NB01 Bus Lockout						
Time	Position	Applicant's Actions or Behavior				
	d" refers to an er r/Sequencer actu	<u>NOTE</u> nergency bus that has experienced a loss of power or spurious Load lation.				
		3. Go To The Appropriate ATTACHMENT For The Affected Bus:				
	CRS	AFFECTED BUS				
		NB01 ATTACHMENT A				
	AT	TACHMENT A, LOSS OF AC EMEREGENCY BUS NB01				
	ATC	A1. Check Reactor Power – LESS THAN OR EQUAL TO 99% - Yes				
	ATC	A2. Check Red Train AC Emergency Bus – DEENERGIZED - Yes				
	ATC	A3. Ensure CCW Service Loop Aligned to Yellow Train – Yes				
 Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status. WHEN contacted as Aux Building Watch to locally close EG HV-15 and 53, Red Train CCW Supply and Return Valves, acknowledge requests. Insert Key 11. Wait 2 minutes and report valves are closed. 						
	BOP	 A4. Perform the Following: a. Locally close CCW Red Train Supply / Return Valves o EG HV-15 (2026' Aux BLDG, About 30' south of CCW HX 'A', by West Wall) o EG HV-53 (2026' Aux BLDG, North of CCW Train 'B' Room) b. Open CCW Surge Tank 1 Vent Valve o EG HIS-9 				

Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 3 Total No Pages 36 Event Description: AC Emergency Bus NB01 Bus Lockout						
Time	Position	Applicant's Actions or Behavior				
	BOP	A5. Ensure RCP Thermal Barrier L/U – NORMAL a. Ensure RCP Thermal Barrier Return Valves – OPEN o BB HIS-13 for RCP A o BB HIS-14 For RCP B o BB HIS-15 For RCP C o BB HIS-16 For RCP D b. Ensure CCW Return From RCS Isolation Valves – OPEN o EG HIS-61 o EG HIS-62				
	ATC	A6. Check Reactor Power <99% - Yes				
		de. This can cause a Safety Injection. Steam Dumps should be monitored as ed or controlled in manual, as necessary <u>NOTE</u>				
being in	operable. Local	-43, ESW A TO AIR COMPRESSOR (2000' AB NE) results in ESW Train A opening of the valve, on 2000' NORTH END AUX BLDG, will preclude it from n a high flow condition.				
	ATC	A7. Ensure Instrument Air Aligned to Red Train - Yes				
	A8. Check RCP Cooling – Normal ATC a. CCW Flow to RCS >1.25x10 ⁶ LBM/HR b. RCP Seal Injection flow to each RCP Between 8 gpm and 13 gpm.					
	ATC	A9. (p) Restore Power to PZR Backup Heaters a. Check NB02 Energized by offsite power b. Ensure supply breaker for PG22 closed. o PG HIS-21 c. Place B Train PZR backup heaters in AUTO or CLOSE, as desired, maintain PZR pressure. o BB HIS-52A.				

Op-Tes	t No.: Dec 201	9 Scenario No.: 5 Event No.: 3 Total No Pages 36					
Event Description: AC Emergency Bus NB01 Bus Lockout							
Time	Position	Applicant's Actions or Behavior					
		NOTE					
	rain ESW must b OPERABLE.	be started and isolated from Service Water to ensure yellow train components					
		A10. Establish ESW to Yellow Train: a. Check ESW Pump B – Running – No					
	ATC	 RNO Perform the following: 1) Start ESW Pump B EF HIS-56A b. Open ESW Train B to Ultimate Heat Sink. EF HIS-38 c. Close Yellow train ESW valves EF HIS-26 EF HIS-40 					
	BOP	A11. Check if TDAFW Flow should be reduced. a. Check Reactor Power <10% - No RNO Go to Step A12					
	BOP	A12. Check Yellow Train Spent Fuel Pool Cooling Pump RUNNING – Yes					
	BOP	A13. Check Yellow Train A/C Units – Running - Yes					
		CAUTION					
Prior to using any normal operating procedure to restore equipment and/or resetting any lockout relays, all faults should be verified to be clear.							
	 NOTE Annunciator 00-018A, NB01 BUS LOCKOUT being lit is indicative of a bus lockout. This will prevent energization of the NB bus from any source until the bus fault is cleared. 						
		A, NB01 BUS LOCKOUT will not alarm if a bus fault occurs with breakers 9 open and EDG A carrying the bus.					

Op-Test No.: Dec 2019Scenario No.: 5Event No.: 3Total No Pages 36								
Event D	Event Description: AC Emergency Bus NB01 Bus Lockout							
Time	Position	Applicant's Actions or Behavior						
	ATC A14. Check NB01 Bus Status: Annunciator 00-018A, NB01 BUS LOCKOUT – CLEAR – No RNO Perform the following: IF diesel is running AND cooling will NOT be restored within 30 minutes, THEN locally stop the diesel, as follows: I) Place Master Transfer Switch to LOC/MAN KJ HS-9 Stop the diesel KJ HS-8B Dispatch Electrical Maintenance to clear bus fault. WHEN bus fault is clear, THEN continue with step B15. 							
Simulator Operator: IF contacted as TB Watch to secure A EDG, Insert Key 10								
Event Termination: After the crew has stabilized the plant and/or at the direction of the Lead Examiner Simulator Operator: Insert Key 4 at the direction of Lead Examiner								

Op-Tes	t No.: Dec 201	9 Scenario No.: 5	Event No.: 4	Total No Pages 36		
<u>Event D</u>	Event Description: PRNI 42 fails LOW					
Time	Position	Арг	licant's Actions or Beh	avior		
<u>Simulat</u>	or Operator: Ins	sert Key 4 at direction of L	ead Examiner.			
	stics: Annuncia rip status panel,	tor Alarms, Indication on S SB-069	E NI-42B low scale, Light	t indications change on		
Annunc	iators: 078 & 08	3C				
	CREW	Recognizes indications a instrument	nd diagnoses a failure of	a Power Range Nuclear		
	CRS	Enters and directs ALR 0 008 directly.	0-078A, PR CHANNEL [DEV. May enter OFN SB-		
		ALR 00-078A, PF	R CHANNEL DEV			
	ATC	1.Check For Dropped Or	Misaligned Rod: -No			
		RNO Go to Step 3.				
	ATC	a. Check NI Powe OTHER o SE NI-41E o SE NI-42E o SE NI-42E o SE NI-43E o SE NI-44E RNO: I <u>F</u> a <u>THEN</u> per 1. Declare 2. Refer to TR 3.	3 - No 3 larm is caused by failed N form the following: QPTR alarm INOPERAE D Technical Specification	NI power range channel, 3LE. 3.3.1 Table 3.3.1-1 AND		
	CRS	Enters and directs C	FN SB-008, INSTRUMEI	NT MALFUNCTIONS.		

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 4 Total No Pages 36					
<u>Event [</u>	Event Description: PRNI 42 fails LOW					
Time	Position		Applicant's	s Actions or Behavior	r	
		OFN SB-008,	INSTRUMENT M	ALFUNCTIONS		
		* Cheo Malfu	unctioning: - Yes	imentation System Cha		
	CRS		Perform appropria from table below:	ate attachment for malf	unctioning channel	
			VARIABLE Power Range	CHANNELS N-41, N-42, N-43,	ATTACHMENT	
			(SE)	N-44	ATTACHMENT R	
	CRS	Enters and dire		NT R, POWER RANGE	NEUTRON FLUX	
		OFN \$	SB-008, ATTACH	MENT R		
			NOTES			
o Step	os R1 through R3	are Memory Act	ion steps			
	er to FIGURE 4, N tioning correctly.	II OVERLAP, as	needed, to deterr	nine if power range ins	truments are	
	ATC	 R1. Identify Failed Instrument Channel: * One power range flux or delta flux meter indicates abnormally higher or lower than other power range meters–Yes (SE NI 42B) 				
	BOP O Generator Load MW – STABLE – Yes					
	ATC		R3. Switch ROD BANK AUTO/MAN SEL Switch To Manual. o SE HS-9			

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 4 Total No Pages 36					
Event Description: PRNI 42 fails LOW						
Time	Position	Applicant's Actions or Behavior				
	ATC	following 1) Turn the Up channel. 2) Turn the Lo channel. 3) Turn the Po range flux 4) Turn the Ro channel. b. At the Comparate	Current Comparator Drawer per Section switch to the fa PRN42 wer Section switch to the fa PRN42 wer Mismatch Bypass switch channel. BYPASS PRN42 of Stop Bypass switch to th BYPASS PRN42 or and Rate Drawer (N37/4 mparator Channel Defeat s	ailed power range flux ailed power range flux ch to the failed power 2 e failed power range flux 6), perform the following:		
	ike several minut g back to automa	es for power and temperat	<u>DTE</u> cure rate circuitry outputs to	o return to normal before		
	ATC R5. Check ROD BANK AUTO/MAN SEL Switch In Auto. ο SE HS-9 RNO (ρ) WHEN Tavg is within 1°F of Tref, THEN place ROD BANK AUTO/MAN SEL switch in auto. ο SE HS-9					
	ATC	R6. Monitor Rod Contro	System Response To Ens	sure Proper Control		
	BOP R7. Check Failed Power Range Flux Channel Not Used For Recording On OPΔT/OTΔT Recorder: ο OPΔT/OTΔT Recorder – No, selected to Loop 1					
	CRS		Annunciator 00-079C, RP RIFICATION OF OPERABIL			
	t <mark>or Operator:</mark> IF ledge status.	contacted as WWM, ackno	owledge requests. <u>IF</u> conta	cted as Call Supt.,		

Appendix D

Op-Tes	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 4 Total No Pages 36					
Event [Event Description: PRNI 42 fails LOW					
Time	Position	Applicant's Actions or Behavior				
		<u>N0</u>	DTE			
			hannels if less than or equerform a flux map when gr			
	R9. Verify QPTR Operability: a. Check Reactor Power Greater Than 50%. Yes b. Check Reactor Power Greater Than 75%. Yes c. Perform STS RE-012, QPTR DETERMINATION for one PR Channel being INOPERABLE <u>AND</u> above 75% RTP every 12 hours to verify QPTR is within limits.					
Examiner Note: The rest of attachment R will NOT be performed. The crew should wait on troubleshooting activities. Monitor the crews' response to maintain Tavg/Tref within band Event Termination: After the crew has identified Tech Specs and/or at the direction of the Lead Examiner						
<u>Simula</u>	tor Operator: In	sert Key 5 at the lead exa	iminers direction.			

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 5 Total No Pages 36		
Event Description: AD HIS-8 'A' Condensate Pump Discharge Valve fails CLOSED				
Time	Position	Applicant's Actions or Behavior		
Simulator	Simulator Operator: Insert Key 5 at direction of Lead Examiner.			
_	Diagnostics: All four S/G levels lowering			
Annuncia	tors: 120B and	123B		
	CREW	Diagnoses failure and either performs ALR 00-120B (123B), or enters OFN AF-025 and OFN MA-038 directly.		
	CRS	Reviews ALR 00-120B and/or enters OFN AF-025 directly		
		ALR 00-120B, MFP A SUCT PRESS LO		
	BOP	1. Verify PAE01A, STEAM GENERATOR FEEDWATER PUMP Suction Pressure - LOW - Yes		
	BOP	 2. Check Condensate Header Pressure: NPIS Point ADP0025 <290 psig – Yes AD PI-24 <290 psig - Yes 		
	BOP	3. Check Condensate Pumps - THREE RUNNING - Yes		
	Simulator Operator: IF contacted as Turbine Watch to investigate/manually open AD HIS-8, acknowledge request, wait 2 MINUTES, report valve is closed and cannot be opened			
	BOP	4. Check Running Condensate Pumps Discharge Valve(s) – OPEN – No		
	201	RNO Manually - OPEN VALVE, AD HIS-8 For Pump A		
	Simulator Operator: IF contacted as Turbine Watch to OPEN AD HIS-8, wait 2 minutes and report that the valve will NOT open			
	BOP	 Check Running Condensate Pump Recirculation Control Valves – CLOSED - Yes 		
	BOP	6. Check Heater Drain Pumps – Two Running - Yes		
	BOP	7. Check Running Heater Drain Pump Recirc Control Valves – CLOSED - Yes		

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 5 Total No Pages 36		
Event Description: AD HIS-8 'A' Condensate Pump Discharge Valve fails CLOSED				
Time	Position	Applicant's Actions or Behavior		
	BOP	8. Open Condensate Demineralizer Bypass Valve AD HIS-28		
		NOTE		
There is a	a popup window	7993 for each recirc valve.		
	BOP	9. Check Running MFP Recirc Valves – CLOSED - Yes		
	BOP	 10. Check Feedwater Recirculation Control Valve – CLOSED – Yes O AD HK-35 		
		<u>NOTE</u>		
Head loss through the LP heaters cause a pressure drop from Condensate to the Main Feed Pumps that varies with flow rate (power level).				
		11. Check MFP A suction Pressure >340 psig – <i>No</i>		
	BOP	RNO Perform the following:		
		 a. Reduce Turbine load as necessary to restore MFP suction pressure to >340 psig per GEN 00-004, or OFN MA-038 		
OFN AF-025, UNIT LIMITATIONS				
NOTE Steps 1 through 12 may be done in any order.				
NOTE				
Reactor power reductions using this OFN are limited to 6MWe (0.5%) per minute. Reactor power reductions at >12 MWe (1.0%) per minute must be done using OFN MA-038, RAPID PLANT SHUTDOWN.				
	CRS	 Check For Conditions Requiring Unit Load Reduction: a. Determine maximum unit load, using ATTACHMENT A, UNIT LOAD LIMITS. 		

Event Description: AD HIS-8 'A' Condensate Pump Discharge Valve fails CLOSED			
Position	Applicant's Actions or Behavior		
	CONDITION REQUIRING LOAD	DNDENSATE MAXIMUM UNIT LOAD	
000	REDUCTION One condensate pump out of service	1102 MWE 90% (1) (2)	
CKS	MFP suction pressure greater than 34 (2) Maintain Motor Current for the ope than or equal to 440 amps as indicated	0 psig as indicated on Graphic 6101. rating Condensate Pumps to less d on NPIS Computer points, ADI0010,	
CREW	CRS should announce to the crew to perform a 10% power reduction per the beginning of shift brief using guidance OFN MA-038		
Simulator Operator: IF contacted as WWM, acknowledge requests. IF contacted as Call Supt., acknowledge status.			
	OFN MA-038, RAPID PLANT SHU	TDOWN	
CAUTION			
ading rates may	result in increased turbine vibration.		
	NOTES		
ut page shall be	monitored throughout this procedure		
\circ Load reduction at greater than 65 MW (5%)/minute will arm condenser steam dumps			
• Steps 1, 2 and 3 are memory action steps.			
BOP	a. Check Desired Unloading Rate MW/MINUTE (5%)	– LESS THAN OR EQUAL TO 65	
	CRS CREW CREW r Operator: IF c dge status. ading rates may ut page shall be reduction at grea 1, 2 and 3 are n	FEED AND CO CONDITION REQUIRING LOAD REDUCTION One condensate pump out of service (1) If one condensate pump is lost, rec MFP suction pressure greater than 34 (2) Maintain Motor Current for the oper than or equal to 440 amps as indicated ADI0011 or ADI0012 as applicable. Per Condensate Motors is 442 amps. CREW CRS should announce to the crew to p the beginning of shift brief using guida r Operator: IF contacted as WWM, acknowledge request dge status. OFN MA-038, RAPID PLANT SHUT CAUTION ading rates may result in increased turbine vibration. NOTES ut page shall be monitored throughout this procedure reduction at greater than 65 MW (5%)/minute will arm co 1, 2 and 3 are memory action steps. 1. Determine Turbine Unloading Methor a. Check Desired Unloading Methor a. Check Desired Unloading Methor	

Appendix D

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 5 Total No Pages 36			
Event Description: AD HIS-8 'A' Condensate Pump Discharge Valve fails CLOSED					
Time	Position	Applicant's Actions or Behavior			
		NOTES			
Contro	If the High Limiter Active on Graphic 5551 is in alarm, load can only be decreased with the Load Control selected to Open Loop. When High Limiter Active is cleared as indicated by the alarm changing to Limiter Activated, the Load Control Mode may be changed.				
o The fo	llowing is the pro	eferred Mode of Load Control, unless otherwise directed by another			
Open MW – If a se	procedure: Open Loop – When Turbine Load is not being changed or the first 10% load decrease from 100%. MW – If making Turbine Load changes where there is no ongoing secondary side transient. FSP – If a secondary side transient requires changing Turbine Load or there is a need to keep primary side more stable.				
		2. (p) Reduce Turbine Load In Automatic:			
		a. From Graphic 5551, TURBINE CONTROL SYSTEM – OPERATION PANEL, LOAD CONTROL section – Select method of Load Control, as directed by CRS/SM.			
		* Open Loop (Only for first 10% load decrease from 100%)			
		b. Perform the following steps to reduce turbine load:			
		1) From Graphic 5551, SETPOINTS section, select CHANGE.			
		 At popup 7055, enter the desired MW (greater than or equal to 90% if in Open Loop) and select ENTER. 			
		 At popup 7055, in the RATE - DEC field enter the desired rate of decrease and select ENTER. 			
	вор	 From Graphic 5551, SETPOINTS section, select GO to commence load reduction. 			
	BOF	c. (p) Energize PZR Backup Heaters.			
		o BB HIS-51A			
		o BB HIS-52A			
		 d. (p) Borate RCS And Adjust Control Rods, As Necessary, To Maintain the following: 			
		o Target Tavg/Tref Temperature Error Between 0°F And +5°F			
		o Control Rods Above the Rod Insertion Limits			
		e. Maintain desired turbine unloading rate.			
		f. Go to step 4.			
		Examiner Note : Copy of the Laminated SYS BG-200 for ATC Boration actions included as Attachment 2.			

Op-Test	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 5 Total No Pages 36				
Event Description: AD HIS-8 'A' Condensate Pump Discharge Valve fails CLOSED					
Time	Position	Applicant's Actions or Behavior			
	ATC	 4. Check PZR PORVs: a. RCS Pressure – LESS THAN 2335 PSIG - Yes b. PZR PORVs – CLOSED - Yes BB HIS-455A BB HIS-456A c. RCS Pressure – GREATER THAN 2185 PSIG - Yes d. PORV Block Valves – OPEN - Yes BB HIS-8000A BB HIS-8000B 			
	ATC	5. Check PZR Pressure – Stable at or trending to 2235 psig- Yes			
	ATC	6. Check PZR Level – Stable at or Trending to program level- Yes			
	ATC	7. Check S/G Levels controlling between 45% and 55%- Yes			
<u>Simulato</u>	Simulator Operator: IF contacted as RP or Chemistry, acknowledge requests				
	BOP	 8. Notify RP to perform the following: Monitor RCS and other connecting systems for rising radiation levels due to unplanned crud burst. Notify all personnel in the affected areas. 			
	BOP	9. Check if sampling is required: - Not yet			
	ATC	10. Check Reactor Power <65%			
of the Lea	Event termination: After the crew has commenced load reduction and boration and/or at the discretion of the Lead Examiner. Simulator operator: Insert Key 6 at the lead examiners direction.				

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 6/7 Total No Pages 36		
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI				
Time	Position	Applicant's Actions or Behavior		
Simulator	Simulator Operator: Insert Key 6 at direction of Lead Examiner.			
Diagnostic	s: RCS pressur	e and PZR level lowering rapidly		
	CREW	Recognizes lowering RCS pressure and PZR level diagnoses RCS leakage		
	CRS	Directs manual Reactor Trip and Safety Injection, enters EMG E-0, REACTOR TRIP OR SAFETY INJECTION		
	E	EMG E-0, REACTOR TRIP OR SAFETY INJECTION		
		<u>NOTES</u>		
o Steps	1 through 4 are	immediate action steps		
o Foldo	ut page shall be	monitored throughout this procedure.		
	ATC	 1. Verify Reactor Trip: - Yes a. Check all rod bottom lights – LIT b. Check reactor trip breakers and bypass breakers – OPEN SB ZL-1 SB ZL-2 SB ZL-3 SB ZL-4 c. Check intermediate range neutron flux – DECREASING SE NI-35B [GAMMA METRICS] SE NI-36B [GAMMA METRICS] 		
	BOP	2. Verify Turbine Trip: - Yes a. Check Main Stop Valves – ALL CLOSED – Yes		
	ATC	<u>3.</u> Check AC Emergency Busses – AT LEAST ONE ENERGIZED – Yes *NB01 – ENERGIZED *NB02 – ENERGIZED		

Op-Test	No.: Dec 2019	Scenario No.: 5	Event No.: 6/7	Total No Pages 36
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI				
Time	Position	Applicant's Actions or Behavior		
	ATC	*Annunciator 0 *Annunciator 0 *ESFAS status *Partial Trip St LIGHT LIT b. Check both trair o Ann 00-03	ion is Actuated: ation SI is actuated – LIT – 1 00-030A, NF039A LOCA SEC 00-031A, NF039B LOCA SEC 5 panel SIS section – ANY W atus Permissive/Block status 1s of SI actuated – Yes 0A, NF039A LOCA SEQ AC 1A, NF039B LOCA SEQ AC	Q ACTUATED – LIT Q ACTUATED – LIT /HITE LIGHTS LIT s panel – SI RED CTUATED – LIT
			TION	
	ower is lost after ed configuration		nay be required to restore sa	afeguards equipment to
	ATC	* Containment pres OR EQUAL TO 3.5 * RCS pressure is o 1830 PSIG – Yes	ictuated AND was required - sure is currently or has been) – GREATER THAN S THAN OR EQUAL TO
	BOP	IF all conditions listed be • RCS press • CCPs or S • Operator co CT2: Trip all RCPs with	1. RCP TRIP CRITERIA elow occur, <u>THEN</u> trip all RC ure – LESS THAN 1400 PSI I pumps – AT LEAST ONE F ontrolled cooldown – NOT IN hin 5 minutes of RCS pressu out page step 1 AND after ha	IG RUNNING - NO N PROGRESS Ire going below 1400
	BOP	 IF a Loss-Of-Of *AB HS-79 *AB HS-80 IF no RCPS are select STM PRE AB US-500 IF RCS C/L tem 	7. RCS TEMPERATURE CO fsite Power has occurred, <u>Th</u> running AND off-site power ESS mode on the steam dun Z perature is less than 557°F <i>J</i> d flow to limit RCS cooldown	<u>HEN</u> close MSIVs is available, <u>THEN</u> nps AND decreasing, <u>THEN</u>

Op-Test	No.: Dec 2019	O Scenario No.: 5 Event No.: 6/7 Total No Pages 36		
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI				
Time	Position	Applicant's Actions or Behavior		
	ATC	 6. Verify Automatic Actions using Attachment F Examiner Note: See Attachment 1 for complete list of actions F5. Verify ECCS Pumps Running: Check SI pumps – BOTH RUNNING – No, Both Unavailable F13. Verify ECCS Flow: Check Centrifugal Charging Pumps To Boron Injection Tank Flow meters – FLOW INDICATED – No EM FI-917A EM FI-917B RNO Perform the following: I) IF BIT valves have NOT been closed by operator action, THEN manually start pumps and align valves. Open EM HIS-8803A – No Power Open EM HIS-8803B C11: Given a failure of the BIT inlet valves to open and no available Safety Injection Pumps, establish high head injection flow to the RCS by opening EM HIS-8803B before RVLIS Forced Flow Range drops to 66% w/ 4 RCPs running AND prior to Tripping RCPs. F17. Check FBIS Is NOT ACTUATED: Annunciator 00-062D, FBIS – NOT LIT – No RNO Perform the following: a. Ensure No Movement of irradiated fuel assemblies in the fuel building – Yes b. Bypass GG RE-27 and GG RE-28 Examiner Note: These switches are NOT modeled in the Simulator, when the Applicant goes around back and discusses the step, inform the Simulator Operator to insert Key 15 to bypass, and then Cue the applicant the step is complete. Reset FBIS: SA HS-10 SA HS-11 Ensure FUE BLD EMERG EXH DAMPERS are closed GG HIS-43 		

Op-Test	No.: Dec 2019	OScenario No.: 5Event No.: 6/7Total No Pages 36		
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI				
Time	Position	Applicant's Actions or Behavior		
	BOP	 7. Check Main Generator Breakers and Exciter Breaker – OPEN – Yes MA ZL-3A MA ZL-4A MA ZL-2 		
	BOP	8. Check Total AFW Flow – GREATER THAN 270,000 LBM/HR – Yes		
	BOP	 <u>9.</u> Check RCS Cold Leg Temperatures: *Stable at or trending to 557°F for condenser steam dumps or S/G ARVs *Stable at or trending to a range of 553°F to 557°F for S/G ARVs if recovering from an inadvertent SI 		
	BOP	 10. Establish S/G Pressure Control: a. Check condenser – AVAILABLE – Yes C-9 LIT MSIV – OPEN Circulating water pumps - RUNNING b. Place Steam Header Pressure Control in Manual AB PK-507 c. Manually set Steam Header Pressure Control output to zero AB PK-507 d. Place Steam Dump Select Switch in STEAM PRESS position AB US-500Z Place Steam Header Pressure Control in Automatic AB PK-507 		
	ATC	 11. Check PZR PORVs a. Check PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A b. Power to block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B c. RCS pressure – LESS THAN 2185 PSIG 		
	ATC	12. Check Normal PZR Spray Valves – CLOSED – Yes o BB ZL-455B o BB ZL-455C		
	ATC	 13. Check PZR Safety Valves – CLOSED – Yes BB ZL-8010A BB ZL-8010B BB ZL-8010C 		

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 6/7 Total No Pages 36			
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI					
Time	Position	Applicant's Actions or Behavior			
	NOTE				
Seal injec	tion flow shall be	e maintained to all RCPs			
	ATC/BOP	14. Check if RCPs should be stopped:a. Check RCPs – ANY RUNNING – No			
		RNO a. Go to Step 15			
	CRS	15. Direct operator to Monitor Critical Safety Functions Using EMG F-0, CRITICAL SAFETY FUNCTION STATUS TREES (CSFST)			
	BOP	 16. Check if S/Gs are not Faulted: - Yes a. Check pressures in all S/Gs – NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER NO S/G COMPLETELY DEPRESSURIZED 			
	BOP	 17. (t) Check if S/G tubes are intact: Check S/G Levels – NOT INCREASING IN AN UNCONTROLLED MANNER – Yes Narrow range Wide range Condenser air discharge radiation – NORMAL BEFORE ISOLATION – Yes GEG 925 S/G blowdown and sample radiation – NORMAL BEFORE ISOLATION – Yes BML 256 SJL 026 Turbine driven auxiliary feedwater pump exhaust radiation – NORMAL – Yes FCT 381 S/G steamline radiation – NORMAL – Yes ABS 114 for S/G A ABS 113 for S/G B ABS 111 for S/G D 			

2/	
- 24	•

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 6/7 Total No Pages 36		
Event Description: SBLOCA inside Containment. BIT inlet valves fail to open on SI				
Time	Position	Applicant's Actions or Behavior		
	ATC	 18. Check if RCS is intact in Containment: - NO Containment radiation – NORMAL BEFORE ISOLATION GTP 311 GTI 312 GTG 313 GTF 321 GTF 321 GTA 591 GTA 601 Containment pressure – NORMAL GN PI-934 GN PI-935 GN PI-937 GT PDI-40 GN PR-934 Containment sump level – NORMAL EJ LI-7 EJ LI-8 EJ LR-6 LF LI-9 LF LI-10 RNO Perform the following: a. Ensure BIT Inlet AND Outlet Valves are open – Yes EM HIS-8803A EM HIS-8801B EM HIS-8801B b. Go to EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT,		
	CRS	Step 1 Conducts brief and transitions to EMG E-1, LOSS OF REACTOR OR SECONDARY COOLANT		
Event termination: After the crew has secured the NCP per EMG E-0, Att. F and/or at the discretion of the Lead Examiner. Simulator Operator: Insert Key 8 at the lead examiners direction.				

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
Simulator	r Operator: Ins	ert Key 8 at direction of Lead Examiner.			
	ics: Bit Flow Lov for CORE COOL	wers, Amber Light lit on BG HIS-2A, Eventually an ORANGE PATH condition _ING			
		w will perform EMG E-1 actions until CSFST Core Cooling Degrades to ns, at which time the crew will transition to EMG FR-C2 (See Page 32)			
	or Operator: IF of stripped on over	contacted as Aux Watch to investigate the 'B' CCP, wait 2 minutes and report rcurrent.			
	EMG	E-1, LOSS OF REACTOR OR SECONDARY COOLANT			
o Foldou	ut page shall be	NOTES monitored throughout this procedure			
 Seal in 	njection flow sha	all be maintained to all RCPs			
	ATC/BOP	 1. 14. Check if RCPs should be stopped: a. Check RCPs – ANY RUNNING – No 			
		RNO a. Go to Step 2			
	BOP 2. Check if S/Gs are not Faulted: - Yes a. Check pressures in all S/Gs – o NO S/G PRESSURE DECREASING IN AN UNCONTROLLED MANNER o NO S/G COMPLETELY DEPRESSURIZED				
	BOP	3. Check intact S/G Levels: a. Check Narrow Range Level in at Least One S/G – GREATER THAN 6% [29%]			
		 b. Control feed flow to maintain narrow range level in all S/Gs between 6% [29%] and 50% 			
	CAUTION				
	If offsite power is lost after SI reset, manual action may be required to restore safeguards equipment to the required configuration				

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
	ATC	4. Reset SI ○ SB HS-42A ○ SB HS-43A			
	ATC	 5. Reset Containment Isolation Phase A and Phase B SB HS-56 For Phase A SB HS-53 For Phase A SB HS-55 For Phase B SB HS-52 For Phase B 			
		CAUTION			
	nes in Area 5 of g local surveys	Auxiliary Building are not intact extreme caution will be necessary when			
	BOP	 6. Determine Secondary Radiation Levels: a. Direct Health Physics to survey steamlines in Area 5 of the Aux Bldg b. Check S/G Sampling ISOLATED – Yes c. Check Instrument Air Pressure – GREATER THAN 105 PSIG – Yes KA PI-40 d. Open CCW to Radwaste System Isolation Valves EG HS-69 EG HS-70 			

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
	BOP	 7. Check Secondary Radiation – NORMAL a. Condenser Air Discharge Radiation – NORMAL BEFORE ISOLATION Yes GEG 925 b. S/G Blowdown Radiation – NORMAL BEFORE ISOLATION – Yes BML 256 c. S/G Sample Radiation – NORMAL – Yes SJL 026 Sample results d. Turbine Driven Auxiliary Feedwater Pump Exhaust Radiation – NORMAL – Yes FCT 381 e. S/G Steamline Radiation – NORMAL – Yes ABS 114 For S/G A ABS 113 For S/G B ABS 111 For S/G D Local Surveys 			
<u>Simulato</u>	o <mark>r Operator:</mark> WH	EN contacted as HP and Chemistry, acknowledge requests			
		CAUTION because of high PZR pressure, the PORV shall be monitored to ensure it ecreases to less than 2335 psig			
	BOP	 <u>8.</u> Check PORVs and Block Valves a. Power to block valves – AVAILABLE – Yes b. BB HIS-8000A b. BHIS-8000B b. Check PZR PORVs – CLOSED – Yes b. BB HIS-455A b. BB HIS-456A c. RCS pressure – LESS THAN 2185 PSIG 			
	NOTE				
Locally opening EF-HV-43, ESW A TO AIR COMPRESSOR or EG HV-44, ESW B TO AIR COMPRESSOR requires the associated ESW train to be declared inoperable. Local opening of the valve, on 2000' NORTH END AUX BLDG, will preclude it from automatically isolating on a high flow condition					

Op-Test	Op-Test No.: Dec 2019 Scenario No.: 5 Event No.: 8 Total No Pages 36				
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Арј	plicant's Actions or Beha	avior	
	BOP	OPEN – Yes *EF HIS-43 *EF HIS-44 b. Check AIR COMP open ESW Valve(s) - *KA HIS-3C *KA HIS-2C RNO b. Reset and cle *KA HIS-2C c. Check INST AIR P o KA PI-40 d. Check neither ESV - No o EF HV-43 o EF HV-44 e. Check both ESW T Yes o EF HIS-43 o EF HIS-44	ESW TRN TO AIR COM RESSOR BRKR RESET s	witch associated with RKR RESET Switch I 105 PSIG – Yes Valve – Locally Opened OR Valves – OPEN –	
	BOP	10. Verify Instrument Air a. Check PZR PRES Yes o BB PK-455A b. Open INST AIR SF o KA HIS-29	S MASTER CTRL Output	– LESS THAN 55% <i>-</i>	

Op-Test	No.: Dec 2019	Scenario No.: 5	Event No.: 8	Total No Pages 36
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI			
Time	Position	Applicant's Actions or Behavior		
	ATC	b. Secondary heat sink: *Total Feed Flow to LBM/HR <u>OR</u>	REATER THAN 30°F [45 Intact S/Gs – GREATEF el in at least one intact S BLE OR INCREASING	- R THAN 270,000
	ATC	<u>12.</u> Check if Containment S a. Check Spray Pumps		
		THEN got to step 12.b -	pump has been stopped - No	
		2) <u>IF</u> no spray pumps a TO STEP 13 and go to	re running, <u>THEN</u> OBSEI step 13 – Yes	RVE CAUTION PRIOR
		CAUTIC	<u>DN</u>	
After RHF	After RHR pumps have been stopped, RCS pressure shall be monitored for RHR pump restart criteria			
	ATC	<u>13.</u> Check if RHR Pumps S a. Check RHR Pumps -		
		RNO Go to step 14		
	ATC	14. Check RCS and S/G Pl a. Check RCS Pressure	essures: STABLE OR DECREAS	SING – Yes
		b. Check Pressure in Al	I S/Gs – STABLE OR IN	CREASING - Yes

Op-Test	No.: Dec 2019	Scenario No.: 5	Event No.: 8	Total No Pages 36
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI			
Time	Position	Applicant's Actions or Behavior		
	ATC	a. Check NB01 – EN e. Check NB02 – EN f. Depress START/R o KJ HS-108A g. Depress STOP pu o KJ HS-108A h. Place EDG NE02	shbutton for Diesel Genera in standby using KJ-121, E NEUP FOR AUTOMATIC (OWER – No OWER – Yes el Generator NE02 ator NE01 DIESEL GENERATOR
	min and Insert		ing Watch, acknowledge r om and report EDG B is li	
	ATC	a. Locally reset and o NG01AHF4 o NG02AAF4		Pump beakers
		o NG04CPF2	For BG HV-8104	
 Wait 2 Boric 2 Wait 4 	 Simulator Operator: WHEN contacted as the Turbine/Auxiliary Building Watch, acknowledge request: Wait 2 min and Insert Key 13, contact control room and report breakers are reset and closed for Boric Acid Transfer pumps Wait 4 min and Insert Key 14, contact control room and report breaker is reset and closed for Emergency Borate valve 			
	ATC	17. Close Non-Class 1E o PK HIS-2 For Pl o PK HIS-3 For Pl o PK HIS-4 For Pl o PK HIS-5 For Pl	<-22 <-23	
	ATC	18. Check ALL non-clas BY OFFSITE POWER o PA o PB o PG o SL	s 1E AC Busses and Load	Centers – ENERGIZED

		Scenario No.: 5 Event No.: 8 Total No Pages 36 CP trips and BG FK-121 fails closed on SI		
Time	Position	Applicant's Actions or Behavior		
	BOP	 19. Place Hydrogen Analyzers Inservice a. On RL011, place power lockout switches for containment sample valves in NON-ISO position GS HIS-40 GS HIS-41 GS HIS-42 GS HIS-43 b. On RL011, open one Hydrogen Analyzer Supply Inner Containment Isolation Valve per train GS HIS-4 <u>OR</u> GS HIS-14 For Red Train GS HIS-4 <u>OR</u> GS HIS-5 For Yellow Train c. On RL011, open remaining hydrogen analyzer containment isolation valves GS HIS-12 GS HIS-17 GS HIS-18 GS HIS-3 GS HIS-9 d. On RL020, place containment hydrogen analyzer control switches in ANALYZE position GS HIS-16A GS HIS-11A e. On RL020, monitor containment hydrogen concentration GS AI-19 GS AI-10 		
	BOP	 20. Verify Cold Leg Recirculation Capability: a. Check ESFAS Status Panel SIS Section – NO AMBER LIGHT LIT Red Train – No Yellow Train – No RNO Perform the following: 1. Ensure Power to Components Listed in Attachment A – Available – Yes 2. IF cold leg recirculation capability can NOT be verified for at least one RHR train, THEN go to EMG C-11, LOSS OF EMERGENCY COOLANT RECIRCULATION, Step 1 		

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
	EMG	FR-C2, RESPONSE TO DEGRADED CORE COOLING			
		NOTES			
o Foldo	out page shall be	monitored throughout this procedure			
		running RCPs are desired. If normal conditions can not be established or ould not be tripped			
	BOP	 1. Verify SI Valves – PROPERLY ALIGNED a. Check ESFAS status panel SIS section – ALL WHITE LIGHTS LIT FOR CURRENT ECCS LINEUP - No			
	ATC	 2. Verify Charging and SI flow in all trains: a. Check Centrifugal Charging pumps to Boron Injection Tank Flow Meters – FLOW INDICATED – No EM FI-917A EM FI-917B RNO a. Perform the following: 1) Start pumps and align valves as necessary to establish normal BIT injection 2) Ensure CCP discharge to Charging Header isolation valves – AT LEAST ONE OPEN *BG-8483A (1974' AUX BLDG., CCP A ROOM) *BG-8483C (1974' AUX BLDG., CCP B ROOM) 3) If normal ECCS injection can NOT be established, THEN try to establish alternate high head injection using ATTACHMENT A, ESTABLISHING ALTERNATE HIGH HEAD INJECTION Examiner Note See Page 34 for ATTACHMENT A Actions 			

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
<u>Event De</u>	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
	BOP	 3. Verify RHR Flow In All Trains a. Check RCS pressure – LESS THAN 325 PSIG b. Check RHR to Accumulator Injection Loop Flow meters – FLOW INDICATED – <i>No</i> EJ FI-618 EJ FI-619 RNO b. Perform the following: 1) Start pumps and align valves as necessary to establish normal RHR injection 2) IF RHR flow to cold legs can NOT be established, THEN establish RHR flow to hot legs as directed by Shift Manager or Control Room 			
		Supervisor			
	BOP	 4. Check RCS Vent Paths: a. Power to PZR PORV block valves – AVAILABLE – Yes BB HIS-8000A BB HIS-8000B b. PZR PORVs – CLOSED – Yes BB HIS-455A BB HIS-456A c. RCS pressure – LESS THAN 2185 PSIG – Yes d. Reactor Vessel head vents – AT LEAST ONE VALVE CLOSED IN EACH TRAIN – Yes BB HIS-8001A OR BB HIS-8002A for red train BB HIS-8001B OR BB HIS-8002B for yellow train 			
	вор	5. Check RCPs – AT LEAST ONE RUNNING – No RNO Go to Step 9			
	BOP	 9. Check Core Cooling: a. Check RVLIS natural circulation range indication – AVAILABLE – Yes b. Check RVLIS natural circulation range indication – GREATER THAN 45% - No RNO b. Perform the following 1) IF RVLIS indication increasing, THEN OBSERVE NOTES PRIOR TO STEP 1 and return to Step 1 – No 2) IF RVLIS indication NOT increasing, THEN go to Step 10 – Yes 			

Op-Test	No.: Dec 2019	Scenario No.: 5 Event No.: 8 Total No Pages 36			
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Applicant's Actions or Behavior			
	BOP	 10. Check SI Accumulator Isolation Valve Status: a. Locally close breakers for SI accumulator outlet valve(s) NG01BGF3 for EP HV-8808A NG02BGF3 for EP HV-8808B NG01BGF2 for EP HV-8808C NG02BHF2 for EP HV-8808D b. Check Accumulator Tank – Outlet Isolation Valves – OPEN EP HV-8808A EP HV-8808B EP HV-8808D 			
		contacted as Aux Watch to close SI Accumulator Breakers acknowledge complete prior to the action being accomplished.			
	ATTACHME	ENT A, ESTABLISHING ALTERNATE HIGH HEAD INJECTION			
	ATC	 A1. Ensure Charging Pump Suction: *Charging Pump Suction from RWST valves – AT LEAST ONE OPEN *BN HIS-112D *BN HIS-112E <u>OR</u> *VCT Outlet Valves – BOTH OPEN o BG HIS-112B o BG HIS-112C 			
	ATC	A2. Check CCPs – ANY RUNNING – No			
		 RNO Perform the following: a. Manually start CCPS BG HIS-1A for CCP A BG HIS-2A for CCP B b. IF neither CCP can be started, THEN start NCP on recirc: 1) Start NCP BG HIS-3 c. IF no charging pump can be started, THEN return to procedure and step in effect 			
		CAUTION			
	ower is lost afte ed configuration	r SI reset, manual action may be required to restore safeguards equipment to			
	BOP	A3. Reset SI: o SB HS-42A o SB HS-43A Page 34 of 36			

Op-Test	No.: Dec 2019	Scenario No.: 5	Event No.: 8	Total No Pages 36	
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Aŗ	oplicant's Actions or Beha	avior	
	BOP	A4. Reset Containment o SB HS-56 For F o SB HS-53 For F o SB HS-55 For F o SB HS-52 For F	Phase A Phase B	se B:	
		N	DTE		
COMPRE	SSOR requires	the associated ESW Trai	RESSOR or EF HV-44, ES n to be declared inoperable lude it from automatically is	. Local opening of the	
	BOP	a. Ensure At Least (OPEN – Yes *EF HIS-43 *EF HIS-44 b. Check AIR COMF Open ESW Valve *KA HIS-3C *KA HIS-2C RNO: Reset and *KA HIS-3C *KA HIS-3C *KA HIS-3C *KA HIS-3C *KA HIS-2C c. Check INST AIR o KA PI-40 – d. Check Neither ES - No o EF HV-43 o EF HV-44 e. Check Both ESW Yes o EF HIS-43 o EF HIS-44	PRESOSR BRKR RESET S e(s) - No Close AIR COMPRESSOF PRESS – GREATER THAN	Switch Associated With R BRKR RESET Switch I 105 PSIG R Valve – Locally Opened	

Op-Test	No.: Dec 2019	Scenario No.: 5	Event No.: 8	Total No Pages 36	
Event De	Event Description: 'B' CCP trips and BG FK-121 fails closed on SI				
Time	Position	Ar	Applicant's Actions or Behavior		
	BOP	Yes ○ BB PK-455/	SS MASTER CTRL Output	– LESS THAN 55% <i>-</i>	
	ATC	a. Open Charging H o BG HC b. Open Charging P Isolation Valves o BG HIS o BG HIS c. Align Regenerativ establish only one o *BG HIS-81	umps to Regenerative Hea S-8105 S-8106 re Heat Exchanger to Loop	t Exchanger Containment	
	ATC	 BG FK-462 b. Go to step A10 CT3: Establish Alterna 			
Event termination: After the crew has established Alternate High Head Injection and/or at the discretion of the Lead Examiner. Simulator operator: FREEZE					

ATTACHMENT 1

Revision: 41A		EMG E· REACTOR TRIP OR SAFETY INJECTION		
Continuous Use		REACTOR TRIP OR	R SAFETY INJECTION Page 79 of 103	
STEP ACTION/		EXPECTED RESPONSE	RESPONSE NOT OBTAINED	
ATTACHMENT F (Page 1 of 13) AUTOMATIC SIGNAL VERIFICATION F1. Check AC Emergency Busses -				
	ENERGIZE			
	o NB01 -	ENERGIZED	o Depress START/RESET pushbutton for EDG A.	
			o KJ HS-8A	
	o NB02 -	ENERGIZED	o Depress START/RESET pushbutton for EDG B.	
			o KJ HS-108A	

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 81 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 2 of AUTOMATIC SIGNAL V	13)
F2.	Verify Feedwater Isolation:	
	a. Main feedwater pumps - TRIPPED	a. Manually trip Main Feedwater Pumps.
	o Annunciator 00-120A, MFP A TRIP - LIT o Annunciator 00-123A, MFP B TRIP - LIT	tripped, <u>THEN</u> depress
		o FC HS-18A For MFWP A o FC HS-18B For MFWP A
		o <u>IF</u> MFWP B is <u>NOT</u> tripped, <u>THEN</u> depress the following:
		o FC HS-118A For MFWP B o FC HS-118B For MFWP B
	b. Main feedwater reg valves - CLOSED	<pre>b. Manually close valves. * AE FK-510 for S/G A</pre>
	o AE ZL-510 for S/G A o AE ZL-520 for S/G B o AE ZL-530 for S/G C o AE ZL-540 for S/G D	* AE FK-510 for S/G A * AE FK-520 for S/G B * AE FK-530 for S/G C * AE FK-540 for S/G D
	c. Main feedwater reg bypass valves - CLOSED	c. Manually close valves.
	o AE ZL-550 for S/G A o AE ZL-560 for S/G B o AE ZL-570 for S/G C o AE ZL-580 for S/G D	* AE LK-550 for S/G A * AE LK-560 for S/G B * AE LK-570 for S/G C * AE LK-580 for S/G D
	d. Main feedwater isolation valves - CLOSED	_
	o AE HIS-39 for S/G A o AE HIS-40 for S/G B o AE HIS-41 for S/G C o AE HIS-42 for S/G D	 Manually close valves. <u>IF</u> valves can <u>NOT</u> be closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MFIV sub-racks: o ALS-411-1 o ALS-411-2

(Step F2. continued on next page)

Revision: 41A	EMG E-0					
Continuous Use	REACTOR TRIP OR SAFETY INJECTION Page 83 of 103					
STEP ACTION	EXPECTED RESPONSE RESPONSE NOT OBTAINED					
Step F2. (cont	ATTACHMENT F (Page 3 of 13) AUTOMATIC SIGNAL VERIFICATION					
e. Main injec o AE o AE o AE	<pre>feedwater chemical tion valves - CLOSED HIS-43 for S/G A HIS-44 for S/G B HIS-46 for S/G D HIS-46 for S</pre>					
SGBSI LIGHT o Red	SOUTH OF MFIV) ESFAS status panel S section - ALL WHITE S LIT train low train Suttow train					

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 85 of 103

STEP	ACTION/EXPECTED RESPONSE		RESPONSE NOT OBTAINED
	ATTACHMEN (Page 4 of AUTOMATIC SIGNAL	E 13)	FICATION
F3.	Verify Containment Isolation Phase A:		
	 a. Check ESFAS status panel CISA section - ALL WHITE LIGHTS LIT o Red train o Yellow train 	a.	 Perform the following: 1) <u>IF</u> containment isolation phase A has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment isolation phase A. 0 SB HS-47 o SB HS-48 2) <u>IF</u> any CISA valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT B, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE A.

Revision: 41A	REACTOR TRIP OR SAFET	EMG E-0
Continuous Use	REACIOR IRIP OR SAFE	Page 87 of 103
STEP ACTION	/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 5 of 1 AUTOMATIC SIGNAL VE	13)
F4. Verify A	FW Pumps Running:	
	motor driven AFW - BOTH RUNNING	a. Manually start pumps. o AL HIS-22A o AL HIS-23A
b. Check	turbine driven AFW	b. Perform the following:
	- RUNNING	 Check if turbine driven AFW pump should be running:
		* At least 2/4 S/G narrow range level channels on 2/4 S/Gs - LESS THAN 23.5%
		OR
		* Loss of NB01 voltage has occurred
		OR
		* Loss of NB02 voltage has occurred
		OR
		* AMSAC actuation
		2) <u>IF</u> turbine driven AFW pump should be running, <u>THEN</u> manually open steam supply valves:
		a) AB HIS-5A
		b) AB HIS-6A
		c) FC HIS-312A

Revision: 41A		41A	EMG E REACTOR TRIP OR SAFETY INJECTION			EMG E-0	
Continuous Use		s Use					Page 89 of 103
STEP	ACTION/EXPECTED RESPONSE		$\left - \right $		RESPONSE NOT	OBTAINED	
ATTACHMENT F (Page 6 of 13) AUTOMATIC SIGNAL VERIFICATION							
F5.	Vei	cify E	CCS Pumps Running:				
	a.	Check	CCPs - BOTH RUNNING		a.	Manually sta	rt pumps.
						o BG HIS-1A o BG HIS-2A	
	b.	Check RUNNI	SI pumps - BOTH		b.	Manually sta	rt pumps.
		ROMNT.	NG			o EM HIS-4 o EM HIS-5	
	с.		RHR pumps - BOTH		с.	Manually sta	rt pumps.
	RUNNING					o EJ HIS-1 o EJ HIS-2	
F6.	Vei	cify C	CW Alignment:				
	a.		CCW pumps - ONE NG IN EACH TRAIN		a.		rt CCW pumps to establish in each train.
						<pre>o EG HIS-21 for red tr o EG HIS-22 for yellow</pre>	ain or EG HIS-24
	b.	servi Retur:	one pair of CCW ce loop Supply And n Valves for an ting CCW pump - OPEN		b.	Manually ali necessary to flow to serv containment.	establish CCW ice loop and
		* EG	ZL-15 AND EG ZL-53				
		<u>0</u>]	<u>R</u>				
		* EG	ZL-16 AND EG ZL-54				
F7.		eck ES NNING	W Pumps - BOTH		Mar	nually start	pumps.
	1.01					EF HIS-55A EF HIS-56A	

Revision: 41A		EMG E-0				
Continuous Use	REACTOR TRIP OR SAFET	Page 91 of 103				
STEP ACTION	EXPECTED RESPONSE	RESPONSE NOT OBTAINED				
	ATTACHMENT F (Page 7 of 13) AUTOMATIC SIGNAL VERIFICATION					
	ntainment Fan Coolers G IN SLOW SPEED	Perform the following for each Containment Cooler Fan that is still running in Fast or is not running:				
		a. Manually stop ANY Containment Cooler Fans running in fast.				
		* GN HIS-5 For Cooler 1A				
		* GN HIS-9 For Cooler 1B				
		* GN HIS-13 For Cooler 1C				
		* GN HIS-17 For Cooler 1D				
		b. Place Containment Cooler Fan Speed Selector switches in Slow.				
		* GN HS-5 for cooler 1A				
		* GN HS-9 for cooler 1B				
		* GN HS-13 for cooler 1C				
		* GN HS-17 for cooler 1D				
		c. Manually start containment cooler fans.				
		* GN HIS-5 for cooler 1A				
		* GN HIS-9 for cooler 1B				
		* GN HIS-13 for cooler 1C				
		* GN HIS-17 for cooler 1D				

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 93 of 103

STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED ATTACHMENT F (Page 8 of 13) AUTOMATIC SIGNAL VERIFICATION F9. Verify Containment Purge Isolation: a. Perform the following: a. Check ESFAS status panel CPIS section - ALL WHITE LIGHTS LIT 1) <u>IF</u> containment purge isolation has NOT o Red train actuated, THEN manually o Yellow train actuate containment purge isolation. o SA HS-11 o SA HS-15 2) IF any CPIS component NOT properly aligned, THEN manually align component. 3) IF component(s) can NOT be manually aligned, THEN locally isolate instrument air to affected containment penetration. Refer to ATTACHMENT C, VALVES CLOSED BY CONTAINMENT PURGE ISOLATION SIGNAL.

Revision: 41AEMG E-0Continuous UseREACTOR TRIP OR SAFETY INJECTIONPage 95 of 1				
	evision: 41A	REACTOR TRIP OR SA		- 0
	ontinuous Use			103
STEP ACTION/EXPECTED RESPONSE RESPONSE NOT OBTAINED	TEP ACTION	I/EXPECTED RESPONSE	RESPONSE NOT OBTAINED	
ATTACHMENT F (Page 9 of 13) AUTOMATIC SIGNAL VERIFICATION F10. Verify Both Trains Of Control		(Page 9 c AUTOMATIC SIGNAL Both Trains Of Control	of 13) L VERIFICATION	
Room Ventilation Isolation: a. Check ESFAS status panel CRVIS section - ALL WHITE LIGHTS LIT o Red train o Yellow train a. Perform the following: b. Red train o Yellow train a. Perform the following: a. Perform the following: a. Perform the following: b. Red train o Yellow train a. Perform the following: b. Red train o Yellow train b. Red train o Yellow train c. Yellow train c. Yellow train c. Yellow train c. Yellow train b. Yellow train c. SA HS-9 o SA HS-13 c. J. JF any CRVIS componen NOT properly aligned, THEN manually align associated component. c. J. JF neither train of CRVIS is in service, THEN establish one in service train of CRVI using SYS GK-122, MANUAL CRVIS LINE-UP. 4) IF only one train of CRVIS LINE-UP. 4) IF only one train of SYS GK-122, MANUAL CRVIS LINE-UP.	a. Check CRVI LIGH o Red	k ESFAS status panel S section - ALL WHITE IS LIT d train	 <u>IF</u> control room ventilation isolati has <u>NOT</u> actuated, <u>I</u> manually actuate control room ventilation isolati o SA HS-9 o SA HS-13 <u>IF</u> any CRVIS comport <u>NOT</u> properly aligned <u>THEN</u> manually align associated componer <u>IF</u> neither train of CRVIS is in service <u>THEN</u> establish one service train of CF using SYS GK-122, MANUAL CRVIS LINE-U <u>IF</u> only one train of CRVIS can be placed service, <u>THEN</u> withi minutes (76.5 minut control room and 13 minutes local operator), isolate of service train us SYS GK-122, MANUAL 	on THEN On. on. ent ed, in VIS JP. of in n 90 ces 3.5 out

door - CLOSED

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 97 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMEN (Page 10 c AUTOMATIC SIGNAL	of 13)
F11.		Verify steamline isolation:
	a. Check containment pressure - HAS REMAINED LESS THAN 17 PSIG	 If any main steamline isolation valve is <u>NOT</u> closed, <u>THEN</u> perform the following:
	0 GN PR-934	a) Close main steamline isolation valves.
	 b. Check either condition below - SATISFIED: * Low steamline pressure SI - NOT BLOCKED <u>AND</u> steamline pressure - HAS REMAINED GREATER THAN 615 PSIG <u>OR</u> * Low steamline pressure SI - BLOCKED <u>AND</u> steamline pressure rate - HAS REMAINED LESS THAN 100 PSI/50 SEC 	<pre>isolation valves. * AB HS-79 * AB HS-80 b) IF any MSIV is still <u>NOT</u> closed, <u>THEN</u> at SA075A <u>OR</u> SA075B, disconnect the following cards (2 cards total) in the MSIV sub-rack: 0 ALS-411-1 0 ALS-411-2 2. Check ESFAS status panel SLIS section - ALL WHITE LIGHTS LIT 0 Red Train 0 Yellow Train</pre>
		3. <u>IF</u> any SLIS valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected steamline. Refer to ATTACHMENT D, VALVES CLOSED BY STEAMLINE ISOLATION SIGNAL.

Rev	is	ion	:	41A

REACTOR TRIP OR SAFETY INJECTION

EMG E-O

Page 99 of 103

STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHME (Page 11 c AUTOMATIC SIGNAL	of 13)
F <u>12.</u>	Verify Containment Spray Not	Perform the following:
	Required:	1. Stop all RCPs.
	 a. Containment pressure - HAS REMAINED LESS THAN 27 PSIG: o Annunciator 00-059A, CSAS - NOT LIT 	 <u>IF</u> containment spray has <u>NOT</u> actuated, <u>THEN</u> manually actuate containment spray.
	o Annunciator 00-059B, CISB - NOT LIT o GN PR-934	o SB HS-43 <u>AND</u> SB HS-45 o SB HS-44 <u>AND</u> SB HS-46
		3. Check ESFAS status panel CSAS section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		 <u>IF</u> any CSAS component <u>NOT</u> properly aligned, <u>THEN</u> manually align associated component.
		5. Check ESFAS status panel CISB section - ALL WHITE LIGHTS LIT
		o Red train o Yellow train
		6. <u>IF</u> any CISB valve <u>NOT</u> closed, <u>THEN</u> manually close valve. <u>IF</u> valve(s) can <u>NOT</u> be closed, <u>THEN</u> manually or locally isolate affected containment penetration. Refer to ATTACHMENT E, VALVES CLOSED BY CONTAINMENT ISOLATION SIGNAL PHASE B.

Revisi	on: 41A	REACTOR TRIP OR SAF	ETY 1		EMG E-0
Contin	uous Use				ge 101 of 103
STEP	ACTION	/EXPECTED RESPONSE		RESPONSE NOT OF	BTAINED
		ATTACHMEN (Page 12 of AUTOMATIC SIGNAL V	E 13)	ICATION	
F13.	Verify E	CCS Flow:			
	Pumps Tank INDIC o EM	Centrifugal Charging To Boron Injection Flow meters - FLOW ATED FI-917A FI-917B	a.	1) <u>IF</u> BIT valv	res have <u>NOT</u> by operator <u>N</u> manually and align res are perator
		RCS pressure - LESS 1725 PSIG	b.	Go to Step F14	
	Flow INDIC	SI Pump Discharge meters - FLOW ATED FI-918	c.	Manually start align valves.	pumps and
		FI-922			
		RCS pressure - LESS 325 PSIG	d.	Go to Step F14	
	Injec	RHR TO Accumulator tion Loop Flow meters W INDICATED	e.	Manually start align valves.	pumps and
		FI-618 FI-619			
F14.	Verify A ALIGNED:	FW Valves - PROPERLY	NO	any AFAS secti <u>I</u> properly alig	ned, <u>THEN</u>
		ESFAS status panel section - ALL WHITE S LIT	CO	nually align as mponent to esta sired AFAS line	blish
	statu	white train ESFAS s panel AFAS section WHITE LIGHTS LIT			

Revi	si	on:	41A
		O 11 •	I I

REACTOR TRIP OR SAFETY INJECTION

EMG E-0

Page 103 of 103

CONCIN	uous ose	rage 105 OI 105
STEP	ACTION/EXPECTED RESPONSE	RESPONSE NOT OBTAINED
	ATTACHMENT (Page 13 of AUTOMATIC SIGNAL VI	13)
F15.	Verify SI Valves - PROPERLY ALIGNED:	<u>IF</u> any SIS section component <u>NOT</u> properly aligned, <u>THEN</u>
	a. Check ESFAS status panel SIS section - SYSTEM LEVEL WHITE LIGHTS ALL LIT	manually align associated component to establish proper SIS lineup.
	o Red train o Yellow train	
F16.	Check If NCP Should Be Stopped:	
	a. CCPs - ANY RUNNING	a. Go to Step F17
	b. Stop NCP	
	o BG HIS-3	
F17.	Check FBIS Is <u>NOT</u> ACTUATED:	Perform the following:
	o Annunciator 00-062D, FBIS - <u>NOT</u> LIT	a. Ensure NO movement of irradiated fuel assemblies in the fuel building.
		b. Bypass GG RE-27 and GG RE-28.
		c. Reset FBIS:
		o sa hs-10
		o SA HS-14
		d. Ensure FUEL BLD EMERG EXH DAMPERS are closed:
		o GG HIS-40
		o GG HIS-43
F18.	Return To Procedure And Step In Effect	
	-END-	

Revision: 50 Continuous Use

REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION

SYS BG-200

Page 25 of 28

INIT/DATE

 \square

 \square

 \square

 \square

 \square

ATTACHMENT B (Page 1 of 2)

Boration For Temperature Adjustment In Mode 1 And 2

CAUTION

Borations of less than 1 gallon shall NOT be performed due to system limitations. Refer to Precautions/Limitations Step 4.13.

NOTE

A licensed operator shall peer check reactivity manipulations.

B.1 SETUP to borate the RCS:

- B.1.1 (p) <u>IF</u> required to ensure RCS and Pressurizer Boron Concentrations are within 50 ppm, <u>THEN</u> TURN on PZR HTR B/U GROUP A and/or PZR HTR B/U GROUP B , using SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS, to mix Reactor Coolant System with Pressurizer water. [3.2.1]
- B.1.2 BG HS-26 to Normal-After-Stop.
- B.1.3 BG HS-25 to BOR.

B.1.4 BG FK-110 in Auto at desired rate.

CAUTION

BG FY-110B, BA COUNTER can be set in tenth of a gallon increments.

B.1.5 BG FY-110B, BA COUNTER, set to obtain desired gallons.

B.2 COMMENCE boration:

B.2.1 (ρ) BG HS-26 to Normal-After-Run.

B.2.2 VERIFY:

1. One BORIC ACID TRANSFER PUMP running.

2. BG HIS-110B open.

REACTOR MAKEUP CONTROL SYSTEM NORMAL OPERATION

SYS BG-200

Page 26 of 28

	ATTACHMENT B	INIT/DATE
	(Page 2 of 2)	
	Boration For Temperature Adjustment In Mode 1 And 2	
	3. BG HIS-110A throttles open.	
	4. BG FR-110 boric acid flow at proper flowrate.	
в.3	ENSURE boration stops at BG FY-110B setpoint.	
	NOTE	
Pre	essurizer Backup Heaters are normally placed in auto.	
в.4	IF PZR HTR B/U GROUP A and/or PZR HTR B/U GROUP B were turned on in Step B.1.1, THEN PLACE PZR HTR B/U GROUP A & B in desired position, after sufficient time for mixing has elapsed, using SYS BB-203, PRESSURIZER BACKUP HEATER OPERATIONS.	
в.5	REALIGN for auto operation:	
	B.5.1 BG HS-26 to Normal-After-Stop.	
	B.5.2 BG HS-25 to Auto.	
	B.5.3 BG FK-110 set for Auto makeup.	
	B.5.4 BG HS-26 to Normal-After-Run.	
	B.5.5 <u>IF</u> desired, <u>THEN</u> PERFORM ATTACHMENT C, Boric Acid Potentiometer Adjustment.	
	-END-	

Transient and Event Checklist

Facility: V	Volf Cree	k				Date	of Exan	n: Dec	ember	2019	Op	erating	Test N	lo.: C	rew	Α	
А	Е							S	cenario	os							
P P	V E		2			3			4			5		Т	I	М	
L	N T		CREW DSITIO	N	CREV	V PO	SITION	CREV	V POS	ITION	CREV	V POS	ITION	O T		 N 	
C A N T	T Y P E	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	A L	I	M J M(*)	U
	RX	0			0									0	1	1	0
	NOR	0			0									0	1	1	1
SRO-U1	I/C	7			7									14	4	4	- 2
	MAJ	2			1									3	2	2	- 1
	TS	2			2									4	0	2	2
	RX	-	0		-		0							0	1	-	0
RO1	NOR		0				0							0	1	1	1
RUT	I/C		4				5							9	4	4	2
	MAJ		2				1							3	2	2	1
	TS		0				0							0	0	2	2
	RX			0		0								0	1	1	0
RO2	NOR			0		0								0	1	1	1
	I/C			4		4								8	4	4	2
	MAJ			2		1								3	2	2	1
	TS			0		0								0	0	2	2
RO	RX														1	1	0
SRO-I	NOR														1	1	1
	I/C														4	4	2
SRO-U	MAJ														2	2	1
	TS														0	2	2
	s: Check the a are not app positions. I component position, or	licable f Instant § (I/C) m	for RO a SROs (S alfunctio	applica SRO-I) ons an	nts. Ro must s d one n	Ös mu erve ir najor ti	st serve i both the ansient,	n both t sRO a in the A	he at-th ind the . TC pos	ie-contr ATC po ition. If	ols (AT(sitions, an SR(C) and I includir D-I <i>addi</i>	balance ng at lea <i>tionally</i>	-of-pla ist two serve	ant (B o instr s in th	ÓP) umei	nt or
	Reactivity r must be sig additional l	inificant /C malfu	per Se unctions	ction C on a o	2.2.a of one-for-	Appen one ba	dix D. (* asis.) React	ivity and	d norma	l evoluti	ions ma	ay be re	placed	d with		
	Whenever actions that applicant's	t provide	e insigh	t to the	e applica	anťs c	ompeten										DIE
	For new rea examiner m plant contro	nay plac														ating	

Transient and Event Checklist

Form ES-301-5

P(S R O	2 CREW DSITIC A T C		CREV S R O	3 V POS	SITION B O	CREV	cenario 4 V POS A	ITION B	CREV			T O T A	1	M I N I			
P(S R O	CREW OSITIC A T	B O	S R		В	S	V POS			V POS		O T	1	ł.			
P(S R O	OSITIC A T	B O	S R	A	В	S						Т		 N 			
R 0	Т	0	R				Α	B	c	•		Α		N I			
				С	P	R O	T C	O P	R O	A T C	B O P	L	1	M J M(*)	U		
			0							0.0		0	1	1	0		
0			0									0	1	1	1		
7			76									14 13	4	4	2		
2			1									3	2	2	1		
2			2 1									4-3	0	2	2		
	0				0							0	1	1	0		
	0				0						13	0	1	1	1		
	4				5 3							97	4	4	2		
	2				1							3	2	2	1		
	0				0							0	0	2	2		
		0		0								0	1	1	0		
		0		0				< 1				0	1	1	1		
		4		4								8	4	4	2		
		2		1								3	2	2	1		
	ľ.	0		0								0	0	2	2		
	0										1		1	1	0		
													1	1	1		
1967													4	4	2		
													2	2	1		
													0	2	2		
	2	2 0 0 4 2 0 4 2 0 0	2 0 0 4 2 0 4 0 0 0 0 4 0 0 4 4 2 0 0 4 4 2 0 0 4 4 0 0 0 4 0 0 0 0	2 21 0 0 4 2 0 0 0 </td <td>2 21 0 0 4 0 2 0 0 0</td> <td>2 21 0 0 0 0 4 53 2 1 0 0 0 0 0 0 0 0 0 0 0 0 4 4 2 1 0 0 4 4 2 1 0 0 1 1 0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 <td< td=""><td>2 21 0 0 0 0 4 53 2 1 0 0 0 0 0 0 0 0 0 0 0 0 4 4 2 1 0 0 4 4 2 1 0 0 <td< td=""><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 0 0 0 0 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 1 1 1 1 1 1 0 0 0 0 1 <</td><td>2 1 3 2 21 4.3 0 0 0 0 0 0 0 0 4 53 97 2 1 3 0 0 0 4 53 97 2 1 3 0 0 0 0 0 0 0 0 0 4 4 8 2 1 3 0 0 0 4 4 8 2 1 3 0 0 0 1 1 3 0 0 0 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td><td>2 1 3 2 2 21 4.3 0 0 0 0 0 1 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 1 0 0 0 0 0 1 1 3 2 0 0 0 0 0 1 1 1 1 1 2 1 1 2 1 1 0 0 0 0 0 0 1 1 1 2 0 0</td><td>2 1 1 3 2 2 2 21 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 4 53 97 4 4 2 1 3 2 2 0 0 0 0 0 2 2 0 0 0 0 0 2 2 0 0 0 0 0 0 2 0 0 0 0 0 0 1 1 4 4 1 1 1 1 1 1 1 1 3 2 2 1 1 1 1 3 2 2 1 1 1 1 1 1 1 1 1 1</td></td<></td></td<></td>	2 21 0 0 4 0 2 0 0 0	2 21 0 0 0 0 4 53 2 1 0 0 0 0 0 0 0 0 0 0 0 0 4 4 2 1 0 0 4 4 2 1 0 0 1 1 0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 <td< td=""><td>2 21 0 0 0 0 4 53 2 1 0 0 0 0 0 0 0 0 0 0 0 0 4 4 2 1 0 0 4 4 2 1 0 0 <td< td=""><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 0 0 0 0 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 1 1 1 1 1 1 0 0 0 0 1 <</td><td>2 1 3 2 21 4.3 0 0 0 0 0 0 0 0 4 53 97 2 1 3 0 0 0 4 53 97 2 1 3 0 0 0 0 0 0 0 0 0 4 4 8 2 1 3 0 0 0 4 4 8 2 1 3 0 0 0 1 1 3 0 0 0 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td><td>2 1 3 2 2 21 4.3 0 0 0 0 0 1 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 1 0 0 0 0 0 1 1 3 2 0 0 0 0 0 1 1 1 1 1 2 1 1 2 1 1 0 0 0 0 0 0 1 1 1 2 0 0</td><td>2 1 1 3 2 2 2 21 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 4 53 97 4 4 2 1 3 2 2 0 0 0 0 0 2 2 0 0 0 0 0 2 2 0 0 0 0 0 0 2 0 0 0 0 0 0 1 1 4 4 1 1 1 1 1 1 1 1 3 2 2 1 1 1 1 3 2 2 1 1 1 1 1 1 1 1 1 1</td></td<></td></td<>	2 21 0 0 0 0 4 53 2 1 0 0 0 0 0 0 0 0 0 0 0 0 4 4 2 1 0 0 4 4 2 1 0 0 <td< td=""><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<</td><td>2 21 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 0 0 0 0 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 1 1 1 1 0 0 0 0 1 <</td><td>2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 1 1 1 1 1 1 0 0 0 0 1 <</td><td>2 1 3 2 21 4.3 0 0 0 0 0 0 0 0 4 53 97 2 1 3 0 0 0 4 53 97 2 1 3 0 0 0 0 0 0 0 0 0 4 4 8 2 1 3 0 0 0 4 4 8 2 1 3 0 0 0 1 1 3 0 0 0 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td><td>2 1 3 2 2 21 4.3 0 0 0 0 0 1 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 1 0 0 0 0 0 1 1 3 2 0 0 0 0 0 1 1 1 1 1 2 1 1 2 1 1 0 0 0 0 0 0 1 1 1 2 0 0</td><td>2 1 1 3 2 2 2 21 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 4 53 97 4 4 2 1 3 2 2 0 0 0 0 0 2 2 0 0 0 0 0 2 2 0 0 0 0 0 0 2 0 0 0 0 0 0 1 1 4 4 1 1 1 1 1 1 1 1 3 2 2 1 1 1 1 3 2 2 1 1 1 1 1 1 1 1 1 1</td></td<>	2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<	2 21 0 0 0 0 0 0 4 53 1 0 0 0 0 0<	2 21 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 0 0 0 0 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 <	2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 0 1 1 1 1 1 0 0 0 0 1 <	2 21 0 0 0 0 0 0 0 0 0 0 0 4 53 1 1 1 1 1 0 0 0 0 1 1 1 1 0 0 0 1 1 1 1 1 1 0 0 0 0 1 <	2 1 3 2 21 4.3 0 0 0 0 0 0 0 0 4 53 97 2 1 3 0 0 0 4 53 97 2 1 3 0 0 0 0 0 0 0 0 0 4 4 8 2 1 3 0 0 0 4 4 8 2 1 3 0 0 0 1 1 3 0 0 0 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2 1 3 2 2 21 4.3 0 0 0 0 0 1 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 1 4 53 97 4 2 1 3 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 1 0 0 0 0 0 1 1 3 2 0 0 0 0 0 1 1 1 1 1 2 1 1 2 1 1 0 0 0 0 0 0 1 1 1 2 0 0	2 1 1 3 2 2 2 21 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 4 53 97 4 4 2 1 3 2 2 0 0 0 0 0 2 2 0 0 0 0 0 2 2 0 0 0 0 0 0 2 0 0 0 0 0 0 1 1 4 4 1 1 1 1 1 1 1 1 3 2 2 1 1 1 1 3 2 2 1 1 1 1 1 1 1 1 1 1		

3. Whenever practical, both instrument and component malfunctions should be included; only those that require verifiable actions that provide insight to the applicant's competence count toward the minimum requirements specified for the applicant's license level in the right-hand columns.

4. For new reactor facility licensees that use the ATC operator primarily for monitoring plant parameters, the chief examiner may place SRO-I applicants in either the ATC or BOP position to best evaluate the SRO-I in manipulating plant controls.

Transient and Event Checklist

Facility: N	Volf Cree	k				Date	of Exar	n: Dec	ember	2019	Op	erating	Test N	lo.: C	rew	С	
Α	E							S	cenario	os							
P P	V E		2			3			4			5		Т		М	
L	N T		CREW DSITIO	N	CREV	V PO	SITION	CREV	V POS	ITION	CREV	V POS	ITION	О Т	l	I N I	
C A N T	T Y P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	A L		M U M(*)	1
	E											1			R	Ι	U
	RX	0												0	1	1	0
SRO-U3	NOR	0												0	1	1	<mark>1</mark>
	I/C	7												7	4	4	<mark>2</mark>
	MAJ	2												2	2	2	<mark>1</mark>
	TS	2												2	0	2	<mark>2</mark>
	RX		0		0			0						0	1	1	0
SRO-I3	NOR		0		0			0						0	1	1	1
	I/C		4		7			7						18	4	4	2
	MAJ		2		1			1						4	2	2	1
	TS		0		2			2						4	0	2	2
	RX			0		0				0				0	1	1	0
	NOR			0		0				0				0	1	1	1
RO5	I/C			4		4				4				12	<mark>4</mark>	4	2
	MAJ			2		1				1				4	2	2	1
	TS			0		0				0				0	0	2	2
	RX						0		0					0	1	1	0
	NOR						0		0					0	1	1	1
RO6	I/C						5		5					10	<mark>4</mark>	4	2
	MAJ						1		1					2	2	2	1
	TS						0		0					0	0	2	2
	Check the a are not app positions. I	licable i	for RO a SROs (S	applica SRO-I)	nts. Ro must s	Os mu erve ir	st serve i both the	in both f sRO a	he at-th and the <i>l</i>	ie-contr ATC po	ols (AT0 sitions,	C) and b includin	balance ng at lea	-of-pla	ant (E instr	SÓP) rume	nt or
2.	component position, or Reactivity r must be sig additional l	ne I/C m nanipula Inificant	alfunctions m per Sec	on can nay be ction C	conduc	dited to ted un Appen	oward the der norm dix D. (*	e two I/(nal or c o	C malfur	nctions / abnorr	requirec	l for the ditions (ATC po	ositior Secti	n. on D.	5.d)	
3.	Whenever actions that applicant's	practica t provide	ll, both i e insigh	nstrum t to the	ient and applica	l comp ant's c	onent m ompeten										ble
	For new rea examiner m plant contro	nay plac															

Transient and Event Checklist

Facility: Wolf Creek Date of Exam: December 2019 Operating Test No.: Crew D A E Scenarios P V 2 3 4 5 T M																	
								S	cenario	os							
P P	V E													Т		М	
L	N T		CREW DSITIO	N	CREV	V PO	SITION	CREV	V POS	ITION	CREV	V POS	ITION	O T		I N I	
C A N T	T Y P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	A L		M U M(*)	
	E														R		U
	RX	0												0	1	1	0
	NOR	0												0	1	1	1
SRO-U4	I/C	7												7	4	4	2
	MAJ	2												2	2	2	1
	TS	2												2	0	2	<mark>2</mark>
	RX		0					0			0			0	1	1	0
00014	NOR		0					0			0			0	1	<mark>1</mark>	1
SRO-I4	I/C		4					7			7			18	4	<mark>4</mark>	2
	MAJ		2					1			1			4	2	<mark>2</mark>	1
	TS		0					2			2			4	0	<mark>2</mark>	2
	RX			0					0				0	0	1	1	0
	NOR			0					0				0	0	1	1	1
RO7	I/C			4					5				5	14	4	4	2
	MAJ			2					1				1	4	2	2	1
	TS			0					0				0	0	0	2	2
	RX									0		0		0	1	1	0
	NOR									0		0		0	1	1	1
RO8	I/C									4		5		9	4	4	2
	MAJ									1		1		2	2	2	1
	TS									0		0		0	0	2	2
Instruction	s:													l			1
	Check the a are not app positions. I component position, on	licable f nstant \$ (I/C) m	for RO a SROs (S alfunctio	applica SRO-I) ons an	nts. R0 must s d one n	Ös mu erve ir najor ti	st serve i both the ansient,	n both t sRO a in the A	he at-th ind the . TC pos	ie-contr ATC po ition. If	ols (AT) sitions, an SR(C) and I includir D-I <i>addi</i>	balance ng at lea <i>tionally</i>	-of-pla ist two serve	ant (E o insti s in ti	SÓP) rume	nt or
I	Reactivity n must be sig additional I/	nificant	per Se	ction C	2.2.a of	Appen	dix D. (*										but
	Whenever p actions that applicant's	provide	e insigh	t to the	e applica	ant's c	ompeten										ble
	For new rea examiner m	ay plac															

Transient and Event Checklist

Facility:	Facility: Wolf Creek Date of Exam: December 2019 Operating Test No.: Crew E A E Scenarios P V 2 3 4 5 T M																
								S	cenario	os							
P P	V E		2			3			4			5		Т		М	
L	N T		CREW DSITIO	N	CREV	V PO	SITION	CREV	V POS	ITION	CREV	V POS	ITION	O T		I N I	
C A N T	T Y P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	A L		M U M(*)	
	E														R	Ι	U
SRO-I1	RX				0				0		0			0	1	1	0
	NOR				0				0		0			0	1	<mark>1</mark>	1
	I/C				7				5		7			19	4	4	2
	MAJ				1				1		1			3	2	2	1
	TS				2				0		2			4	0	2	2
	RX					0		0					0	0	1	<mark>1</mark>	0
000 10	NOR					0		0					0	0	1	1	1
SRO-I2	I/C					4		7					5	16	4	<mark>4</mark>	2
	MAJ					1		1					1	3	2	2	1
	TS					0		2					0	2	0	2	2
RO9	RX						0			0		0		0	1	1	0
	NOR						0			0		0		0	1	1	1
	I/C						5			4		5		14	4	4	2
	MAJ						1			1		1		3	2	2	1
	TS						0			0		0		0	0	2	2
RO	RX														1	1	0
SRO-I	NOR														1	1	1
	I/C														4	4	2
SRO-U	MAJ														2	2	1
	TS														0	2	2
Instructior	IS:																
	Check the a are not app positions. I component position, on	licable f nstant \$ (I/C) m	for RO a SROs (S alfunctio	applica SRO-I) ons an	ants. R(must s id one n	Ös mu erve ir najor ti	st serve i both the ansient,	n both t sRO a in the A	he at-th ind the . TC pos	ie-contr ATC po ition. If	ols (AT) sitions, an SR(C) and l includir D-I <i>addi</i>	balance ng at lea <i>tionally</i>	-of-pla ist two serve	ant (E o inst s in t	SÓP) rume	nt or
	Reactivity n must be sig additional I/	nificant	per Se	ction C	C.2.a of	Appen	dix D. (*										but
3.	Whenever p actions that applicant's	provide	e insigh	t to the	e applica	anťs c	ompeten										ble
	For new rea examiner m plant contro	ay plac															

Transient and Event Checklist

Facility: \	Nolf Creek	[Date	of Exan	n: Dece	ember	2019	Оре	erating	Test N	lo.: S	pare		
A	E							S	cenario	os							
P P	V E	1	(Spare)										Т	ſ	И	
L	N T		CREW DSITIO	N	CREV	V PO	SITION	CREV	V POS	ITION	CREV	V POS	ITION	O T	I	 N 	
C A N T	T Y P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	S R O	A T C	B O P	A L	l I	M J M(*)	
DO	E														R		U
RO	RX	0												0	1	1	0
SRO-I	NOR	0												0	1	1	1
	I/C	7												7	4	4	2
SRO-U X	MAJ	1												1	2	2	1
	TS	2												2	0	2	2
RO	RX	0												0	1	1	0
SRO-I	NOR	0												0	1	1	1
X	I/C	7												7	4	4	2
SRO-U	MAJ	1												1	2	2	1
	TS	2												2	0	2	2
RO X	RX		0											0	1	1	0
A SRO-I	NOR		0											0	1	1	1
	I/C		5											5	4	4	2
SRO-U	MAJ		1											1	2	2	1
	TS		0											0	0	2	2
RO	RX			0										0	1	1	0
X SRO-I	NOR			0										0	1	1	1
	I/C			4										4	4	4	2
SRO-U	MAJ			1										1	2	2	1
	TS			0										0	0	2	2
	Check the a are not app positions. I component position, on	licable f nstant \$ (I/C) m	for RO a SROs (S alfunctio	applica SRO-I) ons an	nts. R0 must s d one m	Ds mu erve ir najor ti	st serve i both the ansient,	n both t sRO a in the A	he at-th ind the TC pos	e-contr ATC po ition. If	ols (ATC sitions, an SRC	C) and t includir)-I <i>addi</i>	oalance ig at lea <i>tionally</i>	-of-pla st two serve	ant (B o instr s in th	ÓP) umei	nt or
	Reactivity n must be sig additional I/	nificant	per Se	ction C	2.2.a of	Appen	dix D. (*										but
	Whenever p actions that applicant's	provide	e insigh	t to the	e applica	ant's c	ompeten										ble
	For new rea examiner m plant contro	ay plac														ating	

Competencies Checklist

Form ES-301-6

Facility: Wolf Creek	Da	ate of	Exa	mina	ation: D	ecen	nber	201	9 O	pera	ting	g Te	st No.	:		
							APF	PLIC	ANTS							
	RO SRO-I SRO-U1 X			_	RO-I RO-U2 X			RO SRO SRO		3	□ □ X	RO SRO SRO	1	□ □ X		
Competencies	S	CEN	ARIC)	SC	SC	EN/	RI	С	SCENARIO						
	2	3	4	5	2	3	4	5	2	3	4	5	2	3	4	5
Interpret/Diagnose Events and Conditions	1-9	1-8			1-9	1-8			1-9				1-9			
Comply with and Use Procedures (1)	1-9	1-8			1-9	1-8			1-9				1-9			
Operate Control Boards (2)	CRS	CRS			CRS	CRS			CRS				CRS			
Communicate and Interact	1-9	1-8			1-9	1-8			1-9				1-9			
Demonstrate Supervisory Ability (3)	1-9	1-8			1-9	1-8			1-9				1-9			
Comply with and Use TS (3)	1,4	2,5			1,4	2,5			1,4				1,4			
Notes: (1) Includes TS compliar (2) Optional for an SRO- (3) Only applicable to SR	U.	r an f	RO.													

Instructions:

Check the applicants' license type and enter one or more event numbers that will allow the examiners to evaluate every applicable competency for every applicant. (This includes all rating factors for each competency.) (Forms ES 303 1 and ES 303 3 describe the competency rating factors.)

Competencies Checklist

Form ES-301-6

Facility: Wolf Creek	٢	Date o	of Exa	minat	ion	: Dece	embe	r 2019	9 Op	eratir	ng Te	stľ	No.:						
							AI	PLIC	ANTS										
	RO SRO-I1 X SRO-U					RO SRO-12 X SRO-U				RO SRO-I3 X SRO-U					RO SRO-I4 X SRO-U				
Competencies	SCENARIO					SCE	NARI	0	SC		RIO	SCENARIO							
	2	3	4	5	2	3	4	5	2	3	4	5	2	3	4	5			
Interpret/Diagnose Events and Conditions		1-8	1, 3-6, 9	1-8		1-3, 5-6,	1-9	1,3, 5-8	1, 3, 5-6, 8-9	1-8	1-9		1, 3, 5-6, 8-9		1-9	1-8			
Comply with and Use Procedures (1)		1-8	1, 3-6, 9	1-8		1-3, 5-6	1-9	1,3, 5-8	1, 3, 5-6, 8-9	1-8	1-9		1, 3, 5-6, 8-9		1-9	1-8			
Operate Control Boards (2)		CRS	1, 3-6, 9	CRS		1-3, 5-6	CRS	1,3 5-8	1, 3, 5-6, 8-9	CRS	CRS		1, 3, 5-6, 8-9		CRS	CRS			
Communicate and Interact		1-8	1-9	1-8		1-8	1-9	1-8	1-9	1-8	1-9		1-9		1-9	1-8			
Demonstrate Supervisory Ability (3)		1-8	ATC	1-8		ATC	1-9	BOP	ATC	1-8	1-9		ATC		1-9	1-8			
Comply with and Use TS (3)		2,5	ATC	3,4		ATC	1,3	BOP	ATC	2,5	1,3		ATC		1,3	3,4			
Notes: (1) Includes TS complian (2) Optional for an SRO-I (3) Only applicable to SR	U.		RO.																

Instructions:

Check the applicants' license type and enter one or more event numbers that will allow the examiners to evaluate every applicable competency for every applicant. (This includes all rating factors for each competency.) (Forms ES 303 1 and ES 303 3 describe the competency rating factors.)

Competencies Checklist

Form ES-301-6

Facility: Wolf Creek	Date	e of E	xan	ninat	ion: D	ecem	ber	201	9 Op	eratii	ng ⁻	Tes	t No.:			
	APPLICANTS															
	RO1 X SRO-I □ SRO-U □			SRO	RO2 X SRO-I □ SRO-U □			RO3 X SRO-I SRO-U				RO4 SRC SRC	X			
Competencies	SC	ENA	S	CENA	RIO		SC	ENAF	RIO		SCENARIO					
	2	3	4	5	2	3	4	5	2	3	4	5	2	3	4	5
Interpret/Diagnose Events and Conditions	1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6,			1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6,		
Comply with and Use Procedures (1)	1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6			1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6		
Operate Control Boards (2)	1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6			1, 3, 5-6, 8-9	1, 4-8			2-4, 6-8	1-3, 5-6		
Communicate and Interact	1-9	1-8			1-9	1-8			1-9	1-8			1-9	1-8		
Demonstrate Supervisory Ability (3)	ATC	BOP			BOP	ATC			ATC	BOP			BOP	ATC		
Comply with and Use TS (3)	ATC	BOP			BOP	ATC			ATC	BOP			BOP	ATC		
Notes: (1) Includes TS complian (2) Optional for an SRO- (3) Only applicable to SR	U.	an R(D.													

Instructions:

Check the applicants' license type and enter one or more event numbers that will allow the examiners to evaluate every applicable competency for every applicant. (This includes all rating factors for each competency.) (Forms ES 303 1 and ES 303 3 describe the competency rating factors.)

Competencies Checklist

Form ES-301-6

Facility: Wolf Creek	Da	te of E	Examir	nati	on:	Dece	mber	201	9 O	per	ating -	Test N	o.:			
	APPLICANTS															
	RO5 X SRO-I □ SRO-U □			S	806 80-1 80-1		RO7 2 SRO-I [SRO-U [RO8 SRO-I SRO-U			x □□		
Competencies	SCENARIO					SCEN	IARIO	1	S	SCE	NARI	SCENARIO				
	2	3	4	5	2	3	4	5	2	3	4	5	2	3	4	5
Interpret/Diagnose Events and Conditions	2-4, 6-8	1-3, 5-6,	2-3, 5, 7-9			1, 4-8	1, 3-6, 9		2-4, 6-8		1, 3-6, 9	1,3, 5-8			2-3, 5, 7-9	2-6, 8
Comply with and Use Procedures (1)	2-4, 6-8	1-3, 5-6	2-3, 5, 7-9			1, 4-8	1, 3-6, 9		2-4, 6-8		1, 3-6, 9	1,3, 5-8			2-3, 5, 7-9	2-6, 8
Operate Control Boards (2)	2-4, 6-8	1-3, 5-6	2-3, 5, 7-9			1, 4-8	1, 3-6, 9		2-4, 6-8		1, 3-6, 9	1,3 5-8			2-3, 5, 7-9	2-6, 8
Communicate and Interact	1-9	1-8	1-9			1-8	1-9		1-9		1-9	1-8			1-9	1-8
Demonstrate Supervisory Ability (3)	BOP	ATC	BOP			BOP	ATC		BOP		ATC	BOP			BOP	ATC
Comply with and Use TS (3)	BOP	ATC	BOP			BOP	ATC		BOP		ATC	BOP			BOP	ATC

(2) (3) Optional for an SRO-U.

Only applicable to SROs.

Instructions:

Check the applicants' license type and enter one or more event numbers that will allow the examiners to evaluate every applicable competency for every applicant. (This includes all rating factors for each competency.) (Forms ES 303 1 and ES 303 3 describe the competency rating factors.)

Competencies Checklist

Facility: Wolf Creek	[Date o	of Exa	minati	on: [Dece	embe	r 201	9 (Оре	rating	g Te	st N	D.:				
							API	PLIC	ANT	s								
	RO9 X SRO-I □ SRO-U □				0 RO-I RO-I) 70-1 70-1	_		R(SI SI						
Competencies	SCENARIO				5	SCE	NARI	0	S	CEN	ARI	С	SCENARIO					
	2	3	4	5	2	3	4	5	2	3	4	5	2	3	4	5		
Interpret/Diagnose Events and Conditions		1, 4-8	2-3, 5, 7-9	2-6, 8														
Comply with and Use Procedures (1)		1, 4-8	2-3, 5, 7-9	2-6, 8														
Operate Control Boards (2)		1, 4-8	2-3, 5, 7-9	2-6, 8														
Communicate and Interact		1-8	1-9	1-8														
Demonstrate Supervisory Ability (3)		BOP	BOP	ATC														
Comply with and Use TS (3)		BOP	BOP	ATC														
Notes: (1) Includes TS complian (2) Optional for an SRO- (3) Only applicable to SR	U.		RO.															